

Boresight Antenna Mast BAM 4.0 -P

Technical data:

| Antenna height automatic adjustable | 1.0 m – 4.0 m (non-tilted) |
|--|---|
| Total mast height | 4.6 m |
| Load capability non tilted | max. 10 kg (when balanced) |
| Load capability tilted | max. 6 kg (when balanced) |
| For long and heavy antennas, a counter weight is required to balancing the load. | |
| Depending on the distance of the antenna gravity center | |
| Material of antenna mast | Plastic and reinforced fiberglass |
| Mast cross section | 101 mm x 95 mm |
| Base L x W | 1.3 m x 0.7 m |
| Position speed adjustable | |
| in combination with FCU3.0 | 1.0 cm/s – 35 cm/s |
| in combination with NCD | 1.0 cm/s – 20 cm/s |
| Position accuracy | +/- 0.5 cm |
| Pneumatic polarization | 0° / 90° (vert. / hor.) |
| Polarization time | approx. 3 s |
| Polarization drive | Pneumatic rotary actuator |
| Control | Solenoid valve |
| Nominal pressure | max. 6 bar |
| Tilt angle automatically adjusted during scan | From -18.5° to +45° |
| Tilt accuracy | +/- 0.5° |
| Motor | DC stepper Motor |
| Antenna support drive | Toothed belt |
| Material of toothed belts | Kevlar reinforced (non-metallic) |
| Voltage | 110 VAC – 230 VAC, 50 Hz / 60 Hz |
| voltage | single phase |
| Current consumption | max. 16 A |
| Required RCD | 300 mA |
| Control cable | Fiber optic lines |
| Remote control via | LAN (TCP/IP); (IEEE only with NCD) |
| Interference suppression | 20 dB under limits DIN EN 55011:2018-05 |
| interrelence suppression | class B |
| Operating temperature | 10° C – 35 ° C |
| Total weight | approx. 75 kg |
| | Service manual |
| Accessories | 3 m power supply cable |
| | 15 m pneumatic air hose 8 mm |
| | 1x pneumatic feed through |
| | |



Brief description

The Boresight Antenna Mast **BAM 4.0-P** is suitable in magnetic absorption chambers. The antenna mast, with the exception of the drive unit, is fabricated from plastic (PVC and reinforced fibreglass). The BAM 4.0-P has additionally an electrical tilt function from -18.5° to +45°, which automatically tilts during height scan. The tilting angle can be adjusted easily in accordance with the distance of the antenna to the EUT.

Metal parts are located only in the base plate and the drive mechanism (max. 0.3 m above ground level).

Antenna Adapters for all commercially available antennas are available upon request. All antennas during polarization rotate around their axis to eliminate any elevation errors. The LAN (TCP/IP) - interface provides an additional control option for all functions, when operated with the FCU^{3.0} or NCD Controller.



Information presented enclosed is subject to change as product enhancements are made regularly. Pictures included are for illustration purposes only and do not represent all possible configurations.