Machine-Level Programming I: Basics

CENG331 - Computer Organization

Adapted from slides of the textbook: http://csapp.cs.cmu.edu/

Today: Machine Programming I: Basics

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations



ARM

Intel different for different ISAs

IA32

X86-by → AMD

CISC RISC

Reduced

Reduced

Instruction

Set

Computer

X86-64

TA 32

ISA

Intel x86 Processors

Dominate laptop/desktop/server market

- Evolutionary design
 - Backwards compatible up until 8086, introduced in 1978
 - Added more features as time goes on

Intel x86 Processors

Dominate laptop/desktop/server market

Portium

Evolutionary design

- Backwards compatible up until 8086, introduced in 1978
- Added more features as time goes on

Complex instruction set computer (CISC)

- Many different instructions with many different formats
 - But, only small subset encountered with Linux programs
- Hard to match performance of Reduced Instruction Set Computers (RISC)
- But, Intel has done just that!
 - In terms of speed. Less so for low power. of transistor is the met

Ly make it double the

5 Take it chip with number

Intel x86 Evolution: Milestones

Name Date Transistors MHz


■ 8086 1978 29K 5-10

- First 16-bit Intel processor. Basis for IBM PC & DOS
- 1MB address space
- 386 1985 275K 16-33
 - First 32 bit Intel processor, referred to as IA32
 - Added "flat addressing", capable of running Unix
- Pentium 4E 2004 125M 2800-3800
 - First 64-bit Intel x86 processor, referred to as x86-64
- Core 2 2006 291M 1060-3500
 - First multi-core Intel processor
- Core i7 2008 731M 1700-3900
 - Four cores

Intel x86 Processors, cont.

Machine Evolution

386	1985	0.3M
Pentium	1993	3.1M
Pentium/MMX	1997	4.5M
PentiumPro	1995	6.5M
Pentium III	1999	8.2M
Pentium 4	2001	42M
Core 2 Duo	2006	291M
Core i7	2008	731M



Added Features

- Instructions to support multimedia operations
- Instructions to enable more efficient conditional operations
- Transition from 32 bits to 64 bits
- More cores

2015 State of the Art


Core i7 Broadwell 2015

Desktop Model

- 4 cores
- Integrated graphics
- 3.3-3.8 GHz
- **65W**

Server Model

- 8 cores
- Integrated I/O
- 2-2.6 GHz
- **45W**



Quad-core i7-7700K

2.16 Billion transistors

x86 Clones: Advanced Micro Devices (AMD)

Historically

- AMD has followed just behind Intel
- A little bit slower, a lot cheaper

Then

- Recruited top circuit designers from Digital Equipment Corp. and other downward trending companies
- Built Opteron: tough competitor to Pentium 4
- Developed x86-64, their own extension to 64 bits

Recent Years

- Intel got its act together
 - Leads the world in semiconductor technology
- AMD has fallen behind
 - Relies on external semiconductor manufacturer

Intel's 64-Bit History

- 2001: Intel Attempts Radical Shift from IA32 to IA64
 - Totally different architecture (Itanium)
 - Executes IA32 code only as legacy
 - Performance disappointing
- 2003: AMD Steps in with Evolutionary Solution
 - x86-64 (now called "AMD64")
- Intel Felt Obligated to Focus on IA64
 - Hard to admit mistake or that AMD is better
- 2004: Intel Announces EM64T extension to IA32
 - Extended Memory 64-bit Technology
 - Almost identical to x86-64!
- All but low-end x86 processors support x86-64
 - But, lots of code still runs in 32-bit mode

Our Coverage

■ IA32

- The traditional x86
- For 15/18-213: RIP, Summer 2015

■ x86-64

- The standard
- inek> gcc hello.c
- inek> gcc -m64 hello.c

Presentation

- Book covers x86-64
- Web aside on IA32
- We will only cover x86-64

Today: Machine Programming I: Basics

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

Definitions

- Architecture: (also ISA: instruction set architecture) The parts of a processor design that one needs to understand or write assembly/machine code.
 - Examples: instruction set specification, registers.

Definitions

- Architecture: (also ISA: instruction set architecture) The parts of a processor design that one needs to understand or write assembly/machine code.
 - Examples: instruction set specification, registers.
- Microarchitecture: Implementation of the architecture.
 - Examples: cache sizes and core frequency.


Code Forms:

- Machine Code: The byte-level programs that a processor executes
- Assembly Code: A text representation of machine code

Example ISAs:

- Intel: x86, IA32, Itanium, x86-64
- ARM: Used in almost all mobile phones

Assembly/Machine Code View




Programmer-Visible State

- PC: Program counter
 - Address of next instruction
 - Called "RIP" (x86-64)
- Register file
 - Heavily used program data
- Condition codes
 - Store status information about most recent arithmetic or logical operation

- Memory
 - Byte addressable array
 - Code and user data
 - Stack to support procedures

Turning C into Object Code

- Code in files p1.c p2.c
- Compile with command: gcc -Og p1.c p2.c -o p
 - Use basic optimizations (-Og) [New to recent versions of GCC]
 - Put resulting binary in file p



Compiling Into Assembly

C Code (sum.c)

Generated x86-64 Assembly

```
sumstore:
  pushq %rbx
  movq %rdx, %rbx
  call plus
  movq %rax, (%rbx)
  popq %rbx
  ret
```

Obtain (on cow machine) with command

Produces file sum.s

Warning: Will get very different results on different machines (Linux, Mac OS-X, ...) due to different versions of gcc and different compiler settings.

Assembly Characteristics: Data Types

- "Integer" data of 1, 2, 4, or 8 bytes
 - Data values
 - Addresses (untyped pointers)
- Floating point data of 4, 8, or 10 bytes
- Code: Byte sequences encoding series of instructions
- No aggregate types such as arrays or structures
 - Just contiguously allocated bytes in memory

Assembly Characteristics: Operations

- Perform arithmetic function on register or memory data
- Transfer data between memory and register
 - Load data from memory into register
 - Store register data into memory
- Transfer control
 - Unconditional jumps to/from procedures
 - Conditional branches

Object Code

Code for sumstore

0x0400595:

0x53

0x48

0x89

0xd3

0xe8

0xf2

0xff

0xff

0xff

0x48

0x89

0x03

0x5b

0xc3

Assembler

- Translates .s into .o
- Binary encoding of each instruction
- Nearly-complete image of executable code
- Missing linkages between code in different files

Linker

- Resolves references between files
- Combines with static run-time libraries
 - E.g., code for malloc, printf
- Some libraries are dynamically linked
 - Linking occurs when program begins execution

Total of 14 bytes

Each instruction

1, 3, or 5 bytes

Starts at address

0x0400595

Machine Instruction Example

0x40059e: 48 89 03

C Code

Store value t where designated by dest

Assembly

- Move 8-byte value to memory
 - Quad words in x86-64 parlance
- Operands:

t: Register %rax

dest: Register %rbx

*dest: Memory M[%rbx]

Object Code

- 3-byte instruction
- Stored at address 0x40059e

Disassembling Object Code

Disassembled

```
0000000000400595 <sumstore>:
 400595:
          53
                           push
                                   %rbx
 400596: 48 89 d3
                                   %rdx,%rbx
                           mov
 400599: e8 f2 ff ff ff
                           callq 400590 <plus>
 40059e: 48 89 03
                                   %rax, (%rbx)
                           mov
 4005a1: 5b
                                   %rbx
                           pop
                            retq
 4005a2: c3
```

Disassembler

```
objdump -d sum
```

- Useful tool for examining object code
- Analyzes bit pattern of series of instructions
- Produces approximate rendition of assembly code
- Can be run on either a .out (complete executable) or .o file

Alternate Disassembly

Object

Disassembled

```
0 \times 0400595:
    0 \times 53
    0x48
    0x89
    0xd3
    0xe8
    0xf2
    0xff
    0xff
    0xff
    0x48
    0x89
    0 \times 03
    0x5b
    0xc3
```

Within gdb Debugger

gdb sum
disassemble sumstore

Disassemble procedure

x/14xb sumstore

Examine the 14 bytes starting at sumstore

What Can be Disassembled?

```
% objdump -d WINWORD.EXE
WINWORD.EXE: file format pei-i386
No symbols in "WINWORD.EXE".
Disassembly of section .text:
30001000 < text>:
30001000:
30001001:
               Reverse engineering forbidden by
30001003:
             Microsoft End User License Agreement
30001005:
3000100a:
```

- Anything that can be interpreted as executable code
- Disassembler examines bytes and reconstructs assembly source

Today: Machine Programming I: Basics


- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

x86-64 Integer Registers

%rax	%eax	% r8	%r8d
%rbx	%ebx	%r9	%r9d
%rcx	%ecx	%r10	%r10d
%rdx	%edx	%r11	%r11d
%rsi	%esi	%r12	%r12d
%rdi	%edi	%r13	%r13d
%rsp special surpose register	%esp	%r14	%r14d
%rbp	%ebp	% r15	%r15d

Can reference low-order 4 bytes (also low-order 1 & 2 bytes)

Some History: IA32 Registers



Origin (mostly obsolete)

accumulate

counter

data

base

source index

destination index

stack pointer base

pointer

Moving Data

- **Moving Data**

mova Source, Dest:

\$0x08 Immediate % rbx Register Arguments (% rex) Memory


- **Operand Types**
 - **Immediate:** Constant integer data
 - Example: \$0x400, \$-533
 - Like C constant, but prefixed with `\$'
 - Encoded with 1, 2, or 4 bytes
 - Register: One of 16 integer registers
 - Example: %rax, %r13
 - But %rsp reserved for special use


 - Others have special uses for particular instructions
 - mentemen move **Memory:** 8 consecutive bytes of memory at address given by register morg \$15, % rax
 - Simplest example: (%rax)
 - Various other "address modes"




- %rax
- %rcx
- %rdx
- %rbx
- %rsi
- %rdi
- %rsp
- %rbp

%rN







movq Operand Combinations





```
Source
                                              Dest
                                                                             Src, Dest
| Reg(4) movq $0x4, %rax | temp = 0x4 |
| Mem(2) movq $-147, (%rax) | *p = -147; |
| Reg(3) movq %rax, %rdx | temp2 = ter |
| Mem(4) movq %rax, (%rdx) | *p = temp; |
| Mem Reg(5) movq (%rax), %rdx | temp = *p;
                                                                                                                 temp = 0x4;
                                                                                                                 temp2 = temp1;
```

Cannot do memory-memory transfer with a single instruction









MEMORY ADD

$$(:/.rax) \equiv M[R[:/.rax]]$$

$$D(:/.rax) \equiv M[R[:/.rax] + D]$$

$$Signament$$

$$D(:/.rax) \equiv M[Rb + Sx Ri + D]$$

$$D(:/.rax) \equiv M[Rb + Sx Ri + D]$$

$$Scale$$

$$(const)$$

$$m[R[Pb] + R[Pi]xS + D]$$

$$displacement$$

$$m[R[Pb] + R[Pi]xS + D]$$

Simple Memory Addressing Modes

- Normal (R) Mem[Reg[R]]
 - Register R specifies memory address
 - Aha! Pointer dereferencing in C

```
movq (%rcx),%rax
```


- Displacement D(R) Mem[Reg[R]+D]
 - Register R specifies start of memory region
 - Constant displacement D specifies offset

```
movq 8(%rbp),%rdx
```

Example of Simple Addressing Modes


```
void swap
    (long *xp, long *yp)
{
    long t0 = *xp;
    long t1 = *yp;
    *xp = t1;
    *yp = t0;
}
```

void swap (long *xp, long *yp) { long t0 = *xp; long t1 = *yp; *xp = t1; *yp = t0; }




Register	Value
%rdi	хр
%rsi	ур
%rax	t0
%rdx	t1

Registers




Memory




swap:

```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```




swap:


```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```



Understanding Swap()



Understanding Swap()



ret

Simple Memory Addressing Modes

- Normal (R) Mem[Reg[R]]
 - Register R specifies memory address
 - Aha! Pointer dereferencing in C

```
movq (%rcx),%rax
```

- Displacement D(R) Mem[Reg[R]+D]
 - Register R specifies start of memory region
 - Constant displacement D specifies offset

```
movq 8(%rbp),%rdx
```

Complete Memory Addressing Modes

Most General Form

D(Rb,Ri,S) Mem[Reg[Rb]+S*Reg[Ri]+D]

■ D: Constant "displacement" 1, 2, or 4 bytes

■ Rb: Base register: Any of 16 integer registers

■ Ri: Index register: Any, except for %rsp

S: Scale: 1, 2, 4, or 8 (why these numbers?)

Special Cases

(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]]

D(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]+D]

(Rb,Ri,S) Mem[Reg[Rb]+S*Reg[Ri]]

D(, Ri,S) -> this is also possible

Address Computation Examples

%rdx	0xf000
%rcx	0x0100

Expression	Address Computation	Address
0x8'(%rdx) = R(hrdx)	0xf000 + 0x8	0xf008
(%rdx,%rcx)	0xf000 + 0x100	0xf100
(%rdx,%rcx,4)	0xf000 + 4*0x100	0xf400
0x80(,%rdx,2)	2*0xf000 + 0x80	0x1e080 e

Today: Machine Programming I: Basics

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

Address Computation Instruction

leaq Src, Dst

- Src is address mode expression
- Set Dst to address denoted by expression

Uses

- Computing addresses without a memory reference
 - E.g., translation of p = &x[i];
- Computing arithmetic expressions of the form x + k*y
 - k = 1, 2, 4, or 8

Example

```
long m12(long x)
{
   return x*12;
}
```

```
Converted to ASM by compiler:

leaq (%rdi, %rdi, 2), %rax # t <- x+x*2
salq $2, %rax # return t<<2
```

Some Arithmetic Operations

Two Operand Instructions:

```
Computation
Format
  addq
            Src,Dest
                         Dest = Dest + Src
            Src,Dest
  subq
                         Dest = Dest - Src
  imulq Src,Dest
                         Dest = Dest * Src
            Src,Dest
                                                  Also called shlq
  salq
                         Dest = Dest << Src
            Src,Dest
                                                  Arithmetic
                         Dest = Dest >> Src
  sarq
  shrq
            Src,Dest
                         Dest = Dest >> Src
                                                  Logical
            Src,Dest
                         Dest = Dest ^ Src
  xorq
  andq
            Src,Dest
                         Dest = Dest & Src
                         Dest = Dest | Src
            Src,Dest
  orq
```

- Watch out for argument order!
- No distinction between signed and unsigned int (why?)

Some Arithmetic Operations

One Operand Instructions

```
incq Dest Dest = Dest + 1
decq Dest Dest = Dest - 1
negq Dest Dest = - Dest
notq Dest Dest = "Dest
```

See book for more instructions

Arithmetic Expression Example

```
long arith
(long x, long y, long z)
  long t1 = x+y;
  long t2 = z+t1;
  long t3 = x+4;
  long t4 = y * 48;
  long t5 = t3 + t4;
  long rval = t2 * t5;
  return rval;
```

```
arith:
  leaq (%rdi,%rsi), %rax
  addq %rdx, %rax
  leaq (%rsi,%rsi,2), %rdx
  salq $4, %rdx
  leaq 4(%rdi,%rdx), %rcx
  imulq %rcx, %rax
  ret
```

Interesting Instructions

- leaq: address computation
- **salq**: shift
- imulq: multiplication
 - But, only used once

Understanding Arithmetic Expression Example

```
long arith
(long x, long y, long z)
{
    long t1 = x+y;
    long t2 = z+t1;
    long t3 = x+4;
    long t4 = y * 48;
    long t5 = t3 + t4;
    long rval = t2 * t5;
    return rval;
}
```

```
rdit rsi
          fi= X+Y
arith:
  leaq
          (%rdi,%rsi),
                      %rax
                             # t1
  addq
         %rdx, %rax
                             # t2
        (%rsi,%rsi,2),
  leaq
                        Frdx
                          48y # t4
  salq $4, %rdx
         4(%rdi,%rdx), %rcx
  leaq
        %rcx, %rax
                             # rval
  imulq
  ret
```

Register	Use(s)
%rdi	Argument x
%rsi	Argument y
%rdx	Argument z
%rax	t1, t2, rval
%rdx	t4
%rcx	t5

Machine Programming I: Summary

History of Intel processors and architectures

Evolutionary design leads to many quirks and artifacts

C, assembly, machine code

- New forms of visible state: program counter, registers, ...
- Compiler must transform statements, expressions, procedures into low-level instruction sequences

Assembly Basics: Registers, operands, move

 The x86-64 move instructions cover wide range of data movement forms

Arithmetic

 C compiler will figure out different instruction combinations to carry out computation