Coding of X.731 and M.3100 State and Status Information

This supporting document specifies how X.731 and M.3100 state and status information MUST be mapped to the MTNM information model if supported by the EMS. The mapping covers potentially every managed object. For definition of the states and statuses and their values refer to ITU-T recommendations X.731, X.721, and M.3100 respectively, including the specification of which information is read-only and which is read-write. The states and statuses are mapped to the *additionalInfo* field of the managed object or to a transmission parameter of a TP layer if a layered approach is needed (see <u>SD1-16</u>).

Therefore any particular state of a managed object is modelled as a name/value pair with *prescribed* name and values and, usually, an *ITU-T defined* state transition diagram showing the admissible value changes. State parameters may be further qualified by status parameters. A status condition expressed by a status parameter value may force specific values of state parameters. Unlike states, statuses need or can not have a state transition diagram since their changes are often triggered. States and statuses may be single-valued or set-valued. The values of multiple-valued parameters are represented by comma separated lists of single values.

The semantics of every state and status listed below is a matter of bilateral agreement with one exception: if *Oper state*, *Admin state*, and *Service state* (defined for equipment objects and as TP transmission parameter) are used simultaneously, their values have to meet the following table copied from TMF 814A:

ITU-T Operational State	ITU-T Administrative State	MTNM Service State
enabled	unlocked	IN_SERVICE
	locked	OUT_OF_SERVICE_BY_MAINTENANCE
	shutting down	SERV_NA
disabled	unlocked	OUT_OF_SERVICE
	locked	OUT_OF_SERVICE_BY_MAINTENANCE

Table 4-4 ITU-T to MTNM State Mapping

Note that the support of all or some of these additional info (respectively transmission) parameters by the EMS is **entirely optional** and that none of these parameters has any semantic impact on the MTNM interface except the stated dependency on *Service state*. It is only required to use the names and values specified if the EMS supports any of them in order to achieve **multi-vendor interoperability**. The purpose of additional info parameter specifications (and specifications of other name/value pair parameters) in MTNM is not to prescribe implementation issues but to guarantee conditional multi-vendor compatibility: if a feature is implemented by several vendors through name/value pairs it MUST be exposed at the MTNM interface in the same way by all of them.

ITU-T State or Status	Name String	Value String
Oper[ational] state	"X.721::OperationalState"	One of the following: • "DISABLED" • "ENABLED"
Admin[istrative] state	"X.721::AdministrativeState"	One of the following: • "LOCKED" • "UNLOCKED" • "SHUTTING_DOWN"
Usage state	"X.721::UsageState"	One of the following: • "IDLE" • "ACTIVE" • "BUSY"

ITU-T State or Status	Name String	Value String
Avail[ability] status	"X.721::AvailabilityStatus"	One or more of the following separated by ",": """ "IN_TEST" "FAILED" "POWER_OFF" "OFF_LINE" "OFF_DUTY" "DEPENDENCY" "DEGRADED" "NOT_INSTALLED" "LOG_FULL"
Control status	"X.721::ControlStatus"	One or more of the following separated by ",": "" "SUBJECT_TO_TEST" "PART_OF_SERVICES_LOCKED" "RESERVED_FOR_TEST" "SUSPENDED"
Holder status	"M.3100::HolderStatus"	One of the following: • "HOLDER_EMPTY" • "IN_THE_ACCEPTABLE_LIST" • "NOT_IN_THE_ACCEPTABLE_LIST" • "UNKNOWN_TYPE"
	"M.3100::CircuitPackType"	a free-format string
Alarm status	"M.3100::AlarmStatus"	One of the following: "CLEARED" "PENDING" "WARNING" "INDETERMINATE" "MINOR" "MAJOR" "CRITICAL"
ARC state	"M.3100::ArcState"	One of the following: "ALM" "NALM" "NALM_QUALIFIED_INHIBIT" "NALM_TIMED_INHIBIT"
	"M.3100::NALMQIInterval"	"NO_ADJUSTMENT", "0" "5940"
	"M.3100::NALMTIInterval"	"NO_ADJUSTMENT", "0" "5940"
ARC QI status	"M.3100::ArcQIStatus"	One of the following: • "NOT_APPLICABLE" • "NALM_NOT_REPORTED" • "NALM_COUNT_DOWN"
Unknown status	"X.721::UnknownStatus"	One of the following: • "False" • "True"

ITU-T State or Status	Name String	Value String
State	"X.721::State"	One or more of the following separated by ",": "" "X.721::OperationalState" "X.721::AdministrativeState" "X.721::UsageState" "X.721::AvailabilityStatus" "X.721::ControlStatus" "M.3100::HolderStatus" "M.3100::ArcState" "M.3100::ArcQIStatus" "M.3100::ArcQIStatus" "X.721::UnknownStatus"

Revision History

Version	Date	Description of Change
3.0	April 2005	
3.0	June 2005	Reference updated
3.1	November 2005	Version in names of referenced supporting documents
		deleted.
3.2	Novemver 2007	Change cross-ref format.

Acknowledgements

<firstname></firstname>	<lastname></lastname>	<company></company>

How to comment on the document

Comments and requests for information must be in written form and addressed to the contact identified below:

Keith	Dorking	CIENA
Phone:	+1 678 867 5007	
Fax:	+1 678 867 5010	
e-mail:	Kdorking@ciena.com	

Please be specific, since your comments will be dealt with by the team evaluating numerous inputs and trying to produce a single text. Thus we appreciate significant specific input. We are looking for more input than wordsmith" items, however editing and structural help are greatly appreciated where better clarity is the result.