LECTURE IV

Microcontroller Architecture and Arduino

© 2023 Open Project Space, Institute of Electrical and Electronics Engineers at the University of California, Irvine. All Rights Reserved.

SECTION I

Binary Numbers and Digital Signals

Number Systems and Bases

- The Decimal number system contains the set of ten digits {0, 1, 2, 3, 4, 5, 6, 7, 8, 9}, making it a Base-10 number system
- There exist different bases beyond the Decimal number system
 - For example, Base-8 is the Octal number system with the set of only eight digits... {0, 1, 2, 3, 4, 5, 6, 7}
 - Base-16, or the Hexadecimal number system, has a whopping sixteen digits... {0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E, F}

Number Systems and Bases (Cont'd)

- We can convert a number of a different base to Base-10 with the following method
- Ex) Convert Hex number B32₁₆ to Base-10


B is represented by the decimal number 11 $(B \cdot 16^{2}) + (3 \cdot 16^{1}) + (2 \cdot 16^{0})$ $= (B \cdot 16^{2}) + (3 \cdot 16^{1}) + 2$ $= (B \cdot 16^{2}) + 48 + 2$ $= (B \cdot 16^{2}) + 48 + 2$ = 2816 + 48 + 2 = 2866

The base of a hexadecimal number is 16

Each hexadecimal digit represents a power of 16

Binary Signals

- Computers transfer data across wires/lines as digital (discrete) voltage signals
 - These signals are either a HIGH or LOW voltage
 - Contrasts from analog signals which can be values in a continuous range




Digital signals are translated to the Binary number system or Base-2
 (1s and 0s)

Bits, Bytes, and Beyond

- Single Binary digits are called bits
 - Bits compose binary numbers like 10010₂ (18₁₀)
- Eight bits form a byte
 - For example... 10100010₂ 01011111₂
- Data in a computer is stored in memory which is divided into cells each a byte in width
 - This means that on many systems, a byte is the smallest unit of data that can be accessed by a computer

Bits, Bytes, and Beyond (Cont'd)

- Decimal units are used to express the size of binary data
 - i.e. Kilobytes (KB), Megabytes (MB), etc.
- Small embedded computers may store just kilobytes or megabytes of data
- Laptops can store gigabytes or terabytes of information
- Google servers store exabytes of data
 - That's billions of gigabytes!




Petabyte (PB) - 1024 (TB) , Exabyte (EB) - 1024 (PB) Zettabyte (ZB) - 1024 (EB) , Yottabyte (YB) - 1024 (ZB) SECTION II

Microcontrollers

Microcontrollers


- A microcontroller (or MCU) is a small computer on a single integrated circuit
 - It is quite literally a computer, complete with everything needed to run and store programs
- An architecture defines the organization of hardware within the computer
 - MCUs have different architectures
 - Sometimes we say they "belong to different families"



AVR Microcontroller Family

Microcontrollers (Cont'd)

- We will focus on a microcontroller which adheres to the AVR architecture
 - It runs programs made with the AVR instruction set
- To better understand how an AVR microcontroller works, we will examine its key components...



AVR Microcontroller Family

SECTION III


AVR Microcontroller Architecture

AVR Architecture


- Main units of an AVR microcontroller:
 - Central Processing Unit (CPU)
 - Memory
 - Analog-to-Digital Converter
 - Timers
 - Input/Output Ports
 - Serial Communication Units



AVR Architecture (Cont'd)




Central Processing Unit (CPU)




A **CPU executes instructions** provided by a memory unit. These instructions may be mathematical **computations**, memory **data transfer**, or signals to **input and output** ports.

Memory




A memory unit stores data and instructions. There are subunits of memory, some of which are for short-term storage, erased when the microcontroller is disconnected from its power supply, while others are long-term.

Input/Output (I/O) Ports




Input/Output Ports (I/O Ports) connect the microcontroller to peripheral devices that transfer data to and from the microcontroller. This data may be stored in memory or interpreted by the CPU. The I/O Ports are wired to physical leads on the IC called I/O pins.

Analog-To-Digital Converter (ADC)




The analog-to-digital converter (ADC) measures real-world, analog signals from the I/O pins (i.e. temperature, pressure, acceleration) and converts them into digital signals that the microcontroller can interpret.

Timers



Timers are used by the microcontroller to **control the timing** of program execution or output signals and **measure time**.

Serial Communication Units



The TWI, USART, and SPI are all units that generate and interpret serial communication signals between the microcontroller and I/O peripherals. This facilitates data transfer across devices. We will expand on these terms in a future lecture on communication.


SECTION IV

Arduino Boards

Arduino Boards

- The Arduino company designed microcontroller boards to make several AVR microcontrollers hobbyist-friendly
 - Added a USB port, input voltage regulator, onboard LEDs, among other things
 - This family of boards includes the Arduino Uno, Arduino Nano, and many, many more!

The MCU is **an IC that sits in a DIP socket** on the board




Arduino Uno

Arduino Nano

- The current and future lectures use the Arduino Nano (based on the ATmega328P microcontroller)
 - The ATmega328P belongs to the AVR family
 - The Arduino Uno uses the same microcontroller
 - Almost all code written for the Arduino Nano is directly transferable to the Arduino Uno

The MCU is **an SOIC** soldered to the board



Arduino Nano

SECTION V

Arduino IDE

CH340 Driver

- We will use the CH340 driver so that our personal computers understand how to communicate with the Arduino board
- Download the CH340 installer here

Drivers (If You Need Them)

The CH340 has been tested on:

- Windows 7/10
- Mac OSX
 - v10.10.5 (Yosemite)
 - v10.11.6 (El Capitan)
 - v10.13.0 (High Sierra)
 - v10.14.5 (Mojave)
- Linux
 - · Raspbian Stretch (11-13-2018 release) for the Raspberry Pi
 - · Raspbian Buster (2019-07-10 release) for the Raspberry Pi
 - Ubuntu v18.04.2, 64-bit

These operating systems have the CDC drivers pre-installed, which means you shouldn't need to install any extra software. However, there are a wide range of operating systems out there, so if you run into driver problems, you can get the archived drivers linked below

- · Windows (EXE) Driver executable
- Windows (ZIP): Driver v3.4 (2016-09-27)
- Mac (ZIP): Driver v1.5 (2018-07-04)




DRIVERS (ENGLISH PAGE)

find the latest version of their drivers from their website in had the option to have the web page translated. However, you in either language. For those interested in heading to the

DRIVERS (MANDIRIN PAGE)





Arduino IDE

We will write code, compile, and upload it to the Arduino board from our personal computers using the Arduino IDE software kit

Arduino IDE 2.0.1

and even a live debugger.


documentation

section below. SOURCE CODE

GitHub.

Download the IDE installer here





Creating a Sketch

```
File Edit Sketch Tools Help


Select Board

demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:
5
6 }
7
```

- An Arduino source code file is called a sketch and has the .ino extension
- When the IDE opens, a new sketch will be created automatically or a previous sketch will open
 - \circ To create a new sketch, select **File** \rightarrow **New Sketch** from the menu

Editing a Sketch



- Sketches can be modified from the **code editor**, which appears just below the menu
- New sketches opened in the editor come with template code
- The editor is also enhanced with text autocompletion

Setting the Target Board

```
File Edit Sketch Tools Help

Select Board


demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:

5
6 }
7
```

- Before we can upload a sketch, we must connect the Arduino board via USB to the computer and configure the IDE to the correct board and USB port
- Open the Select Board dropdown and select an available Arduino Nano board
 - If no option appears, click Select other board and port...

Setting the Target Board (Cont'd)



- In the popup window, search
 Boards and select Arduino Nano
- From the available items under
 Port, select the USB port to which the board is currently connected
- Confirm the selections by clicking
 OK

Verifying and Uploading a Sketch

```
File Edit Sketch Tools Help

Select Board

demo_sketch.ino.ino

1 //

2 
3 void setup() {
    // put your setup code here, to run once:
    5 
6 }
7
```

- Before uploading the sketch, select Verify (the checkmark icon) to compile the sketch
- Once the sketch compiles successfully, select Upload (the right arrow icon)
 to upload the compiled sketch to the Arduino board

Troubleshooting Ports


Did the upload time out? Are active ports missing from the dropdown? **Here's what to do**:

- Check your USB connection
 - Check your system's device manager to verify the Arduino is connected
 - Replace the USB cable or switch to a different USB port
- Verify your CH340 driver installation
- In the IDE, select Tools → Processor → ATmega328P (Old Bootloader)
- Restart the IDE and/or the personal computer

SECTION VI

Basic Arduino Pins and Functions

Arduino Pinout Diagram



- A pinout diagram is included in the Arduino Nano datasheet
- General Purpose Input/Output (GPIO)
 pins are pins with no predefined purpose
 - These are the analog and digital pins marked by the pinout diagram
 - We will design an Arduino sketch to control these pins





Sketch Structure

- Sketches are written in the Arduino language, which is much like C++
- Assign pins as global variables at the beginning of the sketch:

```
const int pinName = pin#;
```

- Each GPIO pin is associated with an integer
- Just like the C++ main function,
 Arduino has built-in functions
 setup and loop, which must be defined by the programmer

```
const int RECEIVER = 14;
const int LED = 7;
void setup()
   pinMode(LED, OUTPUT);
   pinMode(RECEIVER, INPUT);
   Serial.begin(9600);
void loop()
   Serial.println(analogRead(RECEIVER));
   digitalWrite(LED, HIGH);
```

Sketch Structure (Cont'd)

- setup() runs once at the beginning of program execution
 - Used to initialize pin modes and global variables
- loop () runs repeatedly in an infinite loop
 - This is where you implement the "main" code
- Do not define the main function.
 Arduino does this for you

```
const int RECEIVER = 14;
const int LED = 7;
void setup()
   pinMode(LED, OUTPUT);
   pinMode(RECEIVER, INPUT);
   Serial.begin(9600);
void loop()
```

Serial.println(analogRead(RECEIVER));

digitalWrite(LED, HIGH);

Things to do in setup

- void pinMode(int pin, int mode)
 - Call this function for each digital pin you want to use
 - Pass the global variable assigned to each pin to the pin param
 - Specify if your pin is INPUT or OUTPUT mode
 - We read data from input pins and send data to output pins


```
void setup()
{
   pinMode(LED, OUTPUT);
   pinMode(RECEIVER, INPUT);
   Serial.begin(9600);
}
```

Things to do in setup (Cont'd)

- Serial.begin(int baud_rate)
 - Serial is an object that facilitates communication between the Arduino board and the computer connected to it via USB
 - Pass 9600 bits per second as the argument for this member function
 - To be elaborated in future lectures

```
void setup()
{
   pinMode(LED, OUTPUT);
   pinMode(RECEIVER, INPUT);
   Serial.begin(9600);
}
```

Digital Pins




Digital Pin Functions



- int digitalRead(int pin)
 - Reads the voltage at the input pin, returning HIGH (5V) or LOW (0V) as an integer (1 or 0)
- void digitalWrite(int pin, int value)
 - Sets the voltage at the output pin to either a
 HIGH (5V) or LOW (0V) value
- Analogy light switch and light bulb:
 - You use the switch to set the bulb to either MAX brightness or MIN brightness

Analog Pins



Analog Pin Functions



- int analogRead(int pin)
 - Reads the voltage at the input pin, maps it to a value in the discrete range 0-1023 (0V to 5V) and returns that value
 - Use the aliases A0, A1, A2... for the pin number
- void analogWrite(int pin, int value)
 - Sets the average voltage on digital output pin to a value in the discrete range 0-255 (0V to 5V)
 - This is a function for ~ PWM pins only
- Analogy light dimmer:
 - You use the slide to set the bulb to anywhere between MAX brightness or MIN brightness

ADC and analogRead

- analogRead utilizes the analog-to-digital converter inside the Arduino's AVR microcontroller to measure the real-world, analog signal and convert it to a digital signal
 - The measurement resolution is 10 bits, which is why the function returns values from 0-1023



More Basic Functions

- void delay(int ms)
 - Pauses the program execution by ms milliseconds
- Serial.print(val)
 - Sends val to the computer connected via USB and displays
 val on the Serial Monitor in the IDE
- Serial.println(val)
 - Sends val to the computer connected via USB and displays
 val on the Serial Monitor in the IDE, followed by a newline

Using the Serial Monitor

```
File Edit Sketch Tools Help

Select Board

demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:
5
6 }
7
```

- While the Arduino board is connected to the personal computer via USB, select Serial Monitor (the magnifying glass icon) in the IDE
 - A pane will appear at the bottom of the IDE window which displays all data sent by the Arduino board using Serial.print

Using the Serial Monitor (Cont'd)

```
File Edit Sketch Tools Help

Select Board

demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:
5
6 }
7
```

- In the absence of a debugger (the Arduino Nano is not capable of using one),
 Serial.print is an excellent tool to help debug programs
 - Print values to track across parts of your program
 - Unexpected values displayed to the Serial Monitor indicates an error

Using the Serial Monitor (Cont'd)

```
File Edit Sketch Tools Help


Select Board

demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:
5
6 }
7
```

- The C++ iostream library is not compatible with Arduino
 - Do not use cin or cout to print text
- Serial.print is the primary way to print text to the Serial Monitor

Arduino Reference Library




- Learn more about Arduino functions and libraries <u>here</u>
- The Arduino Reference Library includes support for devices like LCDs, Sensors, and WiFi modules

SECTION VII

Pulse Width Modulation

PWM


- The Arduino board (the underlying AVR microcontroller) is a digital source, meaning it can only output a HIGH (5V) or LOW (0V) voltage
 - Then how does analogwrite output analog signals?
- Pulse Width Modulation (PWM) is an oscillating digital waveform that emulates an analog output
 - By oscillating a signal from HIGH to LOW quickly, the average voltage over time will be between HIGH and LOW - an analog value



The average value, the analog value, of this waveform is **2.5V**

PWM Duty Cycle

- The duty cycle of the PWM wave is the percentage of time where the signal is HIGH
 - For example, a 50% duty cycle translates to an average value of 2.5V (50% of 5V)
 - Allows us to output a continuous range of voltages between HIGH and LOW
 - Duty cycle is controlled by a timer inside the AVR microcontroller




SECTION VIII

Digital LED Circuit Exercises

Prototyping with the Arduino Nano


- The Arduino Nano can be seated along the DIP channel of a standard breadboard just like a DIP IC
- The Arduino Nano's USB port should be oriented away from the board, so the connected cable doesn't obstruct the breadboard
- Circuits that interface with the Arduino board must share a common ground with the GND pin of the board



Digital LED Circuit



Build the circuit below from the schematic. Then, complete the template code, flash it to the Arduino board, and verify the circuit.



```
// Assign variable to pin number for LED


void setup() {
    // Configure LED pin's behavior to OUTPUT
    // Configure the Serial baud rate
}

void loop() {
    // Set LED pin to HIGH
}
```

Digital Blinking LED Circuit




Build the circuit below from the schematic. Then, complete the template code, flash it to the Arduino board, and verify the circuit.



```
void setup() {
void loop() {
```


Potentiometers

- A potentiometer is a three-terminal variable resistor
- We will use the potentiometer as a voltage divider - a circuit which accepts a supply voltage and outputs a voltage which is a fraction of the supply voltage
- The voltage of the potentiometer's output pin ranges between the VCC and GND pin voltages



Potentiometers (Cont'd)


- Internally, a resistive strip connects its VCC and GND pins
 - A rotating wiper connects the output pin to the strip
- The greater the distance along the strip between the wiper and the VCC pin, the greater the resistance between the wiper and VCC
- The wiper reduces the voltage at the output pin the further it is turned clockwise (toward GND)



Digital Dimmable LED Circuit



Build the circuit below from the schematic. Then, complete the template code, flash it to the Arduino board, and verify the circuit.



```
void setup() {
  // Configure the LED pin's behavior to OUTPUT
  // Configure the Pot pin behavior to INPUT
void loop() {
```

"Give me **PWM** or give me a **binary** state of existence!"

Patrick Henry (circa 1775)

Famous Misquotes

FAIR USE DISCLAIMER

Copyright Disclaimer under section 107 of the Copyright Act 1976, allowance is made for "fair use" for purposes such as criticism, comment, news reporting, teaching, scholarship, education and research.

Fair use is a use permitted by copyright statute that might otherwise be infringing.

Non-profit, educational or personal use tips the balance in favor of fair use.