# **WSR-98D DOPPLER WEATHER RADAR**

# DESCRIPTION OF BASE DATA FORMAT

Beijing Metstar Radar Company Oct, 2013

# Contents

Figures and Tables	3
CHAPTER 1 INTRODUCTION	
1.1 Purpose and Scope	4
1.3 Background and Rules	4
1.4 Base Data Architecture	
CHAPTER 2 PRODUCT COMMON HEADER	6
2.1 Introduction.	6
2.2 Generic Header Block	6
2.3 Site Configuration Block	
2.4 Task Configuration Block	8
2.5 Cut Configuration Block	9
CHAPTER 3 Base Data Radial Data	13
3.1 Basedata Radial Header Block	13
3.2 Base Data Moment Header Block	13

# **Figures and Tables**

Figure 1-1 Base Data Architecture	5
Table 2-1 Product Common Blocks	6
Table 2-2 Generic Header Block	6
Table 2-3 Generic Data Type List	6
Table 2-4 Site Configuration Block	
Table 2-5 Task Configuration Block	
Table 2-6 Cut Configuration Block	
Table 2-7 Moments Type/Bit Mask Definition	
Table 2-8 Filters Bit Mask Definition	
Table 3-1 Basedata Radial Header Block	13
Table 3-2 Basedata Moment Header Block	13

# **CHAPTER 1 INTRODUCTION**

## 1.1 Purpose and Scope

The document describes the format of WSR-98D Base Data. It can be used as interface and technical reference for development work on Base Data.

#### 1.3 Background and Rules

Readers who read this document are assumed to have basic knowledge on Computer Science and C/C++ language. Weather Radar theory and experiences are also required to better understand the materials.

Data types are based on 32-bit little end computer system, data types used are defined here.

- INT 4 bytes integer
- SHORT 2 bytes integer
- •CHAR\*N N bytes characters
- FLOAT 4 bytes float value, in format of IEEE754
- LONG 8 bytes integer

#### 1.4 Base Data Architecture

WSR-98D Base Data is formatted in many blocks, each block contains a group of information. For example, Site Configuration block (see Table 2-4) is used to provide information on radar site, like site latitude, longitude and height of antenna.

All blocks are divided into 2 main segments – Product Common Blocks, Radial Data Block.

The Product Common Blocks are a set of blocks shared by all of different types of products and Base Data. It provides user with information on radar site and task, etc. Details of Product Common Blocks are provided in Chapter 2.

The Radial Data Blocks keeps moments data of weather. Radial Data Block consists of 3 sub blocks, Radial Header Block, Moment Header Block and Moment Data Block. Details of Radial Data Blocks are provided in Chapter 3.

The architecture of Base Data is described in Figure 1-1.




Figure 1-1 Base Data Architecture

# **CHAPTER 2 PRODUCT COMMON HEADER**

#### 2.1 Introduction.

In order to illustrate meteorological products and base data, some common blocks are attached ahead of meteorological data. These common blocks provide detail information on radar site and task that generating raw data.

For most of WSR-98D meteorological products and Base Data, there all share these common blocks. Common blocks are described in Table 2-1.

**Table 2-1 Product Common Blocks** 

BLOCK	BYTES	REMARKS
GENERIC HEADER	32	Generic Product Header, see Table 2-2
SITE CONFIG	128	Site Configuration, see Table 2-4
TASK CONFIG	256	Task Configuration, see Table 2-5
CUT CONFIG	256*N	Cut Configuration, see Table 2-6
		For some tasks, more than 1 cut can be included.

#### 2.2 Generic Header Block

Generic Header Block is the first block of all product, it is a general summary block contains the summary information of the following other blocks. Generic Header Block keeps information like version of product format and data type.

Generic Header Block is described in Table 2-2.

**Table 2-2 Generic Header Block** 

NO	FIELD	TYPE	UNIT	RANGE	REMARKS
	NAME	/BYTES			
01	Magic Word	INT	N/A	0x4D545352	Magic word for product
02	Major Version	SHORT	N/A	0 to 65536	Major Version
03	Minor Version	SHORT	N/A	0 to 65536	Minor Version
04	Generic Type	INT	N/A	2	Type of data, see Table
					2-3
05	Product Type	INT	N/A	1 to 100	Type of Product, not
					used for Base Data
06	Reserved	16 Bytes	N/A	N/A	Reserved

**Table 2-3 Generic Data Type List** 

PRODUCT TYPE	Generic NAME	REMARKS
1	Base Data	Base Data
2	Product	Meteorological Product

# 2.3 Site Configuration Block

Site Configuration Block is the second block of product, it provides information on radar site. All parameters related to radar site should be included in this block.

Site Code (No. 1 element in block) is the unique key of radar site, RPG and PUP can use this code to distinguish different radar sites.

Site Configuration Block is described in Table 2-4.

**Table 2-4 Site Configuration Block** 

	Table 2-4 Site Configuration Block						
NO	FIELD NAME	TYPE	UNIT	RANGE	REMARKS		
		/BYTES					
01	Site Code	CHAR*8	N/A	ASCII	Site Code		
					in characters		
02	Site Name	CHAR*32	N/A	ASCII	Site Name or		
					description		
					in characters		
03	Latitude	FLOAT	Degree	-90.0 to 90.0	Latitude of Radar Site		
04	Longitude	FLOAT	Degree	-180.0 to	Longitude of Radar Site		
				180.0	_		
05	Height	INT	Meters	0 to 65536	Height of antenna in		
					meters		
06	Ground	INT	Meters	0 to 65536	Height of ground in		
					meters		
07	Frequency	FLOAT	MHz	1.0 to	Radar operation		
				999,000.0	frequency in MHz		
08	Beam Width Hori	FLOAT	Degree	0.1 to 2.0	Antenna Beam Width		
					Hori		
09	Beam Width Vert	FLOAT	Degree	0.1 to 2.0	Antenna Beam Width		
					Vert		
10	Reserved	60 Bytes	N/A	N/A			

# 2.4 Task Configuration Block

Task Configuration Block provides information on radar scan task. Task can be PPI, RHI or Volume Coverage Pattern.

Task Configuration Block includes the general parameters or data of a task, for detail parameters of elevation or azimuth cut, the Cut Configuration Blocks provides more descriptions in detail.

For most tasks, more than 1 Cut is included, in which case more than 1 Cut Configuration Blocks are followed. Parameter Cut Number (No. 4 element in block) is the number of cut followed.

Task Configuration Block is described in Table 2-5.

**Table 2-5 Task Configuration Block** 

NO	FIELD NAME	TYPE	UNIT	RANGE	REMARKS
01	Task Name	CHAR*32	N/A	ASCII	Name of the Task
					Configuration
02	Task Description	CHAR*128	N/A	ASCII	Description of Task
03	Polarization	INT	N/A	1 to 4	Polarization Type:
	Type				1 - Horizontal
					2 - Vertical
					3 - Simultaneously
					4 - Alternation
04	Scan Type	INT	N/A	1 to 3	Volume Scan Type
					0 - PPI Volume Scan
					1- Single PPI
					2 - Single RHI
					3 -Single Sector
					4 – Sector Volume Scan
					5 – RHI Volume Scan
					6 – Manual Scan
05	Pulse Width	INT	Nanoseconds	1 to 10000	Pulse Width
0.5	T disc Width	1111	Tvanosceonus	1 to 10000	Tuise Width
06	Volume Start	INT	Seconds	UTC	Start time of volume
	Time	1111	Seconds	010	scan
07	Cut Number	INT	N/A	1 to 256	Number of Elevation or
		1111	1,712	1 00 20 0	Azimuth cuts in the task
08	Horizontal Noise	FLOAT	dBm	-100.0 to 0.0	Noise level of
			0,200		horizontal channel
09	Vertical Noise	FLOAT	dBm	-100.0 to 0.0	Noise level of vertical
					channel
10	Horizontal	FLOAT	dB	0.0 to 200.0	System Reflectivity
	Calibration				Calibration Const for
					horizontal channel.
11	Vertical	FLOAT	dB	0.0 to 200.0	System Reflectivity
	Calibration				Calibration Const for
					vertical channel.
12	Horizontal Noise	FLOAT	dB	0.0 to 800.0	System Reflectivity

	Temperature				Calibration Const for
					horizontal channel.
13	Vertical Noise Temperature	FLOAT	dB	0.0 to 800.0	System Reflectivity Calibration Const for
					vertical channel.
14	Zdr Calibration	FLOAT	dB	-10.0 to 10.0	Reflectivity calibration
					difference of horizontal
					and vertical channel
15	Phase	FLOAT	Degree	-180.0 to	Phase calibration
	Calibration			180.0	difference of horizontal
					and vertical channel
16	LDR Calibration	FLOAT	dB	-60 to 0	LDR calibration
					difference of horizontal
					and vertical channel
17	Reserved	40 Bytes	N/A	N/A	

# 2.5 Cut Configuration Block

Cut Configuration Block provides information of a specified cut in task.

For most tasks, more than 1 cut may be included. The parameter "Cut Number" in Task Configuration block decides the number of cuts in the task. When there are many cuts in one task, cut configuration are stored in disk one by one follow the order of antenna scanning.

Cut Configuration Block is described in Table 2-6.

**Table 2-6 Cut Configuration Block** 

NO	FIELD NAME	TYPE	UNIT	RANGE	REMARKS
01	Process Mode	INT	N/A	1 to 2	Main processing mode of signal processing algorithm. 1 - PPP 2 - FFT
02	Wave Form	INT	N/A	1 to 7	WSR-88D defined wave form  0 - CS  1 - CD  2 - CDX  3 - Rx Test  4 - BATCH  5 - Dual PRF  6 - Random Phase  7 - SZ
03	PRF #1	INT	Hz	1 to 3000	Pulse Repetition Frequency #1.  For wave form Batch and Dual PRF mode, it's the high PRF, for other modes it's the only PRF.
04	PRF #2	INT	Hz	1 to 3000	Pulse Repetition Frequency #2.

					For wave form Batch and Dual PRF mode, it's the low PRF, for other modes it's not used.
05	Unfold Mode	INT	N/A	1~4	Dual PRF mode 1 – Single PRF 2 – 3:2 mode 3 – 4:3 mode 4 – 5:4 mode
06	Azimuth	FLOAT	Degree	0.0 to 360.0	Azimuth degree for RHI scan mode,
07	Elevation	FLOAT	Degree	-10.0 to 360.0	Elevation degree for PPI scan mode,
08	Start Angle	FLOAT	Degree	-10.0 to 360.0	Start azimuth angle for PPI Sector mode. Start (High) Elevation for RHI mode.
09	End Angle	FLOAT	Degree	-10.0 to 360.0	Stop azimuth angle for PPI Sector mode. Stop (Low) Elevation for RHI mode.
10	Angle Resolution	FLOAT	Degree	0.0 to 10.0	Azimuth resolution for PPI scan, Elevation resolution for RHI mode.
11	Scan Speed	FLOAT	Deg/sec	0.0 to 36.0	Azimuth scan speed for PPI scan, Elevation scan speed for RHI mode.
12	Log Resolution	INT	Meter	1 to 5,000	Range bin resolution for surveillance data, reflectivity and ZDR, etc.
13	Doppler Resolution	INT	Meter	1 to 5,000	Range bin resolution for Doppler data, velocity and spectrum, etc.
14	Maximum Range	INT	Meter	1 to 500,000	Maximum range of scan
15	Maximum Range2	INT	Meter	1 to 500,000	Maximum range of scan
16	Start Range	INT	Meter	1 to 500,000	Start range of scan
17	Sample #1	INT	N/A	2 to 512	Pulse sampling number #1. For wave form Batch and Dual PRF mode, it's for high PRF, for other modes it's for only PRF.
18	Sample #2	INT	N/A	2 to 512	Pulse sampling number #2. For wave form Batch and Dual PRF mode, it's for low PRF, for other modes it's not used.
19	Phase Mode	INT	N/A	1 to 3	Phase modulation mode.  1 – Fixed Phase  2 – Random Phase

					3 – SZ Phase
20	Atmospheric Loss	FLOAT	dB/km	0.0 to 10.0	two-way atmospheric attenuation factor
21	Nyquist Speed	FLOAT	m/s	0-100	
22	Moments Mask	LONG	N/A	0 to 127	Bit mask indicates which moments are involved in the scan. See Table 2-7
23	Moments Size Mask	LONG	N/A	0 to 0xFFFFFFF	Bit mask indicates range length for moment data in Table 2-7. 0 for 1 byte, 1 for 2 bytes
24	SQI Threshold	FLOAT	N/A	0.0 to 1.0	SQI Threshold for the scan
25	SIG Threshold	FLOAT	dB	0.0 to 20.0	SIG Threshold for the scan
26	CSR Threshold	FLOAT	dB	0.0 to 100.0	CSR Threshold for the scan
27	LOG Threshold	FLOAT	dB	0.0 to 20.0	LOG Threshold for the scan
28	CPA Threshold	FLOAT	N/A	0.0 to 100.0	CPA Threshold for the scan
29	PMI Threshold	FLOAT	N/A	0.0 to 1.0	PMI Threshold for the scan
30	Thresholds Reserved	8 Bytes	N/A	N/A	
31	dBT Mask	INT	N/A		Thresholds used for total reflectivity data. Bits mask start from "SQI Threshold", take is as LSB.
32	dBZ Mask	INT	N/A		Thresholds used for reflectivity data. Bits mask start from "SQI Threshold", take is as LSB.
33	Velocity Mask	INT	N/A		Thresholds used for velocity data. Bits mask start from "SQI Threshold", take is as LSB.
34	Spectrum Width Mask	INT	N/A		Thresholds used for reflectivity data. Bits mask start from "SQI Threshold", take is as LSB.
35	ZDR Mask	INT	N/A		Thresholds used for ZDR data. Bits mask start from "SQI Threshold", take is as LSB.
36	Mask Reserved	12 Bytes	N/A	N/A	Reserved for mask
37	Scan Sync	INT	N/A	N/A	Reserved
38	Direction	INT	N/A	1,2	Antenna rotate direction, 1= clockwise, 2=counter clockwise
39	Ground Clutter Classifier Type	SHORT	N/A		1 - All data is passed 2 - No data is passed 3 - Use Real Time GC

					Classifier 4 – use bypass map
40	Ground Clutter Filter Type	SHORT	N/A		0- none 1 -Adaptive FFT 4 - IIR
41	Ground Clutter Filter Notch Width	SHORT	m/s	0.1-10	Scaled by 10
42	Ground Clutter Filter Window	SHORT	N/A		-1-none 0 - rect 1- Hamming 2- Blackman 3- Adaptive
43	Spare	72 Bytes	N/A	N/A	

**Table 2-7 Moments Type/Bit Mask Definition** 

BIT	MOMENT	REMARKS
1(LSB)	dBT	Total Reflectivity, without clutter removed
2	dBZ	Reflectivity after clutter removed
3	V	Mean Radial Velocity
4	W	Spectrum Width
5	SQI	Signal Quality Index
6	CPA	Clutter Phase Alignment
7	ZDR	Differential Reflectivity
8	LDR	Liner Differential Ratio9
9	CC	Cross Correlation Coefficient
10	ФDР	Differential Phase
11	KDP	Specific Differential Phase
12	СР	Clutter Probability
13	FLAG	Flag of RVP data
14	HCL	Hydro Class
15	CF	Clutter Flag
16	Zc	Reflectivity Corrected
17	Vc	Mean Radial Velocity Corrected
18	Wc	Spectrum Width Corrected
19~63	Spare	

# **Table 2-8 Filters Bit Mask Definition**

BIT	FILTER	REMARKS			
0(LSB)	Interference Filter	Pulse interference filter Algorithm			
1	Censor Filter	WSR-88D Censor filter			
2	1D Surveillance Speckle	1 dimension (along radial) speckle filter			
		algorithm for reflectivity			
3	1D Doppler Speckle	1 dimension (along radial) speckle filter			
		algorithm for Doppler data			
4	2D Surveillance Speckle	2 dimension (3*3 Azimuth and Radial) speckle			
		filter algorithm for reflectivity			

5	2D Doppler Speckle	2 dimension (3*3 Azimuth and Radial) speckle
		filter algorithm for Doppler data
6~31	Spare	

# **CHAPTER 3 Base Data Radial Data**

### 3.1 Basedata Radial Header Block

Table 3-1 Basedata Radial Header Block

	Table 3-1 Basedata Radial Header Block					
NO	FIELD	TYPE	UNIT	RANGE	REMARKS	
	NAME	/BYTES				
01	Radial State	INT	N/A	0 to 6	0= Cut Start 1=Intermediate Data 2=Cut End 3=Volume Start 4=Volume End	
02	Spot Blank	INT	N/A	0 to 1	0=Normal 1=Spot Blank	
03	Sequence Number	INT	N/A	1to 65536	Sequence Number	
04	Radial Number	INT	N/A	1 to 400	Radial Number for each cut	
05	Elevation Number	INT	N/A	1 to 50	Elevation Number	
06	Azimuth	FLOAT	degree	0 to 360	Azimuth Angle	
07	Elevation	FLOAT	degree	-10 to 90	Elevation Angle	
08	Seconds	INT	second	N/A	Radial data time in second	
09	microseconds	INT	Microsecond	N/A	Radial data time in microsecond (expect seconds)	
10	Length of data	INT	bytes	1-	Length of data in this radial, this header is excluded.	
11	Moment Number	INT	N/A	1-64	Moments available in this radial	
12	Reserved	20 Bytes	N/A	N/A	Reserved	

# 3.2 Base Data Moment Header Block

Table 3-2 Basedata Moment Header Block

NO	FIELD	TYPE	UNIT	RANGE	REMARKS
	NAME	/BYTES			
01	Data Type	INT	N/A	1 to 64	Moment data type, See Table 2-7
02	Scale	INT	N/A	0.0 to	Data coding scale Code = value*scale+offset

				32768.0		
03	Offset	INT	N/A	0 to 32768	Data coding offset	
					Code = value*scale+offset	
04	Bin Length	SHORT	Bytes	1 to 2	Bytes to save each bin of data	
05	Flags	SHORT	N/A		Bit Mask of flags for data.	
					Reserved now.	
06	Length	INT	bytes		Length of data of current moment, this header is excluded.	
07	Reserved	12 Bytes				