MIPS Architecture and Assembly Language Overview

Adapted from: http://edge.mcs.dre.g.el.edu/GICL/people/sevy/architecture/MIPSRef(SPIM).html

[Register Description] [I/O Description]

Data Types and Literals

Data types:

- Instructions are all 32 bits
- byte(8 bits), halfword (2 bytes), word (4 bytes)
- a character requires 1 byte of storage
- an integer requires 1 word (4 bytes) of storage

Literals:

- numbers entered as is. e.g. 4
- characters enclosed in single quotes. e.g. 'b'
- strings enclosed in double quotes. e.g. "A string"

Registers

- 32 general-purpose registers
- register preceded by \$ in assembly language instruction

two formats for addressing:

- o using register number e.g. \$0 through \$31
- o using equivalent names e.g. \$t1, \$sp
- special registers Lo and Hi used to store result of multiplication and division
 - o not directly addressable; contents accessed with special instruction mfhi ("move from Hi") and mflo ("move from Lo")
- stack grows from high memory to low memory

This is from Figure 9.9 in the Goodman&Miller text

Register Number	Alternative Name	Description	
0	zero	the value 0	
1	\$at	(assembler temporary) reserved by the assembler	
2-3	\$v0 - \$v1	(values) from expression evaluation and function results	
4-7	\$a0 - \$a3	(arguments) First four parameters for subroutine. Not preserved across procedure calls	
8-15	\$t0 - \$t7	(temporaries) Caller saved if needed. Subroutines can use w/out saving. Not preserved across procedure calls	
16-23	\$s0 - \$s7	(saved values) - Callee saved. A subroutine using one of these must save original and restore it before exiting. Preserved across procedure calls	
24-25	\$t8 - \$t9	(temporaries) Caller saved if needed. Subroutines can use w/out saving. These are in addition to \$t0 - \$t7 above. Not preserved across procedure calls.	
26-27	\$k0 - \$k1	reserved for use by the interrupt/trap handler	
28	\$gp	global pointer. Points to the middle of the 64K block of memory in the static data segment.	
29	\$sp	stack pointer Points to last location on the stack.	
30	\$s8/\$fp	saved value / frame pointer Preserved across procedure calls	
31	\$ra	return address	

See also Britton section 1.9, Sweetman section 2.21, Larus Appendix section A.6

Program Structure

- just plain text file with data declarations, program code (name of file should end in suffix .s to be used with SPIM simulator)
- data declaration section followed by program code section

Data Declarations

10/24/12 MIPS Quick Tutorial

- placed in section of program identified with assembler directive .data
- declares variable names used in program; storage allocated in main memory (RAM)

Code

- placed in section of text identified with assembler directive .text
- contains program code (instructions)
- starting point for code e.g.ecution given label main:
- ending point of main code should use exit system call (see below under System Calls)

Comments

- anything following # on a line # This stuff would be considered a comment
- · Template for a MIPS assembly language program:

```
\ensuremath{\sharp} Comment giving name of program and description of function
# Template.s
# Bare-bones outline of MIPS assembly language program
                         # variable declarations follow this line
                         # instructions follow this line
                         # indicates start of code (first instruction to execute)
main:
# End of program, leave a blank line afterwards to make SPIM happy
```

Data Declarations

format for declarations:

```
storage type
                value(s)
```

- o create storage for variable of specified type with given name and specified value
- $\circ \quad \text{value}(s) \text{ usually gives initial value}(s); \text{ for storage type }. \text{space, gives number of spaces to be allocated} \\$

Note: labels always followed by colon (:)

```
example
var1:
                                 \ensuremath{\text{\#}} create a single integer variable with initial value 3
array1:
                 .byte
                         'a','b' # create a 2-element character array with elements initialized
                                     to a and b
                                  # allocate 40 consecutive bytes, with storage uninitialized
                 .space 40
                                      could be used as a 40-element character array, or a
                                      10-element integer array; a comment should indicate which!
```

Load / Store Instructions

- · RAM access only allowed with load and store instructions
- all other instructions use register operands

load:

```
register destination, RAM source
#copy word (4 bytes) at source RAM location to destination register.
       register destination, RAM source
#copy byte at source RAM location to low-order byte of destination register,
# and sign-e.g.tend to higher-order bytes
```

store word:

```
register_source, RAM_destination
  #store word in source register into RAM destination
sb
         register_source, RAM_destination
  #store byte (low-order) in source register into RAM destination
```

load immediate:

```
register destination, value
```

#load immediate value into destination register

```
example:
       .data
var1:
                               # declare storage for var1; initial value is 23
       .word
       .text
 _start:
               $t0, var1
                                      # load contents of RAM location into register $t0: $t0 = var1
       lw
                               # $t1 = 5 ("load immediate")
               $t1, 5
       l i
       SW
               $t1, var1
                                      # store contents of register $t1 into RAM: var1 = $t1
       done
```

Indirect and Based Addressing

• Used only with load and store instructions

load address:

```
la $t0, var1
```

• copy RAM address of var1 (presumably a label defined in the program) into register \$t0

indirect addressing:

```
lw $t2, ($t0)
```

• load word at RAM address contained in \$t0 into \$t2

```
sw $t2, ($t0)
```

• store word in register \$t2 into RAM at address contained in \$t0

based or indexed addressing:

```
lw $t2, 4($t0)
```

- load word at RAM address (\$t0+4) into register \$t2
- "4" gives offset from address in register \$t0

```
sw $t2, -12($t0)
```

- store word in register \$t2 into RAM at address (\$t0 12)
- · negative offsets are fine

Note: based addressing is especially useful for:

- · arrays; access elements as offset from base address
- · stacks; easy to access elements at offset from stack pointer or frame pointer

```
example
```

```
.data
array1:
              .space 12
                                      # declare 12 bytes of storage to hold array of 3 integers
               .text
                                              # load base address of array into register $t0
               la
.
                      $t0, arrav1
 start:
                      $t1, 5
                                      # $t1 = 5 ("load immediate")
               li
               sw $t1, ($t0)
                                      \# first array element set to 5; indirect addressing
               li $t1, 13
                                      # $t1 = 13
               sw $t1, 4($t0)
                                      # second array element set to 13
               li $t1, -7
                                         $\pm .1 = -7
               sw $t1, 8($t0)
                                      # third array element set to -7
               done
```

Arithmetic Instructions

- most use 3 operands
- all operands are registers; no RAM or indirect addressing
- operand size is word (4 bytes)

```
m111 t
        $t3,$t4
                          \# multiply 32-bit quantities in $t3 and $t4, and store 64-bit
                             result in special registers Lo and Hi: (Hi,Lo) = $t3 * $t4
                         # Lo = $t5 / $t6 (integer quotient)
# Hi = $t5 mod $t6 (remainder)
div
        $15.816
                                                                              $t0 = Hi
mfhi
        $±0
                            move quantity in special register Hi to $t0:
mflo
        $t1
                            move quantity in special register Lo to $t1:
                                                                               $t1 = Lo
                          # used to get at result of product or quotient
move
        $t2.$t3 # $t2 = $t3
```

Control Structures

Branches

• comparison for conditional branches is built into instruction

```
h
                          unconditional branch to program label target
        target
bea
        $t0,$t1,target # branch to target if $t0 = $t1
blt
        $t0,$t1,target # branch to target if $t0 < $t1
ble
        $t0,$t1,target # branch to target if
                                               $t.0 <= $t.1
bgt
        $t0,$t1,target # branch to target if $t0 > $t1
bge
        $t0,$t1,target # branch to target if <math>$t0 >= $t1
bne
        $t0,$t1,target # branch to target if $t0 <> $t1
```

<u>Jumps</u>

```
j target # unconditional jump to program label target jr $$t3$ # jump to address contained in $t3 ("jump register")
```

Subroutine Calls

subroutine call: "jump and link" instruction

```
jal sub label # "jump and link"
```

- copy program counter (return address) to register \$ra (return address register)
- jump to program statement at sub_label

subroutine return: "jump register" instruction

```
jr $ra # "jump register"
```

• jump to return address in \$ra (stored by jal instruction)

Note: return address stored in register \$ra; if subroutine will call other subroutines, or is recursive, return address should be copied from \$ra onto stack to preserve it, since jal always places return address in this register and hence will overwrite previous value

System Calls and I/O (SPIM Simulator)

- used to read or print values or strings from input/output window, and indicate program end
- use syscall operating system routine call
- first supply appropriate values in registers \$v0 and \$a0-\$a1
- result value (if any) returned in register \$v0

The following table lists the possible syscall services.

Service	Code in \$v0	Arguments	Results
print_int	1	\$a0 = integer to be printed	
print_float	2	\$f12 = float to be printed	
print_double	3	\$f12 = double to be printed	
print_string	4	\$a0 = address of string in memory	
read_int	5		integer returned in \$v0
read_float	6		float returned in \$v0
read_double	7		double returned in \$v0
read_string	8	\$a0 = memory address of string input buffer \$a1 = length of string buffer (n)	
sbrk	9	\$a0 = amount	address in \$v0
exit	10		

- o The print_string service expects the address to start a null-terminated character string. The directive .asciiz creates a null-terminated character string.
- · The read_int, read_float and read_double services read an entire line of input up to and including the newline character.
- o The read_string service has the same semantices as the UNIX library routine fgets.

10/24/12 MIPS Quick Tutorial

- It reads up to n-1 characters into a buffer and terminates the string with a null character.
- If fewer than n-1 characters are in the current line, it reads up to and including the newline and terminates the string with a null character.
- The sbrk service returns the address to a block of memory containing n additional bytes. This would be used for dynamic memory allocation.
- o The exit service stops a program from running.

```
Print out integer value contained in register $t2
                       $v0, 1
                                                # load appropriate system call code into register $v0;
                                                \# code for printing integer is 1
                move
                      $a0, $t2
                                                \# move integer to be printed into a0: a0 = t2
                syscall
                                                \ensuremath{\text{\#}} call operating system to perform operation
     Read integer value, store in RAM location with label int value (presumably declared in data section)
e.g.
                                                # load appropriate system call code into register $v0;
                                                # code for reading integer is 5
                syscall
                                                # call operating system to perform operation
                       $v0, int value
                                                # value read from keyboard returned in register $v0;
                                                # store this in desired location
     Print out string (useful for prompts)
                .data
                .asciiz "Print this.\n"
                                                # declaration for string variable,
string1
                                                \# .asciiz directive makes string null terminated
                .text
                        $v0, 4
                                                # load appropriate system call code into register $v0;
main:
               li
                                                # code for printing string is 4
                la $a0, string1
                                                \# load address of string to be printed into a0
                syscall
                                                \# call operating system to perform print operation
\underline{e.g.} To indicate end of program, use \underline{exit} system call; thus last lines of program should be:
                li $v0, 10 # system call code for exit = 10
                syscall
                                                # call operating sys
```