


Construction Manual



Welcome to the FABI

Construction Manual

This manual covers detailed step-by-step instructions for building the FABI alternative input system.

As additional tools you will need:

- a soldering iron with a fine tip
- sharp side-cutting pliers
- a slotted screwdriver
- optionally a PCB holder

The required materials are:

- tin-solder (small diameter)
- adhesive tape (Scotch tape)

Legend





Solder / do not solder





Clip / do not clip with pliers





Fix / do not fix with tape



Attention: orientation of this part is important!




This part is done in this step



Part number for this step (see part overview on page 3)

Part Overview - Electronic Parts



Part Overview - Case Parts



Bild: Case top








Bild: Case bot
































































































































































Copyright 2021, AsTeRICS Foundation, CC-BY-SA 3.0 office@asterics-foundation.org

Acknowledgements:

Futura fonts by www.onlinewebfonts.com (CC BY 3.0) Exclamation mark icon made by Pixel Buddha from www.flaticon.com Illustrations based on work of Moritz Schwarzl (moritz.schwarzl@gmx.at) and Fritzing parts.