
Switch Bounce & Catch the Clown Game Embedded System Design, Lab 6


Ben Lorenzetti

November 5, 2015

Contents

1	Objectives and Problem Description	2
	1.1 Part 1: Does the Switch Bounce?	2
	1.2 Part 2: Catch the Clown!	2
2	Procedure	2
	2.1 Switch Bounce Background	
	2.2 Part 1: Debouncing SW1	3
	2.3 Part 2: Catch the Clown Game	3
3	Expected Results	3
	3.1 Debounce Time	3
4	Experiment and Design Revisions	3
	4.1 Command Line Assembly	3
	4.2 PORTB Input	
	4.3 Adjusting Debounce Time	
5	Observations	6
	5.1 44-Pin Demo Board SW1 Bouncing Time	6
6	Discussion	6
7	Implementation Code	7
	7.1 Does the Switch Bounce?	7
	7.2 Catch the Clown!	





(a) PIC16F887 Demo Board Schematic: pushbutton SW1 is unfiltered and requires software debouncing.

(b) A Hardware Debounced Pushbutton: R_3 and C form a low pass filter.

Figure 1: Hardware vs Software Debouncing for Mechanical Switches

1 Objectives and Problem Description

1.1 Part 1: Does the Switch Bounce?

1.2 Part 2: Catch the Clown!

Build a game for testing reaction times with an 8 LED rotating display, a pushbutton trigger, and a knob for adjusting the speed/difficulty. If the player presses the trigger in sync with the LED display, then the display stops rotating to indicate victory. The specifications can be summarized in the four points below:

- 1. For an 8 LED display, one LED should be illuminated at a time and the illuminated position should rotate right one digit every period.
- 2. The period should be adjustable on the fly with the rotatry potentiometer knob.
- 3. If the user triggers the switch while the topmost (most significant bit) LED is illuminated, then the LED display should stop rotating until the switch is released. The LED rotation loop should also continue—including through the topmost state—if the switch is active but was triggered during the wrong state.
- 4. The pushbutton switch should be debounced based on the results from part 1.

2 Procedure

2.1 Switch Bounce Background

Mechanical switches do not always produce clean, step function electrical signals. Instead, when a switch is thrown, the electric signal often 'bounces' several times before settling at the active level. This is caused by electric arcing and breaking as the contacts near one other and from mechanical vibrations of contacts from the throwing force.

Bouncing can cause problems if the device's function depends on the number of times a switch is thrown. For example, if you keyboard bounced, you would find yourself typing repeat letters and unpredictable backspacing. Traditionally switches were 'debounced' with low pass filters in hardware, but with fast microcontrollers debouncing can be done in software to reduce hardware costs. Figure 1 shows how PIC did this with their PIC16F887 44-pin demo board.

- 2.2 Part 1: Debouncing SW1
- 2.3 Part 2: Catch the Clown Game

3 Expected Results

3.1 Debounce Time

From Professor Vemuri's lecture, figure 3 shows the timescale at which some random switch bounces. Based on this plot, the expected bouncing time of SW1 was on the order of $500 \,\mu s$.

4 Experiment and Design Revisions

4.1 Command Line Assembly

My .asm source files were assembled on the command line so please do this if they don't compile nicely in the IDE. On Ubuntu, with the default MPLAB installation location, from the directory containting catch-the-clown.asm, the commands are:

```
$ cp /opt/microchip/mplabx/v3.10/mpasmx/p16f887.inc ./p16f887.inc
```

- \$ /opt/microchip/mplabx/v3.10/mpasmx/mpasmx -p16f887 catch-the-clown.asm
- \$ more catch-the-clown.ERR

4.2 PORTB Input

On the 44-pin demo board, the pushbutton is connected to RBO on PORTB, in an active low configuration with a $1k\Omega$, $10k\Omega$ voltage divider, as shown in figure 1.

When I first wrote my implementation for part 1 of the lab, I could not get the μ Controller to respond to pressing the pushbutton switch (SW1). After inspecting the hardware with a ohmmeter, I knew the problem had to be in software. I created a knew 'hello world' program for debugging the pushbutton switch.

It turns out the bug was a configuration problem: RBO is connected to one of the 16 analog inputs, AD12. By default, the pin configured use with the ADC and the digital input amplifiers are turned off. Here is a nugget that was buried on page 49 of the PIC16F887 datasheet:

Note: The ANSELH register must be initialized to configure an analog channel as a digital input. Pins configured as analog inputs will read '0'.

Figure 4: Port B Configuration Note

With this nugget, the working 'pushbutton hello world' program was:




Figure 2: Implementation of rising_edge Monitor_SW1() Function




Figure 3: A Bouncing Input Signal from a Switch

```
Initialize_Data_and_IO
        CLRF
                PORTB
        CLRF
                PORTD
        BSF
                STATUS, RP0
                                 ; Switch from Bank 0 to Bank 1
        BSF
                PORTB, RB0
                                   configure RBO as input
                PORTD, RD0
        BCF
                                   configure RD0 as output
                STATUS, RP1
                                   Switch from Bank 1 to Bank 3
        BSF
        BCF
                ANSELH, ANS12
                                  by default RBO/AN12 is configured as analog
                                     input. Set to '0' to enable digital input
        BANKSEL 0x00
                                   Switch to Bank 0
Main_Loop
       MOVF
                PORTB, W
                                  copy pushbutton input into W
        XORLW
                1 \ll RB0
                                   invert active-low pushbutton for active-high
                                     output
       MOVWF
                PORTD
                                  update LED display
        GOTO
                Main_Loop
        END
```

4.3 Adjusting Debounce Time

The results from part 1 of the lab are presented in hyperref[part-1-results-section] section 5.1. From these results, the DEBOUNCE_TIME for the part 2 implementation was adjusted to XXX to require a steady state, debouncing period of

$$T = X * 14 \mu s = XXX$$

before a switch activation is accepted by the program.

- 5 Observations
- 5.1 44–Pin Demo Board SW1 Bouncing Time
- 6 Discussion

7 Implementation Code

7.1 Does the Switch Bounce?

```
; debounce-time.asm
; Ben Lorenzetti
; Embedded Systems Design, Fall 2015
#include <p16f887.inc>
                        _CONFIG1, _LVP_OFF & _FCMEN_OFF & _IESO_OFF & _BOR_OFF
        __CONFIG
            & _CPD_OFF & _CP_OFF & _MCLRE_OFF & _PWRTE_ON & _WDT_OFF &
           _INTRC_OSC_NOCLKOUT
        __CONFIG
                        _CONFIG2, _WRT_OFF & _BOR21V
#define DEBOUNCE_TIME
                                ; software debounce sampling period is
                        . 1
                                : T = DEBOUNCE\_TIME * 14 microseconds
#define rising_edge_counter
                                PORTD
#define timeout_counter
                                0x20
#define ss_counter
                                0x21
                                         ; steady state counter for debouncing
Reset_Vector
        ORG
                0
        GOTO
                Main
                 -- uint8_t rising_edge Monitor_SW1 () ---
Monitor_SW1_Function
                                ; static uint8_t ss_counter;
        CLRF
                timeout_counter; uint8_t timeout_counter = 256;
Debounce\_Loop

    Monitor Pushbutton Input —

        BTFSC
                PORTB, RB0
                               ; if (switch == 1)
        MOVLW
                DEBOUNCE_TIME
                                     ss\_counter = DEBOUNCE\_TIME;
        BTFSS
                PORTB, RB0
                                ; if (!switch) // SW1 is active low
                ss_counter, W ;
        DECF
                                    ss_counter --;
        MOVWF
                ss_counter
                --- Check for Timeout ----
                                    ; debounce_counter --;
        DECF
                timeout_counter, F
        BTFSC
                STATUS, Z
                                       ; if (!debounce_counter)
        REILW
                                             return 0;
                  - Check if SW1 has been steady for debounce time -----;
        ANDLW
                0xFF
                                ; Z = !ss\_counter;
                                ; if (Z)
        BTFSC
                STATUS, Z
        REILW
                1
                                     return 1;
                                ; else
        GOTO
                Debounce_Loop
                                     continue;
Main
Initialize_Variables
                rising_edge_counter
        CLRF
        CLRF
                timeout_counter
        MOVLW
                DEBOUNCE_TIME
       MOVWF
                ss_counter
```

$Configure_IO$

BSF STATUS, RPO ; switch from bank 0 to bank 1 CLRF TRISD ; configure PORTD for 8-LEDs output

BSF TRISB, RBO ; configure PORTB Pin 0 for pushbutton input BANKSEL ANSELH ; by default, RBO/AN12 is configured as analog

BCF ANSELH, ANS12; input. Reconfigure to digital.

BANKSEL 0x00 ; return to bank 0

$For ever_Loop$

CALL Monitor_SW1_Function ADDWF rising_edge_counter

GOTO Forever_Loop

END

7.2 Catch the Clown!

Initialize_IO

```
; catch-the-clown.asm
; Ben Lorenzetti
; Embedded Systems Design, Fall 2015
\#include <p16f887.inc>
        __CONFIG
                        _CONFIG1, _LVP_OFF & _FCMEN_OFF & _IESO_OFF & _BOR_OFF
            & _CPD_OFF & _CP_OFF & _MCLRE_OFF & _PWRTE_ON & _WDT_OFF &
           _INTRC_OSC_NOCLKOUT
                       _CONFIG2, _WRT_OFF & _BOR21V
        __CONFIG
#define OUTER_MIN_PERIOD
                                . 4
#define MIDDLE_SCALAR
#define DEBOUNCE_TIME
                        . 8
#define CLOWN_STATE
                        1 << 7
#define OSC8_CHANNELO_NOGO_ADON 0x41
#define LEFTJUSTIFY_VSS_VDD
                                0 x 0 0
#define led_state
                       PORTD
#define period
                       0x20
#define outer_counter
                       0x21
#define middle_counter 0x22
#define timeout_counter 0x23; timeout counter local to Monitor_SW1 ()
#define ss_counter
                       0x24
                               ; static, steady state time counter
Reset_Vector
       ORG
                0
        COTO
                Main
                  - uint8_t rising_edge Monitor_SW1 () -----
Monitor_SW1_Function
                                ; static uint8_t ss_counter;
                timeout_counter; uint8_t timeout_counter = 256;
        CLRF
Debounce_Loop
                 -- Monitor Pushbutton Input --
        BTFSC
                           ; if (switch == 1)
               PORTB, RB0
                               ; ss\_counter = DEBOUNCE\_TIME;
               DEBOUNCE_TIME
       MOVLW
                                ; if (!switch) // SW1 is active low
        BTFSS
               PORTB, RB0
        DECF
                ss_counter, W
                                ; ss\_counter --;
       MOVWF
                ss\_counter
                --- Check for Timeout --
                                   ; debounce_counter --;
        DECF
                timeout_counter, F
        BTFSC
                STATUS, Z
                                       ; if (!debounce_counter)
        REILW
                                             return false;
                --- Check if SW1 has been steady for debounce time ----;
                               ; Z = !ss\_counter;
        ANDLW
                0xFF
        BTFSC
                STATUS, Z
                               ; if (!ss_counter)
        REILW
                0xFF
                                     return true;
                                ; else
        GOTO
                Debounce_Loop ;
                                     continue;
Main
```

```
BSF
                STATUS, RP0
                                ; switch from Bank 0 to Bank 1
                                ; configure port D to output for LEDs
       CLRF
                TRISD
       BSF
                TRISB, RB0
                                ; configure pushbutton on RBO for input
                                ; configure potentionmeter on RAO for input
       BSF
                TRISA, RA0
       BANKSEL ANSEL
                                ; go to bank 3
       BSF
               ANSEL, 0
       BANKSEL ANSELH
                                ; by default, RB0/AN12 is configured as analog
                ANSELH, ANS12
       BCF
                                    input. Reconfigure to digital.
       BANKSEL 0x00
                                ; return to Bank 0
Initialize_Analog_to_Digital_Converter
       BANKSEL ADCON1
               LEFTJUSTIFY_VSS_VDD
       MOVLW
       MOVWF
                                ; left justify result,
                ; use VSS and VDD for Vref- and Vref+
       BANKSEL ADCONO
               OSC8_CHANNEL0_NOGO_ADON
       MOVLW
       MOVWF
                                ; ADC clock rate = Fosc/8,
               ADCON0
                ; ADC input channel = 0, ADC on
ADC_Acquisition_Time
       CLRF
                outer_counter
       CLRF
                middle_counter
One_Off_Delay_Loop
       DECFSZ
               middle_counter, F
       GOTO
                One_Off_Delay_Loop
       DECFSZ
                outer_counter, F
       GOTO
                One_Off_Delay_Loop
Initialize_State_Machine
       MOVLW
                CLOWN_STATE
       MOVWF
                led_state
       MOVLW
               DEBOUNCE_TIME
       MOVWF
                ss_counter
State_Machine_Loop
Measure\_Potentiometer
       BSF
                ADCON0, GO
                                ; start convertion
       BTFSC
                ADCON0, GO
                                ; is converstion done?
       GOTO
                \$-1
                                ; go back to is conversion done?
Set_Period
                                ; swap upper nibble of ADC result
                                ; into lower 4 bits of W
       SWAPF
                ADRESH, W
                                ; keep only the lower 4 bits
       ANDLW
                0x0F
                OUTER_MIN_PERIOD;
       ADDLW
                period ; period = (ADC_result >> 4) + MIN_PERIOD
       MOVWF
; for (outer_counter=OUTER_SCALAR; !outer_counter; outer_counter--)
Open_Outer_Loop
       MOVF
                period, W
       MOVWF
                                ; outer_counter = OUTER_SCALAR
                outer_counter
Outer_Loop
; for (middle_counter=MIDDLE_SCALAR; !middle_counter; middle_counter--)
```

```
Open_Middle_Loop
       MOVLW
               MIDDLE_SCALAR
       MOVWF
               middle_counter ; middle_counter = MIDDLE_SCALAR
Middle_Loop
Monitor\_SW1
               Monitor_SW1_Function
       CALL
Clown_Caught_Logic
                              ; Z = !return_value
       ADDLW
       BTFSC
               STATUS, Z
                           ; if (!return_value) // timeout occured
               Close_Middle_Loop; continue;
       GOTO
       MOVF
               led_state, W
       SUBLW
               CLOWN_STATE
                              ; Z = if (led_state = CLOWN_STATE)
       BTFSC
               STATUS, Z
                              ; if (Z)
       GOTO
               Initialize_State_Machine; // you win!
Close_Middle_Loop
       DECFSZ middle_counter, F
       GOTO
               Middle_Loop
Close_Outer_Loop
       DECFSZ outer_counter, F
       GOTO
               Outer_Loop
Next_State_Transition
       BCF
               STATUS, C
       RRF
               led_state , F ; led_state = state >> 1;
               STATUS, C ; if (state)
       BTFSS
       GOTO
               State_Machine_Loop; continue; // continue forever loop
                               ; else {
                                   led_state = 128;
       RRF
               led_state, F
       GOTO
               State_Machine_Loop
                               ; continue; // continue forever loop
```

END