Tricycle Lights Embedded System Design, Lab 6

Ben Lorenzetti

October 29, 2015

Contents

1 Objectives and Problem Description			
	1.1 Tricycle Lights	2	
2	2 Procedure		
	2.1 Potentiometer and LEDs on the 44–Pin Demo Board	2	
	2.2 PIC16F887 Analog to Digital Converter (ADC)	3	
	2.3 PIC16F887 Clock Sources	3	
	2.4 Implementation Flowchart	3	
	2.5 Delay Function	3	
	2.6 Linear Mapping	3	
3	Expected Results		
4	Experiment and Design Revisions		
	4.1 Command Line Assembly	3	
5	Observations		
6	Discussion		
7	Tricycle Lights Implementation Code		




Figure 1: I/O Circuit Diagrams from the 44-Pin Demo Board User's Manual

1 Objectives and Problem Description

1.1 Tricycle Lights

Blink two LEDs, representing left and right turn signals, depending on the position of a rotary potentiometer, which represents a steering wheel. The following conditions should be met.

- 1. Use the potentiometer and LEDs on the 44-Pin Demo Board.
- 2. Use the LED connected to RD7 for the left turn signal, and RD0 for right.
- 3. When wheel is in neutral position (wiper in middle of pot.), both turn indicator lights should be off.
- 4. When turned counterclockwise or clockwise from neutral position, the left or right LEDs should blink at a rate proportional to the angular displacement from neutral position.

2 Procedure

2.1 Potentiometer and LEDs on the 44-Pin Demo Board

In this lab, we will need to measure a potentiometer input (the steering wheel) and blink two LEDs for output. The 44-pin demo board for the PIC16F887 has all of this hardware on board. The potentiometer and LEDs are connected to pins as shown in the circuit diagram in figure 1.

According to the specifications, the LED at RD7 should be the left blinker and the LED at RD0 should be the right blinker.

- 2.2 PIC16F887 Analog to Digital Converter (ADC)
- 2.3 PIC16F887 Clock Sources
- 2.4 Implementation Flowchart
- 2.5 Delay Function
- 2.6 Linear Mapping
- 3 Expected Results

4 Experiment and Design Revisions

4.1 Command Line Assembly

My .asm source files were assembled on the command line so please do this if they don't compile nicely in the IDE. On Ubuntu, with the default MPLAB installation location, from the directory containting lfsr.asm, the commands are:

- \$ cp /opt/microchip/mplabx/v3.10/mpasmx/p16f887.inc ./p16f887.inc
- \$ /opt/microchip/mplabx/v3.10/mpasmx/mpasmx -p16f887 lfsr.asm
- \$ more lfsr.ERR

5 Observations

Figures/tricycle-lights-demo.jpg

Figure 2: Demonstration of Tricycle Turn Lights

6 Discussion

7 Tricycle Lights Implementation Code

```
; tricycle-lights.asm
; Ben Lorenzetti
; Embedded Systems Design, Fall 2015
#include <p16f887.inc>
                        _CONFIG1. _LVP_OFF & _FCMEN_OFF & _IESO_OFF & _BOR_OFF
        __CONFIG
            & _CPD_OFF & _CP_OFF & _MCLRE_OFF & _PWRTE_ON & _WDT_OFF &
           _INTRC_OSC_NOCLKOUT
        __CONFIG
                        _CONFIG2, _WRT_OFF & _BOR21V
#define NEUTRALPOS
                                0x80
#define INNER_DELAY_TIME
                                0x8F
#define MIDDLE_DELAY_TIME
                                0x0F
#define MINIMUM_HALF_PERIOD
                                0x06
#define OSC8_CHANNELO_NOGO_ADON B'01000001'
#define LEFTJUSTIFY_VSS_VDD
                                B'00000000'
#define RESOLUTION_MASK
                                B'11111100'
               -----Organize Program Memory-----
Reset_Vector
        ORG 0
        GOTO Initialize
Interupt_Vector
       ORG .4
                    -Allocate Static Variables-----
        cblock 0x20
        adc_result
        turn_signal
        delay_time
        outer_delay_counter
        middle_delay_counter
        inner_delay_counter
        endc
        ---Pause (INNER_DELAY * MIDDLE_DELAY * delay_time)-----;
Delay_Function
       MOVF
                delay_time, W
                                        ; copy delay_time to
       MOVWF
                outer_delay_counter
                                            outer_delay_counter
       MOVLW
                INNER_DELAY_TIME
                                        : initialize
       MOVWF
                inner_delay_counter
                                            inner_delay_counter
       MOVLW
                MIDDLE_DELAY_TIME
                                        ; initialize
       MOVWF
                middle_delay_counter
                                        ; middle_delay_counter
Inner_Loop
        DECFSZ
                inner_delay_counter, f
                Inner_Loop
        GOTO
                INNER_DELAY_TIME
       MOVLW
       MOVWF
                inner_delay_counter
Middle_Loop
       DECFSZ
                middle_delay_counter, f
                Inner_Loop
        GOTO
```

```
MOVLW
               MIDDLE_DELAY_TIME
       MOVWF
               middle_delay_counter
Outer_Loop
       DECFSZ
               outer_delay_counter, f
       GOTO
               Inner_Loop
       RETURN
             ----Initialize Data Memory-----
Initialize
                  --- Initialize I/O -----
       BANKSEL TRISD
                             ; select Register Bank 1
                           ; set all LED pins to output
       CLRF
              TRISD
                             ; back to Register Bank 0
       BANKSEL PORTD
       CLRF
              PORTD
                             ; set all LED pins to low
       BANKSEL TRISA
               TRISA ; clear TRISA 
TRISA, RAO ; set port A pin 0 to input
       CLRF
       BSF
               ----- Initialize ADC-
       BANKSEL ADCON1
       MOVLW
               LEFTJUSTIFY_VSS_VDD
       MOVWF
               ADCON1 ; left justify result,
               ; use VSS and VDD for Vref- and Vref+
       BANKSEL ADCON0
              OSC8_CHANNEL0_NOGO_ADON
       MOVLW
       MOVWF
               ADCONO; ADC clock rate = Fosc/8,
               ; ADC input channel = 0, ADC on
       MOVLW
       MOVWF
               delay_time ; initialize delay_time
       CALL
               Delay_Function; Pause to allow ADC to settle
            ----Begin Main Program Loop-----
Main
                  - Measure Potentiostat Input ----
       BANKSEL ADCON0
                          ; start convertion
               ADCONO, GO
       BSF
       BTFSC
               ADCONO, GO
                             ; is converstion done?
       COTO
               \$-1
                              ; go back to BTFSC instruction
       BANKSEL ADRESH
       MOVFW
              ADRESH
                             ; store ADC result in W
                             ; go back to bank 0
       BANKSEL PORTA
              -- Calculate Angular Displacement from Neutral -----;
               RESOLUTION_MASK; reduce number of steps by
       MOVLW
       ANDWF
               ADRESH, 1
                             ; truncating lower bits in ADRESH
       MOVLW
               NEUTRAL POS
               ADRESH, 1
                              ; compute displacement from Neutral
       SUBWF
       ; Z = 1 if ADRESH == NEUTRALPOS; C = 1 if ADRESH >= NEUTRALPOS
               -----;
       BTFSC
               STATUS. Z
                             ; test zero flag, skip next if clear
       GOTO
               Main
                              ; if (ADRESH == NEUTRAL_POS)
       BTFSS
               STATUS, C
                             ; if (ADRESH < NEUTRAL_POS), invert
               ADRESH, F
                                  angular displacement
       COMF
                             ; assume left turn (ADRESH < NEUTRAL)
       MOVLW
               1 << RD7
                             ; if actually (ADRESH > NEUTRAL POS),
       BTFSC
               STATUS, C
               1 \ll RD0
                             ; then fix it to be right (RD0)
       MOVLW
```

	Blink LEDs
MOVWF	PORTD ; turn on LED
MOVLW	MINIMUM_HALF_PERIOD
MOVWF	delay_time ; keep LED on for fixed delay time
CALL	Delay_Function ;
CLRF	PORTD ; turn off LEDs
MOVF	ADRESH, W ; compute appropriate delay time
SUBLW	NEUTRAL_POS + MINIMUM_HALF_PERIOD
MOVWF	delay_time ; (from angular displacement value)
CALL	Delay_Function ; delay
;	End of Main Function Loop;
GOTO	Main
;	;
END	