

Discussion Section 1

Sean Huang

January 22, 2021

About Me

- 4th-year graduate student
 - Advised by Prof. Bora Nikolic
- Working in the Berkeley Wireless Research Center (BWRC)
- Researching a framework for designing and generating PLLs for all purposes



About This Discussion Section

- Quick review of relevant points from each week
- Some example problems about those topics from lecture and homework

About This Discussion Section




- Quick review of relevant points from each week
- Some example problems about those topics from lecture and homework
 - We'll be doing these together!

Last-Minute Logistics

- Email me at sehuang@berkeley.edu
- Office Hours Fridays 2PM–3PM (14:00–15:00), Zoom link to be posted on the website
 - If this time doesn't work, let me know through email and we can try to set up another time

Process and Frequency Scaling

- Transistors getting smaller, faster, cheaper



Process and Frequency Scaling





IBM 1401 (1959)



Process and Frequency Scaling



Process and Frequency Scaling





Process and Frequency Scaling




Process and Frequency Scaling

Each card ≈ a 7400 chip






8 transistors per card!



Process and Frequency Scaling

Each card \approx a 7400 chip



Process and Frequency Scaling


- Dennard Scaling
 - Reducing dimensions and supply voltage yields performance improvements
 - Decreases gate capacitance (increased speed, lower power)
 - Constant power density (more devices, less power per device)

Process and Frequency Scaling

- Dennard Scaling
 - Reducing dimensions and supply voltage yields performance improvements
 - Decreases gate capacitance (increased speed, lower power)
 - Constant power density (more devices, less power per device)
- Frequency Scaling
 - Keep supply voltage constant, decrease size
 - Speed increases quadratically! 😊
 - Power increases cubically! 😞
- “Power wall” at 3–4GHz
 - Same old tradeoff not worth it anymore


Process and Frequency Scaling

- Moore's Law
 - Still trying to cram more transistors on the same package (chiplets)
 - More transistors = more functionality?



Process and Frequency Scaling


- Moore's Law
 - Still trying to cram more transistors on the same package (chiplets)
 - More transistors = more functionality?
- Frequency Scaling
 - Actually dead
 - Worked up to the power wall, no clear way to get past this
 - Most modern processor clock speeds pretty much constant across generations



	Core i7-7820X	Core i7-8700K	Core i9-9900K	Core i7-9700K
Release Date	June 2017	October 2017	October 2018	
Cores / Threads	8/16	6/12	8/16	8/8
Base Frequency	3.6 GHz	3.5 GHz	3.6 GHz	3.6 GHz
Max Boost Frequency	4.3 GHz	4.7 GHz	5.0 GHz	4.9 GHz
L2 Cache	8 MB	1.5 MB	2 MB	2 MB
L3 Cache	11 MB	12 MB	16 MB	12 MB
Memory Config	Quad-Channel	Dual-Channel		
Max Mem Support	DDR4-2666			
TDP	140 W	95 W		
MSRP	\$600	\$360	\$500	\$374

The Pareto Optimal Frontier


- Tradeoffs
 - Power vs. Performance
 - Cost vs. (Pretty much everything)
 - Time-to-market vs. Performance
- Every engineering project is balancing compromises
 - How much should we sacrifice to meet specifications?
- Pareto optimal frontier
 - Best possible outcome of tradeoff space



Digital Logic Design


Combinational Logic

- Output only depends on current input
 - “Memoryless”
- Truth Table
 - List all possible inputs
 - Define output behavior for each




A	B	Out
0	0	0
0	1	0
1	0	0
1	1	1

Proof By Truth Table




C	B	A	$A \oplus B$	$(A \oplus B) \cdot C$	Out
0	0	0	0	0	1
0	0	1	1	0	1
0	1	0	1	0	1
0	1	1	1	0	1
1	0	0	0	0	1
1	0	1	1	1	0
1	1	0	1	1	0
1	1	1	1	1	0



C	B	A	$A \oplus B$	$!(A \oplus B)$	$!C$	Out
0	0	0	0	1	1	1
0	0	1	1	0	1	1
0	1	0	1	0	1	1
0	1	1	1	0	1	1
1	0	0	0	1	0	1
1	0	1	1	0	0	0
1	1	0	1	0	0	0
1	1	1	1	0	0	0

Sequential Logic


- What if we need memory?
- Registers (flip-flops) store information
 - Output updates to equal input depending on load signal
 - This is not instant
 - Output is held steady until next load edge
- Clock (clk) signal is typically used for synchronizing registers




Register Transfer Level (RTL)

Not to be confused with Resistor-Transistor Logic

- All digital designs can be abstracted as RTL
 - Mix of combinational and sequential logic blocks



- There are limitations for synchronous designs
 - No combinational loops




- HDL Languages (Verilog, VHDL)
 - Use this abstraction to describe systems
 - Follow similar division of designs
 - Combinational section
 - Sequential section

ASIC vs. FPGA

ASIC vs. FPGA

Application-Specific Integrated Circuit (ASIC)



- Customizable layout
- Control over entire chip layout (at design)
- Optimized for few applications

Field-Programmable Gate Array (FPGA)



- Array of pre-placed general logic blocks
 - Look-up tables, Registers, Multiplexer, Memory, DSP accelerators, Combinational Logic, Interconnect
- Can be reprogrammed on the fly to implement hardware even after manufacture

ASIC vs. FPGA

ASIC

- **Area-efficient**
 - Only place what you need
- **Inflexibility**
 - Can only configure as far as designed to
 - Usually only a few applications
- **Design turnaround time in months/years**
- **High Fixed Cost (NRE)**
 - Design and Verification
 - Only have 1 shot to get the chip right
 - Many hours of engineering work to create each iteration
- **Low Manufacturing Cost**
 - Once design verified, can mass produce ASICs at very low cost
 - Area optimized for application, so higher yield
- **Need to sell a lot of chips to offset NRE cost!**

FPGA

- **Generality**
 - Some logic blocks won't be used for every application
- **Flexibility**
 - Can change hardware connections on the fly
 - Many potential applications
- **Design turnaround time in minutes/hours**
- **Low Fixed Cost (NRE)**
 - Just need to program some existing FPGAs
 - Low risk as redesign is quick
- **Moderate Manufacturing Cost**
 - Need to source FPGAs from a third party
 - Need more area for generality, more cost per die
 - Less tolerance for manufacturing defects because of larger die
- **Good for low volume production or need for flexible implementation**

Simulation


- RTL Simulation
 - Quick verification of logical function
 - Used more in early stages of design to verify idea works
 - Ideal behavioral models
- Gate-level Simulation
 - More “real” effects taken into account (e.g. timing)
 - Used in later design stages to verify actual chip still works
 - Models each gate with library of parameters
- Circuit Level Simulation (SPICE, Spectre)
 - Lowest level simulation, taking everything possible into account

Simulation

Simulation is your friend!

(But also your worst enemy)

- SPICE is a tool, not an oracle
- Sometimes (rarely) the simulation is wrong!
 - Incorrect setup
 - Bad model
- Have an idea for what to expect
 - Do hand calcs before simulating
 - Know what the system **should** do



LTSpice Installation and Tutorial