Introduction to Feedback Control

Updated: November 6, 2023

Contents

Analysis of Feedback Control Systems

Routh-Hurwitz Criterion 2

Nyquist Plot 4

Stability Margins 5

Controller Synthesis 8

Loop shaping 8

Integral control 10

Analysis of Feedback Control Systems

Routh-Hurwitz Criterion

To assess the stability of a closed-loop system (Fig. 1) we need to determine its poles, i.e. the roots of the polynomial

$$1 + L(s) = 0. (1)$$

Consider the polynomial

$$\pi(s) = s^n + a_{n-1}s^{n-1} + \ldots + a_1s + a_0.$$
 (2)

Definition 1 $\pi(s)$ is Hurwitz if all its roots have negative real part.

Suppose $\pi(s)$ has r real roots, $\lambda_1, \ldots, \lambda_r$, and p complex conjugate pairs of roots, $\mu_1, \bar{\mu}_1, \dots, \mu_p, \bar{\mu}_p$. Then, we can write

$$\pi(s) = \underbrace{(s - \lambda_1) \dots (s - \lambda_r)}_{(\star)} \underbrace{(s - \mu_1)(s - \bar{\mu}_1) \dots (s - \mu_p)(s - \bar{\mu}_p)}_{(\star \star)}. \quad (3)$$

 $\pi(s)$ being Hurwitz means that $\lambda_i < 0$, i = 1, ..., r and $\Re(\mu_i) < 1$ 0, i = 1, ..., p. In such case, $\pi(s)$ has positive coefficients. This can be seen by expanding the polynomials (\star) and $(\star\star)$ in (3) and realizing that both have positive coefficients, hence their product does too. Thus, if $\pi(s)$ is Hurwitz, necessarily its coefficients $a_i > 0$, $\forall i$.

Example 1

$$s^4 + 3s^3 - 2s^2 + 5s + 6$$
 Not Hurwitz as $a_2 < 0$
 $s^3 + 4s + 6$ Not Hurwitz as $a_2 = 0$
 $s^3 + 5s^2 + 9s + 1$ Don't know

A NECESSARY AND SUFFICIENT CONDITION for a polynomial to be Hurwitz is provided by Routh's algorithm and the Routh-Hurwitz criterion. The first step of Routh's algorithm consists of building the following table—the *Routh table*—starting from the polynomial $\pi(s)$ in (2):

October 27, 2023

Figure 1: Transfer function of a closedloop system.





Figure 2: Adolf Hurwitz (1859-1919, left), German mathematician. His doctoral advisor was Felix Klein, who devised the Klein bottle. Edward Routh (1831-1907, right), English mathematician. He was born in Quebec.

Step 1 of Routh's algorithm

where

$$r_{2,0} = -\frac{1}{a_{n-1}} \begin{vmatrix} 1 & a_{n-2} \\ a_{n-1} & a_{n-3} \end{vmatrix}, \qquad r_{2,1} = -\frac{1}{a_{n-1}} \begin{vmatrix} 1 & a_{n-4} \\ a_{n-1} & a_{n-5} \end{vmatrix}, \qquad \dots$$

$$r_{3,0} = -\frac{1}{r_{2,0}} \begin{vmatrix} a_{n-1} & a_{n-3} \\ r_{2,0} & r_{2,1} \end{vmatrix}, \qquad r_{3,1} = -\frac{1}{r_{2,0}} \begin{vmatrix} a_{n-1} & a_{n-5} \\ r_{2,0} & r_{2,2} \end{vmatrix}, \qquad \dots$$

continuing along each row until a 0 appears, and terminating if a 0 appears in the first column.

The second step of Routh's algorithm consists in applying the following criterion.

Step 2 of Routh's algorithm

Theorem 1 (Routh-Hurwitz criterion)

- All elements in the first column of the (i) $\pi(s)$ is Hurwitz Routh table have the same sign
- (ii) If the first column of the Routh table has no 0's, then
 - (a) # sign changes = # roots with positive real part
 - (b) ∄ roots on the imaginary axis

Using Routh's algorithm, we can predict whether a polynomial is Hurwitz without explicitly computing its roots. This is convenient to ensure the stability of a system, in particular of a closed loop system, whose poles are the roots of 1 + L(s).

Example 2 (P-control design using Routh's algorithm) We are given a system with transfer function

$$G(s) = \frac{1}{s^4 + 6s^3 + 11s^2 + 6s}. (5)$$

The system is not stable and we would like to design a controller C(s) = Kfor some $K \in \mathbb{R}$ in order to stabilize it. The transfer function of the closedloop system is


$$\frac{Y(s)}{R(s)} = \frac{K}{s^4 + 6s^3 + 11s^2 + 6s + K}. (6)$$

The Routh table is



For the closed-loop system to be stable, the Routh-Hurwitz criterion says that we need $6 - \frac{3}{5}K > 0$ and K > 0, i.e. 0 < K < 10.

Nyquist Plot



Definition 2 The Nyquist plot of a transfer function L(s) is the image of the Nyquist contour (Fig. 3, on the left).

If L(s) has poles on the imaginary axis, then we modify the Nyquist contour to avoid these poles by going around them on infinitesimal semicircles on the right half plane (Fig. 3, on the right).

Note 1

- (i) $L(-j\omega) = \overline{L(j\omega)}$
- (ii) If L(s) is strictly proper, then $L(\infty) = 0$, i.e. the whole semicircle of infinite radius is mapped to o

Example 3

$$L(s) = \frac{\mu}{1 + \tau s}, \quad \mu > 0, \tau > 0. \tag{7}$$

Theorem 2 (Nyquist criterion) The closed-loop system in Fig. 1 is stable if and only if N = P, where

- P is the number of poles of L(s) with positive real part
- *N* is the number of loops that the Nyquist plot of *L*(*s*) makes around the point -1 in the complex plane (positive if counterclockwise, negative if clockwise); N is undefined if the Nyquist plot passes through -1

October 30, 2023

Figure 3: Nyquist contour (left) and its modified version to account for poles on the imaginary axis.



Figure 4: Harry Nyquist (1889-1976), Swedish-American physicist. Nyquist is also a programming language for sound synthesis.




Figure 5: Nyquist plot of the transfer function (7).

Note 2

- (i) If N is undefined, the closed-loop can be stable or unstable
- (ii) If N is well-defined and $N \neq P$, then the closed-loop system is unstable and it has P - N poles with positive real part

Example 3 (Continued) P = 0 and N = 0. By the Nyquist criterion, the negative feedback interconnection of (7) is stable.

Exercise 1 Applying the Nyquist criterion, determine the stability property of the closed-loop system in Fig. 1, where $L(s) = \frac{\mu}{1+\tau s}$, where $\mu < 0$ and $\tau > 0$.

Corollary 1 (to Theorem 2) Given a stable L(s), the following are sufficient conditions for the closed-loop system in Fig. 1 to be stable.

- $|L(j\omega)| < 1 \,\forall \omega$
- $|\angle L(j\omega)| < 180^{\circ} \forall \omega$

Stability Margins

Assume we designed a controller C(s) for a system G(s) so that the Nyquist plot of L(s) = C(s)G(s) is the one in Fig. 6. The further the Nyquist plot from the point -1, the higher the safety margin with respect to perturbations of L(s) (coming, for instance, from unmodeled dynamics). This margin can be conveniently decomposed into two stability margins which can be read directly from the Bode plots of L(s).

Assume L(s) has positive steady state gain, no unstable poles, and that its Nyquist plot intersects the negative real axis once, on the right of -1. Let ω_{π} be the frequency such that $\angle L(j\omega_{\pi}) = -180^{\circ}$. The gain margin, k_m , is defined as follows (Fig. 7, on the left):

$$k_m = \frac{1}{|L(j\omega_\pi)|},\tag{8}$$

and it represents the maximum multiplicative factor on the gain of L(s) at ω_{π} that the system can tolerate before becoming unstable.

November 1, 2023




Figure 6: Δ is a stability margin.




Figure 7: Gain margin, $k_m = \frac{1}{|L(j\omega_{\pi})|}$, on the left, and phase margin φ_m 180° − $|\angle L(j\omega_c)|$, on the right.

Assume the Nyquist plot of L(s) crosses the unit circle only once, from outside to inside. Let ω_c be the frequency such that $|L(j\omega_c)|=1$ — ω_c is the *crossover* frequency. The phase margin, φ_m , is defined as follows (Fig. 7, on the right):

$$\varphi_m = 180^\circ - |\angle L(j\omega_c)|,\tag{9}$$

and it represents the maximum (negative) phase shift of L(s) at ω_c that the system can tolerate before becoming unstable.




Figure 8: Reading k_m and φ_m on the Bode plots in correspondence of ω_{π} and ω_c , respectively.

As anticipated, the gain and phase margins can be read off from the Bode plots of L(s), as shown in Fig. 8.


Positive gain (in decibels) and phase margins of L(s) ensure that the closed-loop system is stable.

Note 3 Just like for the Nyquist criterion, using the gain and phase margins we are able to predict the stability of the closed-loop system by evaluating metrics defined on the open-loop system.

Controller Synthesis

Loop shaping

November 3, 2023



The goal of controller synthesis is to design the controller transfer function C(s), in order to make the closed loop system, modeled by the transfer function

$$F(s) = \frac{Y(s)}{R(s)} = \frac{L(s)}{1 + L(s)} = \frac{C(s)G(s)}{1 + C(s)G(s)},$$

satisfy desired specifications.

Specifications are typically defined in the time domain. Examples include rise time, overshoot, and steady-state value of the output signal y(t) in response to a step reference signal r(t). Therefore, the control design process can be broken down in the following steps:

- Step 1: Turn specifications from the time domain behavior of F(s)to the frequency domain behavior of L(s)
- Step 2: Design the transfer function of the controller C(s) so that L(s) = C(s)G(s) has the desired frequency domain behavior

Step 1 is summarized in the following table, where the time domain specifications of F(s) are listed next to the corresponding frequency domain specification of L(s). The latter are specified as constraints on the Bode plot of L(s).

Time domain specification of $F(s)$	Frequency domain specification of $L(s)$	Graphical representation on the Bode plot of $L(s)$
Stability	 Positive gain margin k_m > 0 Positive phase margin φ_m > 0 No cancelations in the computation of L(s) = C(s)G(s) 	Frequency where the magnitude Bode plot crosses of B $\varphi_m = - L(j\omega_x) _{\mathrm{olg}}$ Gain margin bow much we can increase reaching the stability limit for the magnitude Bode plot crosses of B $\varphi_m = 180^\circ - L(j\omega_c) $ Frequency where the phase Bode plot crosses -180° we can introduce at ω_x before reaching the stability limit for the phase Bode plot crosses -180° where -18
Robust stability	 The higher k_m and φ_m, the more robust we can expect our design to be Upper bound on ω_c: a time delay of τ contributes to -ω_cτ phase shift at ω_c 	
Static performance $\lim_{s\to 0} s \frac{F(s)}{s} = F(0) = \frac{\mu}{s^\rho + \mu}$ We want $F(0)$ as close to 1 as possible So, the higher μ the better, or $\rho > 0$ (μ and ρ are the steady state gain and the number of poles at the origin, respectively, of $L(s)$)	 High magnitude at low frequencies Or, L(jw) ^{ω→0}/_{→∞} ∞ (F(0) = 1, i.e. zero steady-state error) 	High values Integral action
Dynamic performance Tracking fast reference trajectories, not just regulating to constant references	• Lower bound on ω_c (as $ F(j\omega) \approx 1$ for $\omega < \omega_c$, while $\omega > \omega_c$ are attenuated)	
Disturbance rejection $\frac{Y(s)}{D(s)} = \frac{G(s)}{1+C(s)G(s)}$ must attenuate frequencies characterizing the disturbance (typically low frequencies)	 L(jω) ≫ 1 for the range of ω characterizing the disturbance (typically low frequencies) Or, equivalently, lower bound on ω_c 	Same as "Static performance"
Noise attenuation $\frac{Y(s)}{N(s)} = -\frac{C(s)G(s)}{1+C(s)G(s)}$ must attenuate frequencies characterizing the noise (typically high frequencies)	 L(jω) ≪ 1 for the range of ω characterizing the noise (typically high frequencies) Or, equivalently, upper bound on ω_c 	
Realizability of the controller $C(s)$ must be proper	• Slope of $ L(j\omega) \le$ slope of $ G(j\omega) $ for $\omega \to \infty$	Slope of $ G(j\omega) $ for $\omega \to \infty$

Exercise 2 Consider a system modeled by the following transfer function

$$G(s) = \frac{10}{(1+10s)(1+5s)(1+s)}.$$

*Design a controller C(s) such that the closed-loop system has the follow*ing specifications:

- The steady state error in response to a unit step reference is $|e_{\infty}| \leq 0.1$
- The cross-over frequency is $\omega_c \geq 0.2$
- The phase margin is $\varphi_m \geq 60^\circ$

Integral control

November 6, 2023

The main purpose of an integral controller

$$C(s) = \frac{\mu}{s} \tag{10}$$

is to obtain zero steady-state error, i.e. to have the measured output precisely track the reference signal. The output of the integral controller integrates the error between the reference signal and the measured output. Whenever an integral action is introduced, one needs to pay attention to the phase Bode plot of L(s), since a pole at the origin shifts the phase down by 90° for all frequencies, which could result in reducing the phase margin of rendering it negative.

Exercise 3 Consider a system modeled by the following transfer function

$$G(s) = \frac{10}{(1+10s)(1+5s)(1+s)}.$$

Design a controller C(s) such that the closed-loop system has the following specifications:

- The steady state error in response to a unit step reference is $|e_{\infty}| = 0$
- The cross-over frequency is $\omega_c \geq 0.2$
- The phase margin is $\varphi_m \geq 60^\circ$