# Department of Electronic and Telecommunication Engineering University of Moratuwa, Sri Lanka

EN4603 - Digital IC Design



# Laboratory Experiment 2 RTL Synthesis

Laboratory Report

#### Submitted by

#### Submitted by

C.S.Pallikkonda 180441C R.M.A.S.Rathnayake 180534N B.P.Thalagala 180631J

Submitted on

February 18, 2023

# Contents

Li	st of	Figures	2							
Li	st of	Tables	2							
Li	st of	Abbreviations	2							
1		roduction	3							
	1.1	Practical	3							
	1.2	DFT Insertion	4							
	1.3	Associated Genus Commands	5							
	1.4	Top Level Design before and after Design For Testability (DFT) Insertion	9							
2	Exercise									
	2.1	Comments on the Area	10							
	2.2	Comments on the Ports	11							
$\mathbf{B}^{!}$	ibliog	graphy	12							

#### Note:

All the materials related to the report can also be found at ht tps://github.com/b imal ka 98/D ig it al-IC-D es ig n

# List of Figures

1	Top level diagram of the Universal Asynchronous Receiver Transmitter (UART)	
	design	3
2	Overview of DFT insertion flow of 'Scan Test' in Cadence Genus software	4
3	Genus log for the check_dft_rules command	6
4	Genus log for the scan configuration and scan stitching commands	7
5	Genus log for the check_dft_rules command after scan chain connecting	8
6	Initial top level diagram of the UART design, before DFT insertion	9
7	Final top level diagram of the UART design, after DFT insertion	9
8	Ports of the UART design, before scan synthesis (Lab 1)	0
9	Ports of the UART design, after scan synthesis	0
10	Ports of the UART design, before scan synthesis (Lab 1)	1
11	Ports of the UART design, after scan synthesis	1

## List of Tables

### List of Abbreviations

**ASIC** Application Specific Integrated Circuit

ATPG Automatic Test Pattern Generation

**DEF** Design Exchange Format

**DFT** Design For Testability

 $\mathbf{GPDK}$  Generic Process Design Kit

**HDL** Hardware Description Language

**RTL** Register-Transfer Level

**RX** Receiver

TCL Tool Command Language

 $\mathbf{TX}$  Transmitter

**UART** Universal Asynchronous Receiver Transmitter

#### 1 Introduction

#### 1.1 Practical

In this practical, we will be using Cadence Genus - Ver. 18.10 to perform DFT insertion into an example Register-Transfer Level (RTL) design, a UART transceiver (shown in Figure 1). As inputs to Genus, we will provide

- 1. Source Verilog files
- 2. Technology libraries provided by the fabrication plant (here, 45 nm educational Generic Process Design Kit (GPDK) given by Cadence): (.lib, .lef, .tch)
  - Library Timing (.lib) files specify timing (cell delay, cell transition time, setup and hold time requirement) and power characteristics of standard cells. Slow and fast libraries characterize standard cells with maximum and minimum signal delays, which could occur from process variations.
  - Tch files are binary files that accurately characterize library elements, that include capacitance and resistance.
  - Library Exchange Format (LEF) specify design rules, metal capacitances, layer information...etc.

#### 3. Timing constraints

and will obtain the Scan-test compatible netlist (Verilog files), timing constrains (.sdc file), scanDesign Exchange Format (DEF) file and a set of files to be used as inputs to Cadence Modus for Automatic Test Pattern Generation (ATPG) as output. We will then analyze, compare and comment on the area and ports of the design at various stages of the Scan test insertion design flow.




Figure 1: Top level diagram of the  $\overline{\text{UART}}$  design

#### 1.2 DFT Insertion

In the context of Application Specific Integrated Circuit (ASIC) design, DFT refers to the process of inserting additional logic to improve the testability of the design. Here the testability is defined as the ability to communicate to the internal nodes through the primary input and output ports. The goal in DFT is to cover a maximum number of faults with a minimum amount of additional logic, as the insertion of additional logic directly translates to additional cost per chip. Although there are various DFT techniques in digital IC design, in this experiment, we will be focusing on inserting the 'Scan Test' into an example design.




Figure 2: Overview of DFT insertion flow of 'Scan Test' in Cadence Genus software.

#### 1.3 Associated Genus Commands

Note: Genus is a Tool Command Language (TCL) based tool and therefore .tcl scripts can be created to execute a series of commands instead of typing each command individually. The entire interface of Genus is accessible through TCL, and true TCL syntax and semantics are supported.

Followings are the commands used in this lab, and the entire script could be executed once using a single .tcl file. However, it was encouraged to execute the commands one-by-one in order to understand the process of DFT insertion to an RTL design.

```
# 1. Link Technology Library
source ../scripts/setup.tcl

# 2. Read HDLs
read_hdl [glob ../input/rtl/*.v]

# 3. Elaborate the top module
elaborate uart_top

# Uniquify the top module
uniquify uart_top

# 5. Set timing constraints
source ../input/constraints.tcl
```

Now that we have set the target libraries, read the design files and set the design constrains as done in the Laboratory Experiment 1. We can now proceed to the DFT insertion steps.

```
# 7. Set the DFT scan style in order to configure the DFT rule checker
set_db dft_scan_style muxed_scan

# 8. Set the prefix for names of additional modules/ports
set_db dft_prefix dft_

# 9. Define shift_enable signal
define_shift_enable -name SE -active high -create_port SE

# 10. Run DFT rule checker
check_dft_rules
```

If all steps have been followed correctly up until this point, we should not see any DFT violations, and Genus should generate an output similar to that of Figure 3. The DFT rule checker checks all flip-flops to determine if clock pins to the flip-flops can be controlled and if asynchronous set/reset pins (if available) to the flip-flops can be held to their non-controlling value during scan-shift mode. It is essential that there are no DFT violations at this step as any flip-flops with DFT violations will not be affected by DFT insertion commands which will be executed in the subsequent steps.

```
@file(lab2.tcl) 38: check_dft_rules
  Checking DFT rules for 'uart top' module under 'muxed scan' style
  Checking DFT rules for clock pins
  Checking DFT rules for async. pins
  Checking DFT rules for shift registers.
Detected 0 DFT rule violation(s)
        Summary of check dft rules
        Number of usable scan cells: 48
Clock Rule Violations:
         Internally driven clock net: 0
              Tied constant clock net: 0
                  Undriven clock net: 0
        Conflicting async & clock net: 0
                     Misc. clock net: 0
Async. set/reset Rule Violations:
        Internally driven async net: 0
             Tied active async net: 0
                Undriven async net: 0
                   Misc. async net: 0
  Total number of DFT violations: 0
  Total number of Test Clock Domains: 2
  Number of user specified non-Scan registers:
      Number of registers that fail DFT rules: 0
      Number of registers that pass DFT rules: 176
  Percentage of total registers that are scannable: 100%
```

Figure 3: Genus log for the check\_dft\_rules command

Now the design is synthesized into the generic logic netlist, and then mapped to the technology library.

```
# 11.1 Synthesize to generic logic with medium effort
set_db syn_generic_effort medium
syn_generic

# 11.2 Map to technology library and re-synthesize with medium effort
set_db syn_map_effort medium
syn_map

# 12. Write the scan synthesized netlist as uart_top_1.v
write_hdl > ../output/uart_top_1.v

# 13. Generate the reports after scan synthesis.
report_area > ../report/after_scan_synthesis/area.log
report_timing -nworst 10 > ../report/after_scan_synthesis/timing.log
report_port * > ../report/after_scan_synthesis/ports.log
report_power > ../report/after_scan_synthesis/power.log
```

Then the Scan Configuration and Scan Stitching is done using the below commands. The genus log of those commands are shown in the Figure 4.

```
# 14. Set scan configuration

define_scan_chain -name top_chain_a -sdi scan_in_a -sdo scan_out_a
        -non_shared_output -create_ports -domain clk_a

define_scan_chain -name top_chain_b -sdi scan_in_b -sdo scan_out_b
        -non_shared_output -create_ports -domain clk_b

# 15. Preview the scan chains/Scan Stitching
connect_scan_chains -preview -auto_create_chains

# 16. Preview the scan chains/Scan Stitching
connect_scan_chains -auto_create_chains
```

Figure 4: Genus log for the scan configuration and scan stitching commands

After scan chain connecting, incremental synthesis is performed to generate th netlist of the scan connected design. Then DFT rules are checked again to identify any potential violations. The Genus log of that is shown in the Figure 5.

```
# 17. Perform incremental synthesis to generate the netlist
# of the scan connected design
syn_opt -incr
# 18. Perform DFT rule check after scan connecting
check_dft_rules
```

```
@file(lab2.tcl) 77: check_dft_rules
  Checking DFT rules for 'uart top' module under 'muxed scan' style
  Checking DFT rules for clock pins
  Checking DFT rules for async. pins
  Checking DFT rules for shift registers.
Detected 0 DFT rule violation(s)
        Summary of check dft rules
       Number of usable scan cells: 48
Clock Rule Violations:
         Internally driven clock net: 0
              Tied constant clock net: 0
                  Undriven clock net: 0
        Conflicting async & clock net: 0 \,
                      Misc. clock net: 0
Async. set/reset Rule Violations:
       Internally driven async net: 0
              Tied active async net: 0
                Undriven async net: 0
                    Misc. async net: 0
  Total number of DFT violations: 0
  Total number of Test Clock Domains: 2
  Number of user specified non-Scan registers:
      Number of registers that fail DFT rules:
      Number of registers that pass DFT rules: 164
  Percentage of total registers that are scannable: 100%
```

Figure 5: Genus log for the check\_dft\_rules command after scan chain connecting

Once the above mentioned steps are completed, the below commands are used to finalize the DFT insertion process. They generate the Scan-test compatible netlist (Verilog files), further timing constrains (.sdc file), scanDEF file and a set of files to be used as inputs to Cadence Modus for ATPG as output.

```
# 19. Report scan setup and scan chain information
report_scan_setup > ../report/scan_setup.log
report_scan_chains > ../report/scan_chains.log
# 20. Write the DFT (scan test) inserted netlist and constrains.
write_hdl > ../output/uart_top_2.v
write_sdc > ../output/uart_top_2.sdc
# 21. Write the scanDEF file
write_scandef > ../output/uart_top_2_scanDEF.scandef
# 22. Generate the reports after scan connect
report_area > ../report/after_scan_connect/area.log
report_timing -nworst 10 > ../report/after_scan_connect/timing.log
report_port * > ../report/after_scan_connect/ports.log
report_power > ../report/after_scan_connect/power.log
# 23. Write the scripts required for the ATPG tool
write_dft_atpg -library
    ../input/libs/gsclib045/timing/slow_vdd1v0_basicCells.lib
```

#### 1.4 Top Level Design before and after DFT Insertion




Figure 6: Initial top level diagram of the UART design, before DFT insertion




Figure 7: Final top level diagram of the UART design, after DFT insertion

By comparing the Figures 6 and 7, it can be observed that, additional ports have been created to facilitate the Scan Test. Those are scan\_in\_a, scan\_in\_b, SE, scan\_out\_a and scan\_out\_b. In total there are two scan chains in the design, each having 82 registers in a chain.

#### 2 Exercise

This section documents the answers to the questions at the end of the practical guide, with screenshots and explanations.

#### 2.1 Comments on the Area

The area.log files in the report directories, provide a breakdown of the area usage by design hierarchy and by instance, which can be helpful in identifying specific modules that are contributing to the overall area of the design. Specifically it provides the below information[1]. Figures 8 and 9 illustrates the log files, before and after the scan synthesis process respectively.

- i. **Cell Count**: The total count of cells mapped against the hierarchical blocks in the current design.
- ii. Cell Area: The combined cell area in each of the blocks and the top level design (hierarchical breakup)
- iii. **Net Area**: The estimated post-route net area, which is based on the minimum wire widths defined in the LEF and capacitance table files and the area of the design blocks.
- iv. Total Area: Simply combines the 'Cell Area' and the 'Net Area'

Instance	Module	Cell Count	Cell Area	Net Area	Total Are
uart_top		772	2220.948	946.493	3167.44
ins_uart_transceiver_B	uart_transceiver_CLOCK_IN_MHZ100_TX_WORD_LENGTH8_T	386	1110.474	423.318	1533.79
ins_rx_wrapper	rx_wrapper_NO_OF_WORS_IN_BUFFER1_NO_OF_DATA_BITS8_	197	621.072	209.103	830.1
ins_rx_buffer	rx_buffer_WORD_SIZE8_NO_OF_WORDS1_1	67	292.068	61.047	353.1
ins_rx_fsm	rx_fsm_NO_OF_DATA_BITS8_PARITY_ENABLED32h54525545_	74	180.918	77.867	258.7
ins_sampling_tick_generator	sampling_tick_generator_BAUD115200_CLOCK_IN_MHZ100	56	148.086	62.149	210.2
ins_tx_wrapper	tx_wrapper_NO_OF_WORDS_IN_BUFFER1_NO_OF_DATA_BITS8	189	489.402	214.215	703.6
ins_tx_fsm	tx_fsm_NO_OF_DATA_BITS8_PARITY_ENABLED32h54525545_	94	210.330	103.544	313.8
ins_tx_buffer	tx_buffer_WORD_SIZE8_NO_OF_WORDS1_1	53	146.718	52.247	198.9
ins_sampling_tick_generator	sampling_tick_generator_BAUD115200_CLOCK_IN_MHZ100	42	132.354	46.412	178.7
ins_uart_transceiver_A	uart_transceiver_CLOCK_IN_MHZ100_TX_WORD_LENGTH8_T	386	1110.474	423.318	1533.7
ins_rx_wrapper	rx_wrapper_NO_OF_WORS_IN_BUFFER1_NO_OF_DATA_BITS8_	197	621.072	209.103	830.1
ins_rx_buffer	rx_buffer_WORD_SIZE8_NO_OF_WORDS1	67	292.068	61.047	353.1
ins_rx_fsm	rx_fsm_NO_OF_DATA_BITS8_PARITY_ENABLED32h54525545_	74	180.918	77.867	258.7
ins_sampling_tick_generator	sampling_tick_generator_BAUD115200_CLOCK_IN_MHZ100	56	148.086	62.149	210.2
ins_tx_wrapper	tx_wrapper_NO_OF_WORDS_IN_BUFFER1_NO_OF_DATA_BITS8	189	489.402	214.215	703.6
ins_tx_fsm	tx_fsm_NO_OF_DATA_BITS8_PARITY_ENABLED32h54525545_	94	210.330	103.544	313.8
ins_tx_buffer	tx_buffer_WORD_SIZE8_NO_OF_WORDS1	53	146.718	52.247	198.9
ins sampling tick generator	sampling tick generator BAUD115200 CLOCK IN MHZ100	42	132.354	46.412	178.7

Figure 8: Ports of the UART design, before scan synthesis (Lab 1)

Instance	Module	Cell Count	Cell Area	Net Area	Total Are
art_top		764	2570.472	987.659	3558.13
ins_uart_transceiver_B	uart_transceiver_CLOCK_IN_MHZ100_TX_WORD_LENGTH8_T	382	1285.236	443.179	1728.41
ins_rx_wrapper	rx_wrapper_NO_OF_WORS_IN_BUFFER1_NO_OF_DATA_BITS8_	191	717.516	214.481	931.99
ins_rx_buffer	rx_buffer_WORD_SIZE8_NO_OF_WORDS1_1	70	336.186	69.809	405.99
ins_rx_fsm	rx_fsm_NO_OF_DATA_BITS8_PARITY_ENABLED32h54525545_	75	214.776	81.136	295.91
ins_sampling_tick_generator	sampling_tick_generator_BAUD115200_CLOCK_IN_MHZ100	46	166.554	52.608	219.16
ins_tx_wrapper	tx_wrapper_NO_OF_WORDS_IN_BUFFER1_NO_OF_DATA_BITS8	191	567.720	228.698	796.41
ins_tx_fsm	tx_fsm_NO_OF_DATA_BITS8_PARITY_ENABLED32h54525545_	96	250.002	108.999	359.00
ins_tx_buffer	tx_buffer_WORD_SIZE8_NO_OF_WORDS1_1	53	162.108	56.580	218.68
	sampling_tick_generator_BAUD115200_CLOCK_IN_MHZ100	42	155.610	50.023	205.63
ins_uart_transceiver_A	uart_transceiver_CLOCK_IN_MHZ100_TX_WORD_LENGTH8_T	382	1285.236	443.179	1728.41
ins_rx_wrapper	rx_wrapper_NO_OF_WORS_IN_BUFFER1_NO_OF_DATA_BITS8_	191	717.516	214.481	931.99
ins_rx_buffer	rx_buffer_WORD_SIZE8_NO_OF_WORDS1	70	336.186	69.809	405.99
ins_rx_fsm	rx_fsm_NO_OF_DATA_BITS8_PARITY_ENABLED32h54525545_	75	214.776	81.136	295.91
ins_sampling_tick_generator	sampling_tick_generator_BAUD115200_CLOCK_IN_MHZ100	46	166.554	52.608	219.16
ins_tx_wrapper	tx_wrapper_NO_OF_WORDS_IN_BUFFER1_NO_OF_DATA_BITS8	191	567.720	228.698	796.41
ins_tx_fsm	tx_fsm_NO_OF_DATA_BITS8_PARITY_ENABLED32h54525545_	96	250.002	108.999	359.00
ins_tx_buffer	tx_buffer_WORD_SIZE8_NO_OF_WORDS1	53	162.108	56.580	218.68
ins sampling tick generator	sampling tick generator BAUD115200 CLOCK IN MHZ100	42	155.610	50.023	205.63

Figure 9: Ports of the UART design, after scan synthesis

#### 2.2 Comments on the Ports

The ports.log files in the report directories carry the details related to the ports of the current design. By default, the report gives information on port direction, external delays, exception objects and their types, driver, slew, fanout load, pin capacitance and wire capacitance for the ports[1]. Figures 10 and 11 illustrates a part of the 'External Delays & Exceptions' section of the ports log files, before and after the scan synthesis process respectively.

	clk_b	in	clk_b	0.0	no_value	<pre>create_clock_delay_domain_1_clk_b_R_0</pre>	N/A
			clk_b	no_value	0.0	create_clock_delay_domain_1_clk_b_F_0	
	reset_b	in	N/A	N/A	N/A	N/A	N/A
	<pre>tx_parallel_data_in_b[7]</pre>	in	clk_b	6000.0	6000.0	in_del_10_1	N/A
	tx_parallel_data_in_b[6]	in	clk_b	6000.0	6000.0	in_del_11_1	N/A
	<pre>tx_parallel_data_in_b[5]</pre>	in	clk_b	6000.0	6000.0	in_del_12_1	N/A
	tx_parallel_data_in_b[4]	in	clk_b	6000.0	6000.0	in_del_13_1	N/A
	<pre>tx_parallel_data_in_b[3]</pre>	in	clk_b	6000.0	6000.0	in_del_14_1	N/A
	<pre>tx_parallel_data_in_b[2]</pre>	in	clk_b	6000.0	6000.0	in_del_15_1	N/A
	<pre>tx_parallel_data_in_b[1]</pre>	in	clk_b	6000.0	6000.0	in_del_16_1	N/A
	<pre>tx_parallel_data_in_b[0]</pre>	in	clk_b	6000.0	6000.0	in_del_17_1	N/A
	tx_data_wr_enable_in_b	in	clk_b	6000.0	6000.0	in_del_18_1	N/A
	rx_data_rd_enable_in_b	in	clk_b	6000.0	6000.0	in_del_19_1	N/A
	tx_busy_out_a	out	clk_a	6000.0	6000.0	ou_del	N/A
	rx_full_a	out	clk_b	6000.0	6000.0	ou_del_32_1	N/A
	rx_parallel_data_out_a[7]	out	clk_a	6000.0	6000.0	ou_del_21_1	N/A
	rx_parallel_data_out_a[6]	out	clk_a	6000.0	6000.0	ou_del_22_1	N/A
	rx_parallel_data_out_a[5]	out	clk_a	6000.0	6000.0	ou_del_23_1	N/A
	rx_parallel_data_out_a[4]	out	clk_a	6000.0	6000.0	ou_del_24_1	N/A
	rx_parallel_data_out_a[3]	out	clk_a	6000.0	6000.0	ou_del_25_1	N/A
	rx_parallel_data_out_a[2]	out	clk_a	6000.0	6000.0	ou_del_26_1	N/A
	rx_parallel_data_out_a[1]	out	clk_a	6000.0	6000.0	ou_del_27_1	N/A
	rx_parallel_data_out_a[0]	out	clk_a	6000.0	6000.0	ou_del_28_1	N/A
	rx_parity_error_a	out	clk_a	6000.0	6000.0	ou_del_29_1	N/A
	rx_stop_bit_error_a	out	clk_a	6000.0	6000.0	ou_del_30_1	N/A
	tx_busy_out_b	out	clk_b	6000.0	6000.0	ou_del_31_1	N/A
	rx_full_b	out	N/A	N/A	N/A	N/A	N/A
1							

Figure 10: Ports of the UART design, before scan synthesis (Lab 1)

clk_b	in	clk_b	0.0	no_value	<pre>create_clock_delay_domain_1_clk_b_R_0</pre>	N/A
		clk_b	no_value	0.0	create_clock_delay_domain_1_clk_b_F_0	
reset_b	in	N/A	N/A	N/A	N/A	N/A
<pre>tx_parallel_data_in_b[7]</pre>	in	clk_b	6000.0	6000.0	in_del_10_1	N/A
<pre>tx_parallel_data_in_b[6]</pre>	in	clk_b	6000.0	6000.0	in_del_11_1	N/A
<pre>tx_parallel_data_in_b[5]</pre>	in	clk_b	6000.0	6000.0	in_del_12_1	N/A
tx parallel data in b[4]	in	clk b	6000.0	6000.0	in del 13 1	N/A
<pre>tx_parallel_data_in_b[3]</pre>	in	clk b	6000.0	6000.0	in del 14 1	N/A
<pre>tx_parallel_data_in_b[2]</pre>	in	clk_b	6000.0	6000.0	in_del_15_1	N/A
tx parallel data in b[1]	in	clk b	6000.0	6000.0	in del 16 1	N/A
tx parallel data in b[0]	in	clk b	6000.0	6000.0	in del 17 1	N/A
tx_data_wr_enable_in_b	in	clk_b	6000.0	6000.0	in_del_18_1	N/A
rx data rd enable in b	in	clk b	6000.0	6000.0	in del 19 1	N/A
SE	in	N/A	N/A	N/A	N/A	N/A
tx_busy_out_a	out	clk_a	6000.0	6000.0	ou_del	N/A
rx_full_a	out	clk_b	6000.0	6000.0	ou_del_32_1	N/A
rx_parallel_data_out_a[7]	out	clk_a	6000.0	6000.0	ou_del_21_1	N/A
rx parallel data out a[6]	out	clk a	6000.0	6000.0	ou del 22 1	N/A
rx parallel data out a[5]	out	clk a	6000.0	6000.0	ou del 23 1	N/A
rx_parallel_data_out_a[4]	out	clk_a	6000.0	6000.0	ou_del_24_1	N/A
rx parallel data out a[3]	out	clk a	6000.0	6000.0	ou del 25 1	N/A
<pre>rx_parallel_data_out_a[2]</pre>	out	clk a	6000.0	6000.0	ou del 26 1	N/A
rx_parallel_data_out_a[1]	out	clk_a	6000.0	6000.0	ou_del_27_1	N/A
rx parallel data out a[0]	out	clk a	6000.0	6000.0	ou del 28 1	N/A
rx_parity_error_a	out	clk_a	6000.0	6000.0	ou_del_29_1	N/A
rx stop bit error a	out	clk_a	6000.0	6000.0	ou del 30 1	N/A
tx busy out b	out	clk b	6000.0	6000.0	ou del 31 1	N/A
rx_full_b	out	N/A	N/A	N/A	N/A	N/A

Figure 11: Ports of the  $\overline{\text{UART}}$  design, after scan synthesis

# Bibliography

[1] "Genus Command Reference," version 19.1, November 2019, published by  $\ \ Cadence\ Design\ Systems, \ Inc.$