

Notation and Definitions

Stefan Leutenegger¹*, modified by Binbin Xu¹

Abstract

In the following, a set of suggestions for notations and definitions is presented. We might want to adopt some of this for future work. Let's discuss!

Keywords

Notation — Definitions — Transformations — Rotations — Quaternions

Contents Symbols 1.2 Spaces and Manifolds 1 **Coordinates and Transformations** 2.2 Ellipsoid Coordinates 2 Tait-Bryan Angles • Quaternions • Angle-Axis and Rotation Vector • Operators • Local Parameterisation • Transforming Representations 2.4 Homogeneous Transformation 3 **Time Derivatives of Position & Orientation** Rotation Matrix Time Derivative vs. Angular Velocity • Rotation Quaternion Time Derivative vs. Angular Velocity • Angle-Axis Time Derivative vs. Angular Velocity • Rotation Vector Time Derivative vs. Angular Velocity • Tait-Bryan Angles Time Derivatives vs. Angular Velocity **Acknowledgments**

1.1 Basic Symbols

- A lower-case symbol denotes a scalar (with common capital exceptions).
- **a** A bold lower-case symbol denotes a vector.
- A bold lower-case italic symbol denotes a homogeneous vector.
- A A bold capital symbol denotes a matrix.
- 1 The identity matrix, optionally with dimension as subscript.
- **0** A zero matrix, optionally with dimensions as subscripts.
- \mathscr{A} A set.

1.2 Spaces and Manifolds

 \mathbb{R} The Real numbers.

 \mathbb{C} The Complex numbers.

 \mathbb{R}^3 The 3D Euclidean space.

 S^3 The 3-Sphere group.

SO(3) The 3D rotation group.

SE(3) The Special Euclidean group.

In general the states live in a manifold, therefore we use a perturbation in tangent space $\mathfrak g$ and employ the group operator \boxplus , that is not commutative in general, the exponential exp and logarithm log. Now, we can define the perturbation $\delta \mathbf x := \mathbf x \boxplus \overline{\mathbf x}^{-1}$ around the estimate $\overline{\mathbf x}$. We use a minimal coordinate representation $\delta \boldsymbol \chi \in \mathbb{R}^{\dim \mathfrak g}$. A bijective mapping $\Phi: \mathbb{R}^{\dim \mathfrak g} \to \mathfrak g$ transforms from minimal coordinates to tangent space. Thus we obtain the transformations from and to minimal coordinates:

$$\delta \mathbf{x} = \exp(\Phi(\delta \mathbf{\chi})),\tag{1}$$

$$\delta \mathbf{\chi} = \Phi^{-1}(\log(\delta \mathbf{x})). \tag{2}$$

1.3 Stochastics

 $\mathcal{N}(\boldsymbol{\mu}, \boldsymbol{\Sigma})$ The Normal distribution with mean $\boldsymbol{\mu}$ and covariance $\boldsymbol{\Sigma}$.

E[.] The expectation operator.

1.4 Physical Parameters

Earth's acceleration due to gravity.

¹ Department of Computing, Imperial College, London, United Kingdom

^{*}Corresponding author: {s.leutenegger, b.xu17}@imperial.ac.uk



2. Coordinates and Transformations

2.1 Frames

 \mathcal{Z}_A A frame of reference in \mathbb{R}^3 .

 $\overrightarrow{\mathbf{a}}$ The vector \mathbf{a} expressed in \mathscr{F}_A .

The position vector from the origin of \mathcal{Z}_A to point P expressed in \mathcal{Z}_A .

 $_{A}\mathbf{r}_{BC}$ The position vector from the point of $_{A}\mathbf{r}_{B}$ to point $_{A}\mathbf{r}_{C}$ expressed in \mathscr{F}_{A} , as shown in Fig.1.




Figure 1. The position vector from the point of B to point C expressed in the frame A.

Generally speaking, we use \mathcal{F}_{C_i} for a camera frame (the i^{th}), \mathcal{F}_{S} for an IMU frame, and \mathcal{F}_{B} for a body frame. As for fixed frames, we may use \mathcal{F}_{W} as a World frame (any orientation) or \mathcal{F}_{N} for a navigation frame (fixed directions, e.g. East-North-Up (ENU) as complyant with the ROS standard).

2.2 Ellipsoid Coordinates

- ϕ The WGS 84 latitude.
- λ The WGS 84 longitude.
- h The WGS 84 altitude.

2.3 Orientation

 \mathbf{C}_{AB} The rotation matrix \mathbf{C}_{AB} , represents the orientation of the frame, \mathcal{F}_{A} , with respect to another frame, \mathcal{F}_{A} .

It also means that a vector expressed in the body frame, ${}_{B}\mathbf{a}$, to be rotated into the world frame as ${}_{A}\mathbf{a}$ by ${}_{A}\mathbf{a} = \mathbf{C}_{AB}{}_{B}\mathbf{a}$, as shown in Fig.2.

 \mathbf{q}_{AB} A quaternion of rotation.

 φ roll angle (Tait-Bryan).

 θ pitch angle (Tait-Bryan).

 ψ yaw angle (Tait-Bryan).

2.3.1 Tait-Bryan Angles

Sometimes, it is useful to use a minimal global orientation parameterisation, e.g. for orientation plots. We adopt the Euler Angles ZYX $[\psi, \theta, \phi]$, aka Tait-Bryan angles (Flight convention: yaw, pitch, roll). Singularities are at $\theta = \pm \frac{\pi}{2}$.

Figure 2. The orientation of the frame B with respect to frame A.

2.3.2 Quaternions

Quaternions provide a singularity-free alternative to Euler Angles. We use the Hamilton quaternion convention, i.e.:

$$Q = q_0 + q_1 i + q_2 j + q_3 k \in \mathbb{H}, \quad q_i \in \mathbb{R},$$
 (3)

$$i^2 = j^2 = k^2 = ijk = -1, (4)$$

$$||Q|| = \sqrt{q_0^2 + q_1^2 + q_2^2 + q_3^2} = 1.$$
 (5)

Note that \mathbf{q}_{AB} and $-\mathbf{q}_{AB}$ represent the same rotation, but not the same unit quaternion. Rotation quaternion as vector: $\mathbf{q} = [q_0, q_1, q_2, q_3]^T = [a(\mathbf{q}), \mathbf{v}(\mathbf{q})]^T$ with $a(\mathbf{q}) = q_0$ and $\mathbf{v}(\mathbf{q}) := [q_1, q_2, q_3]^T$.

2.3.3 Angle-Axis and Rotation Vector

We use the Angle α and Axis **n** representation $[\alpha, \mathbf{n}^T]_{AB}^T$ as an alternative to a Quaternion \mathbf{q}_{AB} . The identity Angle-Axis: $[0,1,0,0]^T$.

We may also write the same quantity as a Rotation Vector $\boldsymbol{\alpha}_{AB} = \alpha \mathbf{n}$.

2.3.4 Operators

- \otimes The quaternion multiplication, such that $\mathbf{q}_{AC} = \mathbf{q}_{AB} \otimes \mathbf{q}_{BC}$.
- [.]⁺ The left-hand quaternion matrix, such that $\mathbf{q}_{AC} = [\mathbf{q}_{AB}]^{+}\mathbf{q}_{BC}$.
- [.]^{\oplus} The right-hand quaternion matrix, such that $\mathbf{q}_{AC} = [\mathbf{q}_{BC}]^{\oplus} \mathbf{q}_{AB}$.
- [.] \times The cross-product matrix of a vector, such that $\mathbf{a} \times \mathbf{b} = [\mathbf{a}]^{\times} \mathbf{b}$.

Quaternion multiplication:

$$\mathbf{q} \otimes \mathbf{p} = \begin{bmatrix} (a(\mathbf{q})a(\mathbf{p}) - \mathbf{v}(\mathbf{q})^T \mathbf{v}(\mathbf{p}) \\ a(\mathbf{q})\mathbf{v}(\mathbf{p}) + a(\mathbf{p})\mathbf{v}(\mathbf{q}) + \mathbf{v}(\mathbf{q}) \times \mathbf{v}(\mathbf{p})) \end{bmatrix}. \quad (6)$$



Written in matrix multiplication form, we get

$$\left[\mathbf{q}_{AB}\right]^{+} = \begin{bmatrix} a & -\mathbf{v}^{T} \\ \mathbf{v} & a\mathbf{1} - [\mathbf{v}]^{\times} \end{bmatrix}, \tag{7}$$

$$[\mathbf{q}_{AB}]^{\oplus} = \begin{bmatrix} a & -\mathbf{v}^T \\ \mathbf{v} & a\mathbf{1} + [\mathbf{v}]^{\times} \end{bmatrix}, \tag{8}$$

$$\mathbf{a} \times \mathbf{b} = [\mathbf{a}]^{\times} \mathbf{b} = \begin{bmatrix} a_1 \\ a_2 \\ a_3 \end{bmatrix} \times \begin{bmatrix} b_1 \\ b_2 \\ b_3 \end{bmatrix}$$
 (9)

$$= \begin{bmatrix} 0 & -a_3 & a_2 \\ a_3 & 0 & -a_1 \\ -a_2 & a_1 & 0 \end{bmatrix} \begin{bmatrix} b_1 \\ b_2 \\ b_3 \end{bmatrix}. \tag{10}$$

2.3.5 Local Parameterisation

We use the minimal (3D) axis-angle perturbation of orientation $\delta \alpha \in \mathbb{R}^3$ which can be converted into its quaternion equivalent $\delta \mathbf{q}$ via the exponential map:

$$\delta \mathbf{q} := \exp\left(\begin{bmatrix} 0 \\ \frac{1}{2}\delta \boldsymbol{\alpha} \end{bmatrix}\right) = \begin{bmatrix} \cos\left\|\frac{\delta \boldsymbol{\alpha}}{2}\right\| \\ \sin c\left\|\frac{\delta \boldsymbol{\alpha}}{2}\right\|\frac{\delta \boldsymbol{\alpha}}{2} \end{bmatrix}. \quad (11)$$

Therefore, using the group operator ⊗, we write

$$\mathbf{q}_{WS} = \delta \mathbf{q} \otimes \overline{\mathbf{q}}_{WS} \,. \tag{12}$$

Note that linearization of the exponential map around $\delta \alpha = 0$ yields:

$$\delta \mathbf{q} \approx \begin{bmatrix} 1 \\ \frac{1}{2} \delta \boldsymbol{\alpha} \end{bmatrix} = \mathbf{i} + \frac{1}{2} \begin{bmatrix} \mathbf{0}_{1 \times 3} \\ \mathbf{1}_{3} \end{bmatrix} \delta \boldsymbol{\alpha}, \quad (13)$$

where *t* denotes the identity quaternion.

2.3.6 Transforming Representations Quaternion to rotation matrix:

$$\mathbf{C}_{AB} = \mathbf{1}_{3\times3} + 2a(\mathbf{q}_{AB}) [\mathbf{v}(\mathbf{q}_{AB})]^{\times} + 2([\mathbf{v}(\mathbf{q}_{AB})]^{\times})^{2} = \begin{bmatrix}
q_{0}^{2} + q_{1}^{2} - q_{2}^{2} - q_{3}^{2} & 2q_{1}q_{2} - 2q_{0}q_{3} & 2q_{0}q_{2} + 2q_{1}q_{3} \\
2q_{0}q_{3} + 2q_{1}q_{2} & q_{0}^{2} - q_{1}^{2} + q_{2}^{2} - q_{3}^{2} & 2q_{2}q_{3} - 2q_{0}q_{1} \\
2q_{1}q_{3} - 2q_{0}q_{2} & 2q_{0}q_{1} + 2q_{2}q_{3} & q_{0}^{2} - q_{1}^{2} - q_{2}^{2} + q_{3}^{2}
\end{bmatrix}.$$
(14)

Using the above perturbation, we obtain the following perturbation of the rotation matrix:

$$\mathbf{C}_{AB} = (\mathbf{1} + [\boldsymbol{\delta}\boldsymbol{\alpha}]^{\times})\overline{\mathbf{C}}_{AB}. \tag{15}$$

For the inverse transformation, we get

$$\mathbf{C}_{BA} = \mathbf{C}_{BA}^{T} = \overline{\mathbf{C}}_{BA} (\mathbf{1} - [\delta \boldsymbol{\alpha}]^{\times}). \tag{16}$$

These two expressions are extremely useful when linearizing terms involving quantities undergoing coordinate transformations.

Tait-Bryan Angles to rotation matrix:

$$\mathbf{C}_{WB} = \begin{bmatrix} \cos(\psi) & -\sin(\psi) & 0\\ \sin(\psi) & \cos(\psi) & 0\\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} \cos(\theta) & 0 & \sin(\theta)\\ 0 & 1 & 0\\ -\sin(\theta) & 0 & \cos(\theta) \end{bmatrix} \begin{bmatrix} 1 & 0 & 0\\ 0 & \cos(\phi) & -\sin(\phi)\\ 0 & \sin(\phi) & \cos(\phi) \end{bmatrix}. \tag{18}$$

Quaternions to Angle-Axis: We get the Angle-Axis representation $[\alpha, \mathbf{n}^T]^T$ for $\|\mathbf{v}\| \ge \varepsilon$:

$$\alpha = 2\arccos a,\tag{19}$$

$$\mathbf{n} = \frac{\mathbf{v}}{\|\mathbf{v}\|} \tag{20}$$

for $\|\mathbf{v}\| < \varepsilon$, we use the identity Angle-Axis $[0, 1, 0, 0]^T$

2.4 Homogeneous Transformation

 T_{AB} A homogeneous transformation matrix.

As a composition of rotation matrix and position vector, we write a homogeneous transformation matrix as

$$T_{AB} = \begin{bmatrix} \mathbf{C}_{AB} & {}_{A}\mathbf{r}_{B} \\ \mathbf{0}^{T} & 1 \end{bmatrix} = \begin{bmatrix} \mathbf{C}_{AB} & {}_{A}\mathbf{r}_{AB} \\ \mathbf{0}^{T} & 1 \end{bmatrix}. \tag{21}$$

The resulting transformation matrix, T_{AB} , represents the pose of the frame \mathcal{F}_{A} , with respect to the frame \mathcal{F}_{A} , such that a point expressed in the frame \mathcal{F}_{A} , $_{B}\mathbf{p}$, can be transformed into the frame \mathcal{F}_{A} , $_{A}\mathbf{p}$ by $_{A}\mathbf{p} = T_{AB}_{B}\mathbf{p}$.

"The pose of B with respect to A" "Transforms point from frame B into frame A" $_{\rm B}p\propto {{\tt B}p\choose 1}$ $_{\rm A}p:=_{\rm A}t_{\rm AP}$ $_{\rm B}p:=_{\rm B}t_{\rm BP}$ $_{\rm B}p:=_{\rm B}t_{\rm BP}$ $_{\rm B}p:=_{\rm B}t_{\rm BP}$ $_{\rm B}p:=_{\rm B}t_{\rm BP}$

Figure 3. The pose of frame B with respect to frame A.

2.5 Image warping

 ${}_{A}\mathbf{I}_{B}$ Render the image from $\underline{\mathscr{F}}_{B}$ to $\underline{\mathscr{F}}_{A}$. It can also be seen as viewing $\underline{\mathscr{F}}_{A}$ from $\underline{\mathscr{F}}_{B}$.

2.6 Lie algebra

$$\xi = \left[\begin{array}{c} \rho \\ \phi \end{array} \right] \in \mathbb{R}^6 \tag{22}$$

$$\boldsymbol{\xi}^{\wedge} = \left[\begin{array}{cc} \boldsymbol{\phi}^{\wedge} & \boldsymbol{\rho} \\ \boldsymbol{0}^{\mathrm{T}} & 0 \end{array} \right] \tag{23}$$

$$T = \exp(\xi^{\wedge}) = \begin{bmatrix} \exp(\phi^{\wedge}) & J\rho \\ \mathbf{0}^{\mathrm{T}} & 1 \end{bmatrix}$$
 (24)

$$\approx 1 + \xi^{\wedge}$$
 (25)

$$T \to \exp(\delta \boldsymbol{\xi}) T$$
 (26)

$$T^{-1} \to (\exp(\delta \xi)T)^{-1} = T^{-1}(\exp(\delta \xi))^{-1}$$
 (27)

$$\approx T^{-1}(\exp(-\delta \boldsymbol{\xi})) \approx T^{-1}(1 - \delta \boldsymbol{\xi}) \tag{28}$$

The above three approximations work for small perturbation $\delta {\pmb \xi} \to 0$ only.



3. Time Derivatives of Position & Orientation

 ${}_{A}\mathbf{v}_{BC}$ The velocity of $\underline{\mathscr{F}}_{C}$ as seen from $\underline{\mathscr{F}}_{B}$ represented in \mathscr{F}_{A} .

The rotational velocity of $\underline{\mathscr{F}}_C$ w.r.t. $\underline{\mathscr{F}}_B$ represented in $\underline{\mathscr{F}}_A$.

In the following, we use \mathcal{F}_I as an inertial frame and \mathcal{F}_B as a (moving) body frame.

3.1 Linear Velocity

Velocity of point Q on rigid body \mathcal{F}_B that rotates with ${}_B\boldsymbol{\omega}_{IB}$, w.r.t. to the inertial frame \mathcal{F}_I : ${}_B\mathbf{v}_{IQ} = {}_B\mathbf{v}_{IB} + {}_B\boldsymbol{\omega}_{IB} \times {}_B\mathbf{r}_Q$.

3.2 Angular Velocity

Absolute angular velocity of rigid body B expressed in frame B.

 $_{B}\boldsymbol{\omega}_{IB} = -_{B}\boldsymbol{\omega}_{BI}$ Inverse of angular velocity. $_{I}\boldsymbol{\omega}_{IB} = \mathbf{C}_{IB}_{B}\boldsymbol{\omega}_{IB}$ Coordinate transformation of

angular velocity from frame B to frame W.

 $_{D}\boldsymbol{\omega}_{AD} = _{D}\boldsymbol{\omega}_{AB} +$ Composition of angular velocity: .

3.2.1 Rotation Matrix Time Derivative vs. Angular Velocity

$$\left[{}_{I}\boldsymbol{\omega}_{IB}\right]^{\times} = \dot{\mathbf{C}}_{IB} \,\mathbf{C}_{IB}^{T} = \dot{\mathbf{C}}_{BI}^{T} \,\mathbf{C}_{BI}, \qquad (29)$$

$$[_{R}\boldsymbol{\omega}_{IR}]^{\times} = \mathbf{C}_{IR}^{T} \,\dot{\mathbf{C}}_{IR} = \mathbf{C}_{RI} \,\dot{\mathbf{C}}_{RI}^{T}, \tag{30}$$

$$\dot{\mathbf{C}}_{IB} = \mathbf{C}_{IB} \left[{}_{B} \boldsymbol{\omega}_{IB} \right]^{\times}. \tag{31}$$

3.2.2 Rotation Quaternion Time Derivative vs. Angular Velocity

$$\dot{\mathbf{q}}_{IB} = \mathbf{\Xi}(\mathbf{q}_{IB})_B \boldsymbol{\omega}_{IB} = \mathbf{\Omega}(_B \boldsymbol{\omega}_{IB}) \mathbf{q}_{IB}, \qquad (32)$$

$$\mathbf{\Xi}(\mathbf{q}_{IB}) = \begin{bmatrix} \mathbf{v}(\mathbf{q}_{IB}) & a(\mathbf{q}_{IB})\mathbf{1} + [\mathbf{v}(\mathbf{q}_{IB})]^{\times} \end{bmatrix}, \quad (33)$$

$$\mathbf{\Omega}({}_{B}\mathbf{\omega}_{IB}) = \left[\begin{array}{c} 0 \\ {}_{B}\mathbf{\omega}_{IB} \end{array}\right]^{\oplus}. \tag{34}$$

3.2.3 Angle-Axis Time Derivative vs. Angular Velocity To rotation velocity:

$${}_{I}\boldsymbol{\omega}_{IB} = \mathbf{n}\dot{\alpha} + \dot{\mathbf{n}}\sin\alpha + [\mathbf{n}]^{\times}\dot{\mathbf{n}}(1 - \cos\alpha), \quad (35)$$

$$_{\mathbf{R}}\boldsymbol{\omega}_{I\mathbf{R}} = \mathbf{n}\dot{\alpha} + \dot{\mathbf{n}}\sin\alpha - [\mathbf{n}]^{\times}\dot{\mathbf{n}}(1 - \cos\alpha),$$
 (36)

and back:

$$\dot{\alpha} = \mathbf{n}^T{}_I \boldsymbol{\omega}_{IB} \,, \tag{37}$$

$$\dot{\mathbf{n}} = \left(-\frac{1}{2} \frac{\sin \alpha}{1 - \cos \alpha} ([\mathbf{n}]^{\times})^2 - \frac{1}{2} [\mathbf{n}]^{\times} \right)_I \boldsymbol{\omega}_{IB}, \quad (38)$$

$$\dot{\alpha} = \mathbf{n}^T_{\ B} \mathbf{\omega}_{IB} \,, \tag{39}$$

$$\dot{\mathbf{n}} = \left(-\frac{1}{2} \frac{\sin \alpha}{1 - \cos \alpha} ([\mathbf{n}]^{\times})^2 + \frac{1}{2} [\mathbf{n}]^{\times}\right)_{B} \boldsymbol{\omega}_{IB}, \quad (40)$$

$$\forall \alpha \in \mathbb{R} \setminus \{0\}. \tag{41}$$

3.2.4 Rotation Vector Time Derivative vs. Angular Velocity

To rotation velocity:

$${}_{I}\boldsymbol{\omega}_{IB} = \left(\mathbf{1} + [\boldsymbol{\alpha}]^{\times} \left(\frac{1 - \cos\|\boldsymbol{\alpha}\|}{\|\boldsymbol{\alpha}\|^{2}}\right) + ([\boldsymbol{\alpha}]^{\times})^{2} \left(\frac{\|\boldsymbol{\alpha}\| - \sin\|\boldsymbol{\alpha}\|}{\|\boldsymbol{\alpha}\|^{3}}\right)\right) \dot{\boldsymbol{\alpha}},$$
(42)

$${}_{B}\boldsymbol{\omega}_{IB} = \left(\mathbf{1} - [\boldsymbol{\alpha}]^{\times} \left(\frac{1 - \cos\|\boldsymbol{\alpha}\|}{\|\boldsymbol{\alpha}\|^{2}}\right) + ([\boldsymbol{\alpha}]^{\times})^{2} \left(\frac{\|\boldsymbol{\alpha}\| - \sin\|\boldsymbol{\alpha}\|}{\|\boldsymbol{\alpha}\|^{3}}\right)\right) \dot{\boldsymbol{\alpha}},$$
(43)

$$\forall \|\boldsymbol{\alpha}\| \in \mathbb{R} \setminus \{0\},\tag{44}$$

and back:

$$\dot{\boldsymbol{\alpha}} = \left(\mathbf{1} - \frac{1}{2} [\boldsymbol{\alpha}]^{\times} + ([\boldsymbol{\alpha}]^{\times})^{2} \frac{1}{\|\boldsymbol{\alpha}\|^{2}} \left(1 - \frac{\|\boldsymbol{\alpha}\|}{2} \frac{\sin \|\boldsymbol{\alpha}\|}{1 - \cos \|\boldsymbol{\alpha}\|}\right)\right)_{I} \boldsymbol{\omega}_{IB},$$
(45)

$$\dot{\boldsymbol{\alpha}} = \left(\mathbf{1} + \frac{1}{2} [\boldsymbol{\alpha}]^{\times} + ([\boldsymbol{\alpha}]^{\times})^{2} \frac{1}{\|\boldsymbol{\alpha}\|^{2}} \left(1 - \frac{\|\boldsymbol{\alpha}\|}{2} \frac{\sin \|\boldsymbol{\alpha}\|}{1 - \cos \|\boldsymbol{\alpha}\|}\right)\right)_{B} \boldsymbol{\omega}_{IB},$$
(46)

$$\forall \|\boldsymbol{\alpha}\| \in \mathbb{R} \setminus \{0\}. \tag{47}$$

3.2.5 Tait-Bryan Angles Time Derivatives vs. Angular Velocity

$$\begin{bmatrix} \dot{\boldsymbol{\psi}} \\ \dot{\boldsymbol{\theta}} \\ \dot{\boldsymbol{\phi}} \end{bmatrix} = \begin{bmatrix} 0 & \frac{\sin \phi}{\cos \theta} & \frac{\cos \phi}{\cos \theta} \\ 0 & \cos \phi & -\sin \phi \\ 1 & \frac{\sin \phi \sin \theta}{\cos \theta} & \frac{\cos \phi \sin \theta}{\cos \theta} \end{bmatrix}_{B} \boldsymbol{\omega}_{IB} , \qquad (48)$$

$$\forall \boldsymbol{\theta} \in \mathbb{R} \setminus \{ \frac{\pi}{2} + k\pi \}, k \in \mathbb{Z}.$$

Acknowledgments

Many thanks to the notation and standards workgroup at ASL, ETH Zurich, consisting of Christian Gehring, Hannes Sommer, Paul Furgale, and Remo Diethelm, who helped elaborating the presented notation!