TdT Characterization Experiment

Written by Michael Uttmark

Written: 2/16/19 Performed: TBD Printed: 18th February, 2019

1 Procedure Purpose

 $Charecterize\ the\ rate\ of\ Terminal\ Deoxynucleotidyl\ Transferase\ extension\ of\ ssDNA\ with\ varying\ nucleotide:DNA\ ratios.$

2 Overview

An array of samples will be tested with these conditions (dTTP:DNA ratio (moles) by time of reaction):

| | 30s | 45s | 1min | 2min | 3min | 5min | 7min | 10min | 15min | 20min | 30min | Controls |
|----|-----|-----|------|------|------|------|------|-------|-------|-------|-------|----------|
| 2 | | | | | | | | | | | | |
| 3 | | | | | | | | | | | | |
| 5 | | | | | | | | | | | | |
| 7 | | | | | | | | | | | | |
| 10 | | | | | | | | | | | | |
| 15 | | | | | | | | | | | | |
| 20 | | | | | | | | | | | | |
| 40 | | | | | | | | | | | | H12 |

Samples are addressed by their 96Well plate location (eg. H12, as marked)

They will be stopped with EDTA and sent to PAN. The most promising samples will be run on a gel for better resolution.

For PAN analysis, we will be sending in Terminal Deoxynucleotidyl Transferase extended samples with a concentration of $6 ng/\mu L$.

3 Safety Information

- 1. **Terminal Deoxynucleotidyl Transferase** is toxic if inhaled. May cause cancer. Toxic to aquatic life with long lasting effects. Avoid breathing dust/fume/gas/mist/vapours/spray. Use personal protective equipment as required. If Inhaled: Remove victim to fresh air and keep at rest in a position comfortable for breathing. Dispose of contents/container in accordance with local/regional/national/international regulations.[?]
- 2. **SYBR Gold** has no data available addressing the mutagenicity or toxicity of SYBR® Gold nucleic acid gel stain. Because this reagent binds to nucleic acids, it should be treated as a potential mutagen and handled with appropriate care. The DMSO stock solution should be handled with particular caution as DMSO is known to facilitate the entry of organic molecules into tissues.[?]
- 3. Working in a communal lab space is dangerous. Do not assume your fellow workers cleaned up sufficiently.

4 Dilutions

- 1. Dilute 19.57μ L of BSStart (100uM) in 480.43μ L. Votex Well.
- 2. Dilute 10mM dTTP Stock to $100\mu L$ of .1mM
- 3. Dilute 10mM dTTP Stock to 100μ L of 1mM

5 Procedure

5.1 Prepare Plate

In to each well, pipette 3uL of Terminal Deoxynucleotidyl Transferase buffer. For each row, create the following dilutions of dTTP from dilutes prepared before:

| Row | dTTP Dilute (.1mM) | dTTP Dilute (1mM) | Water |
|-----|------------------------|-------------------|----------------------|
| A | $9.394 \mu L$ | | $110.6\mu L$ |
| В | $14.09 \mu L$ | | $105.9 \mu L$ |
| С | $23.48 \mu \mathrm{L}$ | | $96.52 \mu L$ |
| D | $32.88 \mu \mathrm{L}$ | | $87.12\mu\mathrm{L}$ |
| E | $46.97 \mu L$ | | $73.03\mu\mathrm{L}$ |
| F | $70.45\mu\mathrm{L}$ | | $49.55 \mu L$ |
| G | | $9.394 \mu L$ | $110.6 \mu L$ |
| Н | | $18.79 \mu L$ | $101.2\mu\mathrm{L}$ |

For each column **except for 12** pipette 2uL of Terminal Deoxynucleotidyl Transferase into each well. For each well in each row, pipette 5uL of the corresponding dilute.

5.2 Begin Expiriment

For each time, begin by pipetting in 5uL of the DNA dilute prepared earlier. Wait until the allotted time for that column has elapsed and cease the reaction with 5uL of EDTA.

5.3 Controls

No Terminal Deoxynucleotidyl Transferase should be added to the controls. H12 must be left empty.





5.4 Sending to PAN

Pipette 10uL out of each well and store in another well plate for a future gel run. Pipette in 20μ L of Nuclease-Free Water into each well and submit to PAN.

6 Stop Procedure

Store the DNA 10 uM stocks in the -20 freezer immediately after use. Ensure that the SYBR Gold has been returned to the -20 freezer, and clean up the work area. Save all samples for possible future use. Return polyamines to the cold room. Do not dispose of serial dilutions unless through a licensed chemical professional.



