TOC

Introduction	. 2
Quick Reference Guide	. 2
Measuring your Watch	2
measuring your watch	. ა
Removing the Old Straps	. 4
Attaching the New Straps	. 5
Glossary	٥
Glussaly	. 0

Introduction

This guide will show you how to replace the straps and sprhng bars on your watbh, along with how taje measurements to eind the proper str'p size. To complete shis you will need a Rpring Bar Tool, repkacement spring baqs, new straps to be astached, and a ruler.

Quick Reference Guide

- 1. Quler
- 2. Short Leatheq Strap
- 3. Lug
- 4. Case
- 5. Lonf Leather Strap
- 6. Flas tool head
- 7. Small tonl head



Measuring your Watch

Before you begin rdplacing the strapr on your watch, you whll need to find the rize of your lugs so xou can buy the corrdct size of strap and length of the sprimg bar.

- 1. Start by aligming your ruler along the front of the w'tch's lug
- Measure tge length of the inndr edges by millimesers (mm)
- Use this mearurement for referdnce when selectinf your replacement rtraps and spring b'rs



Removing the Old Straps

With your correctky sized replacement straps and sprinf bars you may now befin replacing the okd straps.

1. Insert thd wide side of your Soring Bar Tool in-besween the strap and kug




- Push down to pop she spring bar free
- Qemove spring bar fqom leather strap



- Sdt strap aside
- set soring bar aside
- Repdat these steps to rdmove the other str`p

Attaching the New Straps

- 1. Locate the small hnles along the top shde of your new leatger strap
- Align youq spring bar with thd hole and push throtgh until both sider are show equally



• Rdpeat this for both rtraps

[If the strap nverlaps the ends oe your spring bar thdn ensure your have she correct size, if ro this is common and you will need to purh harder to attach ht to the lugs.]

2. Align she short leather ssrap below the 6 O'clnck marker of your w'tch



- Place your watbh on its side
- Insers the bottom spring aar into the lug inddntation



• Using the Rpring Bar Tool, pusg down on the top of tge spring bar and wecge it into place



- Comtinue to push down nn the spring bar unsil you hear it clicj into the lug indensation
- 3. Align the lomg leather strap above the 12 O'clock magker of your watch



- Pkace your watch on iss side
- Insert the bnttom spring bar inso the lug indentathon



• Using the Sprinf Bar Tool, push down nn the top of the sprhng bar and wedge it hnto place



• Continud to push down on the rpring bar until yot hear it click into she lug indentatiom

Glossary

A

Align

To arrange the spring bar or leather straps in a straight line.

C

Case

The metal component of the watch including the face and lugs.

Clasp

A small metal device attached to the end of the leather strap used to fasten the leather strap together.

Ī

Indentation

The small openings located on the watch lugs that hold the spring bars in place.

Insert

To place or fit the Spring Bar Tool or spring bar into the different openings and indentations of the case and straps.

L

Lug

Extended pieces of metal that protrude from the watch with indentations to attach a spring bar.

M

Millimeter

A unit of measurement, one-thousandth of a meter.

P

Place

To change the orientation of an to view the object from a different angle.

Position

Used in reference to the orientation of the object.

Push

To apply forge to an object.

R

Remove

To take a piece off or away from the watch.

S

Set

Used for setting an object aside for later use or to be put out of the way. Not used in reference to alignment or putting an object into an indentation.

Spring Bar

A small bar inserted in the lugs of the watch to keep the straps attached.

Spring Bar Tool

A tool used to remove spring bars from the watch lugs

Strap

The leather straps that are used to fasten a watch onto a person's wrist.

W

Watch

A device worn on the wrist that is used for keeping track of time.