


WEBENCH® Design Report

VinMin = 10.0V VinMax = 22.0V Vout = 6.0V lout = 0.2A Device = LM43601PWPR Topology = Buck Created = 2024-11-18 17:06:33.048 BOM Cost = \$2.77 BOM Count = 13 Total Pd = 0.15W

Design: 7 LM43601PWPR LM43601PWPR 10V-22V to 6.00V @ 0.2A




- 1. The input capacitor included in the BOM only contains a small filter capacitor that should be placed near the IC. Depending on where the power supply is laid out in the system additional bulk capacitance may need to be added to filter the line ripple.
- 2. If there is no VinTyp specified, WEBENCH will use the VinMax value. To change the VinTyp value, click on the "Change Design Inputs" button under the Optimization Tuning knob. In some applications, while the design requires the input voltage to be a wide range, for a majority of the time, it is operating at a much lower voltage than the maximum input voltage. Sizing the inductor based on the maximum input voltage may yield an inductance much larger than typically needed, causing a larger footprint for the overall design. At the same time, components such as the input capacitor must be rated based on the maximum input voltage. WEBENCH now supports the use of this additional input voltage specification.


Electrical BOM


Name	Manufacturer	Part Number	Properties	Qty	Price	Footprint
Cbias	Taiyo Yuden	LMK212B7475KG-T Series= X7R	Cap= 4.7 uF ESR= 1.0 mOhm VDC= 10.0 V IRMS= 0.0 A	1	\$0.04	0805 7 mm ²
Cboot	MuRata	GRM155R60J474KE19D Series= X5R	Cap= 470.0 nF ESR= 1.0 mOhm VDC= 6.3 V IRMS= 0.0 A	1	\$0.01	0402 3 mm ²
Cff	Kemet	C0805C220J5GACTU Series= C0G/NP0	Cap= 22.0 pF ESR= 179.0 mOhm VDC= 50.0 V IRMS= 464.0 mA	1	\$0.01	0805 7 mm ²
Cin	TDK	C3225X7R1H106M250AC Series= X7R	Cap= 10.0 uF ESR= 1.0 mOhm VDC= 50.0 V IRMS= 5.0 A	1	\$0.27	1210 15 mm ²
Cinx	Taiyo Yuden	GMK212B7105KG-T Series= X7R	Cap= 1.0 uF ESR= 1.0 mOhm VDC= 35.0 V IRMS= 0.0 A	3	\$0.04	0805 7 mm ²
Cout	Panasonic	25SVPF27MX Series= SVPF	Cap= 27.0 uF ESR= 40.0 mOhm VDC= 25.0 V IRMS= 2.45 A	1	\$0.47	CAPSMT_62_E61 53 mm²
Cvcc	MuRata	GRM21BR71A225KA01L Series= X7R	Cap= 2.2 uF ESR= 4.22 mOhm VDC= 10.0 V IRMS= 2.08454 A	1	\$0.03	0805 7 mm ²
L1	Bourns	SRN6045-330M	L= 33.0 μH 188.0 mOhm	1	\$0.25	SRN6045 64 mm ²

Name	Manufacturer	Part Number	Properties	Qty	Price	Footprint
Rfbb	Yageo	RC0201FR-07205KL Series= ?	Res= 205.0 kOhm Power= 50.0 mW Tolerance= 1.0%	1	\$0.01	0201 2 mm ²
Rfbt	Vishay-Dale	CRCW04021M00FKED Series= CRCWe3	Res= 1000.0 kOhm Power= 63.0 mW Tolerance= 1.0%	1	\$0.01	0402 3 mm ²
U1	Texas Instruments	LM43601PWPR	Switcher	1	\$1.55	









Operating Values

#	Name	Value	Category	Description
1.	Cin IRMS	98.332 mA	Capacitor	Input capacitor RMS ripple current
2.	Cin Pd	9.669 µW	Capacitor	Input capacitor power dissipation
3.	Cout IRMS	77.445 mA	Capacitor	Output capacitor RMS ripple current
4.	Cout Pd	239.91 μW	Capacitor	Output capacitor power dissipation
5.	IC Iq Pd	110.0 μW	IC	IC Iq Pd
6.	IC Pd	137.8 mW	IC	IC power dissipation
7.	IC Tj	35.139 degC	IC	IC junction temperature
8.	ICThetaJA	38.9 degC/W	IC	IC junction-to-ambient thermal resistance
9.	lin Avg	60.956 mA	IC	Average input current
10.	L lpp	268.28 mA	Inductor	Peak-to-peak inductor ripple current
11.	L Pd	8.648 mW	Inductor	Inductor power dissipation

,,	Name	Nation .	0-1	Description
#	Name	Value	Category	Description
12.	Cin Pd	9.669 µW	Power	Input capacitor power dissipation
13.	Cout Pd	239.91 μW	Power	Output capacitor power dissipation
14.	IC Pd	137.8 mW	Power	IC power dissipation
15.	L Pd	8.648 mW	Power	Inductor power dissipation
16.	Total Pd	146.105 mW	Power	Total Power Dissipation
17.	BOM Count	13	System Information	Total Design BOM count
18.	Cross Freq	48.533 kHz	System Information	Bode plot crossover frequency
19.	Duty Cycle	27.687 %	System Information	Duty cycle
20.	Efficiency	89.105 %	System Information	Steady state efficiency
21.	FootPrint	239.0 mm ²	System Information	Total Foot Print Area of BOM components
22.	Frequency	500.0 kHz	System Information	Switching frequency
23.	Gain Marg	-22.122 dB	System Information	Bode Plot Gain Margin
24.	lout	200.0 mA	System Information	lout operating point
25.	Low Freq Gain	91.3 dB	System Information	Gain at 1Hz
26.	Mode	CCM	System Information	Conduction Mode
27.	Phase Marg	66.734 deg	System Information	Bode Plot Phase Margin
28.	Pout	1.2 W	System Information	Total output power
29.	Total BOM	\$2.77	System Information	Total BOM Cost
30.	Vin	22.0 V	System Information	Vin operating point
31.	Vout	6.0 V	System Information	Operational Output Voltage
32.	Vout Actual	5.972 V	System Information	Vout Actual calculated based on selected voltage divider resistors
33.	Vout Tolerance	3.978 %	System Information	Vout Tolerance based on IC Tolerance (no load) and voltage divider resistors if applicable
34.	Vout p-p	10.731 mV	System Information	Peak-to-peak output ripple voltage

Design Inputs

Name	Value	Description	
lout	200.0 m	Maximum Output Current	
VinMax	22.0	Maximum input voltage	
VinMin	10.0	Minimum input voltage	
Vout	6.0	Output Voltage	
base_pn	LM43601	Base Product Number	
source	DC	Input Source Type	
Ta	30.0	Ambient temperature	

WEBENCH® Assembly

Component Testing

Some published data on components in datasheets such as Capacitor ESR and Inductor DC resistance is based on conservative values that will guarantee that the components always exceed the specification. For design purposes it is usually better to work with typical values. Since this data is not always available it is a good practice to measure the Capacitance and ESR values of Cin and Cout, and the inductance and DC resistance of L1 before assembly of the board. Any large discrepancies in values should be electrically simulated in WEBENCH to check for instabilities and thermally simulated in WebTHERM to make sure critical temperatures are not exceeded.

Soldering Component to Board

If board assembly is done in house it is best to tack down one terminal of a component on the board then solder the other terminal. For surface mount parts with large tabs, such as the DPAK, the tab on the back of the package should be pre-tinned with solder, then tacked into place by one of the pins. To solder the tab town to the board place the iron down on the board while resting against the tab, heating both surfaces simultaneously. Apply light pressure to the top of the plastic case until the solder flows around the part and the part is flush with the PCB. If the solder is not flowing around the board you may need a higher wattage iron (generally 25W to 30W is enough).

Initial Startup of Circuit

It is best to initially power up the board by setting the input supply voltage to the lowest operating input voltage 10.0V and set the input supply's current limit to zero. With the input supply off connect up the input supply to Vin and GND. Connect a digital volt meter and a load if needed to set the minimum lout of the design from Vout and GND. Turn on the input supply and slowly turn up the current limit on the input supply. If the voltage starts to rise on the input supply continue increasing the input supply current limit while watching the output voltage. If the current increases on the input supply, but the voltage remains near zero, then there may be a short or a component misplaced on the board. Power down the board and visually inspect for solder bridges and recheck the diode and capacitor polarities. Once the power supply circuit is operational then more extensive testing may include full load testing, transient load and line tests to compare with simulation results.

Load Testing

The setup is the same as the initial startup, except that an additional digital voltmeter is connected between Vin and GND, a load is connected between Vout and GND and a current meter is connected in series between Vout and the load. The load must be able to handle at least rated output power + 50% (7.5 watts for this design). Ideally the load is supplied in the form of a variable load test unit. It can also be done in the form of suitably large power resistors. When using an oscilloscope to measure waveforms on the prototype board, the ground leads of the oscilloscope probes should be as short as possible and the area of the loop formed by the ground lead should be kept to a minimum. This will help reduce ground lead inductance and eliminate EMI noise that is not actually present in the circuit.



Design Assistance

- 1. Master key: C6AE7176C9723757[v1]
- 2. LM43601 Product Folder: http://www.ti.com/product/LM43601: contains the data sheet and other resources.

Important Notice and Disclaimer

TI provides technical and reliability data (including datasheets), design resources (including reference designs), application or other design advice, web tools, safety information, and other resources AS IS and with all faults, and disclaims all warranties. These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

Providing these resources does not expand or otherwise alter TI's applicable Terms of Sale or other applicable terms available either on ti.com or provided in conjunction with TI products.