TOSHIBA

Leading Innovation >>>

NETWORK CAMERA

Model: IK-WDO1A

URL Command Guide



See the user's manual (PDF file) contained in the CD-ROM for settings, operations and other information.

The application Acrobat Reader is needed to see PDF files. If you do not have this application, download it from the Website of Adobe Systems Incorporated.

For information on our latest products and peripheral devices, refer to the following web page:

■ http://www.toshibasecurity.com

The above URL is subject to change without prior notice. If the URL changes, refer to the Toshiba website (http://www.toshiba.com).

URL commands of IK-WD01A (ver. 1.03)

Overview

For some customers who already have their own web site or web control application, Network Camera/Video server can be easily integrated through convenient URLs. This section specifies the external HTTP based application programming interface. The HTTP based camera interface provides the functionality to request a single image, to control camera functions (PTZ, output relay etc.) and to get and set internal parameter values. The image and CGI-requests are handled by the built in Web server.

Style convention

In URL syntax and in descriptions of CGI parameters, a text within angle brackets denotes a content that is to be replaced with either a value or a string. When replacing the text string also the angle brackets shall be replaced. An example of this is the description of the name for the server, denoted with <servername> in the URL syntax description below, that is replaced with the string myserver in the URL syntax example, also below.

URL syntax' are written with the "**Syntax**:" word written in bold face followed by a box with the referred syntax as seen below. The name of the server is written as <servername>. This is intended to be replaced with the name of the actual server. This can either be a name, e.g., "mywebcam" or "thecam.adomain.net" or the associated IP number for the server, e.g., 192.168.0.220.

Syntax:

http://<servername>/cgi-bin/viewer/video.jpg

Description of returned data is written with "**Return:**" in bold face followed by the returned data in a box. All data returned as HTTP formatted, i.e., starting with the string HTTP is line separated with a Carriage Return and Line Feed (CRLF) printed as \r\n.

Return:

HTTP/1.0 < HTTP code > < HTTP text > \r\n

URL syntax examples are written with "**Example:**" in bold face followed by a short description and a light grey box with the example.

Example: request a single snapshot image

http://mywebserver/cgi-bin/viewer/video.jpg

General CGI URL syntax and parameters

CGI parameters are written in lower-case and as one word without any underscores or other separators. When the CGI request includes internal camera parameters, the internal parameters must be written exactly as they are named in the camera or video server. The CGIs are organized in function related directories under the cgi-bin directory. The file extension of the CGI is required.

Syntax:

http://<servername>/cgi-bin/<subdir>[/<subdir>...]/<cgi>.<ext>[?<parameter>=<value>[...]]

Example: Setting digital output #1 to active

http://mywebserver/cgi-bin/dido/setdo.cgi?dol=1

Security level

SECURITY	SUB-DIRECTORY	DESCRIPTION
LEVEL		
0	anonymous	Unprotected.
1 [viewer]	anonymous, viewer,	1. Can view, listen, talk to camera
	dido, camctrl	2. Can control dido of camera
4 [operator]	anonymous, viewer,	Operator's access right can modify most of
	dido, camctrl,	camera's parameters except some privilege and
	operator	network options
6 [admin]	anonymous, viewer,	Administrator's access right can fully control the
	dido, camctrl,	camera's operation.
	operator, admin	
7	N/A	Internal parameters. Unable to be changed by
		any external interface.

Get server parameter values

Note: The access right depends on the URL directory.

Method: GET/POST

Syntax:

```
http://<servername>/cgi-bin/anonymous/getparam.cgi?[<parameter>]
[&<parameter>...]

http://<servername>/cgi-bin/viewer/getparam.cgi?[<parameter>]
[&<parameter>...]

http://<servername>/cgi-bin/operator/getparam.cgi?[<parameter>]
[&<parameter>...]

http://<servername>/cgi-bin/admin/getparam.cgi?[<parameter>]
[&<parameter>...]
```

where the *<parameter>* should be *<group>*[_*<name>*] or *<group>*[. *<name>*] If you do not specify the any parameters, all the parameters on the server will be returned. If you specify only *<group>*, the parameters of related group will be returned.

When query parameter values, the current parameter value are returned. Successful control request returns parameter pairs as follows.

Return:

HTTP/1.0 200 OK\r\n

Content-Type: text/html\r\n Context-Length: <length>\r\n

\r\n

<parameter pair>

where <parameter pair> is <parameter>=<value>\r\n [<parameter pair>]

<length> is the actual length of content.

Example: request IP address and it's response

Request:

http://192.168.0.123/cgi-bin/admin/getparam.cgi?network_ipaddress

Response:

HTTP/1.0 200 OK\r\n

Content-Type: text/html\r\n Context-Length: 33\r\n

 $r\n$

network.ipaddress=192.168.0.123\r\n

Set server parameter values

Note: The access right depends on the URL directory.

Method: GET/POST

Syntax:

http://<*servername*>/cgi-bin/anonymous/setparam.cgi? *<parameter>=<value>* [&<parameter>=<value>...][&update=<value>][&return=<return page>]

http://<servername>/cgi-bin/viewer/setparam.cgi? <parameter>=<value>
[&<parameter>=<value>...][&update=<value>] [&return=<return page>]

http://<servername>/cgi-bin/operator/setparam.cgi? <parameter>=<value>
[&<parameter>=<value>...][&update=<value>] [&return=<return page>]

http://<*servername*>/cgi-bin/admin/setparam.cgi? *<parameter>=<value>* [&<parameter>=<value>...][&update=<value>] [&return=<return page>]

PARAMETER	VALUE	DESCRIPTION
<group>_<name></name></group>	value to assigned	Assign < value > to the parameter < group > _ < name >
update	<boolean></boolean>	set to 1 to actually update all fields (no need to use
		update parameter in each group)
return	<return page=""></return>	Redirect to the page <return page=""> after the parameter is assigned. The <return page=""> can be a full URL path or relative path according the the current path. If you omit this parameter, it will redirect to an empty page.</return></return>
		(note: The return page can be a general HTML file(.htm, .html) or a unique server script executable (.vspx) file. It can not be a CGI command. It can not have any extra parameters. This parameter must be put at end of parameter list)

Return:

HTTP/1.0 200 OK\r\n

Content-Type: text/html\r\n Context-Length: <length>\r\n

\r\n

<parameter pair>

where <parameter pair> is <parameter>=<value>\r\n

[<parameter pair>]

Only the parameters that you set and readable will be returned.

Example: Set the IP address of server to 192.168.0.123

Request:

http://myserver/cgi-bin/admin/setparam.cgi?network_ipaddress=192.168.0.123

Response:

HTTP/1.0 200 OK\r\n

Content-Type: text/html\r\n Context-Length: 33\r\n

 $r\n$

network.ipaddress=192.168.0.123\r\n

Available parameters on the server

Valid values:

VALID VALUES	DESCRIPTION
string[<n>]</n>	Text string shorter than 'n' characters
password[<n>]</n>	The same as string but display '*' instead
integer	Any number between $(-2^{31} - 1)$ and $(2^{31} - 1)$
positive integer	Any number between 0 and (2 ³² – 1)
<m> ~ <n></n></m>	Any number between 'm' and 'n'
domain name[<n>]</n>	A string limited to contain a domain name shorter than 'n'
	characters (eg. www.tsb.com)
email address [<n>]</n>	A string limited to contain a email address shorter than 'n'
	characters (eg. joe@www.tsb.com)
ip address	A string limited to contain an ip address (eg. 192.168.1.1)

mac address	A string limited to contain mac address without hyphen or colon connected
boolean	A boolean value 1 or 0 represents [Yes or No], [True or False], [Enable or Disable].
<value1>, <value2>, <value3>, </value3></value2></value1>	Enumeration. Only given values are valid.
blank	A blank string
everything inside <>	As description

NOTE: The camera should prevent to restart when parameter changed.

Group: system

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
hostname	string[40]	1/6	host name of server
date	<yyyy dd="" mm="">, keep, auto</yyyy>	6/6	Current date of system. Set to 'keep' keeping date unchanged. Set to 'auto' to use NTP to synchronize date.
time	<hh:mm:ss>, keep, auto</hh:mm:ss>	6/6	Current time of system. Set to 'keep' keeping time unchanged. Set to 'auto' to use NTP to synchronize time.
ntp	<domain name>, <ip address="">, <blank></blank></ip></domain 	6/6	NTP server
timezoneindex	-480 ~ 520	6/6	Indicate timezone and area -480: GMT-12:00 Eniwetok, Kwajalein -440: GMT-11:00 Midway Island, Samoa -400: GMT-10:00 Hawaii -360: GMT-09:00 Alaska -320: GMT-08:00 Las Vegas, San_Francisco, Vancouver -280: GMT-07:00 Mountain Time, Denver -281: GMT-07:00 Arizona -240: GMT-06:00 Central America, Central Time,

Mexico City, Saskatchewan -200: GMT-05:00 Eastern Time, New York, Toronto -201: GMT-05:00 Bogota, Lima, Quito, Indiana -160: GMT-04:00 Atlantic Time, Canada, Caracas ,La Paz, Santiago -140: GMT-03:30 Newfoundland GMT-03:00 -120: Brasilia, Buenos Aires, Georgetown, Greenland -80: GMT-02:00 Mid-Atlantic -40: GMT-01:00 Azores, Cape_Verde_IS. 00: GMT Casablanca, Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London 40: GMT 01:00 Amsterdam, Berlin, Rome, Stockholm, Vienna, Madrid, Paris 41: GMT 01:00 Warsaw. Budapest, Bern 80: **GMT** 02:00 Athens, Helsinki, Istanbul, Riga 81: GMT 02:00 Cairo 82: GMT 02:00 Lebanon, Minsk 83: GMT 02:00 Israel 120: GMT 03:00 Baghdad, Kuwait, Riyadh, Moscow, St. Petersburg, Nairobi 121: GMT 03:00 Iraq 140: GMT 03:30 Tehran 160: GMT 04:00 Abu Dhabi, Muscat, Baku, Tbilisi, Yerevan 180: GMT 04:30 Kabul 200: GMT 05:00 Ekaterinburg, Islamabad, Karachi, Tashkent 220: GMT 05:30 Calcutta, Chennai, Mumbai,

updateinterval	0,	6/6	New Delhi 230: GMT 05:45 Kathmandu 240: GMT 06:00 Almaty, Novosibirsk, Astana, Dhaka, Sri Jayawardenepura 260: GMT 06:30 Rangoon 280: GMT 07:00 Bangkok, Hanoi, Jakarta, Krasnoyarsk 320: GMT 08:00 Beijing, Chongging, Hong Kong, Kuala Lumpur, Singapore, Taipei 360: GMT 09:00 Osaka, Sapporo, Tokyo, Seoul, Yakutsk 380: GMT 09:30 Adelaide, Darwin 400: GMT 10:00 Brisbane, Canberra, Melbourne, Sydney, Guam, Vladivostok 440: GMT 11:00 Magadan, Solomon Is., New Caledonia 480: GMT 12:00 Aucklan, Wellington, Fiji, Kamchatka, Marshall Is. 520: GMT 13:00 Nuku'Alofa 0 to Disable automatic time
	3600, 86400, 604800, 2592000		adjustment, otherwise, it means the seconds between NTP automatic update interval.
restore	0, <positive integer></positive 	7/6	Restore the system parameters to default value. Restart the server after <value> seconds.</value>
reset	0, <positive integer></positive 	7/6	Restart the server after <value> seconds.</value>
restoreexceptnet	0, <positive integer></positive 	7/6	Restore the system parameters to default value except (ipaddress, subnet, router, dns1, dns2, ddns settings). Restart the server after <value> seconds.</value>

SubGroup of **system**: **info** (The fields in this group are unchangeable.)

NAME	VALUE		DESCRIPTION
		(get/set)	
modelname	string[40]	0/7	model name of server
serialnumber	<mac< td=""><td>0/7</td><td>12 characters mac address</td></mac<>	0/7	12 characters mac address
	address>		without hyphen connected
firmwareversion	string[40]	0/7	The version of firmware,
			including model, company, and
			version number in the format
			<model-brand-version></model-brand-version>

Group: status

Sidapi Ctatas			
NAME	VALUE	SECURITY	DESCRIPTION
		(get/set)	
di_i<0~(ndi-1)>	<boolean></boolean>	1/7	0 => Inactive, normal
			1 => Active, triggered
do_i<0~ndi-1)>	<boolean></boolean>	1/7	0 => Inactive, normal
			1 => Active, triggered
onlinenum_rtsp	integer	6/7	current RTSP connection
			numbers
onlinenum_httppush	integer	6/7	current HTTP push server
			connection numbers

Group: $di_i<0~(ndi-1)>$

Choop: al_i vo (iio	6.0ap: ai_1.0 (.i.ai 1)			
NAME	VALUE	SECURITY	DESCRIPTION	
		(get/set)		
normalstate	high,	1/1	indicate whether open circuit	
	low		or closed circuit represents	
			inactive status	

Group: **do_i<0~(ndo-1)>**

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
normalstate	open, grounded	1/1	indicate whether open circuit or closed circuit represents inactive status

Group: security

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
user_i0_name	string[64]	6/7	User's name of root
user_i<1~20>_name	string[64]	6/7	User's name
user_i0_pass	string [64]	6/6	Root's password
user_i<1~20>_pass	string [64]	7/6	User's password
user_i0_privilege	admin	6/7	Root's privilege
user_i<1~20>_ privilege	view, operator, admin	6/6	User's privilege.

Group: network

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
type	lan, pppoe	6/6	Network connection type
resetip	<boolean></boolean>	6/6	1 => get ipaddress, subnet, router, dns1, dns2 from DHCP server at next reboot 0 => use preset ipaddress, subnet, rounter, dns1, and dns2
ipaddress	<ip address=""></ip>	6/6	IP address of server
subnet	<ip address=""></ip>	6/6	subnet mask
router	<ip address=""></ip>	6/6	default gateway
dns1	<ip address=""></ip>	6/6	primary DNS server
dns2	<ip address=""></ip>	6/6	secondary DNS server
wins1	<ip address=""></ip>	6/6	primary WINS server
wins2	<ip address=""></ip>	6/6	secondary WINS server

Subgroup of **network: sip**

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
port	5060, 1025 ~ 65535	6/6	SIP port

Subgroup of network: ftp

NAME	VA	LUE	SECURITY	DESCRIPTION
			(get/set)	
port	21	ı	6/6	local ftp server port
	10	25~65535		

Subgroup of **network**: **http**

<u> </u>	Cabgroup of Hottoric Hetp				
NAME	VALUE	SECURITY (get/set)	DESCRIPTION		
port	80, 1025 ~ 65535	6/6	HTTP port		
alternateport	1025~65535	6/6	Alternative HTTP port		
authmode	basic, digest	1/6	HTTP authentication mode		
s0_accessname	string[32]	1/6	Http server push access name for stream 1		
s1_accessname	string[32]	1/6	Http server push access name for stream 2		

Subgroup of **network**: **rtsp**

Subgroup of Hetwo	Subgroup of Hetwork. Itsp				
NAME	VALUE	SECURITY (get/set)	DESCRIPTION		
port	554, 1025 ~ 65535	6/6	RTSP port		
authmode	disable, basic, digest	1/6	RTSP authentication mode		
s0_accessname	string[32]	1/6	RTSP access name for stream1		
s1_accessname	string[32]	1/6	RTSP access name for stream2		

Subgroup of rtsp s<0~(n-1)>: multicast, n is stream count

Subgroup of risp_3 to the rise marries in its stream count				
NAME	VALUE	SECURITY (get/set)	DESCRIPTION	
alwaysmulticast	<boolean></boolean>	4/4	Enable always multicast	
ipaddress	<ip address=""></ip>	4/4	Multicast IP address	
videoport	1025 ~ 65535	4/4	Multicast video port	
audioport	1025 ~ 65535	4/4	Multicast audio port	
ttl	1 ~ 255	4/4	Mutlicast time to live value	

Subgroup of **network**: **rtp**

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
videoport	1025 ~ 65535	6/6	video channel port for RTP
audioport	1025 ~ 65535	6/6	audio channel port for RTP

Subgroup of **network**: **pppoe**

and group artificities proper				
NAME	VALUE	SECURITY	DESCRIPTION	
		(get/set)		
user	string[128]	6/6	PPPoE account user name	
pass	password[64]	6/6	PPPoE account password	

Group: ipfilter

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
allow_i<0~9>_star t	1.0.0.0 ~ 255.255.255. 255	6/6	Allowed starting IP address for RTSP connection
allow_i<0~9>_end	1.0.0.0 ~ 255.255.255. 255	6/6	Allowed ending IP address for RTSP connection
deny_i<0~9>_start	1.0.0.0 ~ 255.255. 255	6/6	Denied starting IP address for RTSP connection
deny_i<0~9>_end	1.0.0.0 ~ 255.255.255. 255	6/6	Denied ending IP address for RTSP connection

Group: videoin

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
cmosfreq	50, 60	4/4	CMOS frequency
whitebalance	auto, indoor, fluorescent, outdoor	4/4	auto, auto white balance indoor, 3200K fluorescent, 5500K outdoor, > 5500K

Group: videoin_c<0~(n-1)> for n channel products, m is stream number

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
color	0, 1	4/4	0 =>monochrome 1 => color

flip	<boolean></boolean>	4/4	flip the image
mirror	<boolean></boolean>	4/4	mirror the image
text	string[16]	1/4	enclosed caption
imprinttimestamp	<boolean></boolean>	4/4	Overlay time stamp on video
maxexposure	1~120	4/4	Maximum exposure time
s<0~(m-1)>_codec type	mpeg4, mjpeg	4/4	video codec type
s<0~(m-1)>_resol ution	176x144, 320x240, 640x480,	4/4	Video resolution in pixel
s<0~(m-1)>_mpeg 4_intraperiod	250, 500, 1000, 2000, 3000, 4000	4/4	The period of intra frame in milliseconds
s<0~(m-1)>_mpeg 4_ratecontrolmode	cbr, vbr	4/4	cbr, constant bitrate vbr, fix quality
s<0~(m-1)>_mpeg 4_quant	1, 2, 3, 4, 5	4/4	quality of video when choosing vbr in "ratecontrolmode". 1 is worst quality and 5 is the best quality.
s<0~(m-1)>_mpeg 4_bitrate	20000, 30000, 40000, 50000, 64000, 128000, 256000, 384000, 512000, 768000, 1000000, 1200000, 1500000, 2000000, 4000000	4/4	set bit rate in bps when choose cbr in "ratecontrolmode"
s<0~(m-1)>_mpeg 4_maxframe	1, 2, 3, 5, 10, 15, 20, 25, 30 (only for 60Hz)	4/4	set maximum frame rate in fps
s<0~(m-1)>_mjpe g_quant	1 ~ 5	4/4	quality of jpeg video. 1 is worst quality and 5 is the best quality.
s<0~(m-1)>_mjpe	1~25,	4/4	set maximum frame rate in

g_maxframe	26~30 (only for 60Hz)		fps (for JPEG)
s<0~(m-1)>_forcei	1	7/6	Force I frame

Group: audioin c<0~(n-1)> for n channel products

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
mute	0, 1	4/4	Enable audio mute
gain	0~31	4/4	Gain of input
boostmic	0, 1	4/4	Enable microphone boost
s<0~(m-1)>_codectype	aac4, gamr	4/4	set audio codec type for input
s<0~(m-1)>_aac4_bitrate	16000, 32000, 48000, 64000, 96000, 128000	4/4	set AAC4 bitrate in bps
s<0~(m-1)>_gamr_bitrate	4750, 5150, 5900, 6700, 7400, 7950, 10200, 12200	4/4	set AMR bitrate in bps

Group: image_c<0~(n-1)> for n channel products

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
brightness	-5 ~ 5	4/4	Adjust brightness of image
			according to mode settings.
saturation	-5 ~ 5	4/4	Adjust saturation of image
			according to mode settings.
contrast	-5 ~ 5	4/4	Adjust contrast of image
			according to mode settings.
sharpness	-3 ~ 3	4/4	Adjust sharpness of image
			according to mode settings.

Group: motion_c<0~(n-1)> for n channel product

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
enable	<boolean></boolean>	4/4	enable motion detection
win_i<0~2>_enable	<boolean></boolean>	4/4	enable motion window 1~3
win_i <0~2>_name	string[14]	4/4	name of motion window 1~3
win_i <0~2>_left	0 ~ 320	4/4	Left coordinate of window
			position.
win_i <0~2>_top	0 ~ 240	4/4	Top coordinate of window
			position.
win_i <0~2>_width	0 ~ 320	4/4	Width of motion detection
			window.
win_i<0~2>_height	0 ~ 240	4/4	Height of motion detection
			window.
win_i<0~2>_objsize	0 ~ 100	4/4	Percent of motion detection
			window.
win_i<0~2>_sensitivity	0 ~ 100	4/4	Sensitivity of motion detection
			window.

Group: ddns

Oloupi uuilo			
NAME	VALUE	SECURITY (get/set)	DESCRIPTION
enable	<boolean></boolean>	6/6	Enable or disable the dynamic dns.
provider	NoIP ChangeIP	6/6	NoIP => No-IP.com ChangeIP => ChangeIP.com
<pre><pre><pre><pre>orovider>_hostn ame</pre></pre></pre></pre>	string[128]	6/6	Your dynamic camera name.
<pre><pre><pre><pre><pre>ameemail</pre></pre></pre></pre></pre>	string[64]	6/6	Your user name to login ddns service provider
<pre><pre><pre><pre>provider>_pass wordkey</pre></pre></pre></pre>	string[64]	6/6	Your password to login ddns service provider

Group: upnppresentation

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
enable	<boolean></boolean>	6/6	Enable or disable the UPNP presentation service.

Group: upnpportforwarding

ereap: apripeerrer			
NAME	VALUE	SECURITY	DESCRIPTION
		(get/set)	
enable	<boolean></boolean>	6/6	Enable or disable the UPNP
			port forwarding service.
upnpnatstatus	0~3	6/7	The status of UPNP port
			forwarding, used internally.
			0 is OK, 1 is FAIL, 2 is no IGD
			router, 3 is no need to do port
			forwarding

Group: syslog

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
enableremotelog	<boolean></boolean>	6/6	enable remote log
serverip	<ip address></ip 	6/6	Log server IP address
serverport	514, 1025~65535	6/6	Server port used for log
level	0~7	6/6	The levels to distinguish the importance of information.

0: LOG_EMERG
1: LOG_ALERT
2: LOG_CRIT
3: LOG_ERR
4: LOG_WARNING
5: LOG_NOTICE
6: LOG_INFO
7: LOG_DEBUG

Group: privacymask_c<0~(n-1)> for n channel product

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
enable	<boolean></boolean>	4/4	Enable the privacy mask
win_i<0~4>_enable	<boolean></boolean>	4/4	Enable the privacy mask window
win_i<0~4>_name	string[14]	4/4	The name of privacy mask window
win_i<0~4>_left	0 ~ 320/352	4/4	Left coordinate of window position.
win_i<0~4>_top	0 ~ 240/288	4/4	Top coordinate of window position.
win_i<0~4>_width	0 ~ 320/352	4/4	Width of privacy mask window
win_i<0~4>_height	0 ~ 240/288	4/4	Height of privacy mask window

Group: capability

NAME	VALUE	SECURITY (get/set)	DESCRIPTION
api_http_version	0200a	0/7	The HTTP API version.
bootuptime	<positive integer=""></positive>	0/7	The server bootup time
ndi	0, <positive integer></positive 	0/7	number of digital input
ndo	0, <positive integer></positive 	0/7	number of digital output
naudioin	0, <positive integer></positive 	0/7	number of audio input

naudioout		0/7	number of guide output
naudioout	0,	0//	number of audio output
	<positive< td=""><td></td><td></td></positive<>		
	integer>		
nvideoin	<positive< td=""><td>0/7</td><td>number of video input</td></positive<>	0/7	number of video input
	integer>		
nmediastream	<positive< td=""><td>0/7</td><td>number of media stream per</td></positive<>	0/7	number of media stream per
	integer>		channel
nvideosetting	<positive< td=""><td>0/7</td><td>number of video settings per</td></positive<>	0/7	number of video settings per
	integer>		channel
naudiosetting	<positive< td=""><td>0/7</td><td>number of audio settings per</td></positive<>	0/7	number of audio settings per
Haddiosetting	integer>	077	channel
nuart		0/7	number of UART interface
Tiuai t	0,	0//	number of UART interface
	<pre><positive< pre=""></positive<></pre>		
	integer>	<u> </u>	
protocol_https	< boolean >	0/7	indicate whether to support
			http over SSL
protocol_rtsp	< boolean >	0/7	indicate whether to support
protocoi_rtsp	< DOULEALL >	0//	1
		0.77	rtsp
protocol_sip	<boolean></boolean>	0/7	indicate whether to support
			sip
protocol_maxconnection	<positive< td=""><td>0/7</td><td>The maximum allowed</td></positive<>	0/7	The maximum allowed
	integer>		simultaneous connections
protocol_rtp_multicast_	<boolean></boolean>	0/7	indicate whether to support
scalable			scalable multicast
protocol_rtp_multicast_	<boolean></boolean>	0/7	indicate whether to support
backchannel	1000104111		backchannel multicast
protocol_rtp_tcp	<boolean></boolean>	0/7	indicate whether to support
protocol_rtp_tcp	< boolean>	077	rtp over tcp
protocol rtp bttp	<boolean></boolean>	0/7	
protocol_rtp_http	<pre><publicall></publicall></pre>	0//	indicate whether to support
		0.47	rtp over http
protocol_spush_mjpeg	<boolean></boolean>	0/7	indicate whether to support
			server push motion jpeg

Group: event_i<0~2>

PARAMETER	VALUE	SECURITY (get/set)	DESCRIPTION
name	string[40]	6/6	The identification of this entry
enable	0, 1	6/6	To enable or disable this event.
priority	0, 1, 2	6/6	Indicate the priority of this event. "0" indicates low priority. "1" indicates normal priority. "2" indicates high priority.
delay	1~999	6/6	Delay seconds before detect next event.
trigger	boot, di, motion, seq,	6/6	Indicate the trigger condition. "boot" indicates system boot. "di" indicates digital input. "motion" indicates video motion detection. "seq" indicates periodic condition.
di	<integer></integer>	6/6	Indicate which di detected. This field is required when trigger condition is "di". One bit represents one digital input. The LSB indicates DI 0.
mdwin	<integer></integer>	6/6	Indicate which motion detection windows detected. This field is required when trigger condition is "md". One bit represents one window. The LSB indicates the 1 st window. For example, to detect the 1 st and 3 rd windows, set mdwin as 5.
inter	1~999	6/6	Interval of period snapshot in minute. This field is used when trigger condition is "seq".

weekday	<interger></interger>	6/6	Indicate which weekday is scheduled.
			One bit represents one weekday.
			The bit0 (LSB) indicates Saturday.
			The bit1 indicates Friday.
			The bit2 indicates Thursday.
			The bit3 indicates Wednesday.
			The bit4 indicates Tuesday.
			The bit5 indicates Monday.
			The bit6 indicates Sunday.
			For example, to detect events on
			Friday and Sunday, set weekday as 66.
begintime	hh: mm	6/6	Begin time of weekly schedule.
endtime	hh: mm	6/6	End time of weekly schedule.
			(00:00 ~ 24:00 means always.)
action_do_i<0~(nd	0, 1	6/6	To enable or disable trigger digital
o-1)>_enable			output.
action_do_i<0~(nd	1~999	6/6	The duration of digital output is
o-1)>_duration			triggered in seconds.
action_server_i<0~	0, 1	6/6	To enable or disable this server action.
4>_enable			The default value is 0.
action_server_i<0~	NULL, 0~4	6/6	The index of attached media.
4>_media			

Group: server_i<0~4>

Group, server_i<0			
PARAMETER	VALUE	SECURITY (get/set)	DESCRIPTION
name	string[40]	6/6	The identification of this entry
type	email, ftp, http, ns	6/6	Indicate the server type. "email" is email server. "ftp" is ftp server. "http" is http server. "ns" is network storage.
http_url	string[128]	6/6	The url of http server to upload.
http_username	string[64]	6/6	The username to login in the server.
http_passwd	string[64]	6/6	The password of the user.
ftp_address	string[128]	6/6	The ftp server address
ftp_username	string[64]	6/6	The username to login in the server.
ftp_passwd	string[64]	6/6	The password of the user.

ftp_port	0~65535	6/6	The port to connect the server.
ftp_location	string[128]	6/6	The location to upload or store the media.
ftp_passive	0, 1	6/6	To enable or disable the passive mode. 0 is to disable the passive mode. 1 is to enable the passive mode.
email_address	string[128]	6/6	The email server address
email_username	string[64]	6/6	The username to login in the server.
email_passwd	string[64]	6/6	The password of the user.
email_senderemail	string[128]	6/6	The email address of sender.
email_recipientemail	string[128]	6/6	The email address of recipient.
ns_location	string[128]	6/6	The location to upload or store the media.
ns_username	string[64]	6/6	The username to login in the server.
ns_passwd	string[64]	6/6	The password of the user.
ns_workgroup	string[64]	6/6	The workgroup for network storage.

Group: media_i<0~4>

PARAMETER	VALUE	SECURITY (get/set)	DESCRIPTION
name	string[40]	6/6	The identification of this entry
type	snapshot, systemlog videoclip	6/6	The media type to send to the server or store by the server.
snapshot_source	<integer></integer>	6/6	Indicate the source of media stream. 0 means the first stream. 1 means the second stream and etc.
snapshot_prefix	string[16]	6/6	Indicate the prefix of the filename.
snapshot_datesuffix	0, 1	6/6	To add date and time suffix to filename or not. 1 means to add date and time suffix. 0 means not to add it.
snapshot_preevent	0 ~ 7	6/6	It indicates the number of pre-event images.
snapshot_postevent	0 ~ 7	6/6	The number of post-event images.

videoclip_source	<integer></integer>	6/6	Indicate the source of media stream. 0 means the first stream. 1 means the second stream and etc.
videoclip_prefix	string[16]	6/6	Indicate the prefix of the filename.
videoclip_preevent	0 ~ 9	6/6	It indicates the time of pre-event recording in seconds.
videoclip_maxduration	1 ~ 10	6/6	The time of maximum duration of one video clip in seconds.
videoclip_maxsize	50 ~ 1500	6/6	The maximum size of one video clip file in Kbytes.

Group: recording_i<0~1>

PARAMETER	VALUE	(get/set)	DESCRIPTION
name	string[40]	6/6	The identification of this entry
enable	0, 1	6/6	To enable or disable this recoding.
priority	0, 1, 2	6/6	Indicate the priority of this recoding. "0" indicates low priority. "1" indicates normal priority. "2" indicates high priority.
source	<integer></integer>	6/6	Indicate the source of media stream. 0 means the first stream. 1 means the second stream and etc.
weekday	<interger></interger>	6/6	Indicate which weekday is scheduled. One bit represents one weekday. The bit0 (LSB) indicates Saturday. The bit1 indicates Friday. The bit2 indicates Thursday. The bit3 indicates Wednesday. The bit4 indicates Tuesday. The bit5 indicates Monday. The bit6 indicates Sunday. For example, to detect events on Friday and Sunday, set weekday as 66.
begintime	hh: mm	6/6	Begin time of weekly schedule.
endtime	hh: mm	6/6	End time of weekly schedule. (00:00~24:00 means always.)
prefix	string[16]	6/6	Indicate the prefix of the filename.
cyclesize	<integer></integer>	6/6	The maximum size for cycle recording in Kbytes.

maxfilesize	200~6000	6/6	The max size for one file in Kbytes
dest	0~4		The destination to store the recording data. "0~4" means the index of network storage.

Drive the digital output

Note: This request requires the privilege of viewer.

Method: GET/POST

Syntax:

http://<servername>/cgi-bin/dido/setdo.cgi?do1=<state>[&do2=<state>] [&do3=<state>][&do4=<state>][&return=<return page>]

Where state is 0, 1. "0" means inactive or normal state while "1" means active or triggered state.

PARAMETER	VALUE	DESCRIPTION
do <num></num>	0, 1	0 – inactive, normal state
		1 – active, triggered state
return	<return page=""></return>	Redirect to the page <return page=""> after the parameter is assigned. The <return page=""> can be a full URL path or relative path according the the current path. If you omit this parameter, it will redirect to an empty page.</return></return>

Example: Drive the digital output 1 to triggered state and redirect to an empty page http://myserver/cgi-bin/dido/setdo.cgi?do1=1

Query status of the digital input

Note: This request requires the privilege of viewer.

Method: GET/POST

Syntax:

http://<servername>/cgi-bin/dido/getdi.cgi?[di0][&di1][&di2][&di3]

If no parameter is specified, all the status of digital input will be returned.

Return:

HTTP/1.0 200 OK\r\n

Content-Type: text/plain\r\n Content-Length: <length>\r\n

\r\n

[di0= <state>]\r\n [di1= <state>]\r\n [di2= <state>]\r\n [di3= <state>]\r\n

where <state> can be 0 or 1.

Example: Query the status of digital input 1

Request:

http://myserver/cgi-bin/dido/getdi.cgi?dil

Response:

HTTP/1.0 200 OK\r\n

Content-Type: text/plain\r\n

Content-Length: 7\r\n

\r\n di1=1\r\n

Query status of the digital output

Note: This request requires the privilege of viewer.

Method: GET/POST

Syntax:

http://<servername>/cgi-bin/dido/getdo.cgi?[do0][&do1][&do2][&do3]

If no parameter is specified, all the status of digital output will be returned.

Return:

HTTP/1.0 200 OK\r\n

Content-Type: text/plain\r\n Content-Length: <length>\r\n

\r\n

[do0= < state>]\r\n [do1= < state>]\r\n [do2= < state>]\r\n [do3= < state>]\r\n

where < state > can be 0 or 1.

Example: Query the status of digital output 1

Request:

http://myserver/cgi-bin/dido/getdo.cgi?do1

Response:

HTTP/1.0 200 OK\r\n

Content-Type: text/plain\r\n Content-Length: 7\r\n

\r\n do1=1\r\n

Capture single snapshot

Note: This request require normal user privilege

Method: GET/POST

Syntax:

http://<*servername*>/cgi-bin/viewer/video.jpg?[channel=<value>][&resolution=<value>]

[&quality=<value>]

If the user requests the size larger than all stream setting on the server, this request will failed!

PARAMETER	VALUE	DEFAULT	DESCRIPTION
channel	0~(n-1)	0	the channel number of video source
	<available resolution=""></available>	0	The resolution of image
quality	1~5	3	The quality of image

Server will return the most up-to-date snapshot of selected channel and stream in JPEG format. The size and quality of image will be set according to the video settings on the server.

Return:

HTTP/1.0 200 OK\r\n

Content-Type: image/jpeg\r\n [Content-Length: <image size>\r\n]

dinary JPEG image data>

Account management

Note: This request requires administrator privilege

Method: GET/POST

Syntax:

http://<servername>/cgi-bin/admin/editaccount.cgi?
method=<value>&username=<name>[&userpass=<value>][&privilege=<value>]
[&privilege=<value>][...][&return=<return page>]

PARAMETER	VALUE	DESCRIPTION
method		Add an account to server. When using this method, "username" field is necessary. It will use default value of other fields if not specified.
		Remove an account from server. When using this method, "username" field is necessary, and others are ignored.

	edit	Modify the account password and privilege. When using this method, "username" field is necessary, and other fields are optional. If not specified, it will keep original settings.
username	<name></name>	The name of user to add, delete or edit
userpass	<value></value>	The password of new user to add or that of old user to modify. The default value is an empty string.
privilege	<value></value>	The privilege of user to add or to modify.
	viewer	viewer's privilege
	operator	operator's privilege
	admin	administrator's privilege
return	<return page=""></return>	Redirect to the page <return page=""> after the parameter is assigned. The <return page=""> can be a full URL path or relative path according the the current path. If you omit this parameter, it will redirect to an empty page.</return></return>

System logs

Note: This request require administrator privilege

Method: GET/POST

Syntax:
http://<servername>/cgi-bin/admin/syslog.cgi

Server will return the up-to-date system log.

Return:

HTTP/1.0 200 OK\r\n

Content-Type: text/plain\r\n

Content-Length: <syslog length>\r\n

\r\n

<system log information>\r\n

Upgrade firmware

Note: This request requires administrator privilege

Method: POST

Syntax:

http://<servername>/cgi-bin/admin/upgrade.cgi

Post data:

fimage=<file name>[&return=<return page>]\r\n

\r\n

<multipart encoded form data>

Server will accept the upload file named <file name> to be upgraded the firmware and return with <return page> if indicated.

IP filtering

Note: This request requires administrator access privilege

Method: GET/POST

Syntax:

http://<servername>/cgi-bin/admin/ipfilter.cgi? method=<value>&[start=<ipaddress>&end=<ipaddress>][&index=<value>] [&return=<return page>]

PARAMETER	VALUE	DESCRIPTION
Method	addallow	Add a set of allow IP address range to server. Start and end parameters must be specified. If the index parameter is specified, it will try to add starting from index position.
	adddeny	Add a set of deny IP address range to server. Start and end parameters must be specified. If the index parameter is specified, it will try to add starting from index position.

	deleteallow	Remove a set of allow IP address range from server. If start and end parameters are specified, it will try to remove the matched IP address. If index is specified, it will try to remove the address from given index position. [start, end] parameters have
		higher priority then the [index] parameter. Remove a set of deny IP address range from server. If start and end parameters are specified, it will try to remove the matched IP address. If index is specified, it will try to remove the address from given index position. [start, end] parameters have higher priority then the [index] parameter.
start	<ip address=""></ip>	The start IP address to add or to delete.
end	<ip address=""></ip>	The end IP address to add or to delete.
index	<value></value>	The start position to add or to delete.
return	<return page=""></return>	Redirect to the page <return page=""> after the parameter is assigned. The <return page=""> can be a full URL path or relative path according the the current path. If you omit this parameter, it will redirect to an empty page.</return></return>

TOSHIBA AMERICA INFORMATION SYSTEMS, INC.

Surveillance & IP Video Products 9740 Irvine Boulevard, Irvine, CA 92618-1697

Phone Number: (877) 855-1349