# Demonstration of MCU Running FreeRTOS in a Questa Simulation

This demo contains files and scripts for:

- 1. Compiling a Questa simulation executable from source files for the hardware system shown below
- 2. Running the simulation with a FreeRTOS main\_blinky ELF file loaded into the TCMs inside mkMCUTop and executed by the MCU. The FreeRTOS C source code and Makefile is not packaged in this demo but is available on request.

## **System Hierarchy**




Figure 1. Simulation System

## mkSoC\_Top

Connects the MCU processor (mkMCUTop) to PLIC, CLINT and UART devices via an AHBL-to-AXI4 bridge and an 1x3 AXI4 fabric. The AHB-L and AXI4 interconnects are 32-bit wide.

The MCU's Debug Module (mkBSDebug) is not connected. The MCU has been generated with 1024 KB ITCM and DTCM memories and does not implement the TCM loader interface. To improve simulation speed, programs are loaded directly into the TCM memories.

The UART is not a fully functional UART for this demo. It is used only in output mode to transmit program output through the simulation function.

## mkTop\_HW\_Side and main

mkTop\_HW\_Side connects the simulation SoC to the top-level testbench functions. It also plumbs the CLK and RST signals from the level above. main serves as the top-level simulation wrapper providing a clock and reset and other simulation controls like verbosity.

# **Directory Structure**

| bin            | Utilities to compile and run the Questa simulation                  |
|----------------|---|
| build          | Directory from which the Questa simulation must be compiled and run |
| C_VPI          | VPI C files (e.g. for UART input when used)                         |
| lib/Verilog    | Top-level TB files (main.v)   |
| lib/C          | C code to import TB routines  |
| programs       | FreeRTOS main_blinky asm and ELF files                              |
| MCU.1024K.AHBL | RTL source for simulation   |
| tools          | Elf-to-Hex utility for loading of TCMs                              |

# **Running the Demo**

#### **Questa Notes**

- 1. Version 2019.1 linux\_x86\_64 Jan 1 2019 run on Debian
- 2. The following was necessary to run Questa:

```
export MTI_VCO_MODE=64
```

### **Steps**

All the steps to build the Questa exectuate and run the simulation must be done from the build directory. Create a build directory if it does not exist already.

```
$ mkdir -p build  # from questa-rtos

$ cd build  # from questa-rtos
$ ../bin/MCU_compile_Questa.sh  # build the Questa executable
$ ../bin/run_MCU_Questa.sh  # load FreeRTOS and run the executable
```

After some initial simulation output, FreeRTOS will start running in about 60 second and until terminated with Ctrl-C will continue printing lines of the form:

```
# [0]: Hello from RX
#
# [0]: Hello from TX
#
# [1] TX: awoken
#
# [1] RX: received value
#
# Blink !!!
```



The memory images that are loaded into the ITCM and DTCM are created in <a href="tmp/itcm.mem">tmp/itcm.mem</a> and <a href="tmp/itcm.mem">tmp/dtcm.mem</a>. Please ensure that these locations are writable.