Sheet1

transmitter Dist	V	sigma	d_TR	d_TMR	MI_	TR
Gaussian 0.1656		1	1	1	1	0.129
		1	1	1	2	0.129
		1	1	1	4	0.129
		1	1	1	0.75	0.129
		1	1	1	0.5	0.129
		1	0.5	1	1	0.23

 $[\]ensuremath{\text{d_TR=}}$ distance to transmitter and receiver via direct path

d_TMR= distance to transmitter and receiver via indirect path (d_TM=d_

Sheet1

MI_TMR	MI_DI		MI_ID	M	_relay
0.	13	0.129		0.129	0.129
0.	04	0.554	-	0.421	0.051
0.01	22	1.4803	-	1.424	0.0149
0.2	15	0.053		0.271	0.158
0.51	24	0.009	0	.3972	0.2072
0.	23	0.23		0.23	0.23

MR)