Position-sensitive device

Bodo Kaiser

Ludwig-Maximilians-Universität München

bodo.ka iser@physik.uni-muenchen.de

April 8, 2019

Contents

1	ntroduction	2
2	Position-sensitive detector	3
3	Preamplifier	4
	B.1 Basic design	4
	3.2 Input offset voltage	5
	3.3 Input bias current	9
	3.4 Noise	10
	3.5 Stability	10

1 Introduction

2 Position-sensitive detector

[1]

Parameter	Symbol	Values		TT 1:
		Typical	Maximum	Unit
Dark current	I_d	0.5	10	nA
Interelectrode resistance	R_e	7	15	$\mathrm{k}\Omega$
Terminal capacitance	C_t	150	300	pF

Table 1: Important parameters of the S5990 extracted from the datasheet [2].

3 Preamplifier

The photocurrents created by our detector are in the range of microampere where they are vulnerable to noise. Using a preamplifier, we can increase the amplitude of the signal for an improved signal-to-noise ratio. The typical photocurrent preamplifier is based on the transimpedance (current-to-voltage) amplifier design using a voltage-feedback operational amplifier. Converting the current to a voltage signal has the benefit that the voltage signal can be easily visualized with an oscilloscope. Furthermore, the voltage-feedback operational amplifier design appears to be more common than the current-feedback operational amplifier, as manufacturers offer much more choice and they are more prominent in the literature. That said, current-feedback operational amplifiers are reported to be a viable solution for high-speed and high-bandwidth applications, see Ref. [3, p. 110] for an overview of the benefits of current-feedback amplifiers and Ref. [4, Ch. 9] for a comparison with voltage-feedback amplifiers.

In the following, we will always refer to the voltage-feedback operational amplifier if not noted otherwise. Moreover, we expect the reader to be familiar with the foundations of the operational amplifier. Well-written introductions to this topic can be found in [3, Ch. 1] and [4, Ch. 3].

3.1 Basic design

The basic design of a transimpedance amplifier is illustrated in Figure 1. Ignoring imperfections of the photodiode, we can represent the photodiode as a current source. The non-inverting input of the operational amplifier is connected to ground. The inverting input is coupled with the output of the operational amplifier via a feedback impedance Z_f .




Figure 1: Basic transimpedance amplifier using voltage feedback operational amplifier.

The ideal operation amplifier has zero input current, thus, in the node of the inverting input of the operational amplifier Kirchhoff's law states that the current going through the feedback impedance has to cancel the current of the current source $I_{\rm in}$. The current through the feedback impedance Z_f can be expressed in terms of the feedback impedance Z_f and the output voltage $V_{\rm out}$ of the operational amplifier through the use of Ohm's law, yielding,

$$V_{\text{out}} = -Z_f I_{\text{in}}. (1)$$

Given a maximum current $I_{\rm in}$ and a desired maximum output voltage $V_{\rm out}$, Equation (1) determines the feedback impedance. Limitations arise for real operational amplifiers where the output voltage is limited to be below the supply voltage of the operational amplifier.

Aside from photodiode applications, it is more common to find the inverting (voltage-to-voltage) operational amplifier in the literature. By using the source transformation on the current source with a parallel impedance in the transimpedance amplifier circuit, we can recover the inverting operational amplifier circuit, and thereby easily use results obtained for the inverting amplifier design.




Figure 2: Equivalence between transimpedance and inverting amplifier using source transformation.

Figure 2 shows the source transformation applied to transimpedance and inverting amplifier circuits. Given a current source $I_{\rm in}$ with parallel impedance $Z_{\rm in}$ the equivalent voltage source has value $V_{\rm in}=Z_{\rm in}I_{\rm in}$ with impedance $Z_{\rm in}$ in series.

3.2 Input offset voltage

Real operational amplifiers only reduce the voltage difference between the inverting and non-inverting input to a non-zero input offset voltage. For high-precision operational amplifiers, the input offset voltage is in the range of microvolts. We can model the input offset voltage as a voltage source at the non-inverting input of an ideal operational amplifier in our transimpedance circuit, as can be seen from Figure 3. In Figure 3 we amended the basic transimpedance circuit of Figure 1 by inserting a voltage source with the input offset voltage between the non-inverting input and ground.




Figure 3: Input offset voltage in the transimpedance amplifier.

In order to estimate the output offset $V_{\rm out}$ caused by the input offset voltage $V_{\rm offset}$ we adapt the picture of the inverting amplifier. Figure 4 shows an inverting amplifier circuit with input impedance $Z_{\rm in}$ and input offset voltage $V_{\rm offset}$ at the non-inverting input of the operational amplifier. According to the superposition theorem, we can replace the input voltage source with a short circuit to estimate the contribution of the input offset voltage source.




Figure 4: Input offset voltage in the inverting amplifier.

From Figure 4 we identify input and feedback impedance as a voltage divider in which the input and output nodes are exchanged. The respective transfer function reads,

$$V_{\text{out}} = -\frac{R_f + R_{\text{in}}}{R_{\text{in}}} V_{\text{offset}} = -\left(1 + \frac{R_f}{R_{\text{in}}}\right) V_{\text{offset}}.$$
 (2)

Comparing Equation (2) with Equation (1) discloses a difference in gain. The gain of the input signal in Eq. 1 is commonly referred to as signal gain. The gain of a signal applied directly to the inputs of the operational amplifier is referred to as noise gain. In the case of the position-sensitive detector, the input resistance is of order $10 \,\mathrm{k}\Omega$. Using a feedback resistance of $R_f = 100 \,\mathrm{k}\Omega$ we find that the input offset voltage experiences a gain of 11.

One approach to compensate for the input offset voltage as described is depicted in Figure 5, see also Ref [3, p. 54]. A potentiometer with maximum resistance Rp connects the positive and negative supply voltage. The wiper of the potentiometer is connected with a first resistor R1 to a node. The node is connected with a second resistor R2 and an optional bypass capacitor to ground. Finally, the equivalent input offset voltage source connects the node with the non-inverting input of the operational amplifier.




Figure 5: Input offset voltage compensation using adjustable potentiometer.

Let $0 \le x \ge 1$ be the position of the potentiometer. For x=1/2 the resistance of the potentiometer is $R_p/2$ and there is no offset compensation. For x < 1/2 the input offset compensation is negative to compensate for a positive input offset voltage. For x > 1/2 the input offset compensation is positive to compensate for a negative input offset voltage. The maximum input offset compensation is obtained for x=0 and x=1. Using circuit analysis techniques, we obtain,

$$V_c(x) = \frac{R_2(1-2x)}{R_1 + R_2 - R_p(1-x)x} V_{\text{supply}},$$
(3)

as an analytical expression for the input offset voltage compensation measured between the node and ground. The maximum absolute value of the compensation voltage follows to be,

$$V_c(0) = V_c(1) = \pm \frac{R_2}{R_1 + R_2} V_{\text{supply}}.$$
 (4)

Given a maximum input offset voltage of $100\,\mu\text{V}$ and a supply voltage of $15\,\text{V}$, we find approximate resistor values $R_1=3\,\text{M}\Omega$ and $R_2=2\,\Omega$. The resistor value of the potentiometer R_p should be chosen sufficiently large such to limit the current. For example, a potentiometer resistance of $R_p=15\,\text{k}\Omega$ would limit the current to $2\,\text{m}A$ with a heat dissipation of $60\,\text{m}W$. In practice, one should aim for a slightly higher maximum compensation voltage in order to handle resistor mismatches.

That said, there are some practical arguments against the use of the described input offset voltage compensation. The first argument is that the low resistance of R_2 acts as a dominant source for thermal current noise density of about $100 \,\mathrm{pA}/\sqrt{\mathrm{Hz}}$. As this current noise contributes to the input of the transimpedance amplifier it gets amplified by the feedback impedance Z_f , yielding up to $110 \,\mathrm{pV}/\sqrt{\mathrm{Hz}}$ in voltage noise density, which — depending on the bandwidth — surpasses the actual input offset voltage to compensate. The second argument is that high-precision potentiometers with large dynamic range get very large and difficult to accommodate on a printed circuit board.

3.3 Input bias current

In addition to the input offset voltage $V_{\rm offset}$, there is a second effect that causes an offset in the output voltage $V_{\rm out}$. This second effect stems from the small amount of current that is drawn from the inputs of the operational amplifier. We highlighted the input currents in Figure 6 where they are represented by the current flows i_+ and i_- directly pointing into the inputs of the operational amplifier in the transimpedance circuit.




Figure 6: Input bias current offset in the transimpedance amplifier.

$$I_{+} = I_{\text{bias}} + \frac{1}{2}I_{\text{offset}}$$
 $I_{\text{offset}} = I_{+} - I_{-}$ (5)
 $I_{-} = I_{\text{bias}} - \frac{1}{2}I_{\text{offset}}$ $I_{\text{bias}} = \frac{I_{+} + I_{-}}{2}$ (6)




Figure 7: Input current offset compensation.

[3, p. 57] [5, p. 25]

$$R_c = \frac{R_{\rm in}R_f}{R_{\rm in} + R_f} \tag{7}$$

3.4 Noise

3.5 Stability

 $[6,\,\mathrm{p.}\ 693]\ [7,\,\mathrm{p.}\ 183]\ [4,\,\mathrm{Ch.}\ 5]\ [5,\,\mathrm{Ch.}\ 3]$

Glossary

\$5990 Hamamatsu two-dimensional PSD. 3

References

- [1] Date Noorlag. "Lateral-photoeffect position-sensitive detectors". PhD thesis. Delft University of Technology, 1974.
- [2] S5990 2D PSD. Hamamatsu. URL: https://www.hamamatsu.com/resources/pdf/ssd/s5990-01_etc_kpsd1010e.pdf (visited on 03/03/2019).
- [3] Walt Jung. Op Amp Applications Handbook. Elsevier, 2005. ISBN: 9780750678445.
- [4] Ron Mancini Bruce Carter. Op Amps for Everyone. Elsevier, 2002. ISBN: 9780750677011.
- [5] Jerald Graeme. *Photodiode Amplifiers. Op Amp Solutions*. McGraw Hill Professional, 1996. ISBN: 9780070242470.
- [6] Philip Hobbs. Building Electro-Optical Systems. Making it all Work. John Wiley & Sons, 2011. ISBN: 9781118211090.
- [7] Art Kay. Operational Amplifier Noise. Techniques and Tips for Analyzing and Reducing Noise. Elsevier, 2012. ISBN: 9780750685252.