Said Trapper (with some editing):

UI2 logic reads the controller model, turns off the 30p UI2Config and turns on the UI2.inputType.


HasSpaceHumid.Out links to EnumSwitch.In Switch
Notn.Out links to UI2.Config/proxyExt.Enabled
FW_Tester.Out links to UI2.inputType/proxyExt.Enabled (already in place)
Unitnn.Model links to FW_Tester.In A (Model must be unhidden from the slot sheet)

Said I:

What I'm hearing you say is that this [the code shown below] needs to be inserted into the station units.

Said Trapper:

I would copy and paste special the units, then delete the UI2Config from the FWs while adding the UI2.inputType and EnumSwitch.



UI2Config: 73.4

UI2.inputType: 73.2

Disable FanModeOut at 553.1

Implemented sites:

H&M 321 Unit 01 [East05]

H&M 421 Unit 02 [Central 05]

H&M 474 Unit 04 [Mountain]

H&M 537 Unit 01 [East04]

H&M 584 Unit 05 [East 03]

H&M 607 Unit 11 [East 13]

H&M 749 all units [Central 07]

H&M 800 Unit 04 [East 10]

Eppendorf [East 10]

Leatherman Jace 1 Unit 32 [192.168.103.237]

NAPA Billings Unit 16 [Mountain]

NAPA Fresno Units 01M, 040 [West 10]

NAPA Kansas City Unit 01 [Central 05]