## How to calculate the damping ratios of a biquadratic notch filter

by Brandon Bickerstaff

## Background

The standard, continuous-time transfer function of a second-order system is ...

$$T_{2o}(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

Where s := Laplace variable,  $\omega_n :=$  natural frequency (rad/s), and  $\zeta :=$  damping ratio (—). A biquadratic—or "biquad"—transfer function is merely the ratio of two second-order transfer functions:

$$T_{biquad}(s) = \frac{T_{20,1}(s)}{T_{20,2}(s)} = \frac{s^2 + 2\zeta_2 \omega_{n,2} s + \omega_{n,2}^2}{s^2 + 2\zeta_1 \omega_{n,1} s + \omega_{n,1}^2}$$

Regarding a notch filter, the center/notch frequency,  $\omega_c$ , is the defining frequency of the corresponding transfer function—as opposed to  $\omega_n$ . Therefore, the transfer function of a biquad notch filter is as follows—where the  $\zeta$  subscripts "2" and "1" are replaced by "num" (numerator) and "den" (denominator), respectively:

$$T_{bn}(s) = \frac{s^2 + 2\zeta_{num}\omega_c s + \omega_c^2}{s^2 + 2\zeta_{den}\omega_c s + \omega_c^2}$$

## Derivation

Ideally, a notch filter can be generated based on three design parameters:

- 1.  $\omega_c$  (rad/s)
- 2. Bandwidth,  $\omega_{bw}$  (rad/s)
  - a. Range of frequencies to attenuate
  - b. Equal to the difference of the "-3 dB" frequencies right (minuend) and left (subtrahend) of  $\omega_c$ —which are denoted  $\omega_r$  and  $\omega_l$ , respectively
- 3. Notch depth, d (dB)
  - a. Amount to attenuate the signal (at  $\omega_c$ )
  - b. Specified as a positive number

The question now is, "How are  $\zeta_{num}$  and  $\zeta_{den}$  calculated?" Well, ...

In the frequency domain, s is replaced by  $j\omega$ ; i.e., in the frequency domain, ...

$$T_{bn}(j\omega) = T_{bn}(s)|_{s=j\omega} = \frac{(j\omega)^2 + 2\zeta_{num}\omega_c(j\omega) + \omega_c^2}{(j\omega)^2 + 2\zeta_{den}\omega_c(j\omega) + \omega_c^2} = \frac{\omega^2 - j2\zeta_{num}\omega_c\omega - \omega_c^2}{\omega^2 - j2\zeta_{den}\omega_c\omega - \omega_c^2}$$

By definition,  $|T_{bn}(j\omega_c)|=10^{-d/20}$ . Consequently, ...

$$\left| \frac{\omega_c^2 - j2\zeta_{num}\omega_c^2 - \omega_c^2}{\omega_c^2 - j2\zeta_{den}\omega_c^2 - \omega_c^2} \right| = \frac{\zeta_{num}}{\zeta_{den}} = 10^{-d/20}$$

Unfortunately, it is not possible for  $\omega_l=\omega_c-\omega_b/2$  and  $\omega_r=\omega_c+\omega_b/2$ . [The solution to  $T_{bn}(j\omega_l)=0$  $T_{bn}(j\omega_r)$  is trivial. Try it for yourself!] The "next best thing" is to let  $\omega_l=\omega_c/a$  and  $\omega_r=a\omega_c$  (where  $a \coloneqq \text{constant})$ —remembering that, as previously stated,  $\omega_b = \omega_r - \omega_l$ . As a result, ...

$$a\omega_c - \frac{\omega_c}{a} = \omega_b \rightarrow \omega_c a^2 - \omega_b a - \omega_c = 0$$

Which is merely a quadratic equation whose solution is ...

$$a = \frac{\omega_b \pm \sqrt{\omega_b^2 + 4\omega_c^2}}{2\omega_c}$$

And—because 1) the radical term will always be greater than  $\omega_b$ , and 2) both  $\omega_l$  and  $\omega_r$  must be positive—only the positive root is of (practical) interest. Finally, also by definition,  $|T_{bn}(j\omega_l)| =$  $|T_{bn}(j\omega_c/a)| = 1/\sqrt{2}$ . (Note that  $1/\sqrt{2} \cong -3 \ dB$ .) Thus, ...

$$\frac{\left|\frac{\left(\frac{\omega_{c}}{a}\right)^{2} - j2\zeta_{num}\omega_{c}\left(\frac{\omega_{c}}{a}\right) - \omega_{c}^{2}}{\left(\frac{\omega_{c}}{a}\right)^{2} - j2\zeta_{den}\omega_{c}\left(\frac{\omega_{c}}{a}\right) - \omega_{c}^{2}}\right| = \left|\frac{1 - a^{2} - j2a\zeta_{num}}{1 - a^{2} - j2a\zeta_{den}}\right| = \frac{\sqrt{(1 - a^{2})^{2} + (-2a\zeta_{num})^{2}}}{\sqrt{(1 - a^{2})^{2} + (-2a\zeta_{den})^{2}}} = \frac{1}{\sqrt{2}}$$

$$\Rightarrow \frac{1 - 2a^{2} + a^{4} + 4a^{2}\zeta_{num}^{2}}{1 - 2a^{2} + a^{4} + 4a^{2}\zeta_{den}^{2}} = \frac{1}{2} \Rightarrow \cdots \Rightarrow 2\zeta_{num}^{2} - \zeta_{den}^{2} = \frac{2 - a^{2} - 1/a^{2}}{4}$$

Plugging in  $10^{-d/20}\,\zeta_{den}$  for  $\zeta_{num}$  (earlier result) yields ...

$$2\left(10^{-d/20}\,\zeta_{den}\right)^2 - \zeta_{den}^2 = \left(2\cdot 10^{-d/10}\,-1\right)\zeta_{den}^2 = \frac{2-a^2-1/a^2}{4} \to \zeta_{den} = \pm \sqrt{\frac{2-a^2-1/a^2}{4(2\cdot 10^{-d/10}\,-1)}}$$

Where, again, only the positive root is of (practical) interest.

## Summary

The algorithm for calculating the damping ratios of a biquad notch filter is as follows:

1. 
$$a = \frac{\omega_b + \sqrt{\omega_b^2 + 4\omega_c^2}}{2\omega_c}$$
2. 
$$\zeta_{den} = \sqrt{\frac{2 - a^2 - 1/a^2}{4(2 \cdot 10^{-d/10} - 1)}}$$

2. 
$$\zeta_{den} = \sqrt{\frac{2 - a^2 - 1/a^2}{4(2 \cdot 10^{-d/10} - 1)}}$$

3. 
$$\zeta_{num} = 10^{-d/20} \zeta_{den}$$