
ESET 349 - Microcontroller Architecture

C- Assembly

Dr. Muhammad Faeyz Karim

Mixing C and Assembly



Why Mixed? Motivation?

- It is quite common especially in embedded applications
- Optimize certain critical codes for better performance
- 2 ways to add assembly to high level code
 - Inline assembler
 - Embedded assembler







Example 1: Myfirstc.C


```
#include <stdio.h>
                                  /* prototype declarations for I/O functions */
#include <LPC21xx.H>
                                  /* LPC21xx definitions
extern void Init serial(void);
/*******
/* main program */
/***************
int main (void) {
                             /* execution starts here
                                                                  */
 Init_serial();
                       /* initialize the serial interface
 /* the 'printf' function call */
 printf ("Hello Everyone, Welcome to the world!\n");
                     /* An embedded program does not stop and
                                                                       */
 while (1) {
  ; /* ... */
                     /* never returns. We use an endless loop.
                     /* Replace the dots (...) with your own code.
                                                                       */
```

View output in Serial Windows → UART1 window



Demo 1: myFirstC.c





Retarget to UART #1

Inline Assembly

- Compiler will try to optimize code as much as possible
- However, we may still need to optimize manually by giving the compiler some assistance
- Use "__inline" keyword to notate a certain function that should be placed in the assembly directly and not to be called as a subroutine (save branching and returning overhead)
- Furthermore, some functions can also be written in assembly

Inline Assembly Syntax

- Invoke with __asm keyword anywhere a statement is expected
- Using either single line or multiple lines
- On single line
 - __asm("instruction[;instruction]"); //must be a single string
 - __asm {instruction[;instruction]}
 - Cannot include comments
 - Example: __asm("ADD r1, r0, 1") or __asm {ADD r1, r0, 1}
- On multiple lines

```
__asm_...instruction...
```

Can include comments anywhere

Restrictions On Using <u>asm</u>

- The compiler optimize your codes, so the final codes may differ from what you wrote
- Cannot use all the ARM instructions, eg. BX and SVC instructions
- The compiler would not be aware if you change the mode
- Cannot change the program counter
- Should not modify the stack in any way
- Use registers r0-r3, sp, Ir and the NZCV flags in CPSR with caution as other C expressions may corrupt them
- The following instructions are not supported
 - BX and SVC instructions
 - LDR Rn = expression pseudo-instruction
 - LDRT, LDRBT, STRT and STRBT instructions
 - MUL, MLA, UMULL, UMLAL, SMULL AND SMLAL flag setting instructions
 - MOV, MVN where 2nd operand is a constant
 - User mode LDM instructions
 - ADR and ADRL pseudo-instructions

Example 2: Inline assembly

```
___inline int myadd (int x, int y)
  int result;
  return result;
  int main (void)
{ //main is written in C
int add2numbers, n1 = 3, n2 = 5;
add2numbers = myadd (n1, n2); //call inline asm function
```

Demo 2: Inline Assembly

```
Project
                ūΧ
                        ± 14InLineAsm.c ×
                      on □ #include < stdio.h>
                                                              /* prototype declarations

☐ 🔁 Target 1

                                                              /* LPC21xx definitions
                      02 #include <LPC21xx.H>
  ⊟ Gource Group 1
                      03 extern void Init serial (void);
      Startup.s
    14InLineAsm.c
                           inline int myadd(int x, int y)
    ⊕ ∄ Retarget.c
    ⊕ 🖹 Serial.c
                              int result;
    ± Init_serial.c
                      07
                               asm{ADD result, x, y};
                      09
                      10
                             return result;
                      11
                      12
                      14 /*************
                      15 /* main program */
                      16 /***********
                      17 int main (void) {
                                                             /* execution starts here
                           int add2numbers, n1=3,n2=5;
                      19
                      20
                                                            /* initialize the serial i
                           Init serial();
                      21
                           add2numbers = myadd(n1, n2);
                      24
                           printf ("%d + %d = %d", n1, n2, add2numbers);
                      25
                           while (1) {
                                                                    /* An embedded program
                              ; /* ... */
                                                                    /* never returns. We
                                                                    /* Replace the dots (
댪 р... | 🌎 в... | { } ғ... | 🛈 🛶 Т...
```

Embedded assembly

- For large subroutine
- Allows declaration of assembly functions in C with full functional prototypes, including arguments and return value
- Have overheads as a function
- Have access to full ARM and THUMB instruction sets

Embedded Assembly Syntax

 Functions declared with __asm can have arguments and return value

```
__asm return-type function-name (parameters list)
{
    ...
    instruction
    ...
}
```

Example 3: Embedded Assembly (1)

```
#include <stdio.h>
extern void init_serial(void);
                                   //initializes the serial driver
__asm void my_strcopy (const char *src, char *dst)
loop
  LDRB r2, [r0], #1
  STRB r2, [r1], #1
  CMP r2, #0; check termination
        loop
  BNE
  BX
          Ir
```

Example 3: Embedded Assembly (2)

```
int main(void)
   const char *a = "hello world"; //12 characters long
   char b[12];
                          //array of 12 characters = string
   init serial();
   my strcopy(a, b);
   printf("original string: '%s'\n", a);
   printf("Copied string: '%s'\n", b);
   return 0;
```

Register r1 = address of string b	String b		
	\longrightarrow $-$	\longrightarrow	ŀ
			7

Example 3: Embedded assembly (3) – strings a and b

•

0

1

0

W

0

е

h

Register r0 = address of string a

String a

Demo 3: Embedded Assembly



```
04
□ Target 1
                             asm void myStrcpy(const char *scr, char *dst)
  — Source Group 1
                          06 - {
      --- 🕍 Startup.s
                            loop
                          07
     LDRB r2, [r0], #1
                          08
     STRB r2, [r1], #1
     ⊕ 🔛 Serial.c
                                CMP r2, #0
     i Init serial.c
                                BNE loop
                          11
                          12
                                      1r
                                 BX
                          13
                          14 4
                          15-/*************
                          16 /* main program */
                          17 /************
                          18⊟int main (void) {
                                                             /*execution starts
                                const char *a="hello world"; /*array of 12 chard
                          19
                                char b[12];
                                 Init serial();
                                                             /*initialize the se
                                myStrcpy(a, b);
                                printf ("original string: %s\n", a);
                                printf ("copied string: %s\n", b);
                          24
■ Project ■ Registers
UART #1
original string: hello world
copied string: hello world
```

Calling Between C And Assembly

- Functions can be written in C or assembly (store in separate files) and then mix together
- They can be called upon one another but must follow AAPCS standard and uses C calling conventions

C Directives - #Include And Extern

#include file

- Tells the preprocessor to treat the contents of a specified file as if those contents had appeared in the source program at the point where the directive appears.
- You can organize constant and macro definitions into include files and then use #include directives to add these definitions to any source file
- Include files are also useful for incorporating declarations of external variables and complex data types
- You need to define and name the types only once in an include file created for that purpose

<u>extern</u>

- Use the extern directive to declare global data and procedures as external
- Indicates to the compiler that a function is written in a different programming language

More Assembly Directives

PRESERVE8

- Specifies that the current file preserves eight-byte alignment of the stack
- LDRD and STRD instructions only work correctly if the address they access is eight-byte aligned

EXPORT symbol

 Use EXPORT to give code in other files access to symbol in the current file

IMPORT symbol

- Provides the assembler with a name that is not defined in the current assembly
- It is resolved at link time to a symbol defined in a separate object file
- The symbol is treated as a program address

Ex 4: Call Assembly Subroutine From C (1)

C code (caller)

```
#include <stdio.h> /* prototype declarations for I/O functions */
#include <LPC21xx.H> /* LPC21xx definitions */
extern void Init_serial(void);
extern void revStr(const char *s, char *d);
```

Ex 4: Call Assembly Subroutine From C (2)

C code (caller)

```
/* main program */
                 /* execution starts here
int main (void) {
         const char *src = "stressed";
         char dst[9];
         Init serial(); /* initialize the serial interface
                                                         */
         revStr (src, dst); /*call asm subroutine revStr
         printf ("%s when reads in reverse is %s\n", src, dst);
                              /* An embedded program does not stop and
         while (1) {
         ; /* ... */ /* never returns. We use an endless loop. */
                          /* Replace the dots (...) with your own code. */
```

Ex 4: Call Assembly Subroutine From C (3)

Assembly code (callee)


```
;input r0 points to src string "stressed"
;output r1 points to dst string
     PRESERVE8
     AREA reverseStr, CODE, READONLY
     EXPORT revStr
     ENTRY
revStr
     STMFD sp!, {r4-r5, lr} ;save temporary registers
     ;get length of src
     MOV r4, #0
                         ;loop counter - temporary
loop1
     LDRB r5, [r0], #1; get character - temporary
     CMP r5, #0
                                    ;end of string?
     BEQ rev
     ADD r4, r4, #1 ;increment counter
        loop1
```

Ex 4: Call Assembly Subroutine From C (4)

<u>Assembly code (callee)</u>

```
rev ;start reversing
   SUB r0, r0, #1 ;adjust src pointer
loop2
   LDRB r5, [r0, #-1]! ;get src character
   STRB r5, [r1], #1; store to dst
   SUBS r4, r4, #1
   BGT loop2
   MOV r5, #0
   STRB r5, [r1] ;terminate dst string
   LDMFD sp!, {r4-r5, pc} ;restore temporary registers
   END
```

Demo 4: Call Assembly Subroutine From C



The ARM APCS (AAPCS)

- Application Procedure Call Standard → a standard
- Defines how subroutines can be separately written, separately compiled and separately assembled
- Contract between subroutine callers and callees
- Standard specifies
 - how parameters be passed to subroutines
 - which registers must have their content preserved (which are corruptible)
 - special roles for certain registers
 - a Full Descending stack pointed by r13 (sp)
 - etc

AAPCS Simplified Specifications

Register	Notes
r0 – r3	Parameters to and results from subroutines. Otherwise may be corrupted.
r4 – r11	Variables. Must be preserved.
r12	Scratch register (corruptible)
r13	Stack pointer (sp)
r14	Link register (Ir)
r15	Program counter (pc)

EE3002: Microprocessor