LA-UR-06-7048

Approved for public release; distribution is unlimited.

Title: | Quick Reference Guide: PFLOTRAN 1.0 (LA-CC 06-093)

Multiphase-Multicomponent-Multiscale Massively Parallel

Reactive Transport Code

Author(s): | SciDAC-2 Project (PI: Peter C. Lichtner, lichtner@lanl.gov)

Contacts: | Glenn Hammond (glenn.hammond@pnnl.gov)

Richard Mills (rmills@ornl.gov)

Date: | April 25, 2008

DRAFT

Los Alamos NATIONAL LABORATORY

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By acceptance of this article, the publisher recognizes that the U.S. Government retains a nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcherÕs right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

TABLE OF CONTENTS

1	Introduction		
2	Installation	3	
	2.1 Openmpi	3	
	2.2 PETSc	4	
	2.3 HDF5	4	
	2.4 PFLOTRAN	5	
3	PFLOTRAN Objects	5	
	3.1 Condition	5	
	3.2 Connection	7	
	3.3 Grid	7	
	3.4 Level	8	
	3.5 Patch	9	
	3.6 Realization	10	
	3.7 Region	10	
	3.8 Simulation	11	
	3.9 Solver	11	
	3.10 Stepper	12	
	3.11 Strata	13	
4	Creating the Input File: PFLOTRAN Keywords	14	
5	References	32	
6	FAQ	33	
	6.1 <i>jobuf load errors</i>	33	

1 Introduction

PFLOTRAN solves a system of generally nonlinear partial differential equations describing multiphase, multicomponent and multiscale reactive flow and transport in porous materials. The code is designed to run on massively parallel computing architectures as well as workstations and labtops. Parallelization is achieved through domain decomposition using the PETSc (Portable Extensible Toolkit for Scientific Computation) libraries for the parallelization framework (Balay et al., 1997).

2 Installation

2.1 Openmpi

Set environment variables PKGS and MPI_HOME and the appropriate PATH:

```
setenv PKGS /Users/lichtner/petsc/packages
setenv MPI_HOME $PKGS/openmpi/openmpi-1.2.5-gcc-4.3.0-absoft-10.1
setenv PATH \$PKGS/openmpi/openmpi-1.2.5-gcc-4.3.0-absoft-10.1:\$PATH
setenv F90 f90
setenv F77 'f90 -YEXT_NAMES=LCS -YEXT_SFX= -f'
setenv FC 'f90 -YEXT_NAMES=LCS -YEXT_SFX= -f'
setenv CC gcc

Configure using:
    ./configure --prefix=$PKGS/openmpi/openmpi-1.2.5-gcc-4.3.0-absoft-10.1

Finally, compile, check installation and install:
    make
    make check
make install
```

2.2 PETSc

PFLOTRAN uses the Developer version of PETSc. To install PETSc first set the environment variables PETSC_DIR and PETSC_ARCH:

```
setenv PETSC_DIR /Users/lichtner/petsc/petsc-dev
setenv PETSC_ARCH Intel_MacOSX10.4.11
```

Configure PETSc on a Mac using openmpi and Fortran 90 Absoft 10.1:

```
./config/configure.py
--with-blas-lapack-lib="-framework vecLib"
--with-mpi-dir=$PKGS/openmpi/openmpi-1.2.5-gcc-4.3.0-absoft-10.1
--with-debugging=0
--with-shared=0
```

Compile and test the PESTc installation with:

```
make all test
```

Optionally install PETSc:

```
make install
```

2.3 HDF5

To install HDF5 set the following environment variables:

```
setenv HDF5_INCLUDE $PKGS/hdf/hdf5-1.6.7-gcc-4.3.0-absoft-10.1/include
setenv HDF5_LIB $PKGS/hdf/hdf5-1.6.7-gcc-4.3.0-absoft-10.1/lib
setenv CC $MPI_HOME/bin/mpicc
setenv F9X $MPI_HOME/bin/mpif90
setenv CFLAGS -fno-strict-aliasing
setenv FFLAGS ""

./configure --enable-fortran
--prefix=$PKGS/hdf/hdf5-1.6.7-gcc-4.3.0-absoft-10.1
--disable-debug --enable-production --enable-parallel
--enable-static --disable-shared
```

```
make
make check
make install
```

2.4 PFLOTRAN

Compile PFLOTRAN using the command

```
make [hdf5=1] pflotran
```

Create input file pflotran.in and run PFLOTRAN with the command:

```
mpirun -n #proc pflotran
```

where #proc is the desired number of processor cores.

3 PFLOTRAN Objects

This section gives an overview in alphabetical order of the objects and their data structures used in PFLOTRAN. The upper most object is **Simulation** followed by **Realization**, followed by **Level**, **Patch** and **Grid**.

3.1 Condition

```
character(len=MAXWORDLENGTH) :: class ! character string describing class of
                                          condition
  PetscInt :: iclass
                                                 ! integer id for class
  logical :: sync_time_with_update
  character(len=MAXWORDLENGTH) :: name ! name of condition (e.g. initial, recharge)
  PetscInt :: num_sub_conditions
  PetscInt :: iphase
  PetscInt, pointer :: itype(:)
  character(len=MAXWORDLENGTH) :: time_units
  character(len=MAXWORDLENGTH) :: length_units
  type(sub_condition_type), pointer :: pressure
  type(sub_condition_type), pointer :: temperature
  type(sub_condition_type), pointer :: concentration
  type(sub_condition_type), pointer :: enthalpy
  type(sub_condition_ptr_type), pointer :: sub_condition_ptr(:)
  type(condition_type), pointer :: next ! pointer to next condition_type for
                                          linked-lists
end type condition_type
type, public :: sub_condition_type
  PetscInt :: itype
                                      ! integer describing type of condition
  character(len=MAXWORDLENGTH) :: ctype ! character string describing type of
                                          condition
  character(len=MAXWORDLENGTH) :: units
                                             ! units
  type(condition_dataset_type) :: datum
  type(condition_dataset_type) :: gradient
  type(condition_dataset_type) :: dataset
end type sub_condition_type
type, public :: sub_condition_ptr_type
  type(sub_condition_type), pointer :: ptr
end type sub_condition_ptr_type
type, public :: condition_ptr_type
  type(condition_type), pointer :: ptr
end type condition_ptr_type
type, public :: condition_list_type
  PetscInt :: num_conditions
  type(condition_type), pointer :: first
  type(condition_type), pointer :: last
```

```
type(condition_ptr_type), pointer :: array(:)
end type condition_list_type
```

3.2 Connection

```
type, public :: connection_type
  PetscInt :: id
  PetscInt :: itype
                       ! connection type (boundary, internal, source sink
  PetscInt :: num_connections
  PetscInt, pointer :: id_up(:)
                                     ! list of ids of upwind cells
  PetscInt, pointer :: id_dn(:)
                                     ! list of ids of downwind cells
  PetscReal, pointer :: dist(:,:)
                                       ! list of distance vectors, size(-1:3,num_conne
                                        -1 = fraction upwind
                                        0 = magnitude of distance
                                        1-3 = components of unit vector
                                    ! list of areas of faces normal to
 PetscReal, pointer :: area(:)
                                      distance vectors
  PetscReal, pointer :: velocity(:,:) ! velocity scalars for each phase
  type(connection_type), pointer :: next
end type connection_type
! pointer data structure required for making an array of region pointers in F90
type, public :: connection_ptr_type
 type(connection_type), pointer :: ptr ! pointer to the connection_type
end type connection_ptr_type
type, public :: connection_list_type
  PetscInt :: num_connection_objects
  type(connection_type), pointer :: first
  type(connection_type), pointer :: last
  type(connection_ptr_type), pointer :: array(:)
end type connection_list_type
```

3.3 Coupler

```
character(len=MAXWORDLENGTH) :: condition_name
  character(len=MAXWORDLENGTH) :: region_name
  PetscInt :: icondition
  PetscInt :: iregion
  PetscInt :: iface
  PetscInt, pointer :: aux_int_var(:,:)
  PetscReal, pointer :: aux_real_var(:,:)
  type(condition_type), pointer :: condition
  type(region_type), pointer :: region
  type(connection_type), pointer :: connection
  type(coupler_type), pointer :: next
end type coupler_type
type, public :: coupler_ptr_type
  type(coupler_type), pointer :: ptr
end type coupler_ptr_type
type, public :: coupler_list_type
  PetscInt :: num_couplers
  type(coupler_type), pointer :: first
  type(coupler_type), pointer :: last
  type(coupler_ptr_type), pointer :: array(:)
end type coupler_list_type
```

! character string defining name
! character string defining name
! id of condition in condition
! id of region in region array/
! for structured grids only
! auxilliary array for integer
! auxilliary array for real v
! pointer to condition in condit
! pointer to region in region ar
! pointer to an array/list of co
! pointer to next coupler

3.4 Grid

```
PetscInt, pointer :: nG2A(:)

PetscReal, pointer :: x(:), y(:), z(:)

PetscReal :: x_min, x_max, y_min, y_max, z_min, z_max

PetscInt, pointer :: hash(:,:,:)
PetscInt :: num_hash_bins

type(structured_grid_type), pointer :: structured_grid
type(unstructured_grid_type), pointer :: unstructured_grid

type(connection_list_type), pointer :: internal_connection_list
end type grid_type
```

3.5 Level

```
type, public :: level_type
 PetscInt :: id
  type(patch_list_type), pointer :: patch_list
 type(level_type), pointer :: next
end type level_type
! pointer data structure required for making an array of level pointers in F90
type, public :: level_ptr_type
 type(level_type), pointer :: ptr
                                             ! pointer to the level_type
end type level_ptr_type
type, public :: level_list_type
 PetscInt :: num_level_objects
 type(level_type), pointer :: first
  type(level_type), pointer :: last
  type(level_ptr_type), pointer :: array(:)
end type level_list_type
```

3.6 Material

```
type, public :: material_type
```

```
PetscInt :: id
  character(len=MAXWORDLENGTH) :: name
  PetscReal :: permeability(3,3)
  PetscReal :: permeability_pwr
  PetscReal :: porosity
  PetscReal :: tortuosity
  PetscInt :: ithrm
  PetscInt :: icap
  type(material_type), pointer :: next
end type material_type
type, public :: material_ptr_type
  type(material_type), pointer :: ptr
end type material_ptr_type
type, public :: thermal_property_type
  PetscInt :: id
 PetscReal :: rock_density
  PetscReal :: spec_heat
  PetscReal :: therm_cond_dry
  PetscReal :: therm_cond_wet
  PetscReal :: pore_compress
  PetscReal :: pore_expansivity
  PetscReal :: tort_bin_diff
  PetscReal :: vap_air_diff_coef
  PetscReal :: exp_binary_diff
  PetscReal :: enh_binary_diff_coef
  type(thermal_property_type), pointer :: next
end type thermal_property_type
type, public :: saturation_function_type
 PetscInt :: id
  character(len=MAXWORDLENGTH) :: saturation_function_ctype
  PetscInt :: saturation_function_itype
  character(len=MAXWORDLENGTH) :: permeability_function_ctype
  PetscInt :: permeability_function_itype
  PetscReal, pointer :: Sr(:)
  PetscReal :: m
  PetscReal :: lambda
  PetscReal :: alpha
  PetscReal :: pcwmax
  PetscReal :: betac
  PetscReal :: power
```

PetscInt :: ihist
PetscReal :: BC_pressure_low
PetscReal :: BC_pressure_high
PetscReal :: BC_spline_coefficients(4)
 type(saturation_function_type), pointer :: next
end type saturation_function_type

type, public :: saturation_function_ptr_type
 type(saturation_function_type), pointer :: ptr
end type saturation_function_ptr_type

3.7 Option

type, public :: option_type PetscMPIInt :: myrank ! rank in PETSC_COMM_WORLD PetscMPIInt :: commsize ! size of PETSC_COMM_WORLD ! defines the mode (e.g. mph, richards, vadose, etc. character(len=MAXWORDLENGTH) :: flowmode PetscInt :: iflowmode character(len=MAXWORDLENGTH) :: tranmode PetscInt :: itranmode PetscInt :: nphase PetscInt :: nflowdof PetscInt :: nspec PetscInt :: ntrandof PetscInt :: ncomp PetscReal :: uniform_velocity(3) ! Program options PetscTruth :: use_matrix_free ! If true, do not form the Jacobian. PetscInt :: imod PetscTruth :: use_isoth character(len=MAXWORDLENGTH) :: generalized_grid logical :: use_generalized_grid

```
PetscReal :: flow_time, tran_time, time ! The time elapsed in the simulation.
 PetscReal :: flow_dt, tran_dt, dt ! The size of the time step.
 PetscReal, pointer :: tplot(:)
 PetscReal, pointer :: tfac(:)
    ! An array of multiplicative factors that specify how to increase time step.
 PetscInt :: iblkfmt ! blocked format
    ! Basically our target number of newton iterations per time step.
 PetscReal :: dpmxe,dtmpmxe,dsmxe,dcmxe !maximum allowed changes in field vars.
 PetscReal :: dpmax,dtmpmax,dsmax,dcmax
 PetscReal :: scale
 PetscReal, pointer :: rock_density(:),cpr(:),dencpr(:),ckdry(:),ckwet(:), &
                     tau(:),cdiff(:),cexp(:)
 PetscReal, pointer :: swir(:),lambda(:),alpha(:),pckrm(:),pcwmax(:),pcbetac(:), &
                     pwrprm(:),sir(:,:)
 PetscInt, pointer:: icaptype(:)
 PetscReal :: m_nacl
 PetscReal :: difaq, delhaq, gravity(3), fmwh2o= 18.0153D0, fmwa=28.96D0, &
           fmwco2=44.0098D0, eqkair, ret=1.d0, fc=1.d0
 PetscInt :: ideriv
 PetscReal :: tref,pref
 PetscReal :: disp
table lookup
 PetscInt :: itable=0
 PetscTruth :: restart_flag
 PetscReal :: restart_time
 character(len=MAXWORDLENGTH) :: restart_file
 PetscTruth :: checkpoint_flag
 PetscInt :: checkpoint_frequency
 PetscLogDouble :: start_time
 PetscTruth :: wallclock_stop_flag
 PetscLogDouble :: wallclock_stop_time
```

```
PetscInt :: log_stage(10)
  logical :: numerical_derivatives
  logical :: compute_statistics
  logical :: use_touch_options
  logical :: overwrite_restart_transport
  PetscInt :: io_handshake_buffer_size
  character(len=MAXWORDLENGTH) :: permx_filename
  character(len=MAXWORDLENGTH) :: permy_filename
  character(len=MAXWORDLENGTH) :: permz_filename
end type option_type
type, public :: output_option_type
  character(len=2) :: tunit
  PetscReal :: tconv
  logical :: print_hdf5
  logical :: print_hdf5_velocities
  logical :: print_hdf5_flux_velocities
  logical :: print_tecplot
  logical :: print_tecplot_velocities
  logical :: print_tecplot_flux_velocities
  PetscInt :: plot_number
  character(len=MAXWORDLENGTH) :: plot_name
end type output_option_type
```

3.8 Patch

```
type, public :: patch_type

PetscInt :: id

! thiese arrays will be used by all modes, mode-specific arrays should
! go in the auxilliary data stucture for that mode
PetscInt, pointer :: imat(:)
PetscReal, pointer :: internal_velocities(:,:)
```

```
PetscReal, pointer :: boundary_velocities(:,:)
  type(grid_type), pointer :: grid
  type(region_list_type), pointer :: regions
  type(coupler_list_type), pointer :: transport_boundary_conditions
  type(coupler_list_type), pointer :: transport_initial_conditions
  type(coupler_list_type), pointer :: transport_source_sinks
  type(coupler_list_type), pointer :: flow_boundary_conditions
  type(coupler_list_type), pointer :: flow_initial_conditions
  type(coupler_list_type), pointer :: flow_source_sinks
  type(strata_list_type), pointer :: strata
  type(breakthrough_list_type), pointer :: breakthrough
  type(auxilliary_type) :: aux
  type(patch_type), pointer :: next
end type patch_type
! pointer data structure required for making an array of patch pointers in F90
type, public :: patch_ptr_type
 type(patch_type), pointer :: ptr
                                             ! pointer to the patch_type
end type patch_ptr_type
type, public :: patch_list_type
  PetscInt :: num_patch_objects
  type(patch_type), pointer :: first
  type(patch_type), pointer :: last
  type(patch_ptr_type), pointer :: array(:)
end type patch_list_type
```

3.9 Realization

```
type, public :: realization_type

type(discretization_type), pointer :: discretization
type(level_list_type), pointer :: level_list
type(patch_type), pointer :: patch
```

```
type(option_type), pointer :: option
type(field_type), pointer :: field
type(pflow_debug_type), pointer :: debug
type(output_option_type), pointer :: output_option

type(region_list_type), pointer :: regions
type(condition_list_type), pointer :: flow_conditions
type(condition_list_type), pointer :: transport_conditions

type(material_type), pointer :: materials
type(material_ptr_type), pointer :: material_array(:)
type(thermal_property_type), pointer :: thermal_properties
type(saturation_function_type), pointer :: saturation_functions
type(saturation_function_ptr_type), pointer :: saturation_function_array(:)

type(waypoint_list_type), pointer :: waypoints

end type realization_type
```

3.10 Region

```
type, public :: block_type
  PetscInt :: i1,i2,j1,j2,k1,k2
  type(block_type), pointer :: next
end type block_type
type, public :: region_type
  PetscInt :: id
  character(len=MAXWORDLENGTH) :: name
  character(len=MAXWORDLENGTH) :: filename
  PetscInt :: i1,i2,j1,j2,k1,k2
  PetscReal :: coordinate(3)
  PetscInt :: iface
  PetscInt :: num_cells
  PetscInt, pointer :: cell_ids(:)
  PetscInt, pointer :: faces(:)
  type(region_type), pointer :: next
end type region_type
type, public :: region_ptr_type
  type(region_type), pointer :: ptr
```

```
end type region_ptr_type

type, public :: region_list_type
  PetscInt :: num_regions
  type(region_type), pointer :: first
  type(region_type), pointer :: last
  type(region_type), pointer :: array(:)
end type region_list_type
```

3.11 Simulation

```
type, public :: simulation_type

type(realization_type), pointer :: realization
type(stepper_type), pointer :: flow_stepper
type(stepper_type), pointer :: tran_stepper
end type simulation_type
```

3.12 Solver

```
type, public :: solver_type
  PetscReal :: linear_atol
                                 ! absolute tolerance
  PetscReal :: linear_rtol
                                 ! relative tolerance
  PetscReal :: linear_dtol
                                 ! divergence tolerance
  PetscInt :: linear_maxit
                               ! maximum number of iterations
                                 ! absolute tolerance
  PetscReal :: newton_atol
  PetscReal :: newton_rtol
                                 ! relative tolerance
  PetscReal :: newton_stol
                                 ! relative tolerance (relative to previous
                                   iteration)
                                 ! divergence tolerance
  PetscReal :: newton_dtol
  PetscReal :: newton_inf_res_tol
                                      ! infinity tolerance for residual
  PetscReal :: newton_inf_upd_tol
                                      ! infinity tolerance for update
  PetscInt :: newton_maxit
                               ! maximum number of iterations
                               ! maximum number of function evaluations
  PetscInt :: newton_maxf
      ! Jacobian matrix
  Mat :: J
  MatFDColoring :: matfdcoloring
```

! Coloring used for computing the Jacobian via finite differences.

```
! PETSc nonlinear solver context
```

SNES :: snes

KSPType :: ksp_type PCType :: pc_type

KSP :: ksp PC :: pc

PetscTruth :: inexact_newton

PetscTruth :: print_convergence

PetscTruth :: print_detailed_convergence

PetscTruth :: check_infinity_norm

PetscTruth :: force_at_least_1_iteration

end type solver_type

3.13 Stepper

```
type, public :: stepper_type
  PetscInt :: steps
                            ! The number of time-steps taken by the code.
  PetscInt :: nstepmax
                            ! Maximum number of timesteps taken by the code.
  PetscInt :: icut_max
                            ! Maximum number of timestep cuts within one time step.
  PetscInt :: ndtcmx
                            ! Steps needed after cutting to increase time step
 PetscInt :: newtcum
                            ! Total number of Newton steps taken.
                            ! Total number of cuts in the timestep taken.
  PetscInt :: icutcum
 PetscInt :: iaccel
                            ! Accelerator index
  PetscReal :: dt_min
  PetscReal :: dt_max
  type(solver_type), pointer :: solver
  type(waypoint_type), pointer :: cur_waypoint
  type(convergence_context_type), pointer :: convergence_context
end type stepper_type
```

3.14 Strata

```
type, public :: strata_type
  PetscInt :: id
                                                  ! id of strata
  logical :: active
  character(len=MAXWORDLENGTH) :: material_name ! character string defining
                                                  name of material to be applied
  character(len=MAXWORDLENGTH) :: region_name
                                                  ! character string defining
                                                  name of region to be applied
                                       ! id of material in material array/list
  PetscInt :: imaterial
  PetscInt :: iregion
                                            ! id of region in region array/list
  type(material_type), pointer :: material
                                                  ! pointer to material in
                                                    material array/list
  type(region_type), pointer :: region
                                                  ! pointer to region in region
                                                    array/list
                                                  ! pointer to next strata
  type(strata_type), pointer :: next
end type strata_type
type, public :: strata_ptr_type
  type(strata_type), pointer :: ptr
end type strata_ptr_type
type, public :: strata_list_type
  PetscInt :: num_strata
  type(strata_type), pointer :: first
  type(strata_type), pointer :: last
  type(strata_ptr_type), pointer :: array(:)
end type strata_list_type
```

4 Creating the Input File: PFLOTRAN Keywords

The PFLOTRAN input file construction is based on keywords. Lines beginning with a colon (:) are treated as comments. Each entry to the input file must begin in the first column. Keywords SKIP and NOSKIP are used to skip over sections of the input file. Blank lines may occur in input file. Alternate keyword spelling is indicated in round brackets (). Input options are indicated in square brackets [], as well as default values. Curly brackets {} indicate the result of invoking the corresponding keyword. Always refer to source code when in doubt!

Initial and boundary conditions and material properties are assigned to spatial regions using a novel *coupler* approach. In this approach, initial and boundary conditions (keyword CONDITION) are assigned to regions (keyword REGION) using keywords INITIAL_CONDITION and

BOUNDARY_CONDITION. Material properties (keyword MATERIAL) are assigned to regions using the keyword STRATIGRAPHY.

Keyword Description

BOUNDARY_CONDITION

BREAKTHROUGH

BRINE (BRIN)

CHECKPOINT

COMPUTE_STATISTICS (STATISTICS)

CONDITION

DATASET

DEBUG

DIFF

DTST

DXYZ

GRAVITY

GRID

HDF5

IMOD

INVERT_Z (INVERTZ)

INITIAL_CONDITION

LINEAR_SOLVER

MATERIAL (MATERIALS, PHIK)

MODE

NEWTON_SOLVER

NUMERICAL_JACOBIAN

ORIG, ORIGIN

OVERWRITE_RESTART_TRANSPORT

REGION

RESTART

RICH

SATURATION_FUNCTION (SATURATION_FUNCTION, PCKR)

SOURCE_SINK

STRATIGRAPHY (STRATA)

TECP

THRM, THERMAL_PROPERTY (THERMAL_PROPERTIES)

TIME

TIMESTEPPER

TRAN

UNIFORM_VELOCITY

USE_TOUCH_OPTIONS

WALLCLOCK_STOP

Keyword: BOUNDARY_CONDITION

BOUNDARY_CONDITION

REGION region_name

CONDITION condition_name

TYPE [initial, boundary, source_sink]

FACE [WEST, EAST, NORTH, SOUTH, BOTTOM, TOP]

END

Keyword: BREAKTHROUGH (BRK)

BREAKTHROUGH

REGION region_name

VELOCITY {print_velocities == PETSC_TRUE}

(., /, END)

Keyword: BRINE (BRIN)

BRIN, BRINE m_nacl [MOLAL, MASS, MOLE]

Keyword: CHECKPOINT

CHECKPOINT checkpoint_frequency

Keyword: COMPUTE_STATISTICS (STATISTICS)

COMPUTE_STATISTICS, STATISTICS {compute_statistics = .true.}

Keyword: CONDITION (COND)

CONDITION	(COND) con	dition_name			
UNITS					
		s, sec, min, hr, d, day, y, yr			
		mm, cm, m, met, meter, dm, km			
		Pa, KPa			
		m/s, m/yr			
		C, K			
		M, mol/L			
		KJ/mol			
(., /, END)					
CLASS	[flow, transport (tran)]				
CYCLIC	{is_cyclic = .t	rue.}			
INTERPOLA	FION step lin	near			
ТҮРЕ					
	PRESSURE (PRES, PRESS) [dirichlet, neumann, mass, hydrostatic (hydro, hydrostat), static, zero_gradient, seepage]				
	FLUX	[dirichlet, neumann, mass, hydrostatic (hydro, hydrostat), static, zero_gradient, seepage]			
	TEMPERATURE (TEMP) [dirichlet, neumann, mass, hydrostatic (hydro, hydrostatic), static, zero_gradient, seepage]				
	CONCENTRATION (CONC) [dirichlet, neumann, mass, hydrostatic (hydro, hydrostat), static, zero_gradient, seepage]				
	ENTHALPY ((H) [dirichlet, neumann, mass, hydrostatic (hydro, hydrostat), static, zero_gradient, seepage]			
	(., /, END)				
TIME					
IPHASE					
DATUM (DA	ГМ)				
[Continued]				

Keyword: CONDITION (COND) [Continued]

GRADIENT (GRAD)

PRESSURE (PRES, PRESS)

FLUX

TEMPERATURE (TEMP)

CONCENTRATION (CONC)

ENTHALPY (H)

(., /, END)

TEMPERATURE (TEMP)

ENTHALPY (H)

PRESSURE (PRES, PRESS)

FLUX (VELOCITY, VEL)

CONCENTRATION (CONC)

(., /, END)

Keyword: DATASET

DATASET [permx, permy, permz] [permx_filename, permy_filename, permz_filename]

Keyword: DEBUG

DEBUG

PRINT_SOLUTION (VECVIEW_SOLUTION, VIEW_SOLUTION)

PRINT_RESIDUAL (VECVIEW_RESIDUAL,VIEW_RESIDUAL)

PRINT_JACOBIAN (MATVIEW_JACOBIAN, VIEW_JACOBIAN)

PRINT_JACOBIAN_NORM (NORM_JACOBIAN)

PRINT_COUPLERS (PRINT_COUPLER)

PRINT_JACOBIAN_DETAILED, (MATVIEW_JACOBIAN_DETAILED,

VIEW_JACOBIAN_DETAILED)

PRINT_NUMERICAL_DERIVATIVES (VIEW_NUMERICAL_DERIVATIVES)

END

Keyword: DIFF

DIFF difaq delhaq

Keyword: DTST

DTST dt_min dt1, dt2, dt3, ..., dt_max

Keyword: DXYZ

DXYZ	[STRUCTURED_GRID, AMR_GRID]			
	dx0			
	dy0			
	dz0			

Keyword: GRAVITY (GRAV)

GRAVITY (GRAV) gravity

Keyword: GRID

GRID

TYPE [structured, unstructured, amr]

NXYZ nx ny nz

FILE

END

Keyword: HDF5

HDF5 [VELO, FLUX]

Keyword: IMOD

IMOD mod

Keyword: INVERT_Z (INVERTZ)

INVERT_Z (INVERTZ) {invert_z_axis = .true.}

Keyword: INITIAL_CONDITION

INITIAL_CONDITION

REGION region_name

CONDITION condition_name

TYPE [initial, boundary, source_sink]

FACE [WEST, EAST, NORTH, SOUTH, BOTTOM, TOP]

END

Keyword: LINEAR_SOLVER

LINEAR_SOLVER

TRAN, TRANSPORT (tran_solver) / DEFAULT (flow_solver)

SOLVER_TYPE (SOLVER, KRYLOV_TYPE, KRYLOV, KSP, KSP_TYPE)

NONE (PREONLY)

GMRES

BCGS (BICGSTAB, BI-CGSTAB)

PRECONDITIONER_TYPE (PRECONDITIONER, PC, PC_TYPE)

ILU (PCILU)

LU (PCLU)

BJACOBI (BLOCK_JACOBI)

ASM (ADDITIVE_SCHWARTZ)

PCASM

ATOL

RTOL

DTOL

MAXIT

(., /, END)

DRAFT

Keyword: MATERIAL (MATERIALS, PHIK)

MATERIAL (MATERIALS, PHIK)

name id icap ithrm por tor permx permy permz permpwr

(., /, END)

Keyword: MODE

MODE [RICHARDS_LITE, RICHARDS, MPH]

Keyword: NEWTON_SOLVER

NEWTON_SOLVER

TRAN, TRANSPORT (tran_solver) / DEFAULT (flow_solver)

INEXACT_NEWTON

NO_PRINT_CONVERGENCE

NO_INF_NORM (NO_INFINITY_NORM)

NO_FORCE_ITERATION

PRINT_DETAILED_CONVERGENCE

ATOL

RTOL

STOL

DTOL

ITOL (INF_TOL, ITOL_RES, INF_TOL_RES)

ITOL_UPDATE (INF_TOL_UPDATE)

MAXIT

MAXF

(., /, END)

Keyword: NUMERICAL_JACOBIAN

NUMERICAL_JACOBIAN {numerical_derivatives = .true.}

Keyword: ORIGIN (ORIG)

ORIGIN (ORIG) X_DIRECTION Y_DIRECTION Z_DIRECTION

Keyword: OVERWRITE_RESTART_TRANSPORT

OVERWRITE_RESTART_TRANSPORT {overwrite_restart_transport = .true.}

Keyword: REGION

REGION region_name

BLOCK i1 i2 j1 j2 k1 k2

COORDINATE x-coordinate y-coordinate z-coordinate

FILE filename

LIST (not implemented)

FACE [WEST, EAST, NORTH, SOUTH, BOTTOM, TOP]

END

Keyword: RESTART

RESTART restart_file restart_time

Keyword: RICH

RICH pref

Keyword: SATURATION_FUNCTION (SATURATION_FUNCTIONS, PCKR)

SATURATION_FUNCTION (SATURATION_FUNCTIONS, PCKR)

id icaptype [(Sr[np],np=1,nphase), Sr] pckrm alpha pcwmax pbetac pwrprm

(., /, END)

Keyword: SOURCE_SINK

SOURCE_SINK

REGION region_name

CONDITION condition_name

TYPE [initial, boundary, source_sink]

FACE [WEST, EAST, NORTH, SOUTH, BOTTOM, TOP]

END

Keyword: STRATIGRAPHY (STRATA)

STRATIGRAPHY (STRATA)

REGION region_name

MATERIAL material_name

INACTIVE

(., /, END)

Keyword: TECP

TECP

[VELO, FLUX]

Keyword: THRM (THERMAL_PROPERTY, THERMAL_PROPERTIES)

THRM (THERMAL_PROPERTY, THERMAL_PROPERTIES)

id rock_density spec_heat therm_cond_dry therm_cond_wet tort_bin_diff vap_air_diff_coef exp_binary_diff

(., /, END)

Keyword: TIME

TIME	[s, m, h, d, mo, y] [every #]
	t1, t2, t3,

Keyword: TIMESTEPPER

TIMESTEPPER

NUM_STEPS_AFTER_TS_CUT [5]

MAX_STEPS [999999]

TS_ACCELERATION [5]

MAX_TS_CUTS [16]

MAX_PRESSURE_CHANGE [5.d4]

MAX_TEMPERATURE_CHANGE [5.d0]

MAX_CONCENTRATION_CHANGE [1.d0]

MAX_SATURATION_CHANGE [0.5d0]

(., /, END)

Keyword: TRAN

|--|

Keyword: UNIFORM_VELOCITY

UNIFORM_VELOCITY vlx vly vlz

Keyword: USE_TOUCH_OPTIONS

USE_TOUCH_OPTIONS {use_touch_options = .true.}

Keyword: WALLCLOCK_STOP

WALLCLOCK_STOP wallclock_stop_time

Example Input File

```
:Description: 2D problem for saturated layered medium
:MODE RICHARDS
MODE RICHARDS_LITE
TRAN 1
:NUMERICAL_JACOBIAN
: INEXACT_NEWTON
:USE_TOUCH_OPTIONS
:CHECKPOINT 1000
:RESTART steady.chk 0.d0
:OVERWRITE_RESTART_TRANSPORT
:COMPUTE_STATISTICS
:USE_TOUCH_OPTIONS
:WALLCLOCK_STOP 0.d0
:
DEBUG
:MATVIEW_JACOBIAN
: VECVIEW_RESIDUAL
: VECVIEW_SOLUTION
:PRINT_COUPLERS
END
GRID
TYPE structured
NXYZ 450 1 4430
END
```

```
ORIGIN 0.d0 0.d0 0.d0
NEWTON_SOLVER
RTOL 1.d-5
ATOL 1.d-7
STOL 1.d-10
:ITOL_RES 1.d-8
:ITOL_UPDATE 0.05d0 ! Pa
NO_INFINITY_NORM
:NO_FORCE_ITERATION
:NO_PRINT_CONVERGENCE
:PRINT_DETAILED_CONVERGENCE
MAXIT 20
END
:noskip
NEWTON_SOLVER TRANSPORT
:RTOL 1.d-50
ATOL 1.d-50
STOL 1.d-50
ITOL_RES 1.d-8
:ITOL_UPDATE 5.dO ! Pa
:NO_INFINITY_NORM
:NO_FORCE_ITERATION
:NO_PRINT_CONVERGENCE
:PRINT_DETAILED_CONVERGENCE
MAXIT 10
END
TIMESTEPPER
TS_ACCELERATION 8
END
:HDF5 !VELO !FLUX
TECP VELO !FLUX
:
DXYZ
0.02d0
1.d0
0.002d0
: d0[m^2/s] delhaq[kJ/mol]
```

BLOCK 1 1 1 1 3931 4430

```
DIFF 1.D-9
               12.6
: Richards Equation Pref
RICH 101325.
SATURATION_FUNCTIONS
: van Genuchten
:id itype swir m alpha pcwmax betac pwr
1 1
        0.1600 0.3391 7.2727d-4 1.e8 0.d0 1.d0
        0.1299 0.7479 1.4319d-4 1.e8
                                   0.d0 1.d0
: Brooks-Corey
:id itype swir
              lambda alpha
                            pcwmax betac pwr
        0.1600 1.97 7.2727d-4 1.e8 0.d0 1.d0
: 2 2 0.1299 0.5193 1.4319d-4 1.e8 0.d0 1.d0
END
THERMAL_PROPERTIES
           cpr ckdry cksat tau cdiff cexp
:ithm rho
     2.76e3 1000.e0 0.5 0.5 0.5 2.13d-5 1.8
 1
END
MATERIALS
:name id icap ithm por tau permx permy permz permpwr
tuff 1 1 1 0.2 0.5 1.d-19 1.d-19 1.d-19 1.d0
END
:TIME y every 10.
TIME y
0.1 0.25 0.5 0.75 1.
DTST 1.d-8
1. 0.001d0
REGION all
BLOCK 1 450 1 1 1 4430
END
REGION Left
FACE west
```

END

REGION Right
FACE east
BLOCK 450 450 1 1 1 500
END

:define initial and boundary conditions-----

:flow-----

CONDITION initial
CLASS flow
TYPE
PRESSURE hydrostatic

END
DATUM 0.d0 0.d0 10.d0
PRESSURE 101325.d0

END

CONDITION Left

CLASS flow TYPE

PRESSURE neumann

F.ND

PRESSURE 1.5854896d-7 ! 5000 mm/yr

END

CONDITION Right

CLASS flow

TYPE

PRESSURE neumann

END

PRESSURE -1.5854896d-7 ! 5000 mm/yr

END

:transport-----

CONDITION initial_c CLASS transport CONCENTRATION 1.d-8 END CONDITION outlet_c
CLASS transport
TYPE
CONCENTRATION zero_gradient
END
CONCENTRATION 1.d-8
END

CONDITION inlet_c CLASS transport CONCENTRATION 1.dO END

:set initial and boundary conditions-----

:flow-----

: initial condition INITIAL_CONDITION CONDITION initial REGION all END

BOUNDARY_CONDITION CONDITION Left REGION Left END

BOUNDARY_CONDITION CONDITION initial REGION Right END

:transport-----

: initial condition INITIAL_CONDITION CONDITION initial_c REGION all END

BOUNDARY_CONDITION CONDITION inlet_c

```
REGION Left
END

BOUNDARY_CONDITION
CONDITION outlet_c
REGION Right
END

:set material properties------
STRATA
MATERIAL tuff
REGION all
END

:read in permeability field-----
DATASET permx perm_inv.dat
DATASET permy perm_inv.dat
DATASET permz perm_inv.dat
```

5 References

Balay S, Eijkhout V, Gropp WD, McInnes LC and Smith BF (1997) Modern Software Tools in Scientific Computing, Eds. Arge E, Bruaset AM and Langtangen HP (Birkhaüser Press), pp. 163–202.

6 FAQ

6.1 *iobuf load errors*

It may be the case that the 'iobuf'module is causing problems. That is a module that, if it's loaded, links with an IO buffering library. It can speed up IO considerably, but there are have been some bugs (hopefully fixed) identified with it before. It is loaded by default. You might want to try a 'module unload' of that before building PFLOTRAN, and seeing if that works. Unfortunately, it may be necessary to mess with the configuration files for the PETSc builds to make sure that you don't link with the iobuf library.