#### LA-UR-06-7048

Approved for public release; distribution is unlimited.

Title: | Quick Reference Guide: PFLOTRAN 1.0 (LA-CC 06-093)

Multiphase-Multicomponent-Multiscale Massively Parallel

Reactive Transport Code

*Author(s):* | SciDAC-2 Project (PI: Peter C. Lichtner, lichtner@lanl.gov)

Contacts: | Glenn Hammond (glenn.hammond@pnnl.gov)

Richard Mills (rmills@ornl.gov)

*Date:* | March 22, 2008

**DRAFT** 

# Los Alamos NATIONAL LABORATORY

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By acceptance of this article, the publisher recognizes that the U.S. Government retains a nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher of sright to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

#### 1 Introduction

# 2 PFLOTRAN Keywords

The PFLOTRAN input file construction is based on keywords. Lines beginning with a colon (:) are treated as comments. Each entry to the input file must begin in the first column. Keywords SKIP and NOSKIP are used to skip over sections of the input file. Blank lines may occur in input file. Alternate keyword spelling is indicated in round brackets (). Input options are indicated in square brackets []. Curly brackets {} indicate the result of invoking the corresponding keyword. Always refer to source code when in doubt!

Initial and boundary conditions and material properties are assigned to spatial regions using a novel *coupler* approach. In this approach, initial and boundary conditions (keyword CONDITION) are assigned to regions (keyword REGION) using keywords INITIAL\_CONDITION and BOUNDARY\_CONDITION. Material properties (keyword MATERIAL) are assigned to regions using the keyword STRATIGRAPHY.

Keyword	Status	Comments
BOUNDARY_CONDITION		
BREAKTHROUGH		
BRINE (BRIN)		
CHECKPOINT		
COMPUTE_STATISTICS (STATISTICS)		
CONDITION		
DATASET		
DEBUG		
DIFF		
DTST		
DXYZ		
GRAVITY		
GRID		
HDF5		
IMOD		
INVERT_Z (INVERTZ)		
INITIAL_CONDITION		
LINEAR_SOLVER		

MATERIAL (MATERIALS, PHIK)

**MODE** 

NEWTON\_SOLVER

NUMERICAL\_JACOBIAN

ORIG, ORIGIN

OVERWRITE\_RESTART\_TRANSPORT

**REGION** 

**RESTART** 

**RICH** 

SATURATION\_FUNCTION (SATURATION\_FUNCTION, PCKR)

SOURCE\_SINK

STRATIGRAPHY (STRATA)

**TECP** 

THRM, THERMAL\_PROPERTY (THERMAL\_PROPERTIES)

**TIME** 

**TIMESTEPPER** 

**TRAN** 

UNIFORM\_VELOCITY

USE\_TOUCH\_OPTIONS

WALLCLOCK\_STOP

## **Keyword: BOUNDARY\_CONDITION**

#### **BOUNDARY\_CONDITION**

**REGION** region\_name

**CONDITION** condition\_name

**TYPE** [initial, boundary, source\_sink]

**FACE** [WEST, EAST, NORTH, SOUTH, BOTTOM, TOP]

**END** 

## **Keyword: BREAKTHROUGH (BRK)**

**BREAKTHROUGH** 

**REGION** region\_name

**VELOCITY** {print\_velocities == PETSC\_TRUE}

(., /, END)

**Keyword: BRINE (BRIN)** 

**BRIN, BRINE** m\_nacl [MOLAL, MASS, MOLE]

**Keyword: CHECKPOINT** 

CHECKPOINT checkpoint\_frequency

**Keyword: COMPUTE\_STATISTICS (STATISTICS)** 

**COMPUTE\_STATISTICS, STATISTICS** {compute\_statistics = .true.}

# **Keyword: CONDITION (COND)**

CONDITION	(COND) con	ndition_name
UNITS		
		s, sec, min, hr, d, day, y, yr
		mm, cm, m, met, meter, dm, km
		Pa, KPa
		m/s, m/yr
		C, K
		M, mol/L
		KJ/mol
(., /, END)		
CLASS	[flow, transpo	ort (tran)]
CYCLIC	{is_cyclic = .t	rue.}
INTERPOLA	<b>FION</b> step lin	near
ТҮРЕ		
	PRESSURE (	(PRES, PRESS) [dirichlet, neumann, mass, hydrostatic (hydro, hydrostat), static, zero_gradient, seepage]
	FLUX	[dirichlet, neumann, mass, hydrostatic (hydro, hydrostat), static, zero_gradient, seepage]
	ТЕМР, ТЕМР	<b>PERATURE</b> [dirichlet, neumann, mass, hydrostatic (hydro, hydrostat), static, zero_gradient, seepage]
	CONCENTRA	<b>ATION (CONC)</b> [dirichlet, neumann, mass, hydrostatic (hydro, hydrostat), static, zero_gradient, seepage]
	ENTHALPY (	(H) [dirichlet, neumann, mass, hydrostatic (hydro, hydrostat), static, zero_gradient, seepage]
	(., /, END)	
TIME		
IPHASE		
DATUM (DA	ГМ)	
[Continued	]	

## **Keyword: CONDITION (COND) [Continued]**

GRADIENT (GRAD)

PRESSURE (PRES, PRESS)

**FLUX** 

TEMPERATURE (TEMP)

CONCENTRATION (CONC)

ENTHALPY (H)

(., /, END)

**TEMPERATURE (TEMP)** 

ENTHALPY (H)

PRESSURE (PRES, PRESS)

FLUX (VELOCITY, VEL)

**CONCENTRATION (CONC)** 

(., /, END)

**Keyword: DATASET** 

**DATASET** [permx, permy, permz] [permx\_filename, permy\_filename, permz\_filename]

## **Keyword: DEBUG**

#### **DEBUG**

PRINT\_SOLUTION (VECVIEW\_SOLUTION, VIEW\_SOLUTION)

PRINT\_RESIDUAL (VECVIEW\_RESIDUAL,VIEW\_RESIDUAL)

PRINT\_JACOBIAN (MATVIEW\_JACOBIAN, VIEW\_JACOBIAN)

PRINT\_JACOBIAN\_NORM (NORM\_JACOBIAN)

PRINT\_COUPLERS (PRINT\_COUPLER)

PRINT\_JACOBIAN\_DETAILED, (MATVIEW\_JACOBIAN\_DETAILED,

VIEW\_JACOBIAN\_DETAILED)

PRINT\_NUMERICAL\_DERIVATIVES (VIEW\_NUMERICAL\_DERIVATIVES)

**END** 

## **Keyword: DIFF**

DIFF difaq delhaq

## **Keyword: DTST**

DTST	dt_min	
	dt1, dt2, dt3,, dt_max	

# **Keyword: DXYZ**

DXYZ	[STRUCTURED_GRID, AMR_GRID]
	dx0
	dy0
	dz0

# **Keyword: GRAVITY (GRAV)**

GRAVITY (GRAV) gravity

# **Keyword: GRID**

**GRID** 

TYPE [structured, unstructured, amr]

NXYZ nx ny nz

**FILE** 

**END** 

**Keyword: HDF5** 

**HDF5** [VELO, FLUX]

**Keyword: IMOD** 

**IMOD** mod

**Keyword: INVERT\_Z (INVERTZ)** 

INVERT\_Z (INVERTZ) {invert\_z\_axis = .true.}

## **Keyword: INITIAL\_CONDITION**

#### INITIAL\_CONDITION

REGION region\_name

CONDITION condition\_name

TYPE [initial, boundary, source\_sink]

FACE [WEST, EAST, NORTH, SOUTH, BOTTOM, TOP]

**END** 

## **Keyword: LINEAR\_SOLVER**

#### LINEAR\_SOLVER

TRAN, TRANSPORT (tran\_solver) / DEFAULT (flow\_solver)

SOLVER\_TYPE (SOLVER, KRYLOV\_TYPE, KRYLOV, KSP, KSP\_TYPE)

NONE (PREONLY)

**GMRES** 

BCGS (BICGSTAB, BI-CGSTAB)

PRECONDITIONER\_TYPE (PRECONDITIONER, PC, PC\_TYPE)

ILU (PCILU)

LU (PCLU)

BJACOBI (BLOCK\_JACOBI)

ASM (ADDITIVE\_SCHWARTZ)

**PCASM** 

**ATOL** 

RTOL

DTOL

**MAXIT** 

(., /, END)

# **Keyword: MATERIAL (MATERIALS, PHIK)**

## MATERIAL (MATERIALS, PHIK)

name id icap ithrm por tor permx permy permz permpwr

(., /, END)

# **Keyword: MODE**

MODE [RICHARDS\_LITE, RICHARDS, MPH]

## **Keyword: NEWTON\_SOLVER**

#### NEWTON\_SOLVER

TRAN, TRANSPORT (tran\_solver) / DEFAULT (flow\_solver)

INEXACT\_NEWTON

NO\_PRINT\_CONVERGENCE

NO\_INF\_NORM (NO\_INFINITY\_NORM)

NO\_FORCE\_ITERATION

PRINT\_DETAILED\_CONVERGENCE

ATOL

**RTOL** 

**STOL** 

DTOL

ITOL (INF\_TOL, ITOL\_RES, INF\_TOL\_RES)

ITOL\_UPDATE (INF\_TOL\_UPDATE)

**MAXIT** 

MAXF

(., /, END)

# **Keyword: NUMERICAL\_JACOBIAN**

**NUMERICAL\_JACOBIAN** {numerical\_derivatives = .true.}

## **Keyword: ORIGIN (ORIG)**

**ORIGIN (ORIG)** X\_DIRECTION Y\_DIRECTION Z\_DIRECTION

## **Keyword: OVERWRITE\_RESTART\_TRANSPORT**

**OVERWRITE\_RESTART\_TRANSPORT** {overwrite\_restart\_transport = .true.}

#### **Keyword: REGION**

**REGION** region\_name

BLOCK i1 i2 j1 j2 k1 k2

COORDINATE x-coordinate y-coordinate z-coordinate

FILE filename

LIST (not implemented)

FACE [WEST, EAST, NORTH, SOUTH, BOTTOM, TOP]

**END** 

## **Keyword: RESTART**

**RESTART** restart\_file restart\_time

## **Keyword: RICH**

**RICH** pref

## **Keyword: SATURATION\_FUNCTION (SATURATION\_FUNCTIONS, PCKR)**

#### SATURATION\_FUNCTION (SATURATION\_FUNCTIONS, PCKR)

id icaptype [(Sr[np],np=1,nphase), Sr] pckrm alpha pcwmax pbetac pwrprm

(., /, END)

## **Keyword: SOURCE\_SINK**

#### SOURCE\_SINK

REGION region\_name

CONDITION condition\_name

TYPE [initial, boundary, source\_sink]

FACE [WEST, EAST, NORTH, SOUTH, BOTTOM, TOP]

**END** 

#### **Keyword: STRATIGRAPHY (STRATA)**

#### **STRATIGRAPHY (STRATA)**

REGION region\_name

MATERIAL material\_name

**INACTIVE** 

(., /, END)

#### **Keyword: TECP**

**TECP** 

[VELO, FLUX]

## **Keyword: THRM (THERMAL\_PROPERTY, THERMAL\_PROPERTIES)**

#### THRM (THERMAL\_PROPERTY, THERMAL\_PROPERTIES)

 $id\ rock\_density\ spec\_heat\ therm\_cond\_dry\ therm\_cond\_wet\ tort\_bin\_diff\\ vap\_air\_diff\_coef\ exp\_binary\_diff$ 

(., /, END)

## **Keyword: TIME**

TIME	[s, m, h, d, mo, y] [every #]
	t1, t2, t3,

# **Keyword: TIMESTEPPER**

#### **TIMESTEPPER**

NUM\_STEPS\_AFTER\_TS\_CUT [5]

MAX\_STEPS [999999]

TS\_ACCELERATION [5]

MAX\_TS\_CUTS [16]

MAX\_PRESSURE\_CHANGE [5.d4]

MAX\_TEMPERATURE\_CHANGE [5.d0]

MAX\_CONCENTRATION\_CHANGE [1.d0]

MAX\_SATURATION\_CHANGE [0.5d0]

(., /, END)

# **Keyword: TRAN**

TRAN	ntrandof		

# **Keyword: UNIFORM\_VELOCITY**

# UNIFORM\_VELOCITY vlx vly vlz

## **Keyword: USE\_TOUCH\_OPTIONS**

**USE\_TOUCH\_OPTIONS** {use\_touch\_options = .true.}

#### **Keyword: WALLCLOCK\_STOP**

WALLCLOCK\_STOP wallclock\_stop\_time

# **Example Input File**

```
:Description: 2D problem for saturated layered medium
:MODE RICHARDS
MODE RICHARDS_LITE
TRAN 1
:NUMERICAL_JACOBIAN
: INEXACT_NEWTON
:USE_TOUCH_OPTIONS
:CHECKPOINT 1000
:RESTART steady.chk 0.d0
:OVERWRITE_RESTART_TRANSPORT
:COMPUTE_STATISTICS
:USE_TOUCH_OPTIONS
:WALLCLOCK_STOP 0.d0
:
DEBUG
:MATVIEW_JACOBIAN
: VECVIEW_RESIDUAL
: VECVIEW_SOLUTION
:PRINT_COUPLERS
END
GRID
TYPE structured
NXYZ 450 1 4430
END
```

```
ORIGIN 0.d0 0.d0 0.d0
NEWTON_SOLVER
RTOL 1.d-5
ATOL 1.d-7
STOL 1.d-10
:ITOL_RES 1.d-8
:ITOL_UPDATE 0.05d0 ! Pa
NO_INFINITY_NORM
:NO_FORCE_ITERATION
:NO_PRINT_CONVERGENCE
:PRINT_DETAILED_CONVERGENCE
MAXIT 20
END
:noskip
NEWTON_SOLVER TRANSPORT
:RTOL 1.d-50
ATOL 1.d-50
STOL 1.d-50
ITOL_RES 1.d-8
:ITOL_UPDATE 5.dO ! Pa
:NO_INFINITY_NORM
:NO_FORCE_ITERATION
:NO_PRINT_CONVERGENCE
:PRINT_DETAILED_CONVERGENCE
MAXIT 10
END
TIMESTEPPER
TS_ACCELERATION 8
END
:HDF5 !VELO !FLUX
TECP VELO !FLUX
:
DXYZ
0.02d0
1.d0
0.002d0
: d0[m^2/s] delhaq[kJ/mol]
```

BLOCK 1 1 1 1 3931 4430

```
DIFF 1.D-9
               12.6
: Richards Equation Pref
RICH 101325.
SATURATION_FUNCTIONS
: van Genuchten
:id itype swir m alpha pcwmax betac pwr
        0.1600 0.3391 7.2727d-4 1.e8 0.d0 1.d0
1 1
        0.1299 0.7479 1.4319d-4 1.e8
                                  0.d0 1.d0
: Brooks-Corey
:id itype swir lambda alpha
                            pcwmax betac pwr
        0.1600 1.97 7.2727d-4 1.e8 0.d0 1.d0
: 2 2 0.1299 0.5193 1.4319d-4 1.e8 0.d0 1.d0
END
THERMAL_PROPERTIES
:ithm rho
           cpr ckdry cksat tau cdiff cexp
     2.76e3 1000.e0 0.5 0.5 0.5 2.13d-5 1.8
 1
END
MATERIALS
:name id icap ithm por tau permx permy permz permpwr
tuff 1 1 1 0.2 0.5 1.d-19 1.d-19 1.d-19 1.d0
END
:TIME y every 10.
TIME y
0.1 0.25 0.5 0.75 1.
DTST 1.d-8
1. 0.001d0
REGION all
BLOCK 1 450 1 1 1 4430
END
REGION Left
FACE west
```

END

REGION Right
FACE east
BLOCK 450 450 1 1 1 500
END

:define initial and boundary conditions-----

:flow-----

CONDITION initial
CLASS flow
TYPE
PRESSURE hydrostatic

DATUM 0.d0 0.d0 10.d0 PRESSURE 101325.d0

END

CONDITION Left CLASS flow

TYPE

PRESSURE neumann

F.NC

PRESSURE 1.5854896d-7 ! 5000 mm/yr

END

CONDITION Right

CLASS flow

TYPE

PRESSURE neumann

END

PRESSURE -1.5854896d-7 ! 5000 mm/yr

END

:transport-----

CONDITION initial\_c CLASS transport CONCENTRATION 1.d-8 END

CONDITION outlet\_c CLASS transport TYPE CONCENTRATION zero\_gradient END CONCENTRATION 1.d-8 **F.ND** CONDITION inlet\_c CLASS transport CONCENTRATION 1.dO END :set initial and boundary conditions-----:flow-----: initial condition INITIAL\_CONDITION CONDITION initial REGION all END BOUNDARY\_CONDITION CONDITION Left REGION Left END BOUNDARY\_CONDITION CONDITION initial REGION Right END :transport-----: initial condition INITIAL\_CONDITION CONDITION initial\_c

REGION all END

BOUNDARY\_CONDITION CONDITION inlet\_c

DATASET permx perm\_inv.dat DATASET permy perm\_inv.dat DATASET permz perm\_inv.dat