

Bart Tanghe



Agenda

- The past board files
- Device tree
- Device tree compiler
- Compability string registers clock interrupt
- Spi example
- DTS-example
- Demo's and questions



Board files (the past)

- Description of the hardware
- Example raspberry pi (rpi kernel tree)
 - Arch/arm/mach-bcm2708/bcm2708.c
 - Register devices
 - platform_device_register(pdev);
 - Registers, irq, clk



Board files (the past)

some_init_code() {


}

From arch/arm/mach-at91/at91sam9263_devices.c static struct resource udc_resources[] = {] = [0].start = AT91SAM9263_BASE_UDP, .end = $AT91SAM9263_BASE_UDP + SZ_16K - 1$, .flags = IORESOURCE_MEM, }, $\lceil 1 \rceil = \{$.start = NR_IRQS_LEGACY + AT91SAM9263_ID_UDP, .end = NR_IRQS_LEGACY + AT91SAM9263_ID_UDP, .flags = IORESOURCE_IRQ, }, }; static struct platform_device at91_udc_device = { = "at91_udc", .name .id = -1, .dev = { .platform_data = &udc_data, }, = udc_resources, .resource .num_resources = ARRAY_SIZE(udc_resources), };

platform_device_register(&at91_udc_device);



- XML
- Description of the hardware
- http://www.devicetree.org/Main_Page



```
#include <dt-bindings/interrupt-controller/irq.h>
#include "imx6dl-pinfunc.h"
#include "imx6qdl.dtsi"
        aliases {
                i2c3 = &i2c4;
       cpus {
                #address-cells = <1>;
                #size-cells = <0>;
                cpu@0 {
                        compatible = "arm, cortex-a9";
                        device_type = "cpu";
                        rea = <0>;
                        next-level-cache = <&L2>;
                        operating-points = <
                                /* kHz
                                          uV */
                                996000 1250000
                                792000 1175000
                                396000 1075000
                        fsl, soc-operating-points = <
                                /* ARM kHz SOC-PU uV */
                                996000 1175000
                                792000 1175000
                                396000 1175000
                        clock-latency = <61036>; /* two CLK32 periods */
                        clocks = <&clks IMX60DL CLK ARM>,
                                 <&clks IMX6QDL_CLK_PLL2_PFD2_396M>,
                                 <&clks IMX6QDL CLK STEP>,
                                 <&clks IMX6QDL_CLK_PLL1_SW>,
                                 <&clks IMX60DL CLK PLL1 SYS>;
                        clock-names = "arm", "pl12_pfd2_396m", "step",
                                      "pll1_sw", "pll1_sys";
                        arm-supply = <&reg_arm>;
                        pu-supply = <&req pu>;
                        soc-supply = <&reg_soc>;
```



- Dts directory
 - arch/arm/boot/dts
 - Most common platforms
- Device tree bindings documentation
 - Documentation/devicetree/bindings
 - ex. pwm/mxs-pwm.txt



Freescale MXS PWM controller

```
Required properties:
- compatible: should be "fsl,imx23-pwm"
- reg: physical base address and length of the controller's registers
- #pwm-cells: should be 2. See pwm.txt in this directory for a description of the cells format.
- fsl,pwm-number: the number of PWM devices
Example:
pwm: pwm@80064000 {
       compatible = "fsl,imx28-pwm", "fsl,imx23-pwm";
       reg = <0x80064000 0x2000>;
       #pwm-cells = <2>;
       fsl,pwm-number = <8>;
};
```



```
Node name
                              Unit address

    Property name

                                                         Property value
                 node@0 {
                     a-string-property = "A string";
                     a-string-list-property = "first string", "second string";
Properties of node@0
                     a-byte-data-property = [0x01 \ 0x23 \ 0x34 \ 0x56];
                     child-node@0 {
                         first-child-property;
                                                             Bytestring
                         second-child-property = <1>;
                         a-reference-to-something = <&node1>;
                     };
                                               A phandle.
                     child-node@1 {
                                               (reference to another node)
         Label.
                     };
                 node1: node@1 {
                     an-empty-property;
                     a-cell-property = <1 2 3 4>;
                     child-node@0 {
                                                  Four cells (32 bits values)
                     };
                 };
            };
```



Device tree compiler

- Device tree compiler (dtc)
- Device tree blob
- Binary code
- Dts => dtb
- Linux source directory
 - scripts/dtc/dtc -I dts -O dtb -o my-tree.dtb my-tree.dts
 - scripts/dtc/dtc -I dtb -O dts -o my-tree.dts my-tree.dtb



Device tree files

- Predefined dts and dtsi (dts include)
- Arch/arm/boot/dts
 - bcm2835.dtsi bcm2835-rpi-b.dts
 - imx6qdl.dtsi imx6qdl-udoo.dtsi imx6q-udoo.dts
 - zynq-7000.dtsi zynq-zed.dts




Device tree boot

- make ARCH=arm CROSS_COMPILE=arm-linux-gnueabi- dtbs -j4
- make ARCH=arm CROSS_COMPILE=arm-linux-gnueabi- zlmage -j4
- U-boot

```
mmc dev 0
setenv fdtfile bcm2835-rpi-b.dtb
setenv bootargs earlyprintk console=tty0 console=ttyAMA0 root=/dev/mmcblk0p2 rootwait
fatload mmc 0:1 ${kernel_addr_r} zImage
fatload mmc 0:1 ${fdt_addr_r} ${fdtfile}
bootz ${kernel_addr_r} - ${fdt_addr_r}
mmc dev 0
setenv fdtfile bcm2835-rpi-b-plus.dtb
setenv bootargs earlyprintk console=tty0 console=ttyAMA0 root=/dev/mmcblk0p2 rootwait
fatload mmc 0:1 ${kernel_addr_r} zImage
fatload mmc 0:1 ${fdt_addr_r} ${fdtfile}
bootz ${kernel_addr_r} - ${fdt_addr_r}
```



Device tree boot





Device tree boot output

```
switch to partitions #0, OK
mmc0 is current device
Scanning mmc 0...
Found U-Boot script /boot.scr.uimg
reading /boot.scr.uimg
337 bytes read in 14 ms (23.4 KiB/s)
## Executing script at 00000000
switch to partitions #0, OK
mmc0 is current device
reading zImage
3416104 bytes read in 548 ms (5.9 MiB/s)
reading bcm2835-rpi-b.dtb
4362 bytes read in 14 ms (303.7 KiB/s)
Kernel image @ 0x1000000 [ 0x000000 - 0x342028 ]
## Flattened Device Tree blob at 02000000
   Booting using the fdt blob at 0x2000000
   Loading Device Tree to 1bb46000. end 1bb4a109 ... OK
Starting kernel ...
Uncompressing Linux... done, booting the kernel.
     0.000000] Booting Linux on physical CPU 0x0
     0.000000] Initializing cgroup subsys cpuset
     0.000000] Initializing cgroup subsys cpu
```



Bcm2835-rpi-b-plus.dts

```
/dts-v1/;
/include/ "bcm2835-rpi.dtsi"
/ {
         compatible = "raspberrypi,model-b-plus", "brcm,bcm2835";
         model = "Raspberry Pi Model B+";
                                                                       Ras
                                                                       Rev
         leds {
                 act {
                         gpios = <&gpio 47 0>;
                 };
                 pwr {
                         label = "PWR";
                         gpios = <&gpio 35 0>;
                          default-state = "keep";
                          linux.default-trigger = "default-on";
                 };
         };
};
&gpio {
         pinctrl-0 = <&gpioout &alt0 &i2s_alt0 &alt3>;
         /* I2S interface */
         i2s_alt0: i2s_alt0 {
                 brcm,pins = <18 19 20 21>;
                 brcm,function = <4>; /* alt0 */
         };
};
```

GPIO Numbers

aspberry Pi B				Raspberry Pi A/B					
ev 1 P1 GPIO Header				Rev 2 P1 GPIO Header					
Pin No.					Pin No				
3.3V	1	2	5V		3.3V	1	2	5V	
GPIO0	3	4	5V		GPIO2	3	4	5V	
GPIO1	5	6	GND		GPIO3	5	6	GND	
GPIO4	7	8	GPIO14		GPIO4	7	8	GPIO14	
GND	9	10	GPIO15		GND	9	10	GPIO15	
PIO17	11	12	GPIO18		GPIO17	11	12	GPIO18	
PI021	13	14	GND		GPIO27	13	14	GND	
PIO22	15	16	GPIO23		GPIO22	15	16	GPIO23	
3.3V	17	18	GPIO24		3.3V	17	18	GPIO24	
PIO10	19	20	GND		GPIO10	19	20	GND	
GPIO9	21	22	GPIO25		GPIO9	21	22	GPIO25	
PIO11	23	24	GPIO8		GPIO11	23	24	GPIO8	
GND	25	26	GPIO7		GND	25	26	GPIO7	

Key

GND

Power + UART

SPI

GPIO

D. GO OI IO HOUGO									
Pin No.									
3.3V	1	2	5V						
GPIO2	3	4	5V						
GPIO3	5	6	GND						
GPIO4	7	8	GPIO14						
GND	9	10	GPIO15						
GPIO17	11	12	GPIO18						
GPIO27	13	14	GND						
GPIO22	15	16	GPIO23						
3.3V	17	18	GPIO24						
GPIO10	19	20	GND						
GPIO9	21	22	GPIO25						
GPIO11	23	24	GPIO8						
GND	25	26	GPIO7						
DNC	27	28	DNC						
GPI05	29	30	GND						
GPIO6	31	32	GPIO12						

Raspberry Pi B+

B+ J8 GPIO Header



GPIO13 33 34 **GND**

GPIO19 35 36 GPIO16

GPIO26 37 38 GPIO20 GND 39 40 GPIO21

Udoo quad (multiplatform kernel)

```
setenv bootargs 'console=ttymxc1,115200 root=/dev/mmcblk0p1 rootwait rw rootfstype=ext4 consoleblank=0' setenv fdt_addr 0x12000000 ext2load mmc ${mmcdev}:${mmcpart} ${fdt_addr} /boot/imx6q-udoo.dtb ext2load mmc ${mmcdev}:${mmcpart} 10800000 /boot/ulmage bootm 10800000 - ${fdt_addr}
```



Udoo dual versus quad

imx6dl.dtsi

```
cpus {
               #address-cells = <1>;
               #size-cells = <0>;
               cpu@0 {
                       compatible = "arm,cortex-a9";
                       device type = "cpu";
                       reg = <0>;
                       next-level-cache = <&L2>;
                       operating-points = <
                               /* kHz uV */
                               996000 1250000
                               792000 1175000
               };
               cpu@1 {
                       compatible = "arm,cortex-a9";
                       device type = "cpu";
                       reg = <1>;
                       next-level-cache = <&L2>;
               };
       };
       soc {
```

Imx6q.dtsi

```
cpus {
          #address-cells = <1>;
          #size-cells = <0>;
          cpu@0 {
                   compatible = "arm,cortex-a9";
                   device type = "cpu";
                   reg = <0>;
                   soc-supply = <&reg soc>;
         };
          cpu@1 {
                   compatible = "arm,cortex-a9";
                   device type = "cpu";
                   reg = <1>;
                   next-level-cache = <&L2>;
         };
          cpu@2 {
                   compatible = "arm,cortex-a9";
                   device type = "cpu";
                   rea = <2>:
                   next-level-cache = <&L2>:
         };
          cpu@3 {
                   compatible = "arm,cortex-a9";
                   device type = "cpu";
                   reg = <3>;
                   next-level-cache = <&L2>;
         };
};
soc {
```



Udoo dual versus quad

```
CPU identified as i.MX6Q, silicon rev 1.2
Console: colour dummy device 80x30
Calibrating delay loop... 1581.05 BogoMIPS (lpj=7905280)
pid max: default: 32768 minimum: 301
Mount-cache hash table entries: 512
CPU: Testing write buffer coherency: ok
CPU0: thread -1, cpu 0, socket 0, mpidr 80000000
Setting up static identity map for 0x805c0638 - 0x805c0690
CPU1: Booted secondary processor
CPU1: thread -1, cpu 1, socket 0, mpidr 80000001
CPU2: Booted secondary processor
CPU2: thread -1, cpu 2, socket 0, mpidr 80000002
CPU3: Booted secondary processor
CPU3: thread -1, cpu 3, socket 0, mpidr 80000003
Brought up 4 CPUs
SMP: Total of 4 processors activated (6324.22 BogoMIPS).
CPU: All CPU(s) started in SVC mode.
devtmpfs: initialized
pinctrl core: initialized pinctrl subsystem
```



Compatible string

DTS

Driver code

```
static int bcm2835 pwm probe(struct platform device *pdev)
                                                           //probe
       r = platform get resource(pdev, IORESOURCE MEM, 0);
       pwm->base = devm ioremap resource(&pdev->dev, r);
       clk = devm clk get(&pdev->dev, NULL);
       static const struct of device id bcm2835 pwm of match[] = {
              { .compatible = "brcm,bcm2835-pwm",
              { /* sentinel */ }
       };
       MODULE DEVICE TABLE(of, bcm2835 pwm of match);
Compatible with board files
       static struct platform_driver bcm2835 pwm driver = {
               .driver = {
                      .name = "bcm2835-pwm",
                      of match table bcm2835 pwm of match
              .probe = bcm2835 pwm probe,
              .remove = bcm2835 pwm remove,
       module platform driver(bcm2835 pwm driver);
```



Clocks – fixed clock (root clock)

DTS

Driver code

```
static int bcm2835 pwm probe(struct platform device *pdev)
                                                            //probe
       r = platform get resource(pdev, IORESOURCE MEM, 0);
       pwm->base = devm_ioremap_resource(&pdev->dev, r);
       clk = devm clk get(&pdev->dev, NULL);
       static const struct of device id bcm2835 pwm of match[] = {
               { .compatible = "brcm,bcm2835-pwm", },
              { /* sentinel */ }
       };
       MODULE DEVICE TABLE(of, bcm2835 pwm of match);
Compatible with board files
       static struct platform driver bcm2835 pwm driver = {
               .driver = {
                      .name = "bcm2835-pwm",
                      .of match table = bcm2835 pwm of match,
              .probe = bcm2835 pwm probe,
               .remove = bcm2835 pwm remove,
       module platform driver(bcm2835 pwm driver);
```



Registers


DTS

Driver code

```
static int bcm2835_pwm_probe(struct platform_device *pdev)
                                                           //probe
       r platform get resource(rdev, IORESOURCE MEM, 0);
       pwni->base = devm_ioremap_resource(&pdev->dev, r);
       clk = devm clk get(&pdev->dev, NULL);
       static const struct of_device_id bcm2835_pwm_of_match[] = {
               { .compatible = "brcm,bcm2835-pwm", },
              { /* sentinel */ }
       };
       MODULE DEVICE TABLE(of, bcm2835 pwm of match);
Compatible with board files
       static struct platform driver bcm2835 pwm driver = {
               .driver = {
                      .name = "bcm2835-pwm",
                      .of match table = bcm2835 pwm of match,
               .probe = bcm2835 pwm probe,
               .remove = bcm2835 pwm remove,
       module platform driver(bcm2835 pwm driver);
```



Interrupt






Interrupt

```
interrupt-parent = <&intc>;
intc: interrupt-controller {
  compatible = "arm, cortex-a9-gic";
  reg = <0x50041000 0x1000 0x50040100 0x0100>;
  interrupt-controller;
  #interrupt-cells = <3>;
};
i2c@7000c000 {
  compatible = "nvidia, tegra20-i2c";
  reg = <0x7000c000 0x100>;
  interrupts = <GIC_SPI 38 IRQ_TYPE_LEVEL_HIGH>;
  #address-cells = <1>;
  #size-cells = <0>;
  [...]
};
gpio: gpio {
    compatible = "nvidia, tegra20-gpio";
    reg = <0x6000d000 0x1000>;
    interrupts = <GIC_SPI 32 IRQ_TYPE_LEVEL_HIGH>, <GIC_SPI 33 IRQ_TYPE_LEVEL_HIGH>,
         [...], <GIC_SPI 89 IRQ_TYPE_LEVEL_HIGH>;
    #gpio-cells = <2>;
    gpio-controller;
    #interrupt-cells = <2>;
    interrupt-controller;
};
```



Pinctrl





Pinctrl

```
&gpio {
    pinctrl-names = "default";
    gpioout: gpioout {
         brcm,pins = <6>;
         brcm,function = <1>; /* GPIO out */
    };
    alt0: alt0 {
         brcm,pins = <0 1 2 3 4 5 7 8 9 10 11 14 15 40 45>;
         brcm,function = <4>; /* alt0 */
    };
    alt3: alt3 {
         brcm,pins = <48 49 50 51 52 53>;
         brcm,function = <7>; /* alt3 */
    };
};
```



Device tree kernel functions

drivers/of/base.c


* Procedures for creating, accessing and interpreting the device tree.

Example drivers/clk/clkdev.c

```
if (np && !of_get_property(np, "clock-ranges", NULL))
```











Zedboard – add pwm to design





Zedboard – add pwm to design






Zedboard - add pwm to design

https://github.com/Xilinx/device-tree-xlnx

Generate the dts file





Zedboard - dts

```
axi timer 0: timer@42800000 {
              clock-frequency = <100000000>;
              \#pwm-cells = <1>;
              clocks = <\&clkc 15>;
              compatible = "xlnx,xlnx-pwm";
              reg = <0x42800000 0x10000>;
              xlnx,count-width = <0x20>;
              xlnx,gen0-assert = <0x1>;
              xlnx,gen1-assert = <0x1>;
              xInx,one-timer-only = <0x0>;
              xlnx,trig0-assert = <0x1>;
              xlnx,trig1-assert = <0x1>;
axi timer 1: timer@42810000 {
              clock-frequency = <100000000>;
              \#pwm-cells = <1>;
              clocks = <\&clkc 15>;
              compatible = "xlnx,xlnx-pwm";
              reg = <0x42810000 0x10000>;
```



SD-card

- boot.bin
 (first stage bootloader, hardware configuration, u-boot)
- ulmage
- uramdisk

Remark: bootargs in the devicetree file

u-boot> fatload mmc 0 0x3000000 ulmage

u-boot> fatload mmc 0 0x2A00000 devicetree.dtb

u-boot> fatload mmc 0 0x2000000 uramdisk.image.gz

u-boot> bootm 0x3000000 0x2000000 0x2A00000



```
## Booting kernel from Legacy Image at 03000000 ...
   Image Name: Linux-3.13.0-xilinx-dirty
  Image Type: ARM Linux Kernel Image (uncompressed)
  Data Size: 3594728 Bytes = 3.4 MiB
  Load Address: 00008000
  Entry Point: 00008000
  Verifying Checksum ... OK
## Loading init Ramdisk from Legacy Image at 02000000 ...
  Image Name:
  Image Type: ARM Linux RAMDisk Image (gzip compressed)
  Data Size: 2512223 Bytes = 2.4 MiB
  Load Address: 00000000
  Entry Point: 00000000
  Verifying Checksum ... OK
## Flattened Device Tree blob at 02a00000
   Booting using the fdt blob at 0x2a00000
  Loading Kernel Image ... OK
  Loading Ramdisk to 1eabf000, end 1ed2455f ... OK
  Loading Device Tree to 1eab9000, end 1eabe974 ... OK
Starting kernel ...
Uncompressing Linux... done, booting the kernel.
    0.000000] Booting Linux on physical CPU 0x0
    0.000000] Linux version 3.13.0-xilinx-dirty (emsys@pc12) (gcc version 4.7.3 (Sou
     0.000000] CPU: ARMv7 Processor [413fc090] revision 0 (ARMv7), cr=18c5387d
```



devicetree_4pwm.dtb

```
zynq> ls /sys/class/pwm/
zynq> insmod /home/bta/xlnx-pwm.ko
zynq> ls /sys/class/pwm/
pwmchip0 pwmchip1 pwmchip2 pwmchip3
zvnq>
```

devicetree_2pwm.dtb


```
zynq> ls /sys/class/pwm/
zynq> insmod /home/bta/xlnx-pwm.ko
zynq> ls /sys/class/pwm/
pwmchip0 pwmchip1
zynq>
```

Look at the source with

scripts/dtc/dtc -I dtb -O dts -o /devicetree_2pwm.dts system_2pwm.dtb



MCP2515





MCP2515 (board file)

```
static struct platform_device bcm2708_spi_device = {
      .name = "bcm2708_spi",
      .id = 0,
      .num_resources = ARRAY_SIZE(bcm2708_spi_resources),
      .resource = bcm2708_spi_resources,
      .dev = {
            .dma_mask = &bcm2708_spi_dmamask,
            .coherent dma mask = DMA BIT MASK(DMA MASK BITS COMMON)},
};
static struct mcp251x_platform_data mcp251x_info = {
   .oscillator_frequency
                          16000000,
                           = NULL,
   .board_specific_setup
   .irq_flags
                           = IRQF_TRIGGER_FALLING,
   .power_enable
                           = NULL,
   .transceiver_enable
                           = NULL,
};
static struct spi_board_info bcm2708_spi_devices[] = {
      .modalias = "mcp2515",
      .max\_speed\_hz = 10000000,
      .platform_data = &mcp251x_info,
      /* .irg = unknown , defined later thru bcm2708_mcp251x_init */
       .bus num = 0
       .chip_select = 0,
       .mode = SPI_MODE_0
};
```



MCP2515 (dts - tegra30-apalis.dtsi)

```
/* SPI4: CAN2 */
spi@7000da00 {
      status = "okay";
      spi-max-frequency = <10000000>;
      can@1 {
            compatible "microchip, mcp2515";
            reg <1>:
            clocks < <&clk16m>;
            interrupt parent <&gpio>;
            interrupts = <TEGRA_GPIO(W, 3) GPIO_ACTIVE_LOW>;
            spi-max-frequency = <10000000>;
      };
};
clocks {
      compatible = "simple-bus";
      #address-cells = <1>;
      #size-cells = <0>;
      clk32k_in: clk@0 {
            compatible = "fixed-clock";
            req=<0>;
            #clock-cells = <0>;
            clock-frequency = <32768>;
      clk16m: clk@1 {
            compatible = "fixed-clock";
            reg=<1>;
            #clock-cells = <0>;
            clock-frequency = <16000000>;
            clock-output-names = "clk16m";
      };
```

};



DTS-example

https://github.com/btanghe/device_tree/

```
example@0 {
    compatible = "general,dts-example";
    reg = <0xdeadbeef 0x40>;
    clocks = <0x2 0xa1>;
    clock-names = "per";
    custom-var = <0x200>;
    interrupts = <0x0 0x1b 0x4>;
    status = "okay";
};
```



Demo's and questions



Resource

Device tree for dummies

http://events.linuxfoundation.org/sites/events/files/slides/petazzoni-device-tree-dummies.pdf

Xillybus zynq device tree

http://www.xillybus.com/tutorials/device-tree-zynq-2

Arm in the linux kernel

https://archive.fosdem.org/2013/schedule/event/arm_in_the_linux_k ernel/attachments/slides/273/export/events/attachments/arm_in_the_linux_kernel/slides/273/arm_support_kernel.pdf

Linux kernel tree

