# **API Reference**

# BTC Embedded Platform - RESTful API documentation

API Version: 23.2p0

This is the documentation for the BTC Embedded Platform RESTful API.

#### **CONTACT**

EMAIL: support@btc-embedded.com

# **INDEX**

1. APPLICATION	8
1.1 DELETE /ep/application	8
2. ARCHITECTURES	9
2.1 POST /ep/architectures/ccode	9
2.2 POST /ep/architectures/embedded-coder-wrapper-creation	9
2.3 POST /ep/architectures/embedded-coder	10
2.4 POST /ep/architectures/targetlink-ev	11
2.5 POST /ep/architectures/mdf	12
2.6 POST /ep/architectures/sdf	13
2.7 GET /ep/architectures/{architecture-uid}	14
2.8 GET /ep/architectures	15
2.9 PUT /ep/architectures	15
2.10 PUT /ep/architectures/model-paths	16
2.11 POST /ep/architectures/simulink	17
2.12 POST /ep/architectures/targetlink	18
2.13 POST /ep/architectures/userdefined	20
3. BACK-TO-BACK TEST REPORTS	22
3.1 POST /ep/b2b/{b2b-test-uid}/b2b-reports	22
3.2 GET /ep/b2b-reports	22
4. BACK-TO-BACK TESTS	24
4.1 GET /ep/b2b/{b2b-uid}	24
4.2 PATCH /ep/b2b/{b2b-uid}	25
4.3 POST /ep/folders/{folder-uid}/b2b	25
4.4 POST /ep/folders/b2b	26
4.5 POST /ep/scopes/{scope-uid}/b2b	27
4.6 POST /ep/scopes/b2b	28
4.7 GET /ep/b2b	29
5. CODE ANALYSIS REPORTS B2B	31
<pre>5.1 POST /ep/folders/{folder-uid}/code-analysis-reports-b2b</pre>	31
5.2 POST /ep/folders/code-analysis-reports-b2b	31
5.3 POST /ep/scopes/{scope-uid}/code-analysis-reports-b2b	32
5.4 GET /ep/code-analysis-reports-b2b	33
6. CODE ANALYSIS REPORTS RBT	34
<pre>6.1 POST /ep/folders/{folder-uid}/code-analysis-reports-rbt</pre>	34
6.2 POST /ep/folders/code-analysis-reports-rbt	34
<pre>6.3 POST /ep/requirements-sources/{requirements-source-uid}/code-analysis- reports-rbt</pre>	35
6.4 POST /ep/requirements-sources/code-analysis-reports-rbt	36
6.5 POST /ep/scopes/{scope-uid}/code-analysis-reports-rbt	37

6.6 GET /ep/code-analysis-reports-rbt	37
7. CODE COVERAGE/ROBUSTNESS CHECK B2B	39
7.1 GET /ep/scopes/{scope-uid}/coverage-details-b2b	39
7.2 GET /ep/scopes/{scope-uid}/coverage-results-b2b	40
7.3 POST /ep/coverage-goals/set-comment-b2b	50
7.4 POST /ep/coverage-goals/set-justified-b2b	50
7.5 POST /ep/scopes/{scope-uid}/set-coverage-overview-comment-b2b	51
8. CODE COVERAGE/ROBUSTNESS CHECK RBT	52
8.1 GET /ep/requirements-sources/{requirement-source-uid}/coverage-details-rbt	52
8.2 GET /ep/scopes/{scope-uid}/coverage-details-rbt	53
8.3 GET /ep/requirements-sources/{requirements-source-uid}/coverage-results-rbt	54
8.4 GET /ep/scopes/{scope-uid}/coverage-results-rbt	64
8.5 POST /ep/coverage-goals/set-comment-rbt	74
8.6 POST /ep/coverage-goals/set-justified-rbt	75
8.7 POST /ep/scopes/{scope-uid}/set-coverage-overview-comment-rbt	75
9. COVERAGE GENERATION	77
9.1 POST /ep/coverage-generation	77
10. DOMAIN CHECKS	80
10.1 POST /ep/domain-checks-ranges	80
10.2 POST /ep/domain-checks-export	80
10.3 GET /ep/scopes/{scope-uid}/domain-check-details	81
10.4 GET /ep/scopes/{scope-uid}/domain-checks-results	82
10.5 POST /ep/domain-checks	84
10.6 POST /ep/domain-check-comments	85
11. EXECUTION CONFIGS	86
11.1 GET /ep/execution-configs	86
12. EXECUTION RECORDS	87
12.1 GET /ep/execution-records/{execution-record-uid}	87
12.2 DELETE /ep/execution-records/{execution-record-uid}	87
12.3 POST /ep/execution-records-export	88
12.4 GET /ep/execution-records	89
12.5 POST /ep/execution-records	89
12.6 GET /ep/folders/{folder-uid}/execution-records	90
12.7 PUT /ep/folders/{folder-uid}/execution-records	91
12.8 GET /ep/scopes/{scope-uid}/execution-records	92
13. FOLDERS	94
13.1 GET /ep/folders	94
13.2 POST /ep/folders	94
13.3 DFLFTF /ep/folders/{folder-uid}	95

14. FORMAL SPECIFICATION REPORTS	97
14.1 GET /ep/formal-specification-reports	97
14.2 POST /ep/formal-specification-reports	97
15. FORMAL SPECIFICATIONS	99
15.1 GET /ep/environmental-assumptions	99
15.2 GET /ep/formal-requirements	99
15.3 GET /ep/formal-requirements/{formal-requirement-uid}/environmental-assumptions	100
15.4 POST /ep/specifications-export	101
15.5 POST /ep/specifications-import	102
16. FORMAL TEST EXECUTION	103
16.1 POST /ep/execute-formal-test	103
17. FORMAL TEST REPORTS	104
17.1 POST /ep/formal-requirements/{formal-requirement-uid}/formal-test-reports	104
17.2 POST /ep/formal-requirements/formal-test-reports	105
17.3 POST /ep/requirements-sources/{requirements-source-uid}/formal-test-reports	105
17.4 POST /ep/requirements-sources/formal-test-reports	106
17.5 POST /ep/scopes/{scope-uid}/formal-test-reports	107
17.6 POST /ep/scopes/formal-test-reports	108
17.7 GET /ep/formal-test-reports	108
18. FORMAL VERIFICATION REPORTS	110
18.1 POST /ep/scopes/{scope-uid}/formal-verification-reports	110
18.2 GET /ep/formal-verification-reports	111
19. INPUT RESTRICTIONS	112
19.1 POST /ep/input-restrictions-export	112
19.2 POST /ep/input-restrictions-import	112
20. INTERFACE REPORTS	114
20.1 POST /ep/scopes/{scope-uid}/interface-reports	114
20.2 GET /ep/interface-reports	114
21. MATLAB SCRIPT EXECUTION	116
21.1 POST /ep/execute-long-matlab-script	116
21.2 POST /ep/execute-short-matlab-script	116
22. MESSAGES	118
22.1 POST /ep/message-markers	118
22.2 GET /ep/message-markers/{marker-date}/messages	118
22.3 GET /ep/messages	119
22.4 POST /ep/messages	120
22.5 DELETE /ep/messages	120

22.6 GET /ep/messages/{message-uid}	121
22.7 DELETE /ep/messages/{message-uid}	122
22.8 POST /ep/messages/message-report	122
23. MODEL COVERAGE REPORTS	124
23.1 POST /ep/folders/{folder-uid}/model-coverage-reports	124
23.2 POST /ep/folders/model-coverage-reports	125
23.3 POST /ep/scopes/{scope-uid}/model-coverage-reports	125
23.4 GET /ep/model-coverage-reports	126
24. PREFERENCES	128
24.1 GET /ep/preferences/{preference-name}	128
24.2 PUT /ep/preferences	128
25. PROFILES	130
25.1 GET /ep/profiles	130
25.2 PUT /ep/profiles	130
25.3 POST /ep/profiles	131
25.4 DELETE /ep/profiles	131
25.5 GET /ep/profiles/{profile-path}	132
26. PROGRESS	134
26.1 GET /ep/progress	134
27. PROJECT REPORTS	136
27.1 POST /ep/scopes/{scope-uid}/project-report	136
27.2 GET /ep/project-reports	136
28. PROOFS	138
28.1 GET /ep/proofs/{proofUID}	138
28.2 PUT /ep/proofs/{proofUID}	139
28.3 POST /ep/proofs/{frUid}	140
28.4 POST /ep/proofs/{proofUID}/execute	141
28.5 GET /ep/proofs	142
28.6 GET /ep/proofs/{proofUID}/detailed-proof-results	142
29. REAL-TIME TESTING	144
29.1 POST /ep/rtt-observers-export	144
30. REGRESSION TEST REPORTS	145
30.1 POST /ep/regression-tests/{regression-test-uid}/regression-test-reports	145
30.2 GET /ep/regression-test-reports	145
31. REGRESSION TESTS	147
31.1 GET /ep/regression-tests/{regression-test-uid}	147
31.2 PATCH /ep/regression-tests/{regression-test-uid}	148
31.3 POST /ep/folders/{folder-uid}/regression-tests	148

31.4 POST /ep/folders/regression-tests	149
31.5 GET /ep/regression-tests	150
32. REPORTS	152
32.1 GET /ep/reports/{report-uid}	152
32.2 POST /ep/reports/{report-uid}	152
33. REQUIREMENT-BASED TEST CASES	154
33.1 GET /ep/test-cases-rbt/{testcase-uid}	154
33.2 DELETE /ep/test-cases-rbt/{testcase-uid}	155
33.3 POST /ep/test-cases-rbt-export	155
33.4 GET /ep/test-cases-rbt	156
33.5 PUT /ep/test-cases-rbt	157
33.6 GET /ep/test-cases-rbt/polarion	158
33.7 GET /ep/folders/{folder-uid}/test-cases-rbt	158
33.8 GET /ep/scopes/{scope-uid}/test-cases-rbt	159
33.9 POST /ep/synchronize-rbt-test-cases	160
33.10 GET /ep/requirements/{requirement-uid}/test-cases-rbt	161
33.11 PUT /ep/requirements/test-cases-rbt	162
33.12 POST /ep/requirements/test-cases-rbt	163
33.13 POST /ep/formal-requirements/test-cases-rbt	163
34. REQUIREMENT-BASED TEST EXECUTION	166
34.1 POST /ep/folders/{folder-uid}/test-execution-rbt	166
34.2 POST /ep/folders/test-execution-rbt	167
34.3 POST /ep/test-cases-rbt/{testcase-uid}/test-execution-rbt	167
34.4 POST /ep/test-cases-rbt/test-execution-rbt	168
34.5 POST /ep/requirements-sources/{requirements-source-uid}/test-execution-rbt	169
34.6 POST /ep/requirements-sources/test-execution-rbt	170
34.7 POST /ep/scopes/{scope-uid}/test-execution-rbt	171
34.8 POST /ep/scopes/test-execution-rbt	172
35. REQUIREMENT-BASED TEST EXECUTION REPORTS	173
35.1 POST /ep/folders/{folder-uid}/test-execution-reports-rbt	173
35.2 POST /ep/folders/test-execution-reports-rbt	173
35.3 POST /ep/requirements-sources/{requirements-source-uid}/test-execution-reports-rbt	174
35.4 POST /ep/requirements-sources/test-execution-reports-rbt	175
35.5 POST /ep/scopes/{scope-uid}/test-execution-reports-rbt	176
35.6 POST /ep/scopes/test-execution-reports-rbt	177
35.7 GET /ep/test-execution-reports-rbt	177
36. REQUIREMENTS	179
36.1 GET /ep/requirements-sources	179
36.2 GET /ep/requirements/{requirement-source-id}	179

36.3 GET /ep/scopes/{scope-id}/linked-requirements	180
37. REQUIREMENTS IMPORT	183
37.1 POST /ep/requirements-import	183
37.2 GET /ep/requirements-import/doors	184
37.3 GET /ep/requirements-import/excel	184
37.4 GET /ep/requirements-import/polarion	185
38. SCOPES	187
38.1 GET /ep/scopes/{scope-uid}	187
38.2 GET /ep/scopes	187
39. SIGNALS	189
39.1 GET /ep/scopes/{scope-uid}/signals	189
40. STIMULI VECTORS	190
40.1 GET /ep/stimuli-vectors/{stimuli-vector-uid}	190
40.2 DELETE /ep/stimuli-vectors/{stimuli-vector-uid}	190
40.3 POST /ep/stimuli-vectors-export	191
40.4 GET /ep/stimuli-vectors	192
40.5 PUT /ep/stimuli-vectors	192
40.6 GET /ep/folders/{folder-uid}/stimuli-vectors	193
40.7 GET /ep/scopes/{scope-uid}/stimuli-vectors	194
41. TEST	195
41.1 GET /ep/test	195
42. TEST CASE/STIMULI VECTOR SIMULATION	196
42.1 POST /ep/folders/{folder-uid}/testcase-simulation	196
42.2 POST /ep/folders/testcase-simulation	197
42.3 POST /ep/scopes/{scope-uid}/testcase-simulation	197
42.4 POST /ep/scopes/testcase-simulation	198
42.5 POST /ep/test-cases/{testcase-uid}/testcase-simulation	199
42.6 POST /ep/test-cases/testcase-simulation	200
43. TOLERANCES	201
43.1 POST /ep/profiles/export-global-tolerances	201
43.2 GET /ep/scopes/{scope-id}/global-tolerances	201
43.3 PUT /ep/profiles/global-tolerances	202
43.4 DELETE /ep/profiles/global-tolerances	203
43.5 GET /ep/test-cases/{test-case-id}/local-tolerances	204
43.6 PUT /ep/test-cases/{test-case-id}/local-tolerances	205
43.7 POST /ep/test-cases/{test-case-id}/local-tolerances	205
43.8 DELETE /ep/test-cases/{test-case-id}/local-tolerances	206

# API

# 1. APPLICATION

Handle the EP application itself.

# 1.1 DELETE /ep/application

#### Exit EP and save the active profile

After calling the exit method, the current active profile will be saved, if there is one. If the profile has no save path, one is created at a temporary directory and a response containing the path is returned.

#### **REQUEST**

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
force- quit	boolean	If set to 'true', the application will force quit without saving the active profile. br>lf set to 'false', the profile is saved at the given location, or at a temporary location if provided none. br>Default is 'false'

#### **RESPONSE**

STATUS CODE - 200: OK

RESPONSE MODEL - text/plain

string

STATUS CODE - 201: Created

RESPONSE MODEL - text/plain

string

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 2. ARCHITECTURES

Import and retrieve architectures.

# 2.1 POST /ep/architectures/ccode

#### Import a C-Code architecture

<br/> <b>Long running task</b> Import a C-Code architecture. Settings are provided as an import info object.

#### **REQUEST**

```
REQUEST BODY - application/json

{
    modelFile* string File name of the C-Code XML file
    mappingFile string File name of the mapping XML file. The file must be provided if architectures are already available in the profile. The file is used to map the first imported architecture to the new imported C-Code architecture.
}
```

#### **RESPONSE**

STATUS CODE - 202: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

## 2.2 POST /ep/architectures/embedded-coder-wrapper-creation

#### Create an EmbeddedCoder™ wrapper model

<b>Long running task</b> Creating an EmbeddedCoder™ wrapper model. Settings are provided as an import wrapper info object.

#### **REQUEST**

```
REQUEST BODY - application/json
{
    ecModelFile* string The absolute or relative path to the Embedded Coder model.
    ecInitScript string The absolute or relative path to the init script of the Embedded Coder model.
```

}

## **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

# 2.3 POST /ep/architectures/embedded-coder

#### Import an EmbeddedCoder™ architecture

<b>Long running task</b> Import an EmbeddedCoder™ architecture. Settings are provided as an import info object.

#### **REQUEST**

REQUEST BODY - application/js {	on	
ecModelFile*	string	The absolute or relative path to the EmbeddedCoder model. br>This file is mandatory and may not be undefined.
ecInitScript	string	The absolute or relative path to the init script of the EmbeddedCoder model. This attribute may be undefined. br>If the specified file path is invalid, an error is reported.
useExistingCode	boolean	Specifies if code generation needs to be done. 'true': Code generation is not explicitly performed. 'Instead it is assumed that the required code files are already generated before import. 'false': Code generation is explicitly performed during the analysis. 'br>The resulting code is used for further steps. 'br>Default is 'false'.
parameterHandling	enum	ALLOWED:OFF, EXPLICIT_PARAMETER
testMode	enum	Specifies how parameter variables are handled. Can be 'OFF' or 'EXPLICIT_PARAMETER'. 'EXPLICIT_PARAMETER'. 'EXPLICIT_PARAMETER': Parameter variables are regarded as additional br>inputs to subsystems. or befault is 'EXPLICIT_PARAMETER'. br>lf not specified (undefined or invalid), the default value is used.  ALLOWED: BLACK_BOX, GREY_BOX
		Specifies the test mode. Can be 'BLACK_BOX' or 'GREY_BOX'. local variables are regarded as additional outputs of subsystems. For BlackBox-Testing only the regularoutputs in the interfaces of subsystems are observed. br>Default is 'GreyBox'. f not specified (undefined or invalid), the default value is used.
fixedStepSolver	boolean	Handling when a non-fixed-step solver is ecountered: If 'true', the solver is automatically set to fixed-step. Otherwise an error is issued.Default is 'false'.
inDepthCcodeAnalysis	boolean	true: Simulink model and C-Code model are imported. simulation is supported. crode and mapping are omitted. br>Default is 'true'
subsystemMatcher	string	A whitelist of all subsystems you would like to import. Street Subsystems whitelist of all subsystems you would like to import.

standard.<br/>
standard.<br/>
standard.<br/>
standard.<br/>
subsystem is identified by its virtual path inside the model.<br/>
for value is defined, all subsystems are imported.<br/>
standard.<br/>
subsystems are imported.<br/>
subsystems are imported.

parameterMatcher string

A whitelist of all parameters you would like to import.<br/>
standard.<br/>
br>Each parameter is identified by its name.<br/>
lif no value is defined, all calibrations are imported.<br/>
br>If the specified regular expression does not produce any match, no calibration is imported.<br/>
br>The list cannot be applied, if parameterHandling is set to 'OFF'.<br/>
br>Please note, that model workspace parameters have their name extended by the model they <br/>
br>are located in and need to be adressed accordingly in the following way: 'modelname:paramname'

}

#### **RESPONSE**

**STATUS CODE - 202**: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 2.4 POST /ep/architectures/targetlink-ev

#### Import a TargetLink™ EV architecture

<b>Long running task</b> Import a TargetLink™ EV architecture. Settings are provided as an import info object.

#### **REQUEST**

```
REQUEST BODY - application/json
   tlModelFile*
                                     string
                                                  The absolute or relativ path to the TargetLink model file (.mdl|.slx).
   tlInitScript
                                     string
                                                  The absolute or relativ path to the script defining all parameters needed for initializing the TL-
                                                  model. If not provided, the TL-model is assumed to be selfcontained.
   fixedStepSolver
                                    boolean
                                                  'true': The analyzed models (TargetLink model and Simulink model) will be set to the fixed-step
                                                  solver type automatically. The usage of the EmbeddedPlatform requires a fixed-step solver. If
                                                  the model is open and the fixed-step solver is not already set, this might lead to a modified
                                                  model. <br/> 'false': The analyzed models (TargetLink model and Simulink model) will not be set
                                                  to the fixed-step solver automatically. If the fixed-step solver is not already set in the model, an
                                                  exception is thrown. In order to proceed the user has to set the fixed-step solver manually in
                                                  the simulation settings. <br/> <br/>br>Note: The option is ignored if the model is currently not in an
                                                  open/loaded state. In this case it has no visible side-effect. <br>>Default is 'false'
   t1Subsystem
                                    string
                                                  Name of the Subsystem representing the TL toplevel subsystem for the analysis.<br/>
-br>Note:
                                                  Argument is obligatory if there is more than one toplevel system in the model.
                                                  ALLOWED: OFF, EXPLICIT_PARAMETER, LIMITED_BLOCKSET
   calibrationHandling enum
                                                  Determine how calibration variables are being handled.<br/>
orF': Only regular inputs in the
```

regarded as additional inputs to subsystems. Their value is set once during the initial phase of the simulation and is held constant thereafter. <br/>
'LIMITED\_BLOCKSET': Calibration variables are regarded as additional inputs to subsystems. Their value is set once during the initial phase of the simulation and is held constant thereafter. Enable support for calibration within block properties, not using workspace calibrations.<br/>
TL-Blocks is different from 'EXPLICIT\_PARAMETER'.<br/>
'EXPLICIT\_PARAMETER'.

subsystemMatcher string

A whitelist of all subsystems you would like to import.<br/>
standard.<br/>
stand

calibrationMatcher string

A whitelist of all calibrations you would like to import.<br/>
standard.<br/>
sta

constantsMatcher string

A whitelist of all constants you would like to import.<br/>
-br>Uses the regular expression standard.<br/>
-br>Each constant is identified by its name.<br/>
-br>If no value is defined, no constants are imported.<br/>
-br>If the specified regular expression does not produce any match, no constant is imported.<br/>
-br>

#### **RESPONSE**

}

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
    string
```

#### 2.5 POST /ep/architectures/mdf

#### Import an MDF™ architecture

<b>Long running task</b> Import an MDF™ architecture. Settings are provided as an import info object.

#### REQUEST

```
REQUEST BODY - application/json
{
   modelFile*    string    Absolute or relative path to the execution record (.mf4).
   sampleTime*    string    Sample time, in seconds.
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
     jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not acceptable
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 2.6 POST /ep/architectures/sdf

#### Import a SDF™ architecture

<b>Long running task</b> Import a SDF™ architecture. Settings are provided as an import info object.

#### **REQUEST**

```
REQUEST BODY - application/json
   sdfFile*
                                  string
                                                 The absolute path to the SDF file. This file is mandatory and may not be null! If the specified
                                                 file path is invalid, an error is reported.
   trcFile*
                                                 The absolute path to the TRC file. This file is mandatory and may not be null! If the specified
                                   string
                                                 file path is invalid, an error is reported.
   sampleTime*
                                                 The SDF architecture sample time in seconds. The format can be only numbers (e.g. 3) or with
                                  string
                                                 the time unit specified (e.g. 3 s). Attempt to use any other format will be reported as an error.
   excludedSubsystems
                                  [string]
                                                 Subsystems names that should not be imported, can be empty. If an invalid subsystem is
                                                 requested, an error is reported.
   propagateSelection boolean
                                                 This option allows to configure the excluded subsystems option. If set to true, also the child
                                                 subsystems of the excluded subsystems are excluded from the import. Default setting is false.
}
```

#### **RESPONSE**

```
STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string
```

# 2.7 GET /ep/architectures/{architecture-uid}

## Get a specific architecture

Get an existing architecture by UID.

#### **REQUEST**

#### PATH PARAMETERS

NAME TYPE		DESCRIPTION
*architecture-uid stri	ng	The UID of the architecture to be returned.

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
     uid
                             string READ-ONLY
                                       The unique identifier (UID) of this object.
     architectureKind string READ-ONLY
                                       The string representation of the concrete architecture
                                       , e.g. 'Simulink', 'C-Code', 'TargetLink'.
     name
                             string READ-ONLY
                                       The architecture name as specified by the model.
     propList {
     The Architecture property List
     }
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

## 2.8 GET /ep/architectures

#### Get all architectures

Search for all open architectures.

#### **REQUEST**

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
architecture- kind	string	Specifies the specific architecture kind to be queried. (e.g. 'Simulink', 'C-Code', 'TargetLink')

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [ {
  Array of object:
     uid
                             string READ-ONLY
                                        The unique identifier (UID) of this object.
     architectureKind string READ-ONLY
                                        The string representation of the concrete architecture
                                       , e.g. 'Simulink', 'C-Code', 'TargetLink'.
     name
                             string READ-ONLY
                                        The architecture name as specified by the model.
     propList {
     The Architecture property List
     }
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

## 2.9 PUT /ep/architectures

#### **Update architectures**

<b>Long running task</b> Perform an architecture update.

#### REQUEST

No request parameters

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

RESPONSE MODEL - application/json

```
f
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain
string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

# 2.10 PUT /ep/architectures/model-paths

#### Update model paths for architectures

Update the paths for imported architectures. If the architecture-uid is not specified, the model paths will be updated for the master architecture.

#### **REQUEST**

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
architecture- uid	string	The UID of the architecture to be updated. If empty, the path will be updated for the master architecture.

#### **RESPONSE**

STATUS CODE - 200: OK

RESPONSE MODEL - text/plain

string

STATUS CODE - 400: Bad request

#### RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 2.11 POST /ep/architectures/simulink

#### Import a Simulink™ architecture

<b>Long running task</b> Import a Simulink™ architecture. Settings are provided as an import info object.

#### **REQUEST**

REQUEST BODY - application {	on/json	
slModelFile*	string	The absolute or relative path to the Simulink model. - This file is mandatory and may not be undefined!
slInitScriptFile	string	The absolute or relative path to the init script of the Simulink model. Simulink model. This attribute may be undefined. If the specified file path is invalid, an error is reported.
parameterHandling	enum	ALLOWED:OFF, EXPLICIT_PARAMETER
		Specifies how parameter variables are handled. Can be 'OFF' or 'EXPLICIT_PARAMETER'. Only regular inputs in the interface of subsystems are observed. Parameter variables are regarded as additional inputs to subsystems. 'EXPLICIT_PARAMETER'. The default value is used.
testMode	enum	ALLOWED:BLACK_BOX, GREY_BOX
		Specifies the test mode. Can be 'BLACK_BOX' or 'GREY_BOX'. br>If set to 'GREY_BOX', local variables are regarded as additional outputs of subsystems. br>For Black Box-Testing only the regular outputs in the interfaces of subsystems are observed. br>Default is 'GREY_BOX'. br>If not specified (undefined or invalid), the default value is used.
fixedStepSolver	boolean	Defines, if the fixed step solver will be set or not. Can be true or false. Simulink model will be set to the fixed-step solver type automatically. The usage of the EmbeddedPlatform requires a fixed-step solver. If the model is open and solver is not already set, this might lead to a modified model. The analyzed Simulink model will not be set to the fixed-step solver automatically. The fixed-step solver is not already set in the model, the method return with state of The solver is not already set in the model, the method return with state of The solver is not already set in the set to the fixed-step solver. In order to proceed the user has to set the fixed-step solver The option is ignored if the model is currently not in an open/loaded state. In this case it has no visible side-effect.
mappingFile	string	File name of the mapping XML file. The file must be provided if architectures are already available in the profile. The file is used to map the first imported architecture to the new imported Simulink architecture. SThis attribute may be undefined. If the specified file path is invalid, an error is reported.
subsystemMatcher	string	A whitelist of all subsystems you would like to import. "br>Uses the regular expression standard. Each subsystem is identified by its virtual path inside the model. "br>If no value is defined, all subsystems are imported. "br>If the specified regular expression does not produce any match, an error is reported. "br>Keep in mind that having multiple Toplevel-Subsystem will result in an error.
parameterMatcher	string	A whitelist of all parameters you would like to import. standard. br>Each parameter is identified by its name. br>If no value is defined, all parameters are imported. br>If the specified regular expression does not produce any match, no parameter is imported. br>The list cannot be applied, if parameterHandling is set to 'OFF'. br>Please note, that model workspace parameters have their name extended by the model they br>are located in and

#### **RESPONSE**

}

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this

need to be adressed accordingly in the following way: 'modelname:paramname'

command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

# 2.12 POST /ep/architectures/targetlink

#### Import a TargetLink™ architecture

fixedStepSolver

<b>Long running task</b> Import a TargetLink™ architecture. Settings are provided as an import info object.

REQUEST		
REQUEST BODY - application/json {		
tlModelFile*	string	The absolute or relative path to the TargetLink model file (.mdl .slx).
tlInitScript	string	The absolute or relative path to the script defining all parameters needed for initializing the TL-model. ssumed to be selfcontained.
slModelFile	string	The absolute or relative path to the Simulink model file (.mdl .slx). br> Note: If a TargetLink model is given, the SL-model is assumed to be equivalent to the TL-model.
slInitScript	string	The absolute or relative path to the script defining all parameters needed for initializing the SL-model. If not provided, the SL-model is assumed to be selfcontained.
environment	string	The absolute or relative path to XML file including information about environmental files like additional code. (see specifications in CodeGeneration.dtd).
useExistingCode	boolean	Determine if code generation needs to be done. rtrue': Code generation is not explicitly performed. stream of the code generation is not explicitly performed. generated and brothat the corresponding DataDictionary of the model includes information about the code generation. false': Code generation is explicitly performed during the analysis. brother resulting code is used for further steps. brother data.
activateModelLinking	boolean	Determine if the source code needs to be linked to the TargetLink model. dlink between the source code and the TargetLink model will be established. br>This setting may lead to a modified TargetLink model. the TargetLink option 'ExtendedBlockComments' needs to be enabled br>with a subsequent TargetLink code generation. br>'false': The source code model linking is not explicitly set by EmbeddedPlatform. br>Default is 'false'.
closedLoopModel	boolean	Determine if the SUT envoronment is analyzed during extraction 'true': The environment of the SUT is also analyzed during the model extraction. 'br> mportant for analyzing closed-loop models. 'false': Only the SUT is considered during the model

extraction. <br/>br>Default is 'false'.

boolean Defines, if the fixed step solver will be set or not.<br/>
-'true': The analyzed models

(TargetLink model and Simulink model) will be set to the fixed-step solver type automatically.<br/>
The usage of the EmbeddedPlatform requires a fixed-step solver. <br/>f the model is open and the fixed-step solver is not already set, <br/>br>this might lead to a modified model.<br/>
'false': The analyzed models (TargetLink model and Simulink model) will not be set to the fixed-step solver automatically.<br/>dr>lf the fixed-step solver is not already set in the model, an exception is thrown.<br/>shr>In order to proceed the user is ignored if the model is currently not in an open/loaded state.<br/>br>In this case it has no visible side-effect. <br/>br>Default is 'false'.

tlSubsystem string Name of the Subsystem representing the TL toplevel subsystem for the

analysis.<br/>
Shr>Note: Argument is obligatory if there is more than one toplevel system in

the model.

calibrationHandling enum ALLOWED:OFF, EXPLICIT\_PARAMETER, LIMITED\_BLOCKSET

Determine how calibration variables are being handled.<br/>
'OFF': Only regular inputs in the interface of subsystems are observed.<br/>
'EXPLICIT\_PARAMETER': Calibration variables are regarded as additional inputs to subsystems.<br/>
'Their value is set once

during the initial phase of the simulation and is held constant

thereafter.<br/>
'LIMITED\_BLOCKSET': Calibration variables are regarded as additional inputs to subsystems.<br/>

bracket value is set once during the initial phase of the simulation and is held constant thereafter.<br/>

bracket value is set once during the initial phase of the simulation and is held constant thereafter.<br/>

bracket value valu

'EXPLICIT\_PARAMETER'.<br>

testMode enum ALLOWED:BLACK\_BOX, GREY\_BOX

Specifies the test mode. Can be 'BLACK\_BOX' or 'GREY\_BOX'.<br/>
local variables are regarded as additional outputs of subsystems.<br/>
Testing only the regular outputs in the interfaces of subsystems are

observed.<br/>br>Default is 'GREY\_BOX'.<br/>br>If not specified (undefined or invalid), the

default value is used.

mappingFileForTLArch string The absolute or relative path to the mapping file for TargetLink architecture

mapping.<br/>
strong in the profile. The file is used to map the first imported architecture to the new<br/>
imported TargetLink architecture. <br/>
strong is not provided, the mapping to the first<br/>
imported architecture is derived from the auto-generated <br/>
strong is mapping between<br/>
TargetLink, C-Code, and Simulink (if available). For the derivation to work, at least one of<br/>
strong is mapping between the service of the s

specified mapping file

mappingFileForCCodeArch string The absolute or relative path to the mapping file for C-Code architecture

mapping.<br/>
strong in the profile. The file is used to map the first imported architecture to the new imported C-Code architecture.<br/>
strong is not provided, the mapping to the first imported architecture is derived from the auto-generated <br/>
strong is not provided, the mapping to the first imported architecture is derived from the auto-generated <br/>
strong is not provided, the mapping to the first imported architecture is derived from the auto-generated <br/>
strong is not provided in the first imported architecture via a strong is not provided in the first

specified mapping file

mappingFileForSLArch string The absolute or relative path to the mapping file for Simulink architecture

mapping.<br/>
br>At least one mapping must be provided if a Simulink architecture is additionally imported and<br/>
br>The file is used to map the first imported architecture to the new imported Simulink architecture.<br/>
br>If this file is not provided, the mapping to the first imported architecture is derived from the auto-generated <br/>
br> mapping between TargetLink, C-Code, and Simulink (if available). For the derivation to work, at least one of <br/>
br> these architectures must be mapped to the first imported architecture via a specified mapping

file

subsystemMatcher string A whitelist of all subsystems you would like to import.<br/>br>Uses the regular expression

standard.<br/>
standard.<br/>
standard.<br/>
standard.<br/>
subsystem is identified by its virtual path inside the model.<br/>
standard.<br/>

the Targetlink wrapper.

calibrations are imported.<br/>br/If the specified regular expression does not produce any match, no calibration is imported.<br/>br/The list cannot be applied, if calibrationHandling

is set to 'OFF'.

constantsMatcher string A whitelist of all constants you would like to import.<br/>
String A whitelist of all constants you would like to import.<br/>
String A whitelist of all constants you would like to import.

standard.<br/>
-Each constant is identified by its name.<br/>
-br>If no value is defined, no constants are imported.<br/>
-br>If the specified regular expression does not produce any

match, no constant is imported.<br>

cfileMatcher string A whitelist of all c-code files you would like to import. <a href="https://doi.org/10.150/j.com/">https://doi.org/10.150/j.com/</a> A whitelist of all c-code files you would like to import. <a href="https://doi.org//>j.com// injection/ object/">https://doi.org// object/</a> A whitelist of all c-code files you would like to import. <a href="https://doi.org//>j.com// object/// object// o

standard.<br/>
standard.<br/>
standard.<br/>
file is identified by its name.<br/>
standard.<br/>
standard.<br/>
fino value is defined, all files are imported.<br/>
standard.<br/>
file is imported.<br/>
standard.

imported.

#### **RESPONSE**

}

```
    jobID string READ-ONLY
        The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

# 2.13 POST /ep/architectures/userdefined

#### Import a User-defined architecture

<b>Long running task</b> Import a User-defined architecture from a XML file that describes the interface of the architecture. <br/> sorly possible to have one User-defined architecture imported at all times. Importing a second User-defined architecture will be rejected.

### **REQUEST**

#### **RESPONSE**

```
RESPONSE MODEL - application/json

{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error
```

# **RESPONSE MODEL - text/plain**

string

# 3. BACK-TO-BACK TEST REPORTS

# 3.1 POST /ep/b2b/{b2b-test-uid}/b2b-reports

#### Create a B2B test report on a B2B test

Creates a Back-to-Back test report on a Back-to-Back test by providing its UID.

#### **REQUEST**

#### PATH PARAMETERS

NAME T	ГҮРЕ	DESCRIPTION
*b2b-test-uid s	string	The Back-to-Back test UID for which the Back-to-Back test report is created.

#### **RESPONSE**

# 3.2 GET /ep/b2b-reports

#### Get all B2B test reports

Retrieve all the Back-to-Back test reports from the profile.

#### **REQUEST**

No request parameters

#### **RESPONSE**

```
reportType string Type of the report.
}]
STATUS CODE - 500: Internal server error.
RESPONSE MODEL - text/plain
string
```

# 4. BACK-TO-BACK TESTS

Create and retrieve Back-to-Back tests.

# 4.1 GET /ep/b2b/{b2b-uid}

#### Get a B2B test

Get a Back-to-Back test with the provided UID.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*b2b-uid	string	The UID of the Back-to-Back test to be returned.

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
     uid
                                string
                                            READ-ONLY
                                            The unique identifier (UID) of this object.
     referenceMode
                                            The reference execution config type.
                               string
     comparisonMode
                               string
                                            The comparison execution config type.
     referenceFolderUIDs [string] Reference folder UIDs
     comparisonFolderUID string
                                            Comparison folder UID
     executionDate
                               string
                                            Execution Date
     verdictStatus
                               enum
                                            ALLOWED: PASSED, FAILED, ERROR, FAILED_ACCEPTED
                                            The verdict status
     verdictState
                                            ALLOWED: VALID, OUTDATED_TOLERANCE_UPDATE,
                                enum
                                            OUTDATED_MISSING_EXECUTIONS
                                            Verdict State
     failed
                                integer
                                            Number of failed comparisons.
     failedAccepted
                                integer
                                            Number of failed accepted comparisons.
     passed
                               integer
                                            Number of passed comparisons.
     error
                               integer
                                            Number of comparisons with error.
     total
                               integer
                                            Total number of comparisons
     comparisons [{
     Array of object: All comparisons.
        uid
                                              string READ-ONLY
                                                        The unique identifier (UID) of this object.
        name
                                              string The name of Test Case / Stimuli Vector used in Comparison.
        verdictStatus
                                                        ALLOWED: PASSED, FAILED, ERROR, FAILED_ACCEPTED
                                              enum
                                                        The verdict status
        referenceExecutionRecordUID
                                              string UID of reference execution record.
        comparisonExecutionRecordUID string UID of compared to execution record.
        comment
                                              string Added comment for Comparison.
     }]
     name
                                string
                                            The name of the Back-To-Back Test.
     stimuliFolderUIDs
                                [string] Folder UIDs for which Back-To-Back Test was generated.
     stimuliScopeUIDs
                                [string] Scope UIDs for which Back-To-Back Test was generated.
```

# RESPONSE MODEL - text/plain string STATUS CODE - 500: Internal server error. RESPONSE MODEL - text/plain

string

# 4.2 PATCH /ep/b2b/{b2b-uid}

#### Change a verdict status for a comparison

Changes verdict status for a comparison. If accept is true, the comparison verdict status is changed from 'failed' to 'failed (accepted)'. If accept is false, the comparison verdict status is changed from 'failed (accepted)' to 'failed'.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*b2b-uid	string	The Back-to-Back test UID for which to change the comparison verdict.

#### **RESPONSE**

```
STATUS CODE - 200: OK

RESPONSE MODEL - application/json

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 4.3 POST /ep/folders/{folder-uid}/b2b

#### Create a B2B test on a folder

<b>Long running task </b>Generates a Back-to-Back test on a given folder UID for the specified reference and comparison execution kinds. Optionally, the execution can be forced to simulate all contained requirements-based test cases/stimulivectors. Optionally, only stimuli vectors can be set to be executed if force execution is activated. Otherwise if there are requirements-based test cases with comparison verdicts, the verdicts will be deleted in order to run the Back-to-Back test.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*folder-uid	string	The folder UID for which the Back-to-Back test is generated.

```
REQUEST BODY - application/json
   refMode*
                                                strina
                                                             Reference execution mode (e.g. 'SL MIL', 'TL MIL', 'TL MIL (EV)', 'SIL', 'PIL', 'SL SIL'). Not
                                                             case-sensitive.
   compMode*
                                                string
                                                             Comparison execution mode (e.g. 'SL MIL', 'TL MIL', 'TL MIL (EV)', 'SIL', 'PIL', 'SL SIL').
                                                             Not case-sensitive.
   forceExecute
                                                boolean
                                                             (Optional) If true, simulates all contained test cases/stimuli-vectors, replacing
                                                             existing execution records. Default is false.
   simulateStimuliVectorsOnlv boolean
                                                             (Optional) This option can be used only when forceExecution is set to true. If true,
                                                              simulates only stimuli-vectors. If false, and there are Requirements-based Test Cases
                                                             with comparison verdicts, the verdicts will be deleted in order to run the Back-To-Back
                                                             Test. Default value is false.
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 4.4 POST /ep/folders/b2b

#### Create a B2B test on a list of folders

<b>Long running task </b>Generates a Back-to-Back test on a given list of folder UIDs for the specified reference and comparison execution kinds. Optionally, the execution can be forced to simulate all contained requirements-based test cases/stimuli-vectors. Optionally, only stimuli vectors can be set to be executed if force execution is activated. Otherwise if there are requirements-based test cases with comparison verdicts, the verdicts will be deleted in order to run the Back-to-

Back test.

#### **REQUEST**

```
REQUEST BODY - application/json
    refMode*
                                                string
                                                               Reference execution mode (e.g. 'SL MIL', 'TL MIL', 'TL MIL (EV)', 'SIL', 'PIL', 'SL SIL').
                                                               Not case-sensitive.
   compMode*
                                                string
                                                               Comparison execution mode (e.g. 'SL MIL', 'TL MIL', 'TL MIL (EV)', 'SIL', 'PIL', 'SL SIL').
                                                               Not case-sensitive.
   forceExecute
                                                boolean
                                                               (Optional) If true, simulates all contained test cases/stimuli-vectors, replacing
                                                               existing execution records. Default is false.
   simulateStimuliVectorsOnly boolean
                                                               (Optional) This option can be used only when forceExecution is set to true. If true,
                                                               simulates only stimuli-vectors. If false, and there are Requirements-based Test
                                                               Cases with comparison verdicts, the verdicts will be deleted in order to run the
                                                               Back-To-Back Test. Default value is false.
   UIDs*
                                                [string] UIDs list (e.g. scopes, folders)
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
    string
```

# 4.5 POST /ep/scopes/{scope-uid}/b2b

#### Create a B2B test on a scope

<b>Long running task </b>Generates a Back-to-Back test on a given scope UID for the specified reference and comparison execution kinds. Optionally, the execution can be forced to simulate all contained requirements-based test cases/stimulivectors. Optionally, only stimuli vectors can be set to be executed if force execution is activated. Otherwise if there are requirements-based test cases with comparison verdicts, the verdicts will be deleted in order to run the Back-to-Back test.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The scope UID for which the Back-to-Back test is generated.

```
REQUEST BODY - application/json
   refMode*
                                                string
                                                             Reference execution mode (e.g. 'SL MIL', 'TL MIL', 'TL MIL (EV)', 'SIL', 'PIL', 'SL SIL'). Not
                                                             case-sensitive.
   compMode*
                                                string
                                                             Comparison execution mode (e.g. 'SL MIL', 'TL MIL', 'TL MIL (EV)', 'SIL', 'PIL', 'SL SIL').
                                                             Not case-sensitive.
   forceExecute
                                                boolean
                                                             (Optional) If true, simulates all contained test cases/stimuli-vectors, replacing
                                                             existing execution records. Default is false.
   simulateStimuliVectorsOnly boolean
                                                             (Optional) This option can be used only when forceExecution is set to true. If true,
                                                              simulates only stimuli-vectors. If false, and there are Requirements-based Test Cases
                                                             with comparison verdicts, the verdicts will be deleted in order to run the Back-To-Back
                                                              Test. Default value is false.
}
```

#### **RESPONSE**

**STATUS CODE - 202**: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
     jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 4.6 POST /ep/scopes/b2b

#### Create a B2B test on a list of scopes

<b>Long running task </b>Generates a Back-to-Back test on a given list of scope UIDs for the specified reference and comparison execution kinds. Optionally, the execution can be forced to simulate all contained requirements-based test cases/stimuli-vectors. Optionally, only stimuli vectors can be set to be executed if force execution is activated. Otherwise if there are requirements-based test cases with comparison verdicts, the verdicts will be deleted in order to run the Back-to-Back test.

#### **REQUEST**

```
REQUEST BODY - application/json
{
    refMode* string
```

Reference execution mode (e.g. 'SL MIL', 'TL MIL', 'TL MIL (EV)', 'SIL', 'PIL', 'SL SIL') Not case-sensitive

```
Comparison execution mode (e.g. 'SL MIL', 'TL MIL', 'TL MIL (EV)', 'SIL', 'PIL', 'SL SIL').
   compMode*
                                                string
                                                               Not case-sensitive.
   forceExecute
                                                boolean
                                                               (Optional) If true, simulates all contained test cases/stimuli-vectors, replacing
                                                               existing execution records. Default is false.
   simulateStimuliVectorsOnly boolean
                                                               (Optional) This option can be used only when forceExecution is set to true. If true,
                                                               simulates only stimuli-vectors. If false, and there are Requirements-based Test
                                                               Cases with comparison verdicts, the verdicts will be deleted in order to run the
                                                               Back-To-Back Test. Default value is false.
   UIDs*
                                                [string] UIDs list (e.g. scopes, folders)
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
    string
```

## 4.7 GET /ep/b2b

#### Get all B2B tests

Get all Back-to-Back tests from active profile.

#### **REQUEST**

No request parameters

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

# RESPONSE MODEL - application/json

{
Array of object:

uid	string	READ-ONLY
		The unique identifier (UID) of this object.
referenceMode	string	The reference execution config type.
comparisonMode	string	The comparison execution config type.
referenceFolderUIDs	[string]	Reference folder UIDs
comparisonFolderUID	string	Comparison folder UID
executionDate	string	Execution Date

verdictStatus ALLOWED: PASSED, FAILED, ERROR, FAILED\_ACCEPTED enum The verdict status ALLOWED: VALID, OUTDATED\_TOLERANCE\_UPDATE, verdictState enum OUTDATED\_MISSING\_EXECUTIONS Verdict State failed integer Number of failed comparisons. failedAccepted Number of failed accepted comparisons. integer passed integer Number of passed comparisons. error integer Number of comparisons with error. total integer Total number of comparisons. comparisons [{ Array of object: All comparisons. uid string **READ-ONLY** The unique identifier (UID) of this object. name string The name of Test Case / Stimuli Vector used in Comparison. verdictStatus ALLOWED: PASSED, FAILED, ERROR, enum FAILED\_ACCEPTED The verdict status referenceExecutionRecordUID string UID of reference execution record. comparisonExecutionRecordUID string UID of compared to execution record. comment string Added comment for Comparison. }] name string The name of the Back-To-Back Test. stimuliFolderUIDs [string] Folder UIDs for which Back-To-Back Test was generated. stimuliScopeUIDs [string] Scope UIDs for which Back-To-Back Test was generated. }] STATUS CODE - 404: Not found **RESPONSE MODEL - text/plain** string STATUS CODE - 500: Internal server error. **RESPONSE MODEL - text/plain** 

string

# 5. CODE ANALYSIS REPORTS B2B

Handle Back-To-Back code analysis reports.

# 5.1 POST /ep/folders/{folder-uid}/code-analysis-reports-b2b

#### Create a report on a folder

Create a B2B code analysis report on given folder.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*folder-uid	string	The folder UID for which to create the B2B code analysis report.

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 404: Not found
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 5.2 POST /ep/folders/code-analysis-reports-b2b

#### Create a report on a list of folders

Create B2B Code Analysis Report on given folders.

#### **REQUEST**

REQUEST BODY - application/json

```
{
    UIDs* [string] List with unique identifiers of the objects.
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 5.3 POST /ep/scopes/{scope-uid}/code-analysis-reports-b2b

#### Create a report on a scope

Create a B2B code analysis report on given scope.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The scope UID for which to create the B2B code analysis report.

#### **RESPONSE**

```
STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 5.4 GET /ep/code-analysis-reports-b2b

#### Get all reports

Retrieve all B2B code analysis reports from profile.

#### **REQUEST**

No request parameters

#### **RESPONSE**

# 6. CODE ANALYSIS REPORTS RBT

Creates requirement-based code analysis reports.

# 6.1 POST /ep/folders/{folder-uid}/code-analysis-reports-rbt

#### Create a report on a folder

<b>Long running task</b> Create an RBT code analysis report on a given folder.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*folder-uid	string	The folder UID for which to create an RBT code analysis report.

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 404: Not found
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 6.2 POST /ep/folders/code-analysis-reports-rbt

#### Create a report on a list of folders

Create an RBT code analysis report on given folders.

#### **REQUEST**

REQUEST BODY - application/json

```
{
    UIDs* [string] List with unique identifiers of the objects.
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 6.3 POST /ep/requirements-sources/{requirements-source-uid}/code-analysisreports-rbt

#### Create a report on a requirements source

Create an RBT code analysis report on a given requirements source UID.

#### REQUEST

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
<pre>*requirements-source- uid</pre>	string	The requirements source UID for which to create RBT code analysis report.

#### **RESPONSE**

```
RESPONSE MODEL - application/json {
```

```
jobID string READ-ONLY
The ID of a job.
}

STATUS CODE - 400: Bad request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 404: Not found
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 6.4 POST /ep/requirements-sources/code-analysis-reports-rbt

#### Create a report on requirements sources

Create an RBT code analysis report on given requirements sources.

#### REQUEST

```
REQUEST BODY - application/json
{
   UIDs* [string] List with unique identifiers of the objects.}
```

#### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}
STATUS CODE - 400: Bad request
RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
```

#### RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 6.5 POST /ep/scopes/{scope-uid}/code-analysis-reports-rbt

## Create a report on scope

Create an RBT code analysis report on a given scope.

### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The scope UID for which to create RBT code analysis report.

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 6.6 GET /ep/code-analysis-reports-rbt

# Get all reports

Retrieve all RBT code analysis reports from the profile.

# **REQUEST**

No request parameters

# 7. CODE COVERAGE/ROBUSTNESS CHECK B2B

Retrieve code coverage/robustness checks details and results in B2B.

# 7.1 GET /ep/scopes/{scope-uid}/coverage-details-b2b

#### Get coverage details for a scope

Get all code coverage/robustness checks details for a scope. Some filters can be applied.

# **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
statuses	array of string ALLOWED: COVERED, UNKNOWN, UNREACHABLE_INF, UNREACHABLE_N, INCONSISTENT, UNKNOWN_JUSTIFIED, UNREACHABLE_N_JUSTIFIED, UNREACHABLE_INF_JUSTIFIED	The status filter for code coverage/robustness check goals. Possible values: COVERED, UNKNOWN, UNREACHABLE_INF, UNREACHABLE_N, INCONSISTENT, UNKNOWN_JUSTIFIED, UNREACHABLE_INF_JUSTIFIED, UNREACHABLE_N_JUSTIFIED. Can also specify multiple options. str>Can also be empty, in which case the results are shown for all statuses.
goal- types	array of string ALLOWED: STM, D, C, MCDC, F, FC, SC, RO, CDC, DZ, CA	The goal type filter for code coverage/robustness check goals. Possible values for code coverage goals: STM(Statement), C(Condition), D(Decision/Branch), CDC(C/DC), MCDC(C/DC and MC/DC), F(Function), SC(Switch-Case), RO(Relational Operator), FC(Function Call). values for robustness check goals are: DZ(Division by Zero), CA(Downcast). Can also specify multiple options. Can also be empty, in which case the results are shown for all goal types.
files	array of string	List of file filters for code coverage/robustness check goals. If list is empty the results are shown for all files.

# **RESPONSE**

STATUS CODE - 200: OK

```
RESPONSE MODEL - application/json
```

```
Array of object:
   pll
                    string
                                  PLL string of the coverage goal.
   type
                    string
                                  Goal type of the coverage goal.
   line
                    integer
                                  The line number of the location where the coverage goal is located in the file.
   file
                    string
                                  The file name where the coverage property can be located.
   properties [{
   Array of object: A list with coverage goal properties.
      p11
                               string
                                             PLL string of the coverage property.
       status
                               string
                                             Status of the coverage property.
      covering Vectors [string] List of string vector names that cover the property.
   }]
```

```
Expression of the coverage goal.
     expression string
     blocks
                   [string]
                              The TargetLink blocks
     comment
                   string
                               The comment.
     justified
                   boolean
                               If this goal is justified
  }]
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 7.2 GET /ep/scopes/{scope-uid}/coverage-results-b2b

# Get coverage results for a scope

Get the code coverage and robustness checks results for a scope. Goal type filters can be applied.

# **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
goal- types	array of string ALLOWED: STM, D, C, MCDC, F, FC, SC, RO, CDC, DZ, CA	The goal type filter for code coverage/robustness check goals. Possible values for code coverage goals: STM(Statement), C(Condition), D(Decision/Branch), CDC(C/DC), MCDC(C/DC and MC/DC), F(Function), SC(Switch-Case), RO(Relational Operator), FC(Function Call). Possible values for robustness check goals are: DZ(Division by Zero), CA(Downcast). Can also specify multiple options. Can also be empty, in which case the results are shown for all goal types.

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
    CDCCoverage {
    CDC goal coverage information.
       coverageGoal
                                             string
                                                      Name of the goal
       coveredCompletelyCount
                                             integer Coverage complete count
       coveredCompletelyPercentage
                                             number
                                                       Coverage complete percentage
       coveredPartiallyCount
                                             integer Coverage partial count
       coveredPartiallyPercentage
                                             number
                                                       Coverage partial percentage
                                                       Handled complete count
```

handledCompletelyCount integer handledCompletelyPercentage number Handled complete percentage handledPartiallyCount integer Handled partial count handledPartiallyPercentage number Handled partial percentage unhandledCount integer Unhandled count unhandledPercentage number Unhandled percentage uncoveredCount integer Uncovered count uncoveredPercentage number Uncovered percentage justifiedCompletelyCount integer Covered completely (justified) count justifiedCompletelyPercentage Covered completely (justified) percentage number justifiedPartiallyCount integer Covered partially (justified) count justifiedPartiallyPercentage number Covered partially (justified) percentage totalCount integer Total count CDCPropertyCoverage { CDC property coverage information. coverageGoal string Name of the goal coveredCount integer Covered count coveredPercentage number Covered percentage unreachableInfiniteCount integer Unreachable Infinite count unreachableInfinitePercentage number Unreachable Infinite percentage unreachableNCount integer Unreachable N count unreachableNPercentage number Unreachable N percentage unreachableInfiniteJustifiedCount integer Unreachable Infinite (justified) count unreachableInfiniteJustifiedPercentage number Unreachable Infinite (justified) percentage unreachableNJustifiedCount integer Unreachable N (justified) count unreachableNJustifiedPercentage number Unreachable N (justified) percentage unknownJustifiedCount integer Unknown (justified) count unknownJustifiedPercentage number Unknown (justified) percentage unknownCount integer Unknown count unknownPercentage number Unknown percentage handledCount integer Handled count handledPercentage Handled percentage number inconsistentCount integer Inconsistent count inconsistentPercentage number Inconsistent percentage unreachableCount integer Unreachable count unreachablePercentage number Unreachable percentage totalCount integer Total count comment string The comment } ConditionCoverage { Condition goal coverage information. coverageGoal string Name of the goal coveredCompletelyCount integer Coverage complete count coveredCompletelyPercentage number Coverage complete percentage coveredPartiallyCount integer Coverage partial count coveredPartiallyPercentage number Coverage partial percentage handledCompletelyCount integer Handled complete count handledCompletelyPercentage number Handled complete percentage handledPartiallyCount integer Handled partial count handledPartiallyPercentage number Handled partial percentage unhandledCount integer Unhandled count unhandledPercentage number Unhandled percentage uncoveredCount integer Uncovered count uncoveredPercentage number Uncovered percentage justifiedCompletelyCount integer Covered completely (justified) count justifiedCompletelyPercentage number Covered completely (justified) percentage

```
Covered partially (justified) count
   justifiedPartiallyCount
                                        integer
  justifiedPartiallyPercentage
                                        number
                                                   Covered partially (justified) percentage
  totalCount
                                        integer
                                                   Total count
ConditionPropertyCoverage {
Condition property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                    number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                    number
                                                              Unreachable Infinite percentage
  unreachableNCount
                                                    integer Unreachable N count
  unreachableNPercentage
                                                    number
                                                              Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                    integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                              Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                    integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                    number
                                                              Unreachable N (justified) percentage
  unknownJustifiedCount
                                                    integer Unknown (justified) count
  unknownJustifiedPercentage
                                                    number
                                                              Unknown (justified) percentage
  unknownCount
                                                    integer Unknown count
  unknownPercentage
                                                    number
                                                              Unknown percentage
  handledCount
                                                    integer Handled count
  handledPercentage
                                                    number
                                                              Handled percentage
  inconsistentCount
                                                    integer Inconsistent count
  inconsistentPercentage
                                                    number
                                                              Inconsistent percentage
  unreachableCount
                                                    integer Unreachable count
  unreachablePercentage
                                                    number
                                                              Unreachable percentage
  totalCount
                                                    integer Total count
  comment
                                                    string
                                                              The comment
}
DecisionCoverage {
Decision goal coverage information.
  coverageGoal
                                        string
                                                   Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                   Coverage complete percentage
  coveredPartiallyCount
                                        integer Coverage partial count
  coveredPartiallvPercentage
                                        number
                                                   Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                   Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                        number
                                                   Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                  Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                   Covered partially (justified) percentage
  totalCount
                                        integer
                                                  Total count
}
DecisionPropertyCoverage {
Decision property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                    number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
```

unreachableInfinitePercentage unreachableNCount unreachableNPercentage unreachableInfiniteJustifiedC unreachableInfiniteJustifiedP unreachableNJustifiedCount unreachableNJustifiedPercenta unknownJustifiedCount unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage	ount ercentage	integer number integer number integer number integer number integer number	Unreachable Infinite (justified) percentage Unreachable N (justified) count Unreachable N (justified) percentage Unknown (justified) count Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count
totalCount		integer	Total count
comment		string	The comment
<pre>} FunctionCoverage { Function goal coverage information.</pre>		3	
coverageGoal	string	Name of the g	goal
coveredCompletelyCount	integer	Coverage con	nplete count
coveredCompletelyPercentage	number	Coverage con	nplete percentage
coveredPartiallyCount	integer		
coveredPartiallyPercentage	number		tial percentage
handledCompletelyCount	integer	Handled com	
handledCompletelyPercentage	number		plete percentage
handledPartiallyCount handledPartiallyPercentage	integer number	Handled parti	
unhandledCount	integer	Handled parti Unhandled co	
unhandledPercentage	number	Unhandled pe	
uncoveredCount	integer	Uncovered co	
uncoveredPercentage	number	Uncovered pe	
justifiedCompletelyCount	integer		pletely (justified) count
justifiedCompletelyPercentage	_		pletely (justified) percentage
justifiedPartiallyCount	integer		ally (justified) count
justifiedPartiallyPercentage	number		ally (justified) percentage
totalCount	integer	Total count	
<pre>FunctionPropertyCoverage { Function property coverage information.</pre>			
coverageGoal		string	Name of the goal
coveredCount coveredPercentage		integer number	
unreachableInfiniteCount		integer	Covered percentage Unreachable Infinite count
unreachableInfinitePercentage		number	Unreachable Infinite percentage
unreachableNCount		integer	Unreachable N count
unreachableNPercentage		number	Unreachable N percentage
unreachableInfiniteJustifiedC	ount	integer	
unreachableInfiniteJustifiedP		_	Unreachable Infinite (justified) percentage
unreachableNJustifiedCount	•	integer	Unreachable N (justified) count
unreachableNJustifiedPercenta	ge	number	Unreachable N (justified) percentage
unknownJustifiedCount		integer	Unknown (justified) count
unknownJustifiedPercentage		number	Unknown (justified) percentage
unknownCount		integer	Unknown count

```
Unknown percentage
  unknownPercentage
                                                   number
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                   integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
  unreachableCount
                                                   integer Unreachable count
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer
                                                             Total count
  comment
                                                             The comment
                                                   string
}
FunctionCallCoverage {
Function call goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                       number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer Total count
}
FunctionCallPropertyCoverage {
Function call property coverage information.
  coverageGoal
                                                   string
                                                             Name of the goal
  coveredCount
                                                   integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                   integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                   integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                             Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                   integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                             Unreachable N (justified) percentage
  unknownJustifiedCount
                                                   integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                             Unknown (justified) percentage
  unknownCount
                                                   integer Unknown count
  unknownPercentage
                                                   number
                                                             Unknown percentage
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                   integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
                                                   integer Unreachable count
  unreachableCount
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer Total count
  comment
                                                   string
                                                             The comment
}
```

```
MCDC goal coverage information.
                                        string
  coverageGoal
                                                  Name of the goal
  coveredCompletelyCount
                                        integer Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                                  Covered completely (justified) percentage
                                        number
   justifiedPartiallyCount
                                        integer Covered partially (justified) count
  justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer Total count
}
MCDCPropertyCoverage {
MCDC property coverage information.
  coverageGoal
                                                   string
                                                             Name of the goal
  coveredCount
                                                   integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                   integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                   integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                             Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                   integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                             Unreachable N (justified) percentage
  unknownJustifiedCount
                                                   integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                             Unknown (justified) percentage
  unknownCount
                                                   integer Unknown count
  unknownPercentage
                                                   number
                                                             Unknown percentage
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                   integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
                                                   integer Unreachable count
  unreachableCount
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer Total count
  comment
                                                   string
                                                             The comment
}
RelationalOperatorCoverage {
Relational operation goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
```

MCDCCoverage {

```
Handled partial percentage
  handledPartiallyPercentage
                                        number
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
                                        integer Uncovered count
  uncoveredCount
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                        number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer
                                                  Total count
}
RelationalOperatorPropertyCoverage {
Relational operation property coverage information.
  coverageGoal
                                                   string
                                                             Name of the goal
  coveredCount
                                                   integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                   integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                   integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                             Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                   integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                             Unreachable N (justified) percentage
  unknownJustifiedCount
                                                   integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                             Unknown (justified) percentage
  unknownCount
                                                   integer Unknown count
  unknownPercentage
                                                   number
                                                             Unknown percentage
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                   integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
  unreachableCount
                                                   integer Unreachable count
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer Total count
  comment
                                                             The comment
                                                   string
}
StatementCoverage {
Statement goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
                                                  Covered completely (justified) percentage
   justifiedCompletelyPercentage
                                       number
   justifiedPartiallyCount
                                        integer Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer Total count
```

```
StatementPropertyCoverage {
Statement property coverage information.
  coverageGoal
                                                    string
                                                             Name of the goal
  coveredCount
                                                   integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                   integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                    integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                    integer
                                                             Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                             Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                    integer
                                                             Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                             Unreachable N (justified) percentage
  unknownJustifiedCount
                                                   integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                             Unknown (justified) percentage
  unknownCount
                                                    integer Unknown count
  unknownPercentage
                                                   number
                                                             Unknown percentage
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                    integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
  unreachableCount
                                                    integer Unreachable count
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                    integer
                                                             Total count
  comment
                                                    string
                                                             The comment
}
SwitchCaseCoverage {
Switch Case goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                  Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
                                        integer
   justifiedCompletelyCount
                                                  Covered completely (justified) count
   justifiedCompletelyPercentage
                                                  Covered completely (justified) percentage
                                        number
   justifiedPartiallyCount
                                        integer
                                                  Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer
                                                  Total count
SwitchCasePropertyCoverage {
Switch Case property coverage information.
  coverageGoal
                                                    string
                                                             Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                    integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
```

Unreachable Infinite (justified) count unreachableInfiniteJustifiedCount integer unreachableInfiniteJustifiedPercentage number Unreachable Infinite (justified) percentage unreachableNJustifiedCount integer Unreachable N (justified) count unreachableNJustifiedPercentage number Unreachable N (justified) percentage unknownJustifiedCount integer Unknown (justified) count unknownJustifiedPercentage number Unknown (justified) percentage unknownCount integer Unknown count unknownPercentage number Unknown percentage handledCount integer Handled count handledPercentage number Handled percentage inconsistentCount integer Inconsistent count number inconsistentPercentage Inconsistent percentage unreachableCount integer Unreachable count unreachablePercentage number Unreachable percentage totalCount integer Total count comment string The comment } DivisionByZeroCoverage { Division By Zero goal coverage information. coverageGoal string Name of the goal coveredCompletelyCount integer Coverage complete count coveredCompletelyPercentage number Coverage complete percentage coveredPartiallyCount integer Coverage partial count coveredPartiallyPercentage number Coverage partial percentage handledCompletelyCount integer Handled complete count handledCompletelyPercentage number Handled complete percentage handledPartiallyCount integer Handled partial count handledPartiallyPercentage number Handled partial percentage unhandledCount integer Unhandled count unhandledPercentage number Unhandled percentage uncoveredCount integer Uncovered count uncoveredPercentage number Uncovered percentage justifiedCompletelyCount integer Covered completely (justified) count justifiedCompletelyPercentage number Covered completely (justified) percentage justifiedPartiallyCount integer Covered partially (justified) count justifiedPartiallyPercentage number Covered partially (justified) percentage totalCount integer Total count DivisionByZeroPropertyCoverage { Division By Zero property coverage information. coverageGoal string Name of the goal coveredCount integer Covered count coveredPercentage number Covered percentage unreachableInfiniteCount integer Unreachable Infinite count unreachableInfinitePercentage number Unreachable Infinite percentage unreachableNCount integer Unreachable N count unreachableNPercentage number Unreachable N percentage unreachableInfiniteJustifiedCount integer Unreachable Infinite (justified) count unreachableInfiniteJustifiedPercentage number Unreachable Infinite (justified) percentage unreachableNJustifiedCount integer Unreachable N (justified) count unreachableNJustifiedPercentage number Unreachable N (justified) percentage unknownJustifiedCount integer Unknown (justified) count unknownJustifiedPercentage number Unknown (justified) percentage unknownCount integer Unknown count unknownPercentage number Unknown percentage handledCount integer Handled count handledPercentage number Handled percentage

```
Inconsistent count
  inconsistentCount
                                                   integer
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
  unreachableCount
                                                   integer
                                                             Unreachable count
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer Total count
  comment
                                                   string
                                                             The comment
}
DownCastCoverage {
DownCast goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handled Partially Count\\
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                        number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer
                                                  Total count
}
DownCastPropertyCoverage {
DownCast property coverage information.
  coverageGoal
                                                   string
                                                             Name of the goal
  coveredCount
                                                   integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                   integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                   integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                             Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                   integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                             Unreachable N (justified) percentage
  unknownJustifiedCount
                                                   integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                             Unknown (justified) percentage
  unknownCount
                                                   integer Unknown count
  unknownPercentage
                                                   number
                                                             Unknown percentage
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                   integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
  unreachableCount
                                                   integer Unreachable count
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer Total count
  comment
                                                   string
                                                             The comment
}
codeCoverageComment
                                      string
                                                     The code coverage overview comment.
robustnessCoverageComment
                                      string
                                                     The robustness coverage overview comment.
```

}

```
RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 7.3 POST /ep/coverage-goals/set-comment-b2b

#### Set goal comments

Set comments of code coverage and robustness check goals.

# **REQUEST**

# 7.4 POST /ep/coverage-goals/set-justified-b2b

#### Set goal justified status

Set justified status of code coverage and robustness check goals.

# **REQUEST**

```
REQUEST BODY - application/json
{
    justified boolean The desired state of justify for the supplied goals.
    plls [string] The Plls of the goals
}
```

```
STATUS CODE - 200: OK

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 7.5 POST /ep/scopes/{scope-uid}/set-coverage-overview-comment-b2b

#### Set overview comments

Set the comments of code coverage overview sections.

# **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uio	string	The UID of the scope

## **RESPONSE**

string

```
STATUS CODE - 200: OK

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
```

# 8. CODE COVERAGE/ROBUSTNESS CHECK RBT

Retrieve code coverage/robustness checks details and results in RBT.

# 8.1 GET /ep/requirements-sources/{requirement-source-uid}/coverage-detailsrbt

# Get coverage details for a requirement source

Get code coverage/robustness checks details for a requirement source. Some filters can be applied.

# **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*requirement-source-uid	string	The UID of the requirement source

#### **OUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
statuses	array of string ALLOWED: COVERED, UNKNOWN, UNREACHABLE_INF, UNREACHABLE_N, INCONSISTENT, UNKNOWN_JUSTIFIED, UNREACHABLE_N_JUSTIFIED, UNREACHABLE_INF_JUSTIFIED	The status filter for code coverage/robustness check goals. Possible values: COVERED, UNKNOWN, UNREACHABLE_INF, UNREACHABLE_N, INCONSISTENT, UNKNOWN_JUSTIFIED, UNREACHABLE_INF_JUSTIFIED, UNREACHABLE_N_JUSTIFIED. Can also specify multiple options. Can also be empty, in which case the results are shown for all statuses.
goal- types	array of string ALLOWED: STM, D, C, MCDC, F, FC, SC, RO, CDC, DZ, CA	The goal type filter for code coverage/robustness check goals. Possible values for code coverage goals: STM(Statement), C(Condition), D(Decision/Branch), CDC(C/DC), MCDC(C/DC and MC/DC), F(Function), SC(Switch-Case), RO(Relational Operator), FC(Function Call). Possible values for robustness check goals are: DZ(Division by Zero), CA(Downcast). Can also specify multiple options. Can also be empty, in which case the results are shown for all goal types.
files	array of string	List of file filters for code coverage/robustness check goals. If list is empty the results are shown for all files.

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

#### **RESPONSE MODEL - application/json**

```
[ {
Array of object:
   p11
                    string
                                 PLL string of the coverage goal.
   type
                    string
                                 Goal type of the coverage goal.
   line
                    integer
                                 The line number of the location where the coverage goal is located in the file.
   file
                    string
                                 The file name where the coverage property can be located.
   properties [{
   Array of object: A list with coverage goal properties.
      p11
                               string
                                            PLL string of the coverage property.
      status
                               string
                                             Status of the coverage property.
      covering Vectors [string] List of string vector names that cover the property.
```

```
}]
    expression string
                           Expression of the coverage goal.
    blocks [string] The TargetLink blocks
    comment
                  string
                             The comment.
    justified boolean If this goal is justified
  }]
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 8.2 GET /ep/scopes/{scope-uid}/coverage-details-rbt

# Get coverage details for a scope

Get all code coverage/robustness checks details for a scope. Some filters can be applied.

# **REQUEST**

# **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope

# **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
statuses	array of string ALLOWED: COVERED, UNKNOWN, UNREACHABLE_INF, UNREACHABLE_N, INCONSISTENT, UNKNOWN_JUSTIFIED, UNREACHABLE_N_JUSTIFIED, UNREACHABLE_INF_JUSTIFIED	The status filter for code coverage/robustness check goals. Possible values: COVERED, UNKNOWN, UNREACHABLE_INF, UNREACHABLE_N, INCONSISTENT, UNKNOWN_JUSTIFIED, UNREACHABLE_INF_JUSTIFIED, UNREACHABLE_N_JUSTIFIED. Can also specify multiple options. options. contact the results are shown for all statuses.
goal- types	array of string ALLOWED: STM, D, C, MCDC, F, FC, SC, RO, CDC, DZ, CA	The goal type filter for code coverage/robustness check goals. Possible values for code coverage goals: STM(Statement), C(Condition), D(Decision/Branch), CDC(C/DC), MCDC(C/DC and MC/DC), F(Function), SC(Switch-Case), RO(Relational Operator), FC(Function Call). values for robustness check goals are: DZ(Division by Zero), CA(Downcast). Can also specify multiple options. Can also be empty, in which case the results are shown for all goal types.
files	array of string	List of file filters for code coverage/robustness check goals. If list is empty the results are shown for all files.

#### STATUS CODE - 200: OK

```
RESPONSE MODEL - application/json
  Array of object:
     pll
                     string
                                 PLL string of the coverage goal.
     type
                     string
                                 Goal type of the coverage goal.
     line
                     integer The line number of the location where the coverage goal is located in the file.
     file
                     string
                                 The file name where the coverage property can be located.
     properties [{
     Array of object: A list with coverage goal properties.
        p11
                               string
                                            PLL string of the coverage property.
        status
                               string
                                            Status of the coverage property.
        covering Vectors [string] List of string vector names that cover the property.
     }]
     expression string
                                 Expression of the coverage goal.
     blocks
                     [string] The TargetLink blocks
     comment
                     string
                                  The comment.
     justified
                    boolean
                                 If this goal is justified
  }]
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 8.3 GET /ep/requirements-sources/{requirements-source-uid}/coverageresults-rbt

# Get coverage results for a requirement source

Get the code coverage and robustness checks results for a requirement source. Goal type filters can be applied.

# **REQUEST**

## **PATH PARAMETERS**

NAME T	ГҮРЕ	DESCRIPTION
*requirements-source-uid s	string	The UID of the requirement source

## **QUERY PARAMETERS**

	TVDE	DECODIDETION
NAME	TYPE	DESCRIPTION

NAME	TYPE	DESCRIPTION
goal- types	array of string ALLOWED: STM, D, C, MCDC, F, FC, SC, RO, CDC, DZ, CA	The goal type filter for code coverage/robustness check goals. Possible values for code coverage goals: STM(Statement), C(Condition), D(Decision/Branch), CDC(C/DC), MCDC(C/DC and MC/DC), F(Function), SC(Switch-Case), RO(Relational Operator), FC(Function Call). Possible values for robustness check goals are: DZ(Division by Zero), CA(Downcast). Can also specify multiple options. Can also be empty, in which case the results are shown for all goal types.

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  {
    CDCCoverage {
    CDC goal coverage information.
       coverageGoal
                                             string
                                                       Name of the goal
       coveredCompletelyCount
                                             integer
                                                       Coverage complete count
       coveredCompletelyPercentage
                                             number
                                                       Coverage complete percentage
       coveredPartiallyCount
                                             integer Coverage partial count
       coveredPartiallyPercentage
                                             number
                                                       Coverage partial percentage
       handledCompletelyCount
                                             integer Handled complete count
       handledCompletelyPercentage
                                             number
                                                       Handled complete percentage
       handledPartiallyCount
                                             integer Handled partial count
       handledPartiallyPercentage
                                             number
                                                       Handled partial percentage
       unhandledCount
                                             integer Unhandled count
       unhandledPercentage
                                             number
                                                       Unhandled percentage
       uncoveredCount
                                             integer Uncovered count
       uncoveredPercentage
                                             number
                                                       Uncovered percentage
        justifiedCompletelyCount
                                             integer Covered completely (justified) count
        justifiedCompletelyPercentage
                                             number
                                                       Covered completely (justified) percentage
        justifiedPartiallyCount
                                             integer
                                                       Covered partially (justified) count
        justifiedPartiallyPercentage
                                             number
                                                       Covered partially (justified) percentage
       totalCount
                                             integer
                                                       Total count
    CDCPropertyCoverage {
    CDC property coverage information.
       coverageGoal
                                                        string
                                                                  Name of the goal
       coveredCount
                                                        integer Covered count
       coveredPercentage
                                                        number
                                                                  Covered percentage
       unreachableInfiniteCount
                                                        integer Unreachable Infinite count
       unreachableInfinitePercentage
                                                        number
                                                                  Unreachable Infinite percentage
                                                        integer Unreachable N count
       unreachableNCount
       unreachableNPercentage
                                                        number
                                                                  Unreachable N percentage
       unreachableInfiniteJustifiedCount
                                                        integer Unreachable Infinite (justified) count
       unreachableInfiniteJustifiedPercentage
                                                        number
                                                                  Unreachable Infinite (justified) percentage
       unreachableNJustifiedCount
                                                        integer Unreachable N (justified) count
       unreachableNJustifiedPercentage
                                                        number
                                                                  Unreachable N (justified) percentage
       unknownJustifiedCount
                                                        integer Unknown (justified) count
       unknownJustifiedPercentage
                                                        number
                                                                  Unknown (justified) percentage
       unknownCount
                                                        integer Unknown count
       unknownPercentage
                                                        number
                                                                  Unknown percentage
       handledCount
                                                        integer Handled count
       handledPercentage
                                                        number
                                                                  Handled percentage
       inconsistentCount
                                                        integer Inconsistent count
       inconsistentPercentage
                                                        number
                                                                  Inconsistent percentage
```

```
Unreachable count
  unreachableCount
                                                    integer
  unreachablePercentage
                                                   number
                                                              Unreachable percentage
  totalCount
                                                    integer
                                                              Total count
  comment
                                                    string
                                                              The comment
}
ConditionCoverage {
Condition goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                  Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer
                                                  Covered completely (justified) count
   justifiedCompletelyPercentage
                                        number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer Total count
}
ConditionPropertyCoverage {
Condition property coverage information.
  coverageGoal
                                                   string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                   number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                              Unreachable Infinite percentage
  unreachableNCount
                                                    integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                              Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                              Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                    integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                              Unreachable N (justified) percentage
  unknownJustifiedCount
                                                    integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                              Unknown (justified) percentage
  unknownCount
                                                   integer Unknown count
  unknownPercentage
                                                   number
                                                              Unknown percentage
  handledCount
                                                    integer Handled count
  handledPercentage
                                                   number
                                                              Handled percentage
  inconsistentCount
                                                    integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                              Inconsistent percentage
  unreachableCount
                                                    integer Unreachable count
  unreachablePercentage
                                                   number
                                                              Unreachable percentage
  totalCount
                                                    integer Total count
  comment
                                                    string
                                                              The comment
}
DecisionCoverage {
Decision goal coverage information.
  coverageGoal
                                        string
                                                   Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
```

coveredPartiallyCount	coveredPartiallyCount integer		Coverage partial count		
coveredPartiallyPercentage	number	Coverage part	tial percentage		
handledCompletelyCount	integer	Handled comp	plete count		
handledCompletelyPercentage	number	Handled comp	plete percentage		
handledPartiallyCount	integer	Handled partia	al count		
handledPartiallyPercentage	number	Handled partia	al percentage		
unhandledCount	integer	Unhandled co			
unhandledPercentage	number	Unhandled pe	rcentage		
uncoveredCount	integer	Uncovered co			
uncoveredPercentage	number	Uncovered per	rcentage		
justifiedCompletelyCount	integer		pletely (justified) count		
justifiedCompletelyPercentage	number		pletely (justified) percentage		
justifiedPartiallyCount	integer		ally (justified) count		
justifiedPartiallyPercentage	number		ally (justified) percentage		
totalCount	integer	Total count			
}	J				
DecisionPropertyCoverage { Decision property coverage information.					
coverageGoal		string	Name of the goal		
coveredCount		integer	Covered count		
coveredPercentage		number	Covered percentage		
unreachableInfiniteCount		integer	Unreachable Infinite count		
unreachableInfinitePercentage		number	Unreachable Infinite percentage		
unreachableNCount		integer	Unreachable N count		
unreachableNPercentage		number	Unreachable N percentage		
unreachableInfiniteJustifiedCo	unt	integer	Unreachable Infinite (justified) count		
unreachableInfiniteJustifiedPe	rcentage	number	Unreachable Infinite (justified) percentage		
unreachableNJustifiedCount		integer	Unreachable N (justified) count		
unreachableNJustifiedPercentag	ie	number	Unreachable N (justified) percentage		
unknownJustifiedCount	,	integer			
unknownJustifiedPercentage		number	Unknown (justified) percentage		
unknownCount		integer	Unknown count		
unknownPercentage		number	Unknown percentage		
handledCount			Handled count		
handledPercentage		number	Handled percentage		
inconsistentCount		integer	Inconsistent count		
inconsistentPercentage		number	Inconsistent percentage		
unreachableCount		integer	Unreachable count		
unreachablePercentage		number	Unreachable percentage		
totalCount		integer	Total count		
comment		string	The comment		
}					
FunctionCoverage { Function goal coverage information.					
coverageGoal	string	Name of the g	goal		
coveredCompletelyCount	integer	Coverage com	nplete count		
coveredCompletelyPercentage	number		nplete percentage		
coveredPartiallyCount	integer	Coverage part			
coveredPartiallyPercentage	•		tial percentage		
handledCompletelyCount	integer	Handled comp			
handledCompletelyPercentage	number		plete percentage		
handledPartiallyCount	integer	Handled partia			
handledPartiallyPercentage	number	Handled partia			
unhandledCount	integer	Unhandled co			
unhandledPercentage	number	Unhandled pe			
uncoveredCount	integer	Uncovered co			
uncoveredPercentage	number	Uncovered per			

```
Covered completely (justified) count
   justifiedCompletelyCount
                                        integer
  justifiedCompletelyPercentage
                                        number
                                                   Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                   Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                   Covered partially (justified) percentage
  totalCount
                                        integer
                                                   Total count
}
FunctionPropertyCoverage {
Function property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                    number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                    number
                                                              Unreachable Infinite percentage
  unreachableNCount
                                                    integer Unreachable N count
  unreachableNPercentage
                                                    number
                                                              Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                    integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                    number
                                                              Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                    integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                    number
                                                              Unreachable N (justified) percentage
  unknownJustifiedCount
                                                    integer Unknown (justified) count
  unknownJustifiedPercentage
                                                    number
                                                              Unknown (justified) percentage
  unknownCount
                                                    integer Unknown count
  unknownPercentage
                                                    number
                                                              Unknown percentage
  handledCount
                                                    integer Handled count
  handledPercentage
                                                    number
                                                              Handled percentage
  inconsistentCount
                                                    integer Inconsistent count
  inconsistentPercentage
                                                    number
                                                              Inconsistent percentage
  unreachableCount
                                                    integer Unreachable count
  unreachablePercentage
                                                    number
                                                              Unreachable percentage
  totalCount
                                                    integer
                                                              Total count
  comment
                                                    string
                                                              The comment
}
FunctionCallCoverage {
Function call goal coverage information.
  coverageGoal
                                        string
                                                   Name of the goal
  coveredCompletelyCount
                                        integer
                                                   Coverage complete count
  coveredCompletelvPercentage
                                        number
                                                   Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                   Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                   Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                   Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                   Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                   Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                   Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                        number
                                                   Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                   Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                   Covered partially (justified) percentage
  totalCount
                                        integer Total count
}
FunctionCallPropertyCoverage {
Function call property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
```

coveredPercentage		number	Covered percentage
unreachableInfiniteCount		integer	Unreachable Infinite count
unreachableInfinitePercentage		number	Unreachable Infinite percentage
unreachableNCount		integer	
unreachableNPercentage		number	Unreachable N percentage
unreachableInfiniteJustifiedC	ount	integer	
unreachableInfiniteJustifiedP		_	Unreachable Infinite (justified) percentage
unreachableNJustifiedCount	ercentage	integer	
unreachableNJustifiedPercenta	90	number	
unknownJustifiedCount	ge		Unreachable N (justified) percentage
		integer	
unknownJustifiedPercentage		number	Unknown (justified) percentage
unknownCount		integer	
unknownPercentage		number	Unknown percentage
handledCount		integer	
handledPercentage		number	Handled percentage
inconsistentCount		integer	
inconsistentPercentage		number	Inconsistent percentage
unreachableCount		_	Unreachable count
unreachablePercentage		number	Unreachable percentage
totalCount		integer	Total count
comment		string	The comment
}			
MCDCCoverage { MCDC goal coverage information.			
		Name of the co	
coverageGoal	string	Name of the o	
coveredCompletelyCount	integer	Coverage con	
coveredCompletelyPercentage	number		nplete percentage
coveredPartiallyCount	integer	Coverage par	
coveredPartiallyPercentage	number		tial percentage
handledCompletelyCount	integer	Handled com	
handledCompletelyPercentage	number		plete percentage
handledPartiallyCount	integer	Handled parti	
handledPartiallyPercentage	number	Handled parti	
unhandledCount	integer	Unhandled co	
unhandledPercentage	number	Unhandled pe	
uncoveredCount	integer	Uncovered co	
uncoveredPercentage	number	Uncovered pe	
justifiedCompletelyCount	integer		oletely (justified) count
justifiedCompletelyPercentage			pletely (justified) percentage
justifiedPartiallyCount	integer		ally (justified) count
justifiedPartiallyPercentage	number		ally (justified) percentage
totalCount	integer	Total count	
) MCDCDranautyCayaraga (			
MCDCPropertyCoverage { MCDC property coverage information.			
coverageGoal		string	Name of the goal
coveredCount		integer	
coveredPercentage		number	Covered percentage
unreachableInfiniteCount		integer	Unreachable Infinite count
unreachableInfinitePercentage		number	Unreachable Infinite percentage
unreachableInTiniterercentage unreachableNCount		integer	
unreachableNPercentage		number	Unreachable N percentage
unreachableInfiniteJustifiedC	ount	integer	Unreachable Infinite (justified) count
unreachableInfiniteJustifiedP		_	Unreachable Infinite (justified) percentage
unreachableNJustifiedCount	crosiicaye	integer	Unreachable N (justified) count
unreachableNJustifiedPercenta	αρ	number	Unreachable N (justified) percentage
unknownJustifiedCount	y <del>c</del>	integer	Unknown (justified) count
anknownous (1) 10000uii (		THEOGET	omalowii (justilieu) coulit

Unknown (justified) percentage unknownJustifiedPercentage number unknownCount integer Unknown count unknownPercentage number Unknown percentage handledCount integer Handled count handledPercentage number Handled percentage inconsistentCount integer Inconsistent count inconsistentPercentage number Inconsistent percentage unreachableCount integer Unreachable count unreachablePercentage number Unreachable percentage totalCount integer Total count comment string The comment } RelationalOperatorCoverage { Relational operation goal coverage information. coverageGoal string Name of the goal coveredCompletelyCount integer Coverage complete count coveredCompletelyPercentage number Coverage complete percentage coveredPartiallyCount integer Coverage partial count coveredPartiallyPercentage number Coverage partial percentage handledCompletelyCount integer Handled complete count handledCompletelyPercentage number Handled complete percentage handledPartiallyCount integer Handled partial count handledPartiallyPercentage number Handled partial percentage unhandledCount integer Unhandled count unhandledPercentage number Unhandled percentage uncoveredCount integer Uncovered count uncoveredPercentage number Uncovered percentage justifiedCompletelyCount integer Covered completely (justified) count justifiedCompletelyPercentage number Covered completely (justified) percentage justifiedPartiallyCount integer Covered partially (justified) count justifiedPartiallyPercentage number Covered partially (justified) percentage totalCount integer Total count } RelationalOperatorPropertyCoverage { Relational operation property coverage information. coverageGoal string Name of the goal coveredCount integer Covered count coveredPercentage number Covered percentage unreachableInfiniteCount integer Unreachable Infinite count unreachableInfinitePercentage number Unreachable Infinite percentage unreachableNCount integer Unreachable N count unreachableNPercentage number Unreachable N percentage unreachableInfiniteJustifiedCount integer Unreachable Infinite (justified) count unreachableInfiniteJustifiedPercentage number Unreachable Infinite (justified) percentage unreachableNJustifiedCount integer Unreachable N (justified) count unreachableNJustifiedPercentage number Unreachable N (justified) percentage unknownJustifiedCount integer Unknown (justified) count unknownJustifiedPercentage number Unknown (justified) percentage unknownCount integer Unknown count unknownPercentage number Unknown percentage handledCount integer Handled count handledPercentage number Handled percentage integer Inconsistent count inconsistentCount inconsistentPercentage number Inconsistent percentage unreachableCount integer Unreachable count unreachablePercentage Unreachable percentage number totalCount integer Total count

```
The comment
  comment
                                                   string
}
StatementCoverage {
Statement goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                  Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer
                                                  Covered completely (justified) count
  justifiedCompletelyPercentage
                                       number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                  Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer
                                                  Total count
}
StatementPropertyCoverage {
Statement property coverage information.
  coverageGoal
                                                   string
                                                             Name of the goal
  coveredCount
                                                   integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                   integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                   integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                             Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                   integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                             Unreachable N (justified) percentage
  unknownJustifiedCount
                                                   integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                             Unknown (justified) percentage
                                                   integer Unknown count
  unknownCount
  unknownPercentage
                                                   number
                                                             Unknown percentage
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                   integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
  unreachableCount
                                                   integer Unreachable count
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer Total count
  comment
                                                   string
                                                             The comment
}
SwitchCaseCoverage {
Switch Case goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                  Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
```

```
Handled complete percentage
  handledCompletelyPercentage
                                        number
  handledPartiallyCount
                                        integer
                                                  Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer
                                                  Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                       number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                  Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                   Covered partially (justified) percentage
  totalCount
                                        integer
                                                  Total count
}
SwitchCasePropertyCoverage {
Switch Case property coverage information.
  coverageGoal
                                                   string
                                                             Name of the goal
  coveredCount
                                                   integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                   integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                   integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                             Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                   integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                             Unreachable N (justified) percentage
  unknownJustifiedCount
                                                   integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                             Unknown (justified) percentage
  unknownCount
                                                   integer Unknown count
  unknownPercentage
                                                   number
                                                             Unknown percentage
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                   integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
  unreachableCount
                                                   integer Unreachable count
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer Total count
  comment
                                                   string
                                                             The comment
}
DivisionByZeroCoverage {
Division By Zero goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                  Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
                                        integer Uncovered count
  uncoveredCount
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer
                                                  Covered completely (justified) count
   justifiedCompletelyPercentage
                                       number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer Covered partially (justified) count
```

```
Covered partially (justified) percentage
   justifiedPartiallyPercentage
                                        number
  totalCount
                                        integer
                                                   Total count
}
DivisionByZeroPropertyCoverage {
Division By Zero property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                    number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                    number
                                                              Unreachable Infinite percentage
  unreachableNCount
                                                    integer Unreachable N count
  unreachableNPercentage
                                                    number
                                                              Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                    integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                              Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                    integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                              Unreachable N (justified) percentage
  unknownJustifiedCount
                                                    integer Unknown (justified) count
  unknownJustifiedPercentage
                                                    number
                                                              Unknown (justified) percentage
  unknownCount
                                                    integer Unknown count
  unknownPercentage
                                                    number
                                                              Unknown percentage
  handledCount
                                                    integer Handled count
  handledPercentage
                                                    number
                                                              Handled percentage
  inconsistentCount
                                                    integer Inconsistent count
  inconsistentPercentage
                                                    number
                                                              Inconsistent percentage
  unreachableCount
                                                    integer Unreachable count
  unreachablePercentage
                                                    number
                                                              Unreachable percentage
  totalCount
                                                    integer Total count
  comment
                                                    string
                                                              The comment
}
DownCastCoverage {
DownCast goal coverage information.
  coverageGoal
                                        string
                                                   Name of the goal
  coveredCompletelyCount
                                        integer Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                   Coverage complete percentage
  coveredPartiallyCount
                                        integer Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                   Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handled {\tt Completely Percentage}
                                        number
                                                   Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                   Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                   Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                   Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                        number
                                                   Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                   Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                   Covered partially (justified) percentage
  totalCount
                                        integer Total count
}
DownCastPropertyCoverage {
DownCast property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                    number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                    number
                                                              Unreachable Infinite percentage
```

```
integer Unreachable N count
       unreachableNCount
       unreachableNPercentage
                                                       number
                                                                 Unreachable N percentage
       unreachableInfiniteJustifiedCount
                                                       integer Unreachable Infinite (justified) count
       unreachableInfiniteJustifiedPercentage number
                                                                 Unreachable Infinite (justified) percentage
       unreachableNJustifiedCount
                                                       integer Unreachable N (justified) count
       unreachableNJustifiedPercentage
                                                       number
                                                                 Unreachable N (justified) percentage
       unknownJustifiedCount
                                                       integer Unknown (justified) count
       unknownJustifiedPercentage
                                                       number Unknown (justified) percentage
       unknownCount
                                                       integer Unknown count
       unknownPercentage
                                                       number Unknown percentage
       handledCount
                                                       integer Handled count
       handledPercentage
                                                       number
                                                                 Handled percentage
       inconsistentCount
                                                       integer Inconsistent count
       inconsistentPercentage
                                                       number Inconsistent percentage
       unreachableCount
                                                       integer Unreachable count
       unreachablePercentage
                                                       number Unreachable percentage
       totalCount
                                                       integer Total count
       comment
                                                       string
                                                                 The comment
    }
    codeCoverageComment
                                           string
                                                         The code coverage overview comment.
     robustnessCoverageComment
                                          string
                                                         The robustness coverage overview comment.
  }
STATUS CODE - 400: Bad request
 RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
 RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
 RESPONSE MODEL - text/plain
string
```

# 8.4 GET /ep/scopes/{scope-uid}/coverage-results-rbt

#### Get coverage results for a scope

Get the code coverage and robustness checks results for a scope. Goal type filters can be applied.

### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope

#### **QUERY PARAMETERS**

NAME TYPE	E TYPE DESCRIPTION			

NAME	TYPE	DESCRIPTION
goal- types	array of string ALLOWED: STM, D, C, MCDC, F, FC, SC, RO, CDC, DZ, CA	The goal type filter for code coverage/robustness check goals. Possible values for code coverage goals: STM(Statement), C(Condition), D(Decision/Branch), CDC(C/DC), MCDC(C/DC and MC/DC), F(Function), SC(Switch-Case), RO(Relational Operator), FC(Function Call). Possible values for robustness check goals are: DZ(Division by Zero), CA(Downcast). Can also specify multiple options. Can also be empty, in which case the results are shown for all goal types.

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  {
    CDCCoverage {
    CDC goal coverage information.
       coverageGoal
                                             string
                                                       Name of the goal
       coveredCompletelyCount
                                             integer
                                                       Coverage complete count
       coveredCompletelyPercentage
                                             number
                                                       Coverage complete percentage
       coveredPartiallyCount
                                             integer Coverage partial count
       coveredPartiallyPercentage
                                             number
                                                       Coverage partial percentage
       handledCompletelyCount
                                             integer Handled complete count
       handledCompletelyPercentage
                                             number
                                                       Handled complete percentage
       handledPartiallyCount
                                             integer Handled partial count
       handledPartiallyPercentage
                                             number
                                                       Handled partial percentage
       unhandledCount
                                             integer Unhandled count
       unhandledPercentage
                                             number
                                                       Unhandled percentage
       uncoveredCount
                                             integer Uncovered count
       uncoveredPercentage
                                             number
                                                       Uncovered percentage
        justifiedCompletelyCount
                                             integer Covered completely (justified) count
        justifiedCompletelyPercentage
                                             number
                                                       Covered completely (justified) percentage
        justifiedPartiallyCount
                                             integer
                                                       Covered partially (justified) count
        justifiedPartiallyPercentage
                                             number
                                                       Covered partially (justified) percentage
       totalCount
                                             integer
                                                       Total count
    CDCPropertyCoverage {
    CDC property coverage information.
       coverageGoal
                                                        string
                                                                  Name of the goal
       coveredCount
                                                        integer Covered count
       coveredPercentage
                                                        number
                                                                  Covered percentage
       unreachableInfiniteCount
                                                        integer Unreachable Infinite count
       unreachableInfinitePercentage
                                                        number
                                                                  Unreachable Infinite percentage
                                                        integer Unreachable N count
       unreachableNCount
       unreachableNPercentage
                                                        number
                                                                  Unreachable N percentage
       unreachableInfiniteJustifiedCount
                                                        integer Unreachable Infinite (justified) count
       unreachableInfiniteJustifiedPercentage
                                                        number
                                                                  Unreachable Infinite (justified) percentage
       unreachableNJustifiedCount
                                                        integer Unreachable N (justified) count
       unreachableNJustifiedPercentage
                                                        number
                                                                  Unreachable N (justified) percentage
       unknownJustifiedCount
                                                        integer Unknown (justified) count
       unknownJustifiedPercentage
                                                        number
                                                                  Unknown (justified) percentage
       unknownCount
                                                        integer Unknown count
       unknownPercentage
                                                        number
                                                                  Unknown percentage
       handledCount
                                                        integer Handled count
       handledPercentage
                                                        number
                                                                  Handled percentage
       inconsistentCount
                                                        integer Inconsistent count
       inconsistentPercentage
                                                        number
                                                                  Inconsistent percentage
```

```
Unreachable count
  unreachableCount
                                                    integer
  unreachablePercentage
                                                   number
                                                              Unreachable percentage
  totalCount
                                                    integer
                                                              Total count
  comment
                                                    string
                                                              The comment
}
ConditionCoverage {
Condition goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                  Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer
                                                  Covered completely (justified) count
   justifiedCompletelyPercentage
                                        number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer Total count
}
ConditionPropertyCoverage {
Condition property coverage information.
  coverageGoal
                                                   string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                   number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                              Unreachable Infinite percentage
  unreachableNCount
                                                    integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                              Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                              Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                    integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                              Unreachable N (justified) percentage
  unknownJustifiedCount
                                                    integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                              Unknown (justified) percentage
  unknownCount
                                                   integer Unknown count
  unknownPercentage
                                                   number
                                                              Unknown percentage
  handledCount
                                                    integer Handled count
  handledPercentage
                                                   number
                                                              Handled percentage
  inconsistentCount
                                                    integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                              Inconsistent percentage
  unreachableCount
                                                    integer Unreachable count
  unreachablePercentage
                                                   number
                                                              Unreachable percentage
  totalCount
                                                    integer Total count
  comment
                                                    string
                                                              The comment
}
DecisionCoverage {
Decision goal coverage information.
  coverageGoal
                                        string
                                                   Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
```

coveredPartiallyCount	integer	Coverage part	ilai Coulit
coveredPartiallyPercentage	number	Coverage part	tial percentage
handledCompletelyCount	integer	Handled comp	plete count
handledCompletelyPercentage	number	Handled comp	plete percentage
handledPartiallyCount	integer	Handled partia	al count
handledPartiallyPercentage	number	Handled partia	al percentage
unhandledCount	integer	Unhandled co	
unhandledPercentage	number	Unhandled pe	rcentage
uncoveredCount	integer	Uncovered co	
uncoveredPercentage	number	Uncovered pe	rcentage
justifiedCompletelyCount	integer		pletely (justified) count
justifiedCompletelyPercentage	number		pletely (justified) percentage
justifiedPartiallyCount	integer		ally (justified) count
justifiedPartiallyPercentage	number		ally (justified) percentage
totalCount		Total count	any (document) percentage
}			
DecisionPropertyCoverage { Decision property coverage information.			
coverageGoal		string	Name of the goal
coveredCount		integer	
coveredPercentage		number	Covered percentage
unreachableInfiniteCount		integer	Unreachable Infinite count
unreachableInfinitePercentage		number	Unreachable Infinite percentage
unreachableNCount		integer	Unreachable N count
unreachableNPercentage		number	Unreachable N percentage
unreachableInfiniteJustifiedCo	ount	integer	
unreachableInfiniteJustifiedPe		_	Unreachable Infinite (justified) percentage
unreachableNJustifiedCount		integer	Unreachable N (justified) count
unreachableNJustifiedPercentag	re	number	Unreachable N (justified) percentage
unknownJustifiedCount	9-		
		integer	
		integer	
unknownJustifiedPercentage		number	Unknown (justified) percentage
unknownJustifiedPercentage unknownCount		number integer	Unknown (justified) percentage Unknown count
unknownJustifiedPercentage unknownCount unknownPercentage		number integer number	Unknown (justified) percentage Unknown count Unknown percentage
unknownJustifiedPercentage unknownCount unknownPercentage handledCount		number integer number integer	Unknown (justified) percentage Unknown count Unknown percentage Handled count
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage		number integer number integer number	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount		number integer number integer number integer	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage		number integer number integer number integer number integer number	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount		number integer number integer number integer number integer	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage		number integer number integer number integer number integer number	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount		number integer number integer number integer number integer integer number	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment		number integer number integer number integer number integer number	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount		number integer number integer number integer number integer integer number	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information.	string	number integer number integer number integer number integer number integer string	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information. coverageGoal	string	number integer number integer number integer number integer number string	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information. coverageGoal coveredCompletelyCount	integer	number integer number integer number integer number integer number string	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information. coverageGoal coveredCompletelyCount coveredCompletelyPercentage	integer number	number integer number integer number integer number integer number integer string	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information.  coverageGoal coveredCompletelyCount coveredCompletelyPercentage coveredPartiallyCount	integer	number integer number integer number integer number integer number integer string  Name of the g Coverage com Coverage com Coverage part	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information.  coverageGoal coveredCompletelyCount coveredPartiallyCount coveredPartiallyPercentage	integer number integer number	number integer number integer number integer number integer number integer string  Name of the g Coverage com Coverage part Coverage part	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information.  coverageGoal coveredCompletelyCount coveredPartiallyCount coveredPartiallyPercentage handledCompletelyCount	integer number integer number integer	number integer number integer number integer number integer number integer string  Name of the g Coverage com Coverage com Coverage part Handled com	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information.  coverageGoal coveredCompletelyCount coveredPartiallyPercentage handledCompletelyPercentage	integer number integer number integer number	number integer number integer number integer number integer number integer string  Name of the g Coverage com Coverage com Coverage part Handled comp	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment
unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information.  coverageGoal coveredCompletelyCount coveredPartiallyCount coveredPartiallyPercentage handledCompletelyPercentage handledCompletelyPercentage	integer number integer number integer number integer	number integer number integer number integer number integer number integer string  Name of the g Coverage com Coverage com Coverage part Handled comp Handled comp	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment  goal inplete percentage tial count tial percentage plete count plete percentage plete count plete percentage al count
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information.  coverageGoal coveredCompletelyCount coveredPartiallyCount coveredPartiallyPercentage handledCompletelyPercentage handledCompletelyPercentage handledCompletelyPercentage handledPartiallyCount handledPartiallyCount	integer number integer number integer number integer number	number integer number integer number integer number integer number integer string  Name of the g Coverage com Coverage com Coverage part Handled comp Handled partis Handled partis	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment  goal inplete count inplete percentage tial count tial percentage plete count plete percentage al count al percentage
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information.  coverageGoal coveredCompletelyCount coveredPartiallyPercentage handledCompletelyPercentage handledCompletelyPercentage handledCompletelyPercentage handledPartiallyCount handledPartiallyCount handledPartiallyPercentage unhandledCount	integer number integer number integer number integer number integer	number integer number integer number integer number integer number integer number integer string  Name of the g Coverage com Coverage com Coverage part Handled comp Handled partic Unhandled co	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment  goal Inplete count Inplete percentage tial count tial percentage al count al percentage al count al percentage
unknownJustifiedPercentage unknownCount unknownPercentage handledCount handledPercentage inconsistentCount inconsistentPercentage unreachableCount unreachablePercentage totalCount comment } FunctionCoverage { Function goal coverage information.  coverageGoal coveredCompletelyCount coveredPartiallyCount coveredPartiallyPercentage handledCompletelyPercentage handledCompletelyPercentage handledCompletelyPercentage handledPartiallyCount handledPartiallyCount	integer number integer number integer number integer number	number integer number integer number integer number integer number integer number integer string  Name of the g Coverage com Coverage com Coverage part Handled comp Handled partic Unhandled pe	Unknown (justified) percentage Unknown count Unknown percentage Handled count Handled percentage Inconsistent count Inconsistent percentage Unreachable count Unreachable percentage Total count The comment  goal Inplete count tial percentage plete count tial percentage al count al percentage unt rcentage

```
Covered completely (justified) count
   justifiedCompletelyCount
                                        integer
  justifiedCompletelyPercentage
                                        number
                                                   Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                   Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                   Covered partially (justified) percentage
  totalCount
                                        integer
                                                   Total count
}
FunctionPropertyCoverage {
Function property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                    number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                    number
                                                              Unreachable Infinite percentage
  unreachableNCount
                                                    integer Unreachable N count
  unreachableNPercentage
                                                    number
                                                              Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                    integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                    number
                                                              Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                    integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                    number
                                                              Unreachable N (justified) percentage
  unknownJustifiedCount
                                                    integer Unknown (justified) count
  unknownJustifiedPercentage
                                                    number
                                                              Unknown (justified) percentage
  unknownCount
                                                    integer Unknown count
  unknownPercentage
                                                    number
                                                              Unknown percentage
  handledCount
                                                    integer Handled count
  handledPercentage
                                                    number
                                                              Handled percentage
  inconsistentCount
                                                    integer Inconsistent count
  inconsistentPercentage
                                                    number
                                                              Inconsistent percentage
  unreachableCount
                                                    integer Unreachable count
  unreachablePercentage
                                                    number
                                                              Unreachable percentage
  totalCount
                                                    integer
                                                              Total count
  comment
                                                    string
                                                              The comment
}
FunctionCallCoverage {
Function call goal coverage information.
  coverageGoal
                                        string
                                                   Name of the goal
  coveredCompletelyCount
                                        integer
                                                   Coverage complete count
  coveredCompletelvPercentage
                                        number
                                                   Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                   Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                   Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                   Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                   Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                   Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                   Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                        number
                                                   Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                   Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                   Covered partially (justified) percentage
  totalCount
                                        integer Total count
}
FunctionCallPropertyCoverage {
Function call property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
```

coveredPercentage		number	Covered percentage
unreachableInfiniteCount		integer	Unreachable Infinite count
unreachableInfinitePercentage		number	Unreachable Infinite percentage
unreachableNCount		integer	Unreachable N count
unreachableNPercentage		number	Unreachable N percentage
unreachableInfiniteJustifiedCo	ount	integer	Unreachable Infinite (justified) count
unreachableInfiniteJustifiedPe	ercentage	number	Unreachable Infinite (justified) percentage
unreachableNJustifiedCount		integer	Unreachable N (justified) count
unreachableNJustifiedPercentag	je	number	Unreachable N (justified) percentage
unknownJustifiedCount		integer	Unknown (justified) count
unknownJustifiedPercentage		number	Unknown (justified) percentage
unknownCount		integer	Unknown count
unknownPercentage		number	Unknown percentage
handledCount		integer	
handledPercentage		number	Handled percentage
inconsistentCount		integer	
inconsistentPercentage		number	Inconsistent percentage
unreachableCount		integer	
unreachablePercentage		number	Unreachable percentage
totalCount		integer	
comment		string	The comment
}		3	
MCDCCoverage {			
MCDC goal coverage information.			
coverageGoal	string	Name of the g	goal
coveredCompletelyCount	integer	Coverage con	nplete count
coveredCompletelyPercentage	number	Coverage con	nplete percentage
coveredPartiallyCount	integer	Coverage par	tial count
coveredPartiallyPercentage	number	Coverage par	tial percentage
handledCompletelyCount	integer	Handled com	plete count
handledCompletelyPercentage	number		plete percentage
handledPartiallyCount	integer	Handled parti	
handledPartiallyPercentage	number	Handled parti	
unhandledCount	integer	Unhandled co	
unhandledPercentage	number	Unhandled pe	
uncoveredCount	integer	Uncovered co	
uncoveredPercentage	number	Uncovered pe	rcentage
justifiedCompletelyCount	integer		pletely (justified) count
justifiedCompletelyPercentage	number		pletely (justified) percentage
justifiedPartiallyCount	integer		ally (justified) count
justifiedPartiallyPercentage	number	Covered parti	ally (justified) percentage
totalCount	integer	Total count	
}			
<pre>MCDCPropertyCoverage {</pre>			
MCDC property coverage information.			
coverageGoal		string	Name of the goal
coveredCount		integer	Covered count
coveredPercentage		number	Covered percentage
unreachableInfiniteCount		integer	Unreachable Infinite count
unreachableInfinitePercentage		number	Unreachable Infinite percentage
unreachableNCount		integer	
unreachableNPercentage		number	Unreachable N percentage
unreachableInfiniteJustifiedCo		integer	Unreachable Infinite (justified) count
unreachableInfiniteJustifiedPe	ercentage		Unreachable Infinite (justified) percentage
unreachableNJustifiedCount		integer	
unreachableNJustifiedPercentag	je	number	Unreachable N (justified) percentage
unknownJustifiedCount		integer	Unknown (justified) count

Unknown (justified) percentage unknownJustifiedPercentage number unknownCount integer Unknown count unknownPercentage number Unknown percentage handledCount integer Handled count handledPercentage number Handled percentage inconsistentCount integer Inconsistent count inconsistentPercentage number Inconsistent percentage unreachableCount integer Unreachable count unreachablePercentage number Unreachable percentage totalCount integer Total count comment string The comment } RelationalOperatorCoverage { Relational operation goal coverage information. coverageGoal string Name of the goal coveredCompletelyCount integer Coverage complete count coveredCompletelyPercentage number Coverage complete percentage coveredPartiallyCount integer Coverage partial count coveredPartiallyPercentage number Coverage partial percentage handledCompletelyCount integer Handled complete count handledCompletelyPercentage number Handled complete percentage handledPartiallyCount integer Handled partial count handledPartiallyPercentage number Handled partial percentage unhandledCount integer Unhandled count unhandledPercentage number Unhandled percentage uncoveredCount integer Uncovered count uncoveredPercentage number Uncovered percentage justifiedCompletelyCount integer Covered completely (justified) count justifiedCompletelyPercentage number Covered completely (justified) percentage justifiedPartiallyCount integer Covered partially (justified) count justifiedPartiallyPercentage number Covered partially (justified) percentage totalCount integer Total count } RelationalOperatorPropertyCoverage { Relational operation property coverage information. coverageGoal string Name of the goal coveredCount integer Covered count coveredPercentage number Covered percentage unreachableInfiniteCount integer Unreachable Infinite count unreachableInfinitePercentage number Unreachable Infinite percentage unreachableNCount integer Unreachable N count unreachableNPercentage number Unreachable N percentage unreachableInfiniteJustifiedCount integer Unreachable Infinite (justified) count unreachableInfiniteJustifiedPercentage number Unreachable Infinite (justified) percentage unreachableNJustifiedCount integer Unreachable N (justified) count unreachableNJustifiedPercentage number Unreachable N (justified) percentage unknownJustifiedCount integer Unknown (justified) count unknownJustifiedPercentage number Unknown (justified) percentage unknownCount integer Unknown count unknownPercentage number Unknown percentage handledCount integer Handled count handledPercentage number Handled percentage integer Inconsistent count inconsistentCount inconsistentPercentage number Inconsistent percentage unreachableCount integer Unreachable count unreachablePercentage Unreachable percentage number totalCount integer Total count

```
The comment
  comment
                                                   string
}
StatementCoverage {
Statement goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                  Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer
                                                  Covered completely (justified) count
  justifiedCompletelyPercentage
                                       number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                  Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer
                                                  Total count
}
StatementPropertyCoverage {
Statement property coverage information.
  coverageGoal
                                                   string
                                                             Name of the goal
  coveredCount
                                                   integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                   integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                   integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                             Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                   integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                             Unreachable N (justified) percentage
  unknownJustifiedCount
                                                   integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                             Unknown (justified) percentage
                                                   integer Unknown count
  unknownCount
  unknownPercentage
                                                   number
                                                             Unknown percentage
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                   integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
  unreachableCount
                                                   integer Unreachable count
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer Total count
  comment
                                                   string
                                                             The comment
}
SwitchCaseCoverage {
Switch Case goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                  Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
```

```
Handled complete percentage
  handledCompletelyPercentage
                                        number
  handledPartiallyCount
                                        integer
                                                  Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer
                                                  Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                       number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                  Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                  Covered partially (justified) percentage
  totalCount
                                        integer
                                                  Total count
}
SwitchCasePropertyCoverage {
Switch Case property coverage information.
  coverageGoal
                                                   string
                                                             Name of the goal
  coveredCount
                                                   integer Covered count
  coveredPercentage
                                                   number
                                                             Covered percentage
  unreachableInfiniteCount
                                                   integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                   number
                                                             Unreachable Infinite percentage
  unreachableNCount
                                                   integer Unreachable N count
  unreachableNPercentage
                                                   number
                                                             Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                   integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                             Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                   integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                             Unreachable N (justified) percentage
  unknownJustifiedCount
                                                   integer Unknown (justified) count
  unknownJustifiedPercentage
                                                   number
                                                             Unknown (justified) percentage
  unknownCount
                                                   integer Unknown count
  unknownPercentage
                                                   number
                                                             Unknown percentage
  handledCount
                                                   integer Handled count
  handledPercentage
                                                   number
                                                             Handled percentage
  inconsistentCount
                                                   integer Inconsistent count
  inconsistentPercentage
                                                   number
                                                             Inconsistent percentage
  unreachableCount
                                                   integer Unreachable count
  unreachablePercentage
                                                   number
                                                             Unreachable percentage
  totalCount
                                                   integer Total count
  comment
                                                   string
                                                             The comment
}
DivisionByZeroCoverage {
Division By Zero goal coverage information.
  coverageGoal
                                        string
                                                  Name of the goal
  coveredCompletelyCount
                                        integer
                                                  Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                  Coverage complete percentage
  coveredPartiallyCount
                                        integer
                                                  Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                  Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handledCompletelyPercentage
                                        number
                                                  Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                  Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                  Unhandled percentage
                                        integer Uncovered count
  uncoveredCount
  uncoveredPercentage
                                        number
                                                  Uncovered percentage
   justifiedCompletelyCount
                                        integer
                                                  Covered completely (justified) count
   justifiedCompletelyPercentage
                                       number
                                                  Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer Covered partially (justified) count
```

```
Covered partially (justified) percentage
   justifiedPartiallyPercentage
                                        number
  totalCount
                                        integer
                                                   Total count
}
DivisionByZeroPropertyCoverage {
Division By Zero property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                    number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                    number
                                                              Unreachable Infinite percentage
  unreachableNCount
                                                    integer Unreachable N count
  unreachableNPercentage
                                                    number
                                                              Unreachable N percentage
  unreachableInfiniteJustifiedCount
                                                    integer Unreachable Infinite (justified) count
  unreachableInfiniteJustifiedPercentage
                                                   number
                                                              Unreachable Infinite (justified) percentage
  unreachableNJustifiedCount
                                                    integer Unreachable N (justified) count
  unreachableNJustifiedPercentage
                                                   number
                                                              Unreachable N (justified) percentage
  unknownJustifiedCount
                                                    integer Unknown (justified) count
  unknownJustifiedPercentage
                                                    number
                                                              Unknown (justified) percentage
  unknownCount
                                                    integer Unknown count
  unknownPercentage
                                                    number
                                                              Unknown percentage
  handledCount
                                                    integer Handled count
  handledPercentage
                                                    number
                                                              Handled percentage
  inconsistentCount
                                                    integer Inconsistent count
  inconsistentPercentage
                                                    number
                                                              Inconsistent percentage
  unreachableCount
                                                    integer Unreachable count
  unreachablePercentage
                                                    number
                                                              Unreachable percentage
  totalCount
                                                    integer Total count
  comment
                                                    string
                                                              The comment
}
DownCastCoverage {
DownCast goal coverage information.
  coverageGoal
                                        string
                                                   Name of the goal
  coveredCompletelyCount
                                        integer Coverage complete count
  coveredCompletelyPercentage
                                        number
                                                   Coverage complete percentage
  coveredPartiallyCount
                                        integer Coverage partial count
  coveredPartiallyPercentage
                                        number
                                                   Coverage partial percentage
  handledCompletelyCount
                                        integer Handled complete count
  handled {\tt Completely Percentage}
                                        number
                                                   Handled complete percentage
  handledPartiallyCount
                                        integer Handled partial count
  handledPartiallyPercentage
                                        number
                                                   Handled partial percentage
  unhandledCount
                                        integer Unhandled count
  unhandledPercentage
                                        number
                                                   Unhandled percentage
  uncoveredCount
                                        integer Uncovered count
  uncoveredPercentage
                                        number
                                                   Uncovered percentage
   justifiedCompletelyCount
                                        integer Covered completely (justified) count
   justifiedCompletelyPercentage
                                        number
                                                   Covered completely (justified) percentage
   justifiedPartiallyCount
                                        integer
                                                   Covered partially (justified) count
   justifiedPartiallyPercentage
                                        number
                                                   Covered partially (justified) percentage
  totalCount
                                        integer Total count
}
DownCastPropertyCoverage {
DownCast property coverage information.
  coverageGoal
                                                    string
                                                              Name of the goal
  coveredCount
                                                    integer Covered count
  coveredPercentage
                                                    number
                                                              Covered percentage
  unreachableInfiniteCount
                                                    integer Unreachable Infinite count
  unreachableInfinitePercentage
                                                    number
                                                              Unreachable Infinite percentage
```

```
integer Unreachable N count
       unreachableNCount
       unreachableNPercentage
                                                       number
                                                                 Unreachable N percentage
       unreachableInfiniteJustifiedCount
                                                       integer Unreachable Infinite (justified) count
       unreachableInfiniteJustifiedPercentage number
                                                                 Unreachable Infinite (justified) percentage
       unreachableNJustifiedCount
                                                       integer Unreachable N (justified) count
       unreachableNJustifiedPercentage
                                                       number
                                                                 Unreachable N (justified) percentage
       unknownJustifiedCount
                                                       integer Unknown (justified) count
       unknownJustifiedPercentage
                                                       number Unknown (justified) percentage
       unknownCount
                                                       integer Unknown count
       unknownPercentage
                                                       number Unknown percentage
       handledCount
                                                       integer Handled count
       handledPercentage
                                                       number
                                                                 Handled percentage
       inconsistentCount
                                                       integer Inconsistent count
       inconsistentPercentage
                                                       number Inconsistent percentage
       unreachableCount
                                                       integer Unreachable count
       unreachablePercentage
                                                       number Unreachable percentage
       totalCount
                                                       integer Total count
                                                       string
       comment
                                                                 The comment
    }
    codeCoverageComment
                                           string
                                                         The code coverage overview comment.
     robustnessCoverageComment
                                          string
                                                         The robustness coverage overview comment.
  }
STATUS CODE - 400: Bad request
 RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
 RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
 RESPONSE MODEL - text/plain
string
```

# 8.5 POST /ep/coverage-goals/set-comment-rbt

#### Set goal comments

Set comments of code coverage and robustness check goals.

#### **REQUEST**

#### **RESPONSE**

STATUS CODE - 200: OK

STATUS CODE - 400: Bad request

```
RESPONSE MODEL - text/plain string
```

STATUS CODE - 500: Internal server error

**RESPONSE MODEL - text/plain** 

string

# 8.6 POST /ep/coverage-goals/set-justified-rbt

# Set goal justified status

Set justified status of code coverage and robustness check goals.

# **REQUEST**

```
REQUEST BODY - application/json
{
    justified boolean The desired state of justify for the supplied goals.
    plls [string] The Plls of the goals
}
```

#### **RESPONSE**

```
STATUS CODE - 200: OK

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
```

# 8.7 POST /ep/scopes/{scope-uid}/set-coverage-overview-comment-rbt

## Set overview comments

Set the comments of code coverage overview sections.

#### **REQUEST**

string

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope

```
REQUEST BODY - application/json
```

Array of object:

type\* enum allowed:CC\_STAT, STM, D, C, MCDC, F, FC, SC, RO, RC\_STAT, DZ, CA

The type of overview for which to set the comment. Possible values for code coverage goals: CC\_STAT(Code

Coverage Statistics), STM(Statement), D(Decision/Branch), C(Condition), MCDC(C/DC and MC/DC), F(Function), FC(Function Call). SC(Switch-Case), RO(Relational Operator), Possible values for robustness check goals are: RC\_STAT(Robustness Check Statistics), DZ(Division by Zero), CA(Downcast). Can also specify multiple options.

```
comment* string The comment to set for the overview type.
}]
```

# **RESPONSE**

STATUS CODE - 200: OK

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 9. COVERAGE GENERATION

For a C-Code function, create stimuli vectors which cover the code function, or mark coverage properties that are unreachable.

# 9.1 POST /ep/coverage-generation

#### **Execute coverage generation**

<b>Long running task</b> Using the provided configuration, execute the coverage generation / stimuli vector generation.

#### **REQUEST**

```
REQUEST BODY - application/json
   targetDefinitions [{
   Array of object: The target definitions to use for this run. <br/>br>lf no target definitions are provided, and no PLL is given, the default target
   definitions are used
       label* string The label of the target definition.
   }]
   folderName
                                            strina
                                                         Name of the folder to store Stimuli Vectors in. If the specified folder doesn't exists.
                                                         it will be created with the given name. <br/> specified the default
                                                         folder 'Default Stimuli Vectors' will be used.
   checkUnreachableProperties
                                           boolean
                                                         Whether or not unreachable properties should be (re-)checked. <br/> Default is
                                                         'false'
   pllString
                                            string
                                                         PLL String for specifc goals to be reached. Default is '::' which matches all goals.
                                                         Use e.g. 'STM;D;CDC' to find stimuli vectors for statement, decision, and condition/
                                                         decision coverage. Individual PLLs can be addressed by their specific label (e.g.
                                                         'D:4:1'). Multiple PLLs can be concatenated using semicolon, e.g. 'D:4:1;C:2'. See
                                                         the user guide for more information about the property location labels. <br/> str>lf this
                                                         is null or empty, only the selected target definitions will be used. If in that case, the
                                                         target definitions are be empty, the default target definitions are used.
   engineSettings {
   The engine settings to use for this run.
       timeoutSeconds
                                                        integer
                                                                      Global timeout (seconds) for the execution <br/> Default is
                                                                      '-1' (unlimited)
      handlingRateThreshold
                                                        integer
                                                                      After each scope is analyzed, the 'handled rate' of the entry scope
                                                                      (potentially including goals from subscopes) is checked against
                                                                      this threshold and the stimuli vector generation is stopped when it
                                                                      is reached. Allowed range are integers from [1, 100] (percent of
                                                                      handled goals). <br/>br>Default: 100
      analyseSubScopesHierarchically
                                                       boolean
                                                                      Enables / disables recursive analysis of subscopes. <br/> speault is
      engineAtg {
       The ATG engine. <a href="https://example.com/shift-neither-ATG">https://example.com/shift-neither-ATG</a>, nor CV engine is provided, both, ATG and CV are used together, using their default settings!
                                                   string
                                                                The name of the engine (heuristic). Currently, only 'ATG' is allowed.
                                                                <br>Default is 'ATG'
          searchDepthSteps
                                                   integer
                                                                The search depth (number of SUT iterations) <br/> br>Default is '20'
          executionMode
                                                                ALLOWED: TOP_DOWN, BOTTOM_UP
                                                   enum
                                                                The search direction, bottom up or top down <br/>br>Default is 'TOP_DOWN'
          mutateExistingVectors
                                                   boolean
                                                               Defines whether or not the Mutation Based ATG engine shall be used.
                                                                <br>MATG requires existing vectors to produce new results. <br>Default
          timeoutSecondsPerSubsystem integer Timeout (seconds) per scope <br/> br>Default is '300'
       }
      engineCv {
      The CV engine. <br/> Shr>Note: If neither ATG, nor CV engine is provided, both, ATG and CV are used together, using their default settings!
          name
                                                   string
                                                                The name of the engine (heuristic). Currently, only 'CV' is allowed.
                                                                <br >Default is 'CV'
          searchDepthSteps
                                                   integer The search depth (number of SUT iterations) <br/> br>Default is '10'
          timeoutSecondsPerProperty
                                                   integer Timeout (seconds) per coverage property <br/>br>Default is '60'
```

```
The maximum amount of system memory to use (MB) <br/> <br/> br>Default is
            memoryLimitMb
                                                                  '-1' (unlimited)
            loopUnroll
                                                     integer
                                                                 The number of internal loop unwindings for potentially unbounded loops
                                                                 within each SUT iteration. <br/>
<br/>
br>Default is '50'
            coreEngines [{
            Array of object: The core engines to use <br/>br>Note: If no core engine is provided, all core engines are used by default!
                name* enum ALLOWED:SMIBMC, VIS, AUTOFXP, CBMC, ISAT
                                 The name of the core engine. If no core engine is provided, all core engines are used by default!
            }]
            assumptionCheckEnabled
                                                     boolean Whether or not core engines are allowed to explicitly checkthe
                                                                  satisfiability of the selected assumptions. <br/> br>Default is 'true'
            searchFocus
                                                                 ALLOWED: BALANCED, REACHABLE, UNREACHABLE
                                                     enum
                                                                 The search focus of the core engines. <br/> Spr>Default is 'BALANCED'
            parallelExecutionMode
                                                                 ALLOWED: BALANCED, ENGINES, GOALS
                                                     enum
                                                                  The mode used for the parallel engine execution. If maximum number of
                                                                 threads used is 1, the value of this parameter is not used (instead the
                                                                 default value BALANCED will be used).
            maximumNumberOfThreads
                                                     integer
                                                                 The maximum number of threads available for parallel engine execution
                                                                 for core engines. Valid values are between 1 and available number of
                                                                 cores. It is possible to set this parameter to a value of -1, which will
                                                                 compute the number of threads automatically as half of the available
                                                                 number of cores. <br/>br>Default is '1'
         allowDenormalizedFloats
                                                         boolean
                                                                       Whether or not the engine may produce denormalized floats.
                                                                       <br > Default is 'true'
     }
     scopeUid*
                                              string
                                                          The UID of the entry scope to use for this run.
     assumptions [{
     Array of object: The environmental assumptions to use for this run.
         id* string The Assumption UID.
     }]
     drivers [{
     Array of object: The drivers to use for this run.
         id* string The Driver source UID.
     }]
     initializationVectorUID
                                                          The UID of the RequirementBasedTestCase or B2BStimuliVector which shall be
                                              string
                                                           used to initialize the engine
  }
RESPONSE
  STATUS CODE - 202: Accepted
    RESPONSE MODEL - application/json
        jobID string READ-ONLY
                            The ID of a job.
     }
  STATUS CODE - 400: Bad request
    RESPONSE MODEL - text/plain
  string
  STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
  string
  STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
```

# 10. DOMAIN CHECKS

Handle domain checks.

# 10.1 POST /ep/domain-checks-ranges

#### Create domain checks ranges

Create the domain checks ranges for a scope and a list of signals. If the list of signals is not given, ranges for all signals of the scope will be created by default. The ranges can be created with some convenience functions applied (partitioned by a percent, with boundaries checks included or with invalid ranges checks included). Please note ALL domain checks ranges created via this service will overwrite any existing ranges for the given list of signals or for all signals (if no signal is specified).

# **REQUEST**

```
REQUEST BODY - application/json
{
   scopeUid*
                                            string
                                                          The scope for which to create the domain checks ranges.
   signalUids
                                            [string]
                                                          The list of signals for which to create the domain checks ranges. If no signal is
                                                          provided, ranges for all signals from the scope are created by default.
   applyBoundaryChecks
                                            boolean
                                                          Used for applying the boundary checks when creating the range. Can only be used
                                                          for applying boundary checks on a defined range, so it must be used only together
                                                          with one of the other options (either apply invalid ranges checks or partition ranges).
                                                          <br>Default is 'false'
   applyInvalidRangesChecks boolean
                                                          Used for applying the invalid ranges checks when creating the range. <br/> Spr>Default is
   percentage
                                                          Percentage used for partioning the range interval when creating the range. <br/> <br/>br>lf no
                                            integer
                                                          value is provided the domain check ranges will not be partitioned.
}
```

#### **RESPONSE**

```
STATUS CODE - 200: OK

RESPONSE MODEL - text/plain
string

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

# 10.2 POST /ep/domain-checks-export

#### **Export domain check ranges**

Export domain check ranges of the given scopeUid.

# **REQUEST**

```
REQUEST BODY - application/json
{
    scopeUid* string    The scopeUid for which to export/import domain check ranges.
    filePath* string    The file path used for exporting/importing domain check ranges. The directory path specified in the filePath must already exist.
```

}

# **RESPONSE**

**STATUS CODE - 202**: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string
```

# 10.3 GET /ep/scopes/{scope-uid}/domain-check-details

#### Get domain check details

Get domain check details for a scope. Some filters can be applied.

# **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope, for which to retrieve the domain check details.

#### **OUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
useCase	enum ALLOWED: B2B, RBT	The use case for which to retrieve the domain check details. Possible values: B2B, RBT. If not provided, details are shown for B2B.
signalNames	array of string	The names of the signals for which to retrieve the domain check details. If not provided, the details for all signals are shown.
signalKinds	array of string ALLOWED: INPUT, OUTPUT, LOCAL, PARAMETER	The kinds of the signals for which to retrieve the domain check details. Possible values: INPUT, OUTPUT, LOCAL, PARAMETER. If not provided, the details will be shown for all kinds.
goalStates	array of string ALLOWED: COVERED, UNREACHABLE, UNKNOWN, ERROR, NOT_DEFINED	The status filter for domain check details. Possible values: COVERED, UNKNOWN, UNREACHABLE, ERROR. If not provided, the details will be shown for all status.

NAME	TYPE	DESCRIPTION
goalTypes	array of string ALLOWED: VALID, INVALID	The goal type filter for domain check details. Possible values: VALID, INVALID. If not provided, the details will be shown for all types.

#### RESPONSE

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
     name
                           string
                                       READ-ONLY
                                       The name of the signal for which domain check goals where created.
     kind
                           enum
                                       READ-ONLY
                                       ALLOWED: INPUT, OUTPUT, LOCAL, PARAMETER
                                       The kind of the signal for which domain check goals where created.
     p11
                           string
                                       PLL string of the domain check goal.
     range
                           string
                                       The range of the domain check goal.
     goalType
                           enum
                                       ALLOWED: VALID, INVALID
                                       The type of the domain check goal.
                                       ALLOWED: COVERED, UNREACHABLE, UNKNOWN, ERROR, NOT_DEFINED
     goalStatus
                           enum
                                       The status of the domain check goal.
     comment
                           string
                                       The comment of the domain check goal.
     covering Vectors [string] List of string vector names that cover the property.
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 10.4 GET /ep/scopes/{scope-uid}/domain-checks-results

# Get domain checks results

Get the domain checks results for a scope. Using the use case option will display the results for SVs and RBTest Cases if B2B is used or only for RBTest Cases if RBT option is used. Also, the results can be requested either only for the invalid goal types and for the valid ones, or for all goal types.

# **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope for which to get the domain checks results.

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
useCase	enum ALLOWED: B2B, RBT	The use case for which to retrieve the domain check results. Possible values: B2B, RBT.Can be empty, in which case the results are shown for B2B use case.
goalTypes	array of string ALLOWED: VALID, INVALID	The goal type for which to retrieve the domain check results. Possible values: VALID, INVALID.Can be empty, in which case the results are shown for all goal types.

#### **RESPONSE**

#### STATUS CODE - 200: OK

# **RESPONSE MODEL - application/json**

totalCountValid string **READ-ONLY** The total number of valid range goals. coveredCountValid string **READ-ONLY** The number of covered valid range goals. unreachableCountValid string **READ-ONLY** The number of unreachable valid range goals. errorCountValid string **READ-ONLY** The number of errorneous valid range goals. handledCountValid string **READ-ONLY** The number of handled valid range goals. unhandledCountValid string **READ-ONLY** The number of unhandled valid range goals. coveredPercValid string **READ-ONLY** The covered percentage for valid range goals. unreachablePercValid string **READ-ONLY** The unreachable percentage for valid range goals. errorPercValid string **READ-ONLY** The error percentage for valid range goals. handledPercValid string READ-ONLY The handled percentage for valid range goals. unhandledPercValid string **READ-ONLY** The unhandled percentage for valid range goals. totalCountInvalid string READ-ONLY The total number of invalid range goals. coveredCountInvalid string **READ-ONLY** The number of covered invalid range goals. unreachableCountInvalid string READ-ONLY The number of unreachable invalid range goals. errorCountInvalid string **READ-ONLY** The number of errorneous invalid range goals. handledCountInvalid string **READ-ONLY** The number of handled invalid range goals. unhandledCountInvalid string **READ-ONLY** The number of unhandled invalid range goals. coveredPercInvalid string **READ-ONLY** The covered percentage for invalid range goals. unreachablePercInvalid string **READ-ONLY** The unreachable percentage for invalid range goals. errorPercInvalid string **READ-ONLY** The error percentage for invalid range goals. handledPercInvalid string **READ-ONLY** The handled percentage for invalid range goals. unhandledPercInvalid string **READ-ONLY** The unhandled percentage for invalid range goals.

```
STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 10.5 POST /ep/domain-checks

## Import domain check ranges

Import domain check ranges on the given scopeUid.

# **REQUEST**

# **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string
```

# 10.6 POST /ep/domain-check-comments

#### Set domain check comments

Set the comments for the domain check ranges specified by the PLL of their corresponding domain check goal. To remove a comment for a given domain check goal, provide an empty string as a comment.

# **REQUEST**

```
REQUEST BODY - application/json
[{
    Array of object:
    pll* string The PLL of the domain check goal for which to set the comment.
    comment* string The comment to set on the domain check goal with the given PLL.
}]

RESPONSE

STATUS CODE - 200: OK

RESPONSE MODEL - text/plain
```

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 11. EXECUTION CONFIGS

# 11.1 GET /ep/execution-configs

# Get all execution configs

Get all execution configs available in the profile.

# **REQUEST**

No request parameters

# **RESPONSE**

```
STATUS CODE - 200: OK

RESPONSE MODEL - application/json
{
    execConfigNames [string] List of the available execution kinds
}

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain
string
```

# 12. EXECUTION RECORDS

Handle execution records.

# 12.1 GET /ep/execution-records/{execution-record-uid}

#### Get an execution record

Get the requested execution record by UID.

# **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*execution-record-uid	string	Execution record UID

# **RESPONSE**

```
STATUS CODE - 200: OK
```

```
RESPONSE MODEL - application/json
```

status enum ALLOWED:OK, WARNING, ERROR

The status of execution record. Possible options: OK, WARNING, or ERROR.

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

}]

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string

# 12.2 DELETE /ep/execution-records/{execution-record-uid}

#### Delete an execution record

Deletes the specified execution record.

#### **REQUEST**

### PATH PARAMETERS

****	TVDE	DECODIDETION
NAME	ITPE	DESCRIPTION

NAME	TYPE	DESCRIPTION
*execution-record-uid	string	The UID of the execution record to be deleted.

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 406: Not acceptable
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

# 12.3 POST /ep/execution-records-export

### **Export execution records**

<b>LONG RUNNING TASK</b> Export single or multiple execution record(s) by providing the list of the execution records which will be exported, the export directory, the export format and a list of additional options for export.

# **REQUEST**

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

**RESPONSE MODEL - application/json** 

```
    jobID string READ-ONLY
        The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

# 12.4 GET /ep/execution-records

#### Get all execution records

Get all execution records available in the profile.

# **REQUEST**

No request parameters

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [ {
  Array of object:
     uid
                            string READ-ONLY
                                       The unique identifier (UID) of this object.
     executionConfig* string
                                       The execution config name
     name*
                            string
                                       The execution record name
                                       ALLOWED: OK, WARNING, ERROR
     status
                            enum
                                       The status of execution record. Possible options: OK, WARNING, or ERROR.
     folderName*
                            string
                                       The folder name on which this execution record can be found.
     length*
                            integer The length of execution record source
     scopeName*
                            string
                                       The scope name of execution record
     sourceName*
                            string
                                       The name of execution record source
  }]
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

# 12.5 POST /ep/execution-records

#### Import execution records

Import multiple execution records by providing the path for each file.

# **REQUEST**

```
REQUEST BODY - application/json
                                       [string]
   paths*
                                                     The path to all execution record files you'd like to import. Supported formats are MDF,
                                                      MF4 and CSV.
   kind*
                                       string
                                                      The simulation kind that was used for creating the execution records from the given files.
                                                      Possible values: TL MIL, SL MIL, SIL, PIL or any external simulation kind. If the user
                                                      defined folder option is not specified, the simulation kind will define the default folder
                                                      where the execution records will be imported.
   folderName
                                                      User defined execution records folder name. <b color="red">If used, folderUID can not be
                                       string
                                                      used at the same time. </b>
   folderUID
                                       string
                                                      Existing user defined folder uid to import records. <b color="red">If used, folderName can
                                                      not be used at the same time. </b>
   referenceExternalFile boolean
                                                      Relevant only for MF4 and CSV import format. Whether to only reference the external file
                                                     rather than importing the execution record in the profile. This would be recommended for
                                                      very big execution records. Default is 'false'
   csvDelimiter
                                       enum
                                                      ALLOWED: SEMICOLON, COMMA, COLON, PIPE
                                                      Relevant only for CSV import format. It can have one of the following values:
                                                      "SEMICOLON", "COMMA", "COLON", "PIPE". Default value is "SEMICOLON".
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 12.6 GET /ep/folders/{folder-uid}/execution-records

#### Get all execution records for a folder

Get all the execution records for a given folder UID.

# **REQUEST**

#### PATH PARAMETERS

NAME T	YPE	DESCRIPTION
*folder-uid s	string	The folder UID from which to retrieve all execution records.

## **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [{
  Array of object:
     uid
                                       READ-ONLY
                            string
                                       The unique identifier (UID) of this object.
     executionConfig* string
                                       The execution config name
     name*
                            string
                                       The execution record name
     status
                                       ALLOWED: OK, WARNING, ERROR
                            enum
                                       The status of execution record. Possible options: OK, WARNING, or ERROR.
     folderName*
                            string
                                       The folder name on which this execution record can be found.
     length*
                            integer The length of execution record source
     scopeName*
                            string
                                       The scope name of execution record
     sourceName*
                            string
                                       The name of execution record source
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 12.7 PUT /ep/folders/{folder-uid}/execution-records

#### Move a list of execution records to a folder

Moves the list of execution records to the requested user-defined execution record folder.

# **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*folder-uid	string	The UID of user-defined execution record folder.

```
REQUEST BODY - application/json
{
    UIDs* [string] UIDs of execution records to be moved.}
```

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

```
RESPONSE MODEL - application/json
```

[{

Array of object:

uid string READ-ONLY

The unique identifier (UID) of this object.

```
ALLOWED: OK, WARNING, ERROR
     status
                            enum
                                       The status of execution record. Possible options: OK, WARNING, or ERROR.
     folderName*
                            string
                                       The folder name on which this execution record can be found.
     length*
                            integer The length of execution record source
     scopeName*
                                       The scope name of execution record
                            string
     sourceName*
                            string
                                       The name of execution record source
  }]
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

# 12.8 GET /ep/scopes/{scope-uid}/execution-records

# Get all execution records for a scope

Get all the execution records for the given scope UID.

# **REQUEST**

# PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The scope UID from which to retrieve all execution records.

The name of execution record source

#### **RESPONSE**

[{

}]

```
STATUS CODE - 200: OK
```

#### **RESPONSE MODEL - application/json**

```
Array of object:
   uid
                           string
                                       READ-ONLY
                                       The unique identifier (UID) of this object.
   executionConfig* string
                                       The execution config name
                                       The execution record name
   name*
                           string
   status
                           enum
                                       ALLOWED: OK, WARNING, ERROR
                                       The status of execution record. Possible options: OK, WARNING, or ERROR.
   folderName*
                           string
                                       The folder name on which this execution record can be found.
   length*
                           integer The length of execution record source
   scopeName*
                           string
                                      The scope name of execution record
```

string

STATUS CODE - 404: Not found

sourceName\*

RESPONSE MODEL - text/plain

string

# STATUS CODE - 500: Internal server error

# **RESPONSE MODEL - text/plain**

string

# 13. FOLDERS

Handle folders.

# 13.1 GET /ep/folders

#### Get a list of folders

Get a list of folders by name and/or kind.

# **REQUEST**

# **QUERY PARAMETERS**

NAME	ТҮРЕ	DESCRIPTION
name	string	Enter the name of the folder you would like to search for. If null, then all folders will be returned.
kind	enum ALLOWED: RB_TEST_CASE, EXECUTION_RECORD, STIMULI_VECTOR	Enter the folder kind. If null, then all folder kinds will be returned.

# **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [ {
  Array of object:
     uid
                  string READ-ONLY
                              The unique identifier (UID) of this object.
     name*
                string The name of the folder.
     kind*
                   string The folder kind.
     isDefault* boolean Set to 'true' if it is a default folder.
  }]
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 13.2 POST /ep/folders

#### Create a folder

Add a folder by providing a folder kind and optionally a folder name. Note that a new UID will be assigned.

# **REQUEST**

```
REQUEST BODY - application/json
     folderKind* string The folder kind. Possible: "RB_TEST_CASE", "EXECUTION_RECORD", "STIMULI_VECTOR"
     folderName string The folder name. This parameter is optional
RESPONSE
  STATUS CODE - 201: Created
    RESPONSE MODEL - application/json
       uid
                     string READ-ONLY
                                The unique identifier (UID) of this object.
       name*
                      string
                                The name of the folder.
       kind*
                      string
                                The folder kind.
       isDefault* boolean Set to 'true' if it is a default folder.
  STATUS CODE - 400: Bad request
    RESPONSE MODEL - text/plain
  string
  STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
  string
```

# 13.3 DELETE /ep/folders/{folder-uid}

### Delete a folder

Delete a folder by providing its UID.

# **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*folder-ui	d string	Enter the UID of the folder you would like to delete.

#### **RESPONSE**

```
STATUS CODE - 200: OK

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain
```

# 14. FORMAL SPECIFICATION REPORTS

Formal Specification Reports

# 14.1 GET /ep/formal-specification-reports

#### Get all reports

Get all formal specification reports from the profile.

#### **REQUEST**

No request parameters

#### **RESPONSE**

# 14.2 POST /ep/formal-specification-reports

#### Create a formal specification report

Create a formal specification report on a list of formal specification UID's.

# **REQUEST**

```
REQUEST BODY - application/json
{
   UIDs* [string] List with unique identifiers of the objects.
}
```

### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

STATUS CODE - 400: Bad request

# **RESPONSE MODEL - text/plain**

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 15. FORMAL SPECIFICATIONS

Handle Formal Specifications.

# 15.1 GET /ep/environmental-assumptions

#### Get all environmental assumptions

Get all environmental assumptions present on active profile, or from the specified scope-uid.

# **REQUEST**

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
scope-uid	string	The UID of scope from which to get the environmental assumptions.

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [ {
  Array of object:
     uid
                       string
                                    READ-ONLY
                                    The unique identifier (UID) of this object.
     name*
                       string
                                    The name of the environmental assumption.
     description* string
                                    The description of the environmental assumption.
     scopeUID*
                       string
                                    The unique identifier (UID) of the scope this object belongs to.
     draft
                       string
                                    States whether or not the FormalRequirement is in Draft-Mode.
     errors
                        [string] List of errors
  }]
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 15.2 GET /ep/formal-requirements

# Get all formal requirements

Get all formal requirements from the profile, or from the specified scope-uid.

# **REQUEST**

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION	
scope-uid string		The UID of scope from which to get the formal requirements.	

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [ {
  Array of object:
     uid
                                    READ-ONLY
                       string
                                    The unique identifier (UID) of this object.
     name*
                       string
                                    The name of the formal requirement.
     description* string
                                    The description of the formal requirement.
     scopeUID*
                       string
                                    The unique identifier (UID) of the scope this object belongs to.
     draft
                       string
                                    States whether or not the FormalRequirement is in Draft-Mode.
     errors
                        [string] List of errors
  }]
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 15.3 GET /ep/formal-requirements/{formal-requirement-uid}/environmental-assumptions

#### Get all environmental assumptions from a formal requirement

Use this command to retrieve the environmental assumptions from a formal requirement.

# **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*formal-requirement- uid	string	The uid of the formal requirement for which all environmental assumptions should be returned.

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

# RESPONSE MODEL - application/json

```
[{
Array of object:
   uid
                       string
                                     READ-ONLY
                                     The unique identifier (UID) of this object.
   name*
                       string
                                     The name of the environmental assumption.
   description* string
                                     The description of the environmental assumption.
   scopeUID*
                                     The unique identifier (UID) of the scope this object belongs to.
                       string
   draft
                       string
                                     States whether or not the FormalRequirement is in Draft-Mode.
   errors
                       [string] List of errors
}]
```

STATUS CODE - 400: Bad request

```
RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
RESPONSE MODEL - text/plain
string
```

# 15.4 POST /ep/specifications-export

#### **Export a SPEC file**

<b>Long running task</b> Exports the given formal specifications belonging to the same scope to the specified SPEC file.

#### **REQUEST**

#### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
    string
```

# 15.5 POST /ep/specifications-import

# Import a SPEC file

Imports formal specifications from the specified SPEC file.<br/>b>Long running task</b> Specify artifact existing policy, one of EXTEND\_NAME, OVERWRITE, or SKIP. By default it will be used 'EXTEND\_NAME'.

#### **REQUEST**

```
REQUEST BODY - application/json

{
    specPath* string scopeId string scopeId string by the given SPEC file. Should have spec extension.

The scopeId to use, when scope definition in SPEC file is invalid. This can happed for two reasons, the first is that in the SPEC file, the component(scope) name is invalid and can not be found in the opened profile, or when the given component(scope) name in the SPEC file is not unique within current profile.e.g. a TL architecture scope name is unique to the one in the generated CCode.

The draft status setting for the formal requirements that will be imported. By default its value is false.

OptionParam enum ALLOWED:EXTEND_NAME, OVERWRITE, SKIP

The options of importing a SPEC file, when the artifacts already exists. If no value is provided, 'EXTEND_NAME' is used.

}
```

#### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 16. FORMAL TEST EXECUTION

Execute Formal Test.

# 16.1 POST /ep/execute-formal-test

#### **Execute formal tests**

<b>Long running task</b> Execute formal test for all not yet existing or outdated results.

# **REQUEST**

No request parameters

#### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 17. FORMAL TEST REPORTS

Create and get formal test reports.

# 17.1 POST /ep/formal-requirements/{formal-requirement-uid}/formal-test-reports

#### Create a report on a formal requirement

Create a formal test report on a formal requirement for the given execution configurations.

# **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*formal-requirement-uid	string	The formal requirement UID for which the formal test report is created.

# **RESPONSE**

```
RESPONSE MODEL - application/json
     jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 17.2 POST /ep/formal-requirements/formal-test-reports

# Create a report on a list of formal requirements

Create a formal test report on on a list of formal requirements for the given execution configurations.

# **REQUEST**

# **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 17.3 POST /ep/requirements-sources/{requirements-source-uid}/formal-test-reports

#### Create a report on a requirements source

Create a formal test report on a requirements source for the given execution configurations.

#### **REOUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*requirements-source-uid	string	The requirements source UID for which the formal test report is created.

```
{
    executionConfigNames* [string] The comma separated list of execution configurations for which the Formal Test report shall
    be created. It can include values like "TL MIL", "SIL" etc. Please keep the specified format
    when you want to introduce a value.
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
     jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 17.4 POST /ep/requirements-sources/formal-test-reports

#### Create a report on a list of requirements sources

Create a formal test report on on a list of requirements sources for the given execution configurations.

#### REQUEST

#### **RESPONSE**

```
RESPONSE MODEL - application/json

{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

# 17.5 POST /ep/scopes/{scope-uid}/formal-test-reports

#### Create a report on a scope

Create a formal test report on a scope for the given execution configurations.

# **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The scope UID for which the formal test report is created.

```
REQUEST BODY - application/json
{
    executionConfigNames* [string] The comma separated list of execution configurations for which the Formal Test report shall be created. It can include values like "TL MIL", "SIL" etc. Please keep the specified format when you want to introduce a value.
}
```

#### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}
STATUS CODE - 400: Bad request
RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
```

```
RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 17.6 POST /ep/scopes/formal-test-reports

#### Create a report for a list of scopes

Create a formal test report on a list of scopes for the given execution configurations.

#### **REQUEST**

# **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 17.7 GET /ep/formal-test-reports

# Get all reports

Retrieve all the Formal Test reports from the profile.

# **REQUEST**

No request parameters

# **RESPONSE**

# 18. FORMAL VERIFICATION REPORTS

Create Formal Verification reports.

# 18.1 POST /ep/scopes/{scope-uid}/formal-verification-reports

#### Create a formal verification report on given scopeUid.

Create a formal verification report on given scope-uid which is found on this active profile. If multiple architectures for report creation are preset, the architecture-uid query parameter must be specified.

#### **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION	
*scope-ui	d string	The UID of the scope.	

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
architecture- uid	string	The UID of the architecture on which the report to be created. br>lf there are multiple valid architectures, but no architecture is specified, the C-Code architecture is used as a default.

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
     jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 18.2 GET /ep/formal-verification-reports

# Get all reports

Get all formal verification reports from the profile.

# **REQUEST**

No request parameters

#### **RESPONSE**

# 19. INPUT RESTRICTIONS

#### 19.1 POST /ep/input-restrictions-export

#### **Export input restrictions**

Export input restrictions to a file

#### **REQUEST**

```
REQUEST BODY - application/json
{
   filePath* string The file containing input restrictions.
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
    string
```

# 19.2 POST /ep/input-restrictions-import

#### Import input restrictions

Import input restrictions from a file

#### **REQUEST**

```
REQUEST BODY - application/json
{
   filePath* string The file containing input restrictions.
}
```

#### **RESPONSE**

STATUS CODE - 202: Long running operation started. The status of the operation can be reviewed by using the <a

href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json

{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 20. INTERFACE REPORTS

Handle interface reports.

# 20.1 POST /ep/scopes/{scope-uid}/interface-reports

#### Create a report on a scope

Create an interface report on given scope. The interface report will use the interface of the architecture of the provided scope.

#### **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*scope- uid	string	The scope on which the interface report should be created. The interface report will use the interface of the architecture of the provide scope.

#### **RESPONSE**

```
STATUS CODE - 201: Created
  RESPONSE MODEL - application/json
     uid
                   string READ-ONLY
                            The unique identifier (UID) of this object.
     reportName string Name of the report.
     reportType string Type of the report.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 20.2 GET /ep/interface-reports

#### Get all reports

Retrieve all interface reports from the profile.

#### **REQUEST**

No request parameters

#### **RESPONSE**

# STATUS CODE - 200: OK

# 21. MATLAB SCRIPT EXECUTION

Execute a MATLAB script.

# 21.1 POST /ep/execute-long-matlab-script

#### **Execute long-running MATLAB script**

Execute a long-running MATLAB script using the given parameters. Should be used when the time it takes for the script to end is longer than the request timeout of your REST client. Otherwise, for ease of use, the <b>Execute a short-running MATLAB script</b> method should be utilized.

#### **REQUEST**

#### **RESPONSE**

STATUS CODE - 202: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}
STATUS CODE - 400: Bad Request
RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 21.2 POST /ep/execute-short-matlab-script

#### **Execute short-running MATLAB script**

Execute a short-running MATLAB script using the given parameters. If the time it takes for the script to end is longer than the request timeout of your REST client, this request may fail. In this scenario the <br/>
b>Execute a long-running MATLAB script</br>
script</b>

# **REQUEST**

```
REQUEST BODY - application/json {
```

```
MATLAB script name.
      scriptName*
                                            string
     outArgs*
                                            integer
                                                                             Number of output arguments to return. Exception will be thrown
                                                                             if the given m-script returns less arguments.
      inArgs* [{
      Array of object: Parameters of the MATLAB script. The order in the list can be important, dependent of the executed m-script. The parameters will
      be received in the MATLAB script as follows: primitive types will be converted into their MATLAB equivalents, JSON arrays will be converted into
      cell arrays, JSON objects will be converted into MATLAB structures.
     }]
  }
RESPONSE
  STATUS CODE - 200: OK
    RESPONSE MODEL - application/json
     {
        outArgs [{
        Array of object: Output objects of the MATLAB script. The objects returned from the script must be primitive types, cell arrays or structures.
        }]
    }
  STATUS CODE - 400: Bad request
    RESPONSE MODEL - text/plain
  string
  STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
```

string

# 22. MESSAGES

Handle messages and message markers.

# 22.1 POST /ep/message-markers

#### Create a message marker

Use this command to create a new message marker at the current time. The response will contain the created message marker time stamp as java Timestamp

#### **REQUEST**

No request parameters

#### **RESPONSE**

# 22.2 GET /ep/message-markers/{marker-date}/messages

# Get a list of messages from a message marker

Search for messages created after a given message marker.

#### **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*marker-date	string	The message marker after which the messages should be queried from the Database.

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
search- string	string	Enter the beginning of the messages you would like to search for. If null, then all messages will be returned.
severity	enum ALLOWED: INFO, WARNING, ERROR, CRITICAL	Choose any severity you would like to search for. If null, then all severities will be returned.

#### **RESPONSE**

STATUS CODE - 200: OK

**RESPONSE MODEL - application/json** 

```
[{
  Array of object:
     uid
                  string READ-ONLY
                            The unique identifier (UID) of this object.
     date
                  string READ-ONLY
                            The creation-date of the message.
     message*
                  string The message itself.
     hint
                  string An additional hint.
                            ALLOWED: INFO, WARNING, ERROR, CRITICAL
     severity* enum
                            The severity of the message.
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 22.3 GET /ep/messages

#### Get a list of messages

Search for past messages up until a certain amount you can set yourself.

# **REQUEST**

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION	
search- string	string	Enter the beginning of the messages you would like to search for. If null, then all messages will be returned. Furthermore, you may use the following wildcards: '*' for any string '?' for any single character.	
severity	enum ALLOWED: INFO, WARNING, ERROR, CRITICAL	Choose any severity you would like to search for. If null, then all severities will be returned.	
max- messages	int32	The maximum number of messages returned. Cannot be > 1000. If > 1000, negative, or null, at most 1000 messages will be returned.	

#### **RESPONSE**

STATUS CODE - 200: OK

# **RESPONSE MODEL - application/json**

Array of object:

uid S

string READ-ONLY

The unique identifier (UID) of this object.

date string READ-ONLY

The creation-date of the message.

message\* string The message itself.
hint string An additional hint.

```
The severity of the message.

} ]

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
```

# 22.4 POST /ep/messages

#### Create a message

Add a message by providing a Message. Note that a new UID will be assigned.

### **REQUEST**

string

# **RESPONSE**

```
STATUS CODE - 201: Created
```

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 22.5 DELETE /ep/messages

#### Delete a list of messages

Search for past messages up until a certain amount you can set yourself and delete them.

#### **REQUEST**

### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
search- string	string	Enter the beginning of the messages you would like to search for. If null, then all messages will be deleted.

NAME	TYPE	DESCRIPTION	
severity	enum ALLOWED: INFO, WARNING, ERROR, CRITICAL	Choose any severity you would like to search for. If null, then all severities will be deleted.	
max- messages	int32	The max number of messages deleted. If negative or null, all messages will be deleted.	

#### **RESPONSE**

```
STATUS CODE - 200: OK

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain
string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

# 22.6 GET /ep/messages/{message-uid}

#### Get a message

Get the message with the provided UID.

#### **REQUEST**

### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*message-uid	string	The UID of the message to be returned.

#### **RESPONSE**

STATUS CODE - 404: Not found

#### RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

**RESPONSE MODEL - text/plain** 

string

# 22.7 DELETE /ep/messages/{message-uid}

#### Delete a message

Delete a message by providing its UID.

# **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*message-uid	string	Enter the UID of the message you would like to delete.

#### **RESPONSE**

STATUS CODE - 200: OK

STATUS CODE - 404: Not found

**RESPONSE MODEL - text/plain** 

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string

# 22.8 POST /ep/messages/message-report

# **Export messages**

Export all messages to the specified report file (in HTML format).

If a <a href='#post-/ep/message-markers'>Message Marker</a> is provided, all messages starting from the marker will be exported.

### **REQUEST**

# **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
*file- name	string	The path and file name of the message report file to create. Note: An existing file will be overwritten!
marker- date	string	If specified, only messages that were posted after this <a href="#post-/ep/message-markers">Message Marker</a> was created will be exported.

#### **RESPONSE**

STATUS CODE - 201: Exported Succesfully. Returns exported report location.

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 23. MODEL COVERAGE REPORTS

Creates RBT or B2B model coverage reports.

# 23.1 POST /ep/folders/{folder-uid}/model-coverage-reports

#### Create a report for a folder

<b>Long running task</b> Create RBT or B2B model coverage report for given folder.

#### **REQUEST**

# PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*folder-uid	string	The folder UID for which to create the model coverage report.

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 404: Not found
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 23.2 POST /ep/folders/model-coverage-reports

#### Create a report for a list of folders

<b>Long running task</b> Create RBT or B2B model coverage report for a list of folders. <br/>for list of folders. <br/>

#### **REQUEST**

```
REQUEST BODY - application/json
   type*
                                     enum
                                                    ALLOWED: RBT, B2B
                                                    Specifies the testing use-case for which the model coverage report should be
                                                    created.<br/>
Smust be 'B2B' or 'RBT' for Back-to-back testing or Requirement based test,
                                                   respectively.
   simulationKind*
                                     string
                                                   Specifies the simulation mode: 'SL MIL', 'TL MIL' or 'TL MIL (EV)'
   useShortCircuitLogic boolean
                                                    Specifies if short circuit logic should be used for Simulink blocks. <br/> <br/>br>The paramter is
                                                    optional. If not provided, the current setting from EP is used.
   folderUIDs*
                                     [string]
                                                   The comma separated list of folder UIDs for which the model coverage report shall be
                                                    created.
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
     jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 23.3 POST /ep/scopes/{scope-uid}/model-coverage-reports

#### Create a report for a scope

<b>Long running task</b> Create RBT or B2B model coverage report on given scope.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uio	string	The scope UID for which to create the model coverage report.

#### **RESPONSE**

**STATUS CODE - 202**: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
     jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 23.4 GET /ep/model-coverage-reports

#### Get a list of reports

Retrieve all model coverage reports of the specified testing use-case from the profile.

#### **REQUEST**

# **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
coverage-type	enum ALLOWED: RBT, B2B	The model coverage testing use-case.

# **RESPONSE**

# 24. PREFERENCES

Set and retrieve preferences.

# 24.1 GET /ep/preferences/{preference-name}

#### Get a preference

Get the preference with a given name. If the retrieved value is empty, the preference might have its default value.

### **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*preference-name	string	Enter the name of the preference that you want retrieved.

#### **RESPONSE**

```
STATUS CODE - 200: OK

RESPONSE MODEL - application/json

{
    preferenceName* string The name of the preference.
    preferenceValue* string The value of the preference.
}

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 24.2 PUT /ep/preferences

#### Set a list of preferences

Set new values for a list of given preferences. The preference name and new value must be provided for each of them.

# **REQUEST**

```
REQUEST BODY - application/json
[{
Array of object:

preferenceName* string The name of the preference.
preferenceValue* string The value of the preference.
}]
```

#### **RESPONSE**

```
STATUS CODE - 200: Preferences set

RESPONSE MODEL - application/json
```

```
messages [string]
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

# 25. PROFILES

Create and handle EP Profiles.

# 25.1 GET /ep/profiles

#### Get the active profile

Use this command to get the currently active profile.

#### **REQUEST**

No request parameters

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
     uid
            string
                        READ-ONLY
                        The unique identifier (UID) of this object.
     metadata* {
     The metadata containing all relevant info about the profile.
     profilePath {
        path string The location where the profile is stored.
     }
  }
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 25.2 PUT /ep/profiles

#### Save the profile

Use this command to save your active profile at a given location. Keep in mind to use only legal profile paths.

#### **REQUEST**

```
REQUEST BODY - application/json
{
   path string The location where the profile is stored.
}
```

#### **RESPONSE**

STATUS CODE - 201: Created

STATUS CODE - 400: Bad request

```
RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
RESPONSE MODEL - text/plain
```

# 25.3 POST /ep/profiles

#### Create a profile

string

Use this command to create a new empty profile. It won't contain a path, since it's not stored anywhere yet.

### **REQUEST**

#### **OUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
discardCurrentProfile	boolean	If 'true' the current profile is discarded and a new profile will be created. Otherwise a new profile will only be created when the current profile is not in a dirty state.Default is 'false'

#### **RESPONSE**

```
STATUS CODE - 201: Created
  RESPONSE MODEL - application/json
     uid string
                       READ-ONLY
                        The unique identifier (UID) of this object.
     metadata* {
     The metadata containing all relevant info about the profile.
     profilePath {
        path string The location where the profile is stored.
     }
  }
STATUS CODE - 428: Precondition Required
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 25.4 DELETE /ep/profiles

Discard a profile

Use this command to discard a profile, even if it is dirty. Changes will not be saved!

# **REQUEST**

No request parameters

#### **RESPONSE**

```
STATUS CODE - 200: OK

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string
```

# 25.5 GET /ep/profiles/{profile-path}

#### Open a profile

Use this command to open an existing profile. Specifiy the path to the profile with a name of your choice. Keep in mind to only use legal profile paths of already existing profiles.

### **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*profile-path	string	The path to the existing profile.

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
discardCurrentProfile	boolean	If 'true' the current profile is discarded and a new profile will be created. Otherwise a new profile will only be created when the current profile is not in a dirty state.Default is 'false'

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

STATUS CODE - 400: Bad request

# RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 428: Precondition Required

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 26. PROGRESS

Get the current status of long-running operations.

# 26.1 GET /ep/progress

#### Get the status of a long running operation

Get the status of a long running operation. If the operation is on-going, the current progress will be returned. If the operation is complete, the resulted object will be returned if there is one. An error will be returned if it occured during the long-running operation.

#### **REQUEST**

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
progress-id	string	The progress id. Can be retrieved by starting a long-running operation. If not specified then last long running operation result will be returned.

#### **RESPONSE**

STATUS CODE - 200: Operation is complete. No resulting object is returned.

```
RESPONSE MODEL - application/json
{
   message string
   progress integer
   result {
   }
}
```

STATUS CODE - 201: Operation is complete. Resulting object is returned as JSON.

```
RESPONSE MODEL - application/json
```

```
{
  message string
  progress integer
  result {
  }
}
```

STATUS CODE - 202: Operation is currently in progress

```
RESPONSE MODEL - application/json
```

```
{
  message string
  progress integer
  result {
  }
}
```

STATUS CODE - 400: Bad request

**RESPONSE MODEL - text/plain** 

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

# 27. PROJECT REPORTS

Create and retrieve project reports.

# 27.1 POST /ep/scopes/{scope-uid}/project-report

#### Create a project report

Create a project report.

# **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope for which the report shall be created.

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
template- name	string	The name of the template to use for report creation. This can be either the full path and filename of a template file to use, or the name of a template that was provided to EP by setting the template folder via the preference REPORT_TEMPLATE_FOLDER template is given, all available data will be included.

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json

{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 27.2 GET /ep/project-reports

#### Get all project reports

Retrieve all project reports from the profile.

# **REQUEST**

No request parameters

# **RESPONSE**

# 28. PROOFS

Create, verify and execute proofs.

# 28.1 GET /ep/proofs/{proofUID}

#### Get a proof based on given proofUID.

Get a proof based on given proofUID found on the active profile.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*proofUID	string	The UID of the proof.

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
     uid
                                                            string
                                                                                            READ-ONLY
                                                                                            The unique identifier (UID) of this object.
     name
                                                                                            Name of the proof.
                                                            string
     description
                                                            string
                                                                                            Description of the proof.
     formalRequirementName
                                                            string
                                                                                            Name of the formal requirement used by this
                                                                                            proof.
     proofSettings {
     The proof settings object. If not provided, default settings will be used.
         timeoutSeconds
                                               integer
                                                           The timeout in seconds, i.e. the limit on how long this proof execution may run.
                                                           Non-positive numbers (<= 0) are interpreted as infinity (i.e. no timeout has been
                                                           specified)
         memoryLimit
                                                           The memory limit in MB. Valid values are <= 0 (to denote infinity) or any positive
                                               integer
                                                           integer >= 500 to set a positive memory limit.
         maxNumberOfThreads
                                               integer
                                                           The maximum number of parallel threads for the proof execution. Valid values
                                                           are between 1 and available number of cores. <br/>
<br/>
specific possible to set this
                                                           parameter to a value of -1, which will compute the number of threads
                                                           automatically as half of the available number of cores.
         maximumSearchDepth
                                                           The maximum search depth, which is the number of unwindings of the main
                                               integer
                                                            function. Non-positive numbers (<= 0) are interpreted as infinity.
         maximumLoopUnroll
                                               integer
                                                           The maximum number of unwindings for internal loops. Non-positive numbers
                                                           (<= 0) are interpreted as infinity.
         resultExpectation
                                               enum
                                                           ALLOWED: FULFILLED, VIOLATED, UNKNOWN
                                                           The expected result for the proof's execution.
         engines [{
         Array of object: The engines of the proof execution.
                                     ALLOWED: SMIBMC, VIS, AUTOFXP, CBMC, ISAT
            name*
                         enum
                                      The name of the engine.
            enabled boolean Whether or not this engine should be considered. Default is true
         }]
         isAllowAssumption
                                               boolean Set to 'true', if assumption check is allowed.
         useLocalInputRestriction boolean Whether or not the proof uses local input restrictions.
      }
```

RESPONSE MODEL - text/plain

#### STATUS CODE - 500: Internal server error

#### RESPONSE MODEL - text/plain

string

# 28.2 PUT /ep/proofs/{proofUID}

#### Apply proof settings.

Apply proof settings on given proofUID.

#### **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*proofUID	string	The ID of the proof.

```
REQUEST BODY - application/json
```

The proof settings object. If not provided, default settings will be used.

```
timeoutSeconds
                                      integer The timeout in seconds, i.e. the limit on how long this proof execution may run. Non-
                                                   positive numbers (<= 0) are interpreted as infinity (i.e. no timeout has been specified).
memoryLimit
                                                   The memory limit in MB. Valid values are <= 0 (to denote infinity) or any positive integer
                                                   >= 500 to set a positive memory limit.
maxNumberOfThreads
                                                   The maximum number of parallel threads for the proof execution. Valid values are
                                      integer
                                                   between 1 and available number of cores. <br/> spr>lt is possible to set this parameter to a
                                                   value of -1, which will compute the number of threads automatically as half of the
                                                   available number of cores.
maximumSearchDepth
                                      integer
                                                   The maximum search depth, which is the number of unwindings of the main function.
                                                   Non-positive numbers (<= 0) are interpreted as infinity.
maximumLoopUnroll
                                      integer
                                                   The maximum number of unwindings for internal loops. Non-positive numbers (<= 0) are
                                                   interpreted as infinity.
resultExpectation
                                                   ALLOWED: FULFILLED, VIOLATED, UNKNOWN
                                      enum
                                                   The expected result for the proof's execution.
engines [{
Array of object: The engines of the proof execution.
                            ALLOWED: SMIBMC, VIS, AUTOFXP, CBMC, ISAT
                             The name of the engine
   enabled boolean Whether or not this engine should be considered. Default is true
```

boolean Set to 'true', if assumption check is allowed.

useLocalInputRestriction boolean Whether or not the proof uses local input restrictions.

#### **RESPONSE**

}

}]

```
STATUS CODE - 200: OK
STATUS CODE - 400: Bad request
 RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
 RESPONSE MODEL - text/plain
string
```

isAllowAssumption

#### **RESPONSE MODEL - text/plain**

string

# 28.3 POST /ep/proofs/{frUid}

#### Create a proof.

Create a proof based on Formal Requirement Uid.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*frUid	string	The UID of the formal requirement.

#### **RESPONSE**

```
STATUS CODE - 201: Created
  RESPONSE MODEL - application/json
     uid
                                                            string
                                                                                            READ-ONLY
                                                                                            The unique identifier (UID) of this object.
     name
                                                            string
                                                                                           Name of the proof.
     description
                                                            string
                                                                                           Description of the proof.
     formalRequirementName
                                                            string
                                                                                           Name of the formal requirement used by this
                                                                                            proof.
     proofSettings {
     The proof settings object. If not provided, default settings will be used.
         timeoutSeconds
                                               integer
                                                           The timeout in seconds, i.e. the limit on how long this proof execution may run.
                                                           Non-positive numbers (<= 0) are interpreted as infinity (i.e. no timeout has been
                                                           specified).
         memoryLimit
                                                           The memory limit in MB. Valid values are <= 0 (to denote infinity) or any positive
                                               integer
                                                           integer >= 500 to set a positive memory limit.
         maxNumberOfThreads
                                                           The maximum number of parallel threads for the proof execution. Valid values
                                               integer
                                                           are between 1 and available number of cores. <br/>br>lt is possible to set this
                                                           parameter to a value of -1, which will compute the number of threads
                                                           automatically as half of the available number of cores.
         maximumSearchDepth
                                                           The maximum search depth, which is the number of unwindings of the main
                                               integer
                                                           function. Non-positive numbers (<= 0) are interpreted as infinity.
         maximumLoopUnroll
                                                           The maximum number of unwindings for internal loops. Non-positive numbers
                                               integer
                                                           (<= 0) are interpreted as infinity.
         resultExpectation
                                                           ALLOWED: FULFILLED, VIOLATED, UNKNOWN
                                               enum
                                                           The expected result for the proof's execution.
         engines [{
         Array of object: The engines of the proof execution.
                                     ALLOWED: SMIBMC, VIS, AUTOFXP, CBMC, ISAT
            name*
                         enum
                                      The name of the engine.
            enabled boolean Whether or not this engine should be considered. Default is true
         }]
         isAllowAssumption
                                               boolean Set to 'true', if assumption check is allowed.
         useLocalInputRestriction boolean Whether or not the proof uses local input restrictions.
      }
  }
```

RESPONSE MODEL - text/plain

STATUS CODE - 500: Internal server error

#### RESPONSE MODEL - text/plain

string

# 28.4 POST /ep/proofs/{proofUID}/execute

#### Execute a proof.

Execute a proof based on the given proofUID. If multiple executable architecture are preset, the architecture-uid query parameter must be specified.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*proofUID	string	The UID of the proof.

#### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
architecture- uid	string	The UID of the architecture on which this proof to be executed. specified, the C-Code architecture is used as a default.

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
```

# 28.5 GET /ep/proofs

#### Get all proofs.

Get all proofs found on the active profile.

#### REQUEST

No request parameters

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

#### **RESPONSE MODEL - application/json**

Array of object:

string	READ-ONLY
	The unique identifier (UID) of this object.
string	Name of the proof.
string	Description of the proof.
string	Name of the formal requirement used by this proof.
	string string

### proofSettings {

The proof settings object. If not provided, default settings will be used.

```
timeoutSeconds
                                               integer The timeout in seconds, i.e. the limit on how long this proof execution may run.
                                                           Non-positive numbers (<= 0) are interpreted as infinity (i.e. no timeout has been
                                                           specified).
         memoryLimit
                                                           The memory limit in MB. Valid values are <= 0 (to denote infinity) or any positive
                                               integer
                                                           integer >= 500 to set a positive memory limit.
         maxNumberOfThreads
                                                           The maximum number of parallel threads for the proof execution. Valid values
                                               integer
                                                           are between 1 and available number of cores. <br/>br>lt is possible to set this
                                                           parameter to a value of -1, which will compute the number of threads
                                                           automatically as half of the available number of cores.
         maximumSearchDepth
                                               integer The maximum search depth, which is the number of unwindings of the main
                                                           function. Non-positive numbers (<= 0) are interpreted as infinity.
         maximumLoopUnroll
                                               integer The maximum number of unwindings for internal loops. Non-positive numbers
                                                           (<= 0) are interpreted as infinity.
         resultExpectation
                                                           ALLOWED: FULFILLED, VIOLATED, UNKNOWN
                                               enum
                                                           The expected result for the proof's execution.
         engines [{
         Array of object: The engines of the proof execution.
            name*
                                     ALLOWED: SMIBMC, VIS, AUTOFXP, CBMC, ISAT
                                      The name of the engine.
            enabled boolean Whether or not this engine should be considered. Default is true
         }]
         isAllowAssumption
                                               boolean Set to 'true', if assumption check is allowed.
         useLocalInputRestriction boolean Whether or not the proof uses local input restrictions.
STATUS CODE - 500: Internal server error
```

#### RESPONSE MODEL - text/plain

string

} }]

# 28.6 GET /ep/proofs/{proofUID}/detailed-proof-results

Get detailed proof results of a proof.

Get detailed proof results of a proof by providing a proofUID.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*proofUID	string	The UID of the proof.

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

```
RESPONSE MODEL - application/json
  [{
  Array of object:
     proofId
                                        string
                                                    The proof UID for which this result was generated.
     steps
                                        integer
                                                    The amount of steps after which the execution was terminated. -1 represents a step
                                                    number which has no useful meaning.
     architectureName
                                        string
                                                    The architecture name on which the result was executed.
     proofResult
                                        string
                                                    The proof result after the execution.
     terminationReason
                                        string
                                                    Termination reason of the proof execution.
     timeoutSeconds
                                        integer
                                                    The timeout in seconds, i.e. the limit on how long this proof execution may run. Non-
                                                    positive numbers (<= 0) are interpreted as infinity (i.e. no timeout has been specified).
     memoryLimit
                                                    The memory limit in MB. Valid values are -1 (to denote infinity) or any positive integer >=
                                        integer
                                                    500 to set a positive memory limit.
     maxNumberOfThreads
                                        integer
                                                   The maximum number of parallel proof execution threads. Valid values are between 1
                                                    and MAX_INT.
     maximumSearchDepth
                                                    The maximum search depth, which is the number of unwindings of the main function.
                                        integer
                                                    Non-positive numbers (<= 0) are interpreted as infinity.
     maximumLoopUnroll
                                        integer
                                                    The maximum number of unwindings for internal loops. Non-positive numbers (<= 0) are
                                                    interpreted as infinity.
     usedEngines
                                        [enum]
                                                    ALLOWED: SMIBMC, VIS, AUTOFXP, CBMC, ISAT
                                                    The engines used in the proof execution.
     isAllowAssumptionCheck boolean
                                                   Returns true if assumption check was allowed.
     inputRestrictions {
     A list with the used input restriction for this execution.
     expectedResult
                                                    ALLOWED: FULFILLED, VIOLATED, UNKNOWN
                                        enum
                                                    The expected result for the proof's execution.
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
```

string

STATUS CODE - 500: Internal server error

**RESPONSE MODEL - text/plain** 

string

# 29. REAL-TIME TESTING

Execute operations with Real-Time Testing observers such as export

# 29.1 POST /ep/rtt-observers-export

#### **Export RTT Observers**

<br/> <b>Long running task</b> Export RTT Observers at specified folder location, and select which formal requirements to contain the export.

### **REQUEST**

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# **30. REGRESSION TEST REPORTS**

Creates a Regression Test Report for a given Regression Test. Retrieves all existing Regression Test reports from the profile.

30.1 POST /ep/regression-tests/{regression-test-uid}/regression-test-reports

#### Create a report for a regression test

Creates a Regression Test Report on a regression test.

## **REQUEST**

#### **PATH PARAMETERS**

NAME TY	YPE	DESCRIPTION
*regression-test-uid s	string	The Regression test UID for which the Regression Report is created.

## **RESPONSE**

## 30.2 GET /ep/regression-test-reports

#### Get all reports

Retrieve all the Regression Test reports from the profile.

## **REQUEST**

No request parameters

## **RESPONSE**

```
STATUS CODE - 200: OK

RESPONSE MODEL - application/json
[ {
    Array of object:
```

```
uid string READ-ONLY
The unique identifier (UID) of this object.
reportName string Name of the report.
reportType string Type of the report.
}]

STATUS CODE - 500: Internal server error.
RESPONSE MODEL - text/plain
string
```

## 31. REGRESSION TESTS

Creates regression tests.

## 31.1 GET /ep/regression-tests/{regression-test-uid}

#### Get a test

Get the Regression Test with the provided UID.

#### **REQUEST**

#### PATH PARAMETERS

NAME TYP	PE	DESCRIPTION
*regression-test-uid str	ring	The UID of the Regression Test to be returned.

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
     uid
                               string
                                           READ-ONLY
                                           The unique identifier (UID) of this object.
     referenceMode
                               string
                                           The reference execution config type.
     comparisonMode
                               string
                                           The comparison execution config type.
     referenceFolderUIDs [string] Reference folder UIDs
     comparisonFolderUID string
                                           Comparison folder UID
     executionDate
                               string
                                           Execution Date
     verdictStatus
                               enum
                                           ALLOWED: PASSED, FAILED, ERROR, FAILED_ACCEPTED
                                            The verdict status
     verdictState
                                           ALLOWED: VALID, OUTDATED_TOLERANCE_UPDATE,
                               enum
                                            OUTDATED_MISSING_EXECUTIONS
                                           Verdict State
     failed
                               integer
                                           Number of failed comparisons.
     failedAccepted
                               integer
                                           Number of failed accepted comparisons.
     passed
                               integer
                                           Number of passed comparisons.
     error
                               integer
                                           Number of comparisons with error.
     total
                               integer
                                           Total number of comparisons
     comparisons [{
     Array of object: All comparisons.
        uid
                                              string READ-ONLY
                                                        The unique identifier (UID) of this object.
        name
                                              string The name of Test Case / Stimuli Vector used in Comparison.
        verdictStatus
                                                        ALLOWED: PASSED, FAILED, ERROR, FAILED_ACCEPTED
                                              enum
                                                        The verdict status
        referenceExecutionRecordUID
                                              string UID of reference execution record.
        comparisonExecutionRecordUID string UID of compared to execution record.
        comment
                                              string Added comment for Comparison.
     }]
     name
                               string
                                           The name of the RegresionTest Test.
```

STATUS CODE - 404: Not found

**RESPONSE MODEL - text/plain** 

```
string
```

STATUS CODE - 500: Internal server error.

## RESPONSE MODEL - text/plain

string

## 31.2 PATCH /ep/regression-tests/{regression-test-uid}

UID of the Comparison

#### Update verdict status for a comparison

comparisonUID\* string

Changes verdict status for a Comparison. If accept is true, the comparison verdict status is changed from 'failed' to 'failed (accepted)'. If accept is false, the comparison verdict status is changed from 'failed (accepted)' to 'failed'

## **REQUEST**

#### PATH PARAMETERS

```
*regression-test-uid string The Regression Test UID for which to change the Comparison verdict.

REQUEST BODY - application/json
```

boolean If accept is true, the comparison verdict status is changed from 'failed' to 'failed (accepted)'. If accept is false, the comparison verdict status is changed from 'failed (accepted)' to 'failed'

```
}
```

accept\*

**RESPONSE** 

```
STATUS CODE - 200: OK

RESPONSE MODEL - application/json

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

## 31.3 POST /ep/folders/{folder-uid}/regression-tests

#### Generate a test on a folder

<b>Long running task </b>Generates a Regression Test on a given folder UID for the specified comparison execution kind. Optionally, the folder where to save the simulated execution records can be provided. If this property is not provided, the execution records are not saved.

#### REQUEST

#### PATH PARAMETERS

NAME TYPE DESCRIPTION

\*folder-uid string The folder UID for which the Regression Test is generated.

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 31.4 POST /ep/folders/regression-tests

#### Generate a test on a list of folders

<br/> <b>Long running task </b>Generates a Regression Test on a given list of folder UIDs for the specified comparison execution kind. Optionally, the folder where to save the simulated execution records can be provided. If this property is not provided, the execution records are not saved.

## **REQUEST**

## **RESPONSE**

**STATUS CODE - 202**: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

## 31.5 GET /ep/regression-tests

#### Get all tests

Get all Regression Tests from active profile.

## **REQUEST**

No request parameters

## **RESPONSE**

#### STATUS CODE - 200: OK

#### **RESPONSE MODEL - application/json**

```
[ {
Array of object:
```

uid	string	READ-ONLY
		The unique identifier (UID) of this object.
referenceMode	string	The reference execution config type.
comparisonMode	string	The comparison execution config type.
referenceFolderUIDs	[string]	Reference folder UIDs
${\it comparison} Folder {\it UID}$	string	Comparison folder UID
executionDate	string	Execution Date
verdictStatus	enum	ALLOWED: PASSED, FAILED, ERROR, FAILED_ACCEPTED
		The verdict status
verdictState	enum	ALLOWED: VALID, OUTDATED_TOLERANCE_UPDATE,
		OUTDATED_MISSING_EXECUTIONS
		Verdict State
failed	integer	Number of failed comparisons.
failedAccepted	integer	Number of failed accepted comparisons.
passed	integer	Number of passed comparisons.
error	integer	Number of comparisons with error.

```
Total number of comparisons.
     total
                                integer
     comparisons [{
     Array of object: All comparisons.
        uid
                                               string READ-ONLY
                                                        The unique identifier (UID) of this object.
        name
                                               string The name of Test Case / Stimuli Vector used in Comparison.
        verdictStatus
                                                        ALLOWED: PASSED, FAILED, ERROR, FAILED_ACCEPTED
                                               enum
                                                        The verdict status
        referenceExecutionRecordUID
                                               string UID of reference execution record.
        comparisonExecutionRecordUID string UID of compared to execution record.
        comment
                                               string Added comment for Comparison.
     }]
     name
                                string
                                            The name of the RegresionTest Test.
  }]
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

## 32. REPORTS

Retrieve and export Reports.

## 32.1 GET /ep/reports/{report-uid}

#### Get a report

Get the report with the provided UID.

## **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*report-uid string		The UID of the report to be returned.

#### **RESPONSE**

## 32.2 POST /ep/reports/{report-uid}

## **Export a report**

Use this command export a report to a given location. The exported report corresponds to the given UID inside the command. New name can be set for file. If file exists, will be overwritten. Keep in mind to use only legal profile paths.

## **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*report-uid	string	The UID of the report to be returned.

```
REQUEST BODY - application/json
{
   exportPath* string Path to export report
```

```
RESPONSE

STATUS CODE - 201: Exported Successfully. Returns exported report location.

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string
```

string (Optional) New report name.

newName

# 33. REQUIREMENT-BASED TEST CASES

Handle requirement-based Test Cases.

## 33.1 GET /ep/test-cases-rbt/{testcase-uid}

#### Get a test case

Get a requirement-based Test Case by providing its UID.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*testcase-uid	string	The UID of the requirement-based Test Case to be returned.

## **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
     uid
                              string
                                          READ-ONLY
                                          The unique identifier (UID) of this object.
     name
                             string
                                          The name of the RBTestCase.
     description
                             string
                                          An optional description of the RBTestCase
     kind
                             string
                                          The datatype or kind of the RBTestCase. Usually "tc" or "csv".
     length
                             integer
                                          The length of the vector.
     draft
                             boolean
                                          States whether or not the RBTestCase is in Draft-Mode.
     lastModifiedDate string
                                          The date of the last modification to the RBTestCase
     folderUID
                             string
                                          The unique identifier of the folder the RBTestCase belongs to.
     scopeUID
                             string
                                           The unique identifier of the scope the RBTestCase belongs to.
     requirementUIDs
                             [string] The unique identifiers of the requirements belonging to the RBTestCase.
     additionalAttributes [{
     Array of object: The additional attributes of the RBTestCase.
        key
                 string Attribute key
        value string Attribute value
     }]
     externalLinks [{
     Array of object: The external links of the RBTestCase.
        testCaseSource string Test Case source
        link
                              string Link
     }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 33.2 DELETE /ep/test-cases-rbt/{testcase-uid}

#### Delete a test case

Delete a requirement-based Test Case by providing its UID.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*testcase-uid	string	The UID of the requirement-based Test Case to be deleted.

#### **RESPONSE**

```
STATUS CODE - 200: OK

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

## 33.3 POST /ep/test-cases-rbt-export

#### **Export test cases**

<b>Long running task</b> Export single or multiple requirement-based Test Case(s) by providing the list of the test cases which will be exported, the export directory, the export format and a list of additional options for export.

## **REQUEST**

```
REQUEST BODY - application/json
   UTDs*
                              [string]
                                           List with the UIDs of the elements which will be exported
   exportDirectory* string
                                            Directory where to export the elements
   exportFormat
                             enum
                                            ALLOWED:TC, EXCEL, CSV, JSON
                                            The format of the exported test cases. Default value is EXCEL.
   additionalOptions {
       csvDelimiter
                               enum
                                            ALLOWED: SEMICOLON, COMMA, COLON, PIPE
                                            Relevant only for CSV export format. It can have one of the following values: "SEMICOLON",
                                            "COMMA", "COLON", "PIPE". Default value is "SEMICOLON"
       singleFile
                               boolean
                                            Relevant only for CSV export format: false - each vector will be exported in it's own file; true - all
                                            vectors will be exported in same file. Default is 'false'
       architectureUid string
                                            Relevant only for Excel export format. It specifies the UID of the architecture on which the
                                            interfaces of the vectors will be exported. Default is the master architecture
                                            ALLOWED: EXTEND_NAME, OVERWRITE, SKIP
   overwritePolicy
                             enum
                                            Overwrite policy: allowed values (not case-sensitive) are: EXTEND_NAME, in which case if the
                                            exported file exists on disk, its name will be extended and the original file on disk will be kept,
                                            OVERWRITE, in which case the original file on disk is overwritten, if it exists. Default value is
                                            EXTEND NAME
}
```

#### **RESPONSE**

STATUS CODE - 202: Long running operation started. The status of the operation can be reviewed by using the <a

href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

## 33.4 GET /ep/test-cases-rbt

#### Get all test cases

Get all requirement-based Test Cases.

#### **REQUEST**

No request parameters

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

```
RESPONSE MODEL - application/json
```

```
Array of object:
   uid
                            string
                                          READ-ONLY
                                          The unique identifier (UID) of this object.
   name
                            string
                                         The name of the RBTestCase.
   description
                            string
                                         An optional description of the RBTestCase
   kind
                            string
                                          The datatype or kind of the RBTestCase. Usually "tc" or "csv".
   length
                            integer
                                         The length of the vector.
   draft
                            boolean
                                         States whether or not the RBTestCase is in Draft-Mode.
   lastModifiedDate string
                                          The date of the last modification to the RBTestCase
                                          The unique identifier of the folder the RBTestCase belongs to.
   folderUID
                            strina
   scopeUID
                                          The unique identifier of the scope the RBTestCase belongs to.
                            strina
   requirementUIDs
                            [string] The unique identifiers of the requirements belonging to the RBTestCase.
   additionalAttributes [{
   Array of object: The additional attributes of the RBTestCase.
               string Attribute key
      value string Attribute value
   }]
   externalLinks [{
   Array of object: The external links of the RBTestCase.
```

testCaseSource string Test Case source

```
link string Link
}]

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

## 33.5 PUT /ep/test-cases-rbt

## Import test cases

<b>LONG RUNNING TASK</b> Import multiple requirement-based Test Cases from external files and ALM tools.

## **REQUEST**

```
REQUEST BODY - application/json
{
   paths
                                           [string]
                                                                The paths to all test cases you would like to import.
   folderUID
                                           string
                                                                The UID of the folder you want to import into. If not specified Test Cases will
                                                                be imported in the default Test Cases folder.
   overwritePolicy
                                                                ALLOWED: EXTEND_NAME, OVERWRITE, SKIP
                                           enum
                                                                Decides what happens in case of duplicate names. Can be "EXTEND_NAME",
                                                                "OVERWRITE" or "SKIP". Default is "SKIP"
   draft
                                           boolean
                                                                Sets the Draft-Mode of the test cases. By default its value is false.
   csvDelimiter
                                           enum
                                                                ALLOWED:SEMICOLON, COMMA, COLON, PIPE
                                                                Relevant only for CSV export format. It can have one of the following values:
                                                                "SEMICOLON", "COMMA", "COLON", "PIPE". Default value is "SEMICOLON".
   importKind
                                           enum
                                                                ALLOWED:TC, EXCEL
                                                                The kind a file should be imported as. Possible values are: "TC", "EXCEL". "TC"
                                                                by default
   additionalAttributes
                                           [string]
                                                                A list of additional attribute ids. Only used when importing Test Cases from
                                                                Polarion.
   settings [{
   Array of object:
       key*
                  string For POLARION requirement kind, the following keys are mandatory: host, port, username, pwd, project_id,
                             workItemType_id, filter. The optional setting keys are: scope_uid, by default the top-level scope, linkedRegSrc_uid,
                             linkedRegRole_id.
       value* string Setting value
   }]
}
```

## **RESPONSE**

```
RESPONSE MODEL - application/json

{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden
```

#### RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

## 33.6 GET /ep/test-cases-rbt/polarion

## Get the Polarion™ configuration template

Get the configuration with default settings for importing Polarion test cases.

## **REQUEST**

No request parameters

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
                                              [string]
      paths
                                                                    The paths to all test cases you would like to import.
      folderUID
                                              string
                                                                    The UID of the folder you want to import into. If not specified Test Cases
                                                                    will be imported in the default Test Cases folder.
                                                                    ALLOWED: EXTEND_NAME, OVERWRITE, SKIP
      overwritePolicy
                                              enum
                                                                    Decides what happens in case of duplicate names. Can be "EXTEND_NAME", "OVERWRITE" or "SKIP". Default is "SKIP"
      draft
                                              boolean
                                                                    Sets the Draft-Mode of the test cases. By default its value is false.
      csvDelimiter
                                              enum
                                                                    ALLOWED: SEMICOLON, COMMA, COLON, PIPE
                                                                    Relevant only for CSV export format. It can have one of the following
                                                                    values: "SEMICOLON", "COMMA", "COLON", "PIPE". Default value is
                                                                    "SEMICOLON".
      importKind
                                              enum
                                                                    ALLOWED:TC, EXCEL
                                                                    The kind a file should be imported as. Possible values are: "TC", "EXCEL".
      additionalAttributes
                                              [string]
                                                                    A list of additional attribute ids. Only used when importing Test Cases from
                                                                    Polarion.
      settings [{
      Array of object:
                                For POLARION requirement kind, the following keys are mandatory: host, port, username, pwd, project_id,
         key*
                                workItemType_id, filter. The optional setting keys are: scope_uid, by default the top-level scope, linkedReqSrc_uid,
                                linkedRegRole_id.
         value* string Setting value
      }]
  }
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 33.7 GET /ep/folders/{folder-uid}/test-cases-rbt

#### Get a list of test cases from a folder

Get all requirement-based Test Cases from a certain Folder by providing its UID.

## **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION	
*folder-uid string		The UID of the Folder containing the requirement based Test Cases.	

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [ {
  Array of object:
     uid
                                           READ-ONLY
                              string
                                           The unique identifier (UID) of this object.
     name
                              string
                                           The name of the RBTestCase.
     description
                              string
                                           An optional description of the RBTestCase
     kind
                              string
                                           The datatype or kind of the RBTestCase. Usually "tc" or "csv".
     lenath
                              integer
                                           The length of the vector.
     draft
                              boolean
                                           States whether or not the RBTestCase is in Draft-Mode.
                                           The date of the last modification to the RBTestCase
     lastModifiedDate string
     folderUID
                              string
                                           The unique identifier of the folder the RBTestCase belongs to.
     scopeUID
                              string
                                           The unique identifier of the scope the RBTestCase belongs to.
                            [string] The unique identifiers of the requirements belonging to the RBTestCase.
     requirementUIDs
     additionalAttributes [{
     Array of object: The additional attributes of the RBTestCase.
                 string Attribute key
        value string Attribute value
     }]
     externalLinks [{
     Array of object: The external links of the RBTestCase.
        testCaseSource string Test Case source
                              string Link
        link
     }]
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 33.8 GET /ep/scopes/{scope-uid}/test-cases-rbt

#### Get a list of test cases from a scope

Get all requirement-based Test Cases from a certain Scope by providing its UID.

## **REQUEST**

## PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the Scope containing the requirement based Test Cases.

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [ {
  Array of object:
     uid
                              string
                                           READ-ONLY
                                           The unique identifier (UID) of this object.
     name
                                           The name of the RBTestCase.
                              string
     description
                              string
                                           An optional description of the RBTestCase
     kind
                              string
                                           The datatype or kind of the RBTestCase. Usually "tc" or "csv".
     length
                              integer
                                           The length of the vector.
     draft
                              boolean
                                           States whether or not the RBTestCase is in Draft-Mode.
     lastModifiedDate string
                                           The date of the last modification to the RBTestCase
     folderUID
                              string
                                           The unique identifier of the folder the RBTestCase belongs to.
     scopeUID
                              string
                                           The unique identifier of the scope the RBTestCase belongs to.
     requirementUIDs
                              [string]
                                           The unique identifiers of the requirements belonging to the RBTestCase.
     additionalAttributes [{
     Array of object: The additional attributes of the RBTestCase.
                 string Attribute key
        value string Attribute value
     }]
     externalLinks [{
     Array of object: The external links of the RBTestCase.
        testCaseSource string Test Case source
        link
                              string Link
     }]
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
```

#### OTATOO GODE GOO. Internal server error

#### RESPONSE MODEL - text/plain

string

## 33.9 POST /ep/synchronize-rbt-test-cases

## Synchronize test cases with ALM Tools

<b>Long running task</b> Synchronize/Export Requirement-based Test Case(s) to ALM Tools by providing the list of the test cases which will be synchronized/exported, and a list of additional settings when exporting test cases that don't exist in the ALM tool.

## **REQUEST**

```
Array of object:
```

## **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
    string
```

## 33.10 GET /ep/requirements/{requirement-uid}/test-cases-rbt

## Get a list of test cases linked to a requirement

Use this command to retrieve the test cases linked to a given requirement uid.

## **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*requirement-uid	string	The uid of the requirement for which all linked test cases should be returned.

## **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION	
only- indirect- testcases	boolean	The flag used to specify whether to retrieve only test cases which are indirectly linked to a given requirement. This flag has an effect only on non-leaves requirements. If no value is specified, this flag will be set to false.	

## **RESPONSE**

```
RESPONSE MODEL - application/json
  [ {
  Array of object:
     uid
                             string
                                          READ-ONLY
                                          The unique identifier (UID) of this object.
     name
                             string
                                          The name of the RBTestCase.
     description
                             string
                                          An optional description of the RBTestCase
     kind
                             string
                                          The datatype or kind of the RBTestCase. Usually "tc" or "csv".
     length
                             integer
                                          The length of the vector.
     draft
                             boolean
                                          States whether or not the RBTestCase is in Draft-Mode.
     lastModifiedDate string
                                          The date of the last modification to the RBTestCase
     folderUID
                             string
                                          The unique identifier of the folder the RBTestCase belongs to.
     scopeUID
                             string
                                          The unique identifier of the scope the RBTestCase belongs to
     requirementUIDs
                             [string] The unique identifiers of the requirements belonging to the RBTestCase.
     additionalAttributes [{
     Array of object: The additional attributes of the RBTestCase.
                 string Attribute key
        key
        value string Attribute value
     externalLinks [{
     Array of object: The external links of the RBTestCase.
        testCaseSource string Test Case source
        link
                              string Link
     }]
  }]
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

## 33.11 PUT /ep/requirements/test-cases-rbt

#### Unlink requirements from test cases

Use this command to unlink requirements from test cases. Only their uids must be specified.

## **REQUEST**

```
REQUEST BODY - application/json
{
    requirementUIDs* [string] The uids of the requirements that need to be linked to test cases.
    testCaseUIDs* [string] The uids of the test cases that need to be linked to the requirements.
}
```

#### **RESPONSE**

```
STATUS CODE - 200: Requirements unlinked from test cases.

STATUS CODE - 400: Bad request.

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string
```

## 33.12 POST /ep/requirements/test-cases-rbt

## Link requirements to test cases

Use this command to link requirements to test cases. Only their uids must be specified.

## **REQUEST**

```
REQUEST BODY - application/json
{
    requirementUIDs* [string] The uids of the requirements that need to be linked to test cases.
    testCaseUIDs* [string] The uids of the test cases that need to be linked to the requirements.
}

RESPONSE
```

```
STATUS CODE - 200: Requirements linked to test cases.

STATUS CODE - 400: Bad request.

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string
```

## 33.13 POST /ep/formal-requirements/test-cases-rbt

#### Generate test cases based on formal requirements

<b>Long running task</b> Generate test cases based on formal requirements using a specific configuration.

## **REQUEST**

```
REQUEST BODY - application/json
   formalRequirements*
                                                [string] The formal requirements for which the coverage will be generated.
   behaviour
                                                enum
                                                              ALLOWED: IMPLEMENTATION, FORMAL_REQUIREMENTS
                                                              Specifies if the vector generation shall be based on the behaviour of the
                                                              SUT or the behaviour specified via formal requirements.
                                                              'IMPLEMENTATION' (default, if profile contains SUT): Uses behaviour from
                                                              'FORMAL_REQUIREMENTS': Uses behaviour described in formal
                                                              requirements (see SurroundingFormalRequirements).
   architecture
                                                string
                                                              Architecture uid for which generation is performed.
                                                              (Only valid for behaviour: FORMAL_REQUIREMENTS).
   surroundingFormalRequirements [string]
                                                              Specifies the formal requirements that describe the behaviour as array.
                                                              (only valid for corresponding 'Behaviour' selection)
```

By default all formal requirements of the scope (see first parameter) are taken into account. restrictOutputBehaviour boolean Set whether or not values for outputs and locals should keep their values if these are not written by formal requirement (only valid for Behaviour: Formal Requirements). Default is 'true' coverageMetric enum ALLOWED: ONCE, LINEAR\_CONDITION\_COVERAGE, MULTIPLE\_CONDITION\_COVERAGE Specifies the type of coverage metric.<br/>
-Default is 'ONCE' ALLOWED: NONE, TRIGGER\_EVENT\_COVERAGE, coverageTarget enum TRIGGER\_CONDITION\_COVERAGE, TRIGGER EVENT CONDITION COVERAGE Specifies the type of coverage target. Allowed values depend on the selected 'coverageMetric' 'NONE' (default) for 'ONCE' coverageMetric, 'TRIGGER\_EVENT\_COVERAGE' (default), 'TRIGGER\_CONDITION\_COVERAGE', or 'TRIGGER\_EVENT\_CONDITION\_COVERAGE' (Trigger event/condition coverage) for LINEAR\_CONDITION\_COVERAGE or 'MULTIPLE\_CONDITION\_COVERAGE' coverageMetric onlyFulfillingTestCases boolean Specifies if only fulfilling test cases shall be considered. Default is 'true' memoryLimit string Defines the memory limit (MB), default: 'inf'. globalTimeout string Defines the global timeout (s), default 'inf'. timeoutPerGoal string Defines the timeout per goal (s), default 'inf'. searchDepth string Defines the search depth (steps), default 'inf'. loopUnroll string Defines the loop unroll, default 32. numberOfThreads integer Defines the maximum number of parallel proof execution threads. Valid values are between 1 and available number of cores. It is possible to set this parameter to a value of -1, which will compute the number of threads automatically as half of the available number of cores. <br/>br>Default is '1' initializationVectorUID string The UID of the RequirementBasedTestCase which shall be used to initialize the engine checkBoundaryCoverageGoals Specifies if boundary coverage goals shall be considered. Default is taken boolean from the preferences. relativeEpsilon Relative epsilon used to derive boundary coverage goals. Default is taken string from the preferences. minimumEpsilon string Minimum epsilon used to derive boundary coverage goals. Default is taken from the preferences.

## **RESPONSE**

}

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
```

# 34. REQUIREMENT-BASED TEST EXECUTION

Executes requirement-based Testing.

## 34.1 POST /ep/folders/{folder-uid}/test-execution-rbt

#### Execute all test cases from a folder

<b>Long running task </b>Executes a requirement-based Test on all Test Cases from a given folder for the specified execution kinds. Optionally, also the model coverage report can be generated or the test execution can be forced to not re-use any previous results.

## **REQUEST**

#### PATH PARAMETERS

forceExecute

NAME	TYPE	DESCRIPTION			
*folder-	uid string	The folder UID for which the requirement-based Test is executed.			
REQUEST B	ODY - applicatio	n/ison			
{	obi applicatio	11, 13011			
execCor	nfigNames*	[string	List of execution kinds (example: SIL, TL MIL, SL MIL, etc.). Not case-sensitive.		
generat	teModelCover	ageReport boolear	Specify (optional) if the model coverage report should be generated. Default		

boolean Specify (optional) if the test execution should be forced (all previous results will

be discarded). Default value is false.

## **RESPONSE**

}

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 34.2 POST /ep/folders/test-execution-rbt

#### Execute all test cases from a list of folders

<b>Long running task </b>Executes a requirement-based Test on all Test Cases from a given list of folders for the specified execution kinds. Optionally, also the model coverage report can be generated or the test execution can be forced to not re-use any previous results.

## **REQUEST**

```
REQUEST BODY - application/json
                                       [strina]
   UTDs*
                                                                               List with unique identifiers of the objects.
   data {
      execConfigNames*
                                                 [string] List of execution kinds (example: SIL, TL MIL, SL MIL, etc.). Not case-
                                                               sensitive.
      generateModelCoverageReport boolean
                                                               Specify (optional) if the model coverage report should be generated.
                                                               Default value is false.
      forceExecute
                                                 boolean
                                                               Specify (optional) if the test execution should be forced (all previous
                                                               results will be discarded). Default value is false.
   }
}
```

#### **RESPONSE**

**STATUS CODE - 202**: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

## 34.3 POST /ep/test-cases-rbt/{testcase-uid}/test-execution-rbt

#### Execute a test case

<b>Long running task </b>Executes a requirement-based Test on a requirement-based Test Case for the specified execution kinds. Optionally, also the test execution can be forced to not re-use any previous results.

#### **REQUEST**

#### PATH PARAMETERS

NAME TYPE DESCRIPTION

\*testcase-uid string The requirement-based Test Case UID for which the RBT is executed.

```
REQUEST BODY - application/json
{
    execConfigNames* [string] List of execution kinds (example: SIL, TL MIL, SL MIL, etc.).
    forceExecute boolean Specify (optional) if the test execution should be forced (all previous results will be discarded).
    Default value is false.
}
```

#### **RESPONSE**

**STATUS CODE - 202**: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 34.4 POST /ep/test-cases-rbt/test-execution-rbt

#### Execute a list of test cases

<b>Long running task </b>Executes a requirement-based Test on a list of requirement-based Test Cases for the specified execution kinds. Optionally, also the test execution can be forced to not re-use any previous results.

#### **REQUEST**

}

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
    string
```

# 34.5 POST /ep/requirements-sources/{requirements-source-uid}/test-execution-rbt

## Execute all test cases linked to a requirements source

<b>Long running task </b>Executes a requirement-based Test on all Test Cases linked to the requirements of the given requirements source for the specified execution kinds. Optionally, also the model coverage report can be generated or the test execution can be forced to not re-use any previous results.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*requirements-source-uid	string	The requirements source UID for which the RBT is executed.

#### **RESPONSE**

```
RESPONSE MODEL - application/json
     jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 34.6 POST /ep/requirements-sources/test-execution-rbt

#### Execute all test cases linked to a list of requirements sources

<b>Long running task </b>Executes a requirement-based Test on all Test Cases linked to the requirements of the given requirements sources for the specified execution kinds. Optionally, also the model coverage report can be generated or the test execution can be forced to not re-use any previous results.

## **REQUEST**

```
REQUEST BODY - application/json
{
   UIDs*
                                       [string]
                                                                              List with unique identifiers of the objects.
   data {
      execConfigNames*
                                                 [string]
                                                              List of execution kinds (example: SIL, TL MIL, SL MIL, etc.). Not case-
      generateModelCoverageReport boolean
                                                               Specify (optional) if the model coverage report should be generated.
                                                               Default value is false.
      forceExecute
                                                 boolean
                                                               Specify (optional) if the test execution should be forced (all previous
                                                               results will be discarded). Default value is false.
}
```

#### **RESPONSE**

```
RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

## 34.7 POST /ep/scopes/{scope-uid}/test-execution-rbt

#### Execute all test cases from a scope

<b>Long running task </b>Executes a requirement-based Test on all Test Cases from a given scope for the specified execution kinds. Optionally, also the model coverage report can be generated or the test execution can be forced to not re-use any previous results.

## **REQUEST**

## PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The scope UID for which the requirement-based Test is executed.

#### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}
STATUS CODE - 400: Bad Request
RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string
```

```
STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

## 34.8 POST /ep/scopes/test-execution-rbt

## Execute all test cases from a list of scopes

<b>Long running task </b>Executes a requirement-based Test on all Test Cases from a given list of scopes for the specified execution kinds. Optionally, also the model coverage report can be generated or the test execution can be forced to not re-use any previous results.

## **REQUEST**

```
REQUEST BODY - application/json
                                       [string]
   UIDs*
                                                                              List with unique identifiers of the objects.
   data {
      execConfigNames*
                                                 [string] List of execution kinds (example: SIL, TL MIL, SL MIL, etc.). Not case-
                                                               sensitive
      generateModelCoverageReport boolean
                                                               Specify (optional) if the model coverage report should be generated.
                                                               Default value is false.
      forceExecute
                                                 boolean
                                                               Specify (optional) if the test execution should be forced (all previous
                                                               results will be discarded). Default value is false.
}
```

#### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

# 35. REQUIREMENT-BASED TEST EXECUTION REPORTS

Creates requirement-based Test Execution Reports.

## 35.1 POST /ep/folders/{folder-uid}/test-execution-reports-rbt

#### Create a report on a folder

Create a requirement-based Test Execution Report on a given folder.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*folder-uid	string	The folder UID for which the Test Execution Report is created.

```
REQUEST BODY - application/json
{
    execConfigName* string Execution kind (example: SIL, TL MIL, SL MIL, etc.). Not case-sensitive.
}
```

## **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 35.2 POST /ep/folders/test-execution-reports-rbt

Create a report on a list of folders

Create a requirement-based Test Execution Report on a given list of folders.

## **REQUEST**

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 35.3 POST /ep/requirements-sources/{requirements-source-uid}/test-execution-reports-rbt

#### Create a report on a requirements source

Create a requirement-based Test Execution Report on a given requirements source.

## **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*requirements-source- uid	string	The requirements source UID for which the Test Execution Report is created.

```
REQUEST BODY - application/json {
```

```
execConfigName* string Execution kind (example: SIL, TL MIL, SL MIL, etc.). Not case-sensitive.
}
```

## **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 35.4 POST /ep/requirements-sources/test-execution-reports-rbt

## Create a report on a list of requirements sources

Create a requirement-based Test Execution Report on a given list of requirements sources.

#### **REQUEST**

#### **RESPONSE**

```
RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

## 35.5 POST /ep/scopes/{scope-uid}/test-execution-reports-rbt

#### Create a report on a scope

Create a requirement-based Test Execution Report on a given scope.

## **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The Scope UID for which the Test Execution Report is created.

```
REQUEST BODY - application/json
{
    execConfigName* string Execution kind (example: SIL, TL MIL, SL MIL, etc.). Not case-sensitive.
}
```

## **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}
STATUS CODE - 400: Bad request
RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string
```

```
STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

## 35.6 POST /ep/scopes/test-execution-reports-rbt

## Create a report on a list of scopes

Create a requirement-based Test Execution Report on a given list of scopes.

## **REQUEST**

## **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 35.7 GET /ep/test-execution-reports-rbt

Retrieve all the requirement-based Test Execution reports from the profile.

## **REQUEST**

No request parameters

## **RESPONSE**

# **36. REQUIREMENTS**

Retrieve Requirements, Linked Requirements, or Requirement Sources.

## 36.1 GET /ep/requirements-sources

#### Get all requirement sources

Get all requirement sources found on the opened profile.

#### **REQUEST**

No request parameters

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

#### **RESPONSE MODEL - application/json**

[{

Array of object:

kind\*

string

The kind of this requirement source. The kind identifies this source to be from a specific requirement management tool.

#### settings\* [{

Array of object: A list with requirement settings.For EXCEL requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, excel\_file\_path, projectName\_attr (or excel\_sheet\_name), excel\_id\_attr, excel\_start\_row, excel\_parent\_id.For DOORS requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, projectName\_attr, doors\_module\_qualifier, doors\_baseline\_major, doors\_baseline\_minor, doors\_baseline\_suffix.

```
key* string For EXCEL requirement kind, the following keys are mandatory: excel_file_path, projectName_attr, excel_id_attr. The optional setting keys are: excel_start_row, excel_parent_id. For DOORS requirement kind, the following keys are mandatory: projectName_attr, doors_module_qualifier. The optional setting keys are: doors_baseline_major, doors_baseline_minor, doors_baseline_suffix. For POLARION requirement kind, the following keys are mandatory: host, port, username, pwd, project_id. The optional setting key is: filter, by default empty string.
```

value\* string Setting value

}]

definedAdditionalAttributes
externalUUID\*

name\*

uid\*

string string string

[string]

A list with additional attributes.

The unique ID identifying the external

requirement source.

The requirement source name.

The universally unique identifier of this requirement source.

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

}]

## 36.2 GET /ep/requirements/{requirement-source-id}

#### Get all requirements of a requirement source

Get the requirements of the given requirement source id.

#### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*requirement-source-id	string	The UID of the requirement source.

#### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [ {
  Array of object:
      wid*
                                                       string
                                                                                          The universally unique identifier.
      identifier*
                                                       string
                                                                                          The requirement identifier (e.g. a chapter
                                                                                          number within DOORS).
      isRemoved
                                                       boolean
                                                                                          Value meaning whether this requirement has
                                                                                          been removed within the requirement
                                                                                          management tool.
      additionalAttributes {
      Map containing all additional attributes.
      }
      scopeId*
                                                       string
                                                                                          The scope id this requirement is directly linked
      description*
                                                       string
                                                                                          The requirement description.
      name*
                                                       string
                                                                                          The requirement name.
      dateOfLastUpdate*
                                                       string
                                                                                          The requirement last update date.
      requirementSource* {
         kind*
                                                                  string
                                                                                               The kind of this requirement source. The
                                                                                               kind identifies this source to be from a
                                                                                               specific requirement management tool.
         settings* [{
         Array of object: A list with requirement settings. For EXCEL requirement kind, the following keys can be: name_attr_value,
         desc_attr_value, additional_attr, modification_date, excel_file_path, projectName_attr (or excel_sheet_name), excel_id_attr,
         excel_start_row, excel_parent_id.For DOORS requirement kind, the following keys can be: name_attr_value, desc_attr_value,
         additional_attr, modification_date, projectName_attr, doors_module_qualifier, doors_baseline_major, doors_baseline_minor,
         doors_baseline_suffix.
             key*
                        string For EXCEL requirement kind, the following keys are mandatory: excel_file_path, projectName_attr,
                                   excel_id_attr. The optional setting keys are: excel_start_row, excel_parent_id. For DOORS requirement
                                   kind, the following keys are mandatory: projectName_attr, doors_module_qualifier. The optional setting
                                   keys are: doors_baseline_major, doors_baseline_minor, doors_baseline_suffix. For POLARION requirement
                                   kind, the following keys are mandatory: host, port, username, pwd, project_id. The optional setting key is:
                                   filter, by default empty string.
             value* string Setting value
         }]
         definedAdditionalAttributes
                                                                  [string]
                                                                                               A list with additional attributes.
         externalUUID*
                                                                   string
                                                                                               The unique ID identifying the external
                                                                                              requirement source.
         name*
                                                                  string
                                                                                               The requirement source name.
         uid*
                                                                  string
                                                                                               The universally unique identifier of this
                                                                                               requirement source.
      }
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

## 36.3 GET /ep/scopes/{scope-id}/linked-requirements

## Get all requirements for a scope

Get the linked requirements of this given scope id.

### **REQUEST**

#### PATH PARAMETERS

**RESPONSE MODEL - text/plain** 

NAME	TYPE	DESCRIPTION
*scope-id	string	The UID of the scope id.

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  Array of object:
      uid*
                                                        string
                                                                                          The universally unique identifier.
      identifier*
                                                        string
                                                                                          The requirement identifier (e.g. a chapter
                                                                                          number within DOORS).
      isRemoved
                                                        boolean
                                                                                          Value meaning whether this requirement has
                                                                                          been removed within the requirement
                                                                                          management tool.
      additionalAttributes {
      Map containing all additional attributes.
      scopeId*
                                                       string
                                                                                          The scope id this requirement is directly linked
      description*
                                                       string
                                                                                          The requirement description.
      name*
                                                        string
                                                                                          The requirement name.
      dateOfLastUpdate*
                                                        string
                                                                                          The requirement last update date.
      requirementSource* {
         kind*
                                                                   string
                                                                                               The kind of this requirement source. The
                                                                                               kind identifies this source to be from a
                                                                                               specific requirement management tool.
         settings* [{
         Array of object: A list with requirement settings. For EXCEL requirement kind, the following keys can be: name_attr_value,
         desc_attr_value, additional_attr, modification_date, excel_file_path, projectName_attr (or excel_sheet_name), excel_id_attr,
         excel_start_row, excel_parent_id.For DOORS requirement kind, the following keys can be: name_attr_value, desc_attr_value,
         additional_attr, modification_date, projectName_attr, doors_module_qualifier, doors_baseline_major, doors_baseline_minor,
         doors baseline suffix.
             key*
                        string For EXCEL requirement kind, the following keys are mandatory: excel_file_path, projectName_attr,
                                   excel_id_attr. The optional setting keys are: excel_start_row, excel_parent_id. For DOORS requirement
                                   kind, the following keys are mandatory: projectName_attr, doors_module_qualifier. The optional setting
                                   keys are: doors_baseline_major, doors_baseline_minor, doors_baseline_suffix. For POLARION requirement
                                   kind, the following keys are mandatory: host, port, username, pwd, project_id. The optional setting key is:
                                   filter, by default empty string.
             value* string Setting value
         }]
         definedAdditionalAttributes
                                                                   [string]
                                                                                               A list with additional attributes.
         externalUUID*
                                                                   string
                                                                                               The unique ID identifying the external
                                                                                               requirement source.
         name*
                                                                   string
                                                                                               The requirement source name.
         uid*
                                                                   string
                                                                                               The universally unique identifier of this
                                                                                               requirement source.
      }
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
```

# 37. REQUIREMENTS IMPORT

Import Requirements.

### 37.1 POST /ep/requirements-import

#### Import requirements

Import requirements by specifying the kind of requirements.

### **REQUEST**

```
REQUEST BODY - application/json
   kind*
                                                  enum
                                                                                ALLOWED: EXCEL, DOORS, POLARION
                                                                                The kind of imported requirements. Allowed types:
                                                                                EXCEL, DOORS and POLARION.
   nameAttribute*
                                                  string
                                                                                The name of imported requirements. Required for
                                                                                DOORS, EXCEL and POLARION import.
   descriptionAttribute
                                                  string
                                                                                The description of imported requirements.
                                                                                Required for DOORS and EXCEL import. Optional
                                                                                for Polarion, by default is 'Description'.
   additionalAttributes
                                                  [string]
                                                                                A list with additional attributes.
   settings* [{
```

Array of object: A list with requirement settings. For EXCEL requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, excel\_file\_path, projectName\_attr (or excel\_sheet\_name), excel\_id\_attr, excel\_start\_row, excel\_parent\_id. For DOORS requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, projectName\_attr, doors\_module\_qualifier, doors\_baseline\_major, doors\_baseline\_minor, doors\_baseline\_suffix.

```
key* string For EXCEL requirement kind, the following keys are mandatory: excel_file_path, projectName_attr, excel_id_attr.
The optional setting keys are: excel_start_row, excel_parent_id. For DOORS requirement kind, the following keys
are mandatory: projectName_attr, doors_module_qualifier. The optional setting keys are: doors_baseline_major,
doors_baseline_minor, doors_baseline_suffix. For POLARION requirement kind, the following keys are mandatory:
host, port, username, pwd, project_id. The optional setting key is: filter, by default empty string.

value* string Setting value
}]
```

#### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain
```

#### STATUS CODE - 500: Internal server error

### RESPONSE MODEL - text/plain

string

### 37.2 GET /ep/requirements-import/doors

### Get the DOORS™ configuration template

Get the configuration with default settings for importing Doors requirements.

### REQUEST

No request parameters

STATUS CODE - 200: OK

### **RESPONSE**

```
RESPONSE MODEL - application/json
```

kind\*

enum

string

string

ALLOWED: EXCEL, DOORS, POLARION

The kind of imported requirements. Allowed types: EXCEL, DOORS and POLARION.

The name of imported requirements. Required for DOORS, EXCEL and POLARION import.

The description of imported requirements.

Required for DOORS and EXCEL import. Optional for Polarion, by default is 'Description'.

A list with additional attributes.

additionalAttributes settings\* [{

descriptionAttribute

nameAttribute\*

[string]

Array of object: A list with requirement settings. For EXCEL requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, excel\_file\_path, projectName\_attr (or excel\_sheet\_name), excel\_id\_attr, excel\_start\_row, excel\_parent\_id.For DOORS requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, projectName\_attr, doors\_module\_qualifier, doors\_baseline\_major, doors\_baseline\_minor, doors\_baseline\_suffix.

```
kev*
```

String For EXCEL requirement kind, the following keys are mandatory: excel\_file\_path, projectName\_attr, excel\_id\_attr. The optional setting keys are: excel\_start\_row, excel\_parent\_id. For DOORS requirement kind, the following keys are mandatory: projectName\_attr, doors\_module\_qualifier. The optional setting keys are: doors\_baseline\_major, doors\_baseline\_minor, doors\_baseline\_suffix. For POLARION requirement kind, the following keys are mandatory: host, port, username, pwd, project\_id. The optional setting key is: filter, by default empty string.

value\* string Setting value }]

STATUS CODE - 500: Internal server error

**RESPONSE MODEL - text/plain** 

string

### 37.3 GET /ep/requirements-import/excel

#### Get the Excel™ configuration template

Get the configuration with default settings for importing Excel requirements.

### **REQUEST**

No request parameters

#### STATUS CODE - 200: OK

```
RESPONSE MODEL - application/json
```

kind\* enum ALLOWED: EXCEL, DOORS, POLARION

> The kind of imported requirements. Allowed types: EXCEL, DOORS and POLARION.

nameAttribute\* string The name of imported requirements. Required for

DOORS, EXCEL and POLARION import. descriptionAttribute The description of imported requirements. string

Required for DOORS and EXCEL import. Optional

for Polarion, by default is 'Description'.

additionalAttributes settinas\* [{

[string]

A list with additional attributes.

Array of object: A list with requirement settings. For EXCEL requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, excel\_file\_path, projectName\_attr (or excel\_sheet\_name), excel\_id\_attr, excel\_start\_row, excel\_parent\_id.For DOORS requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, projectName\_attr, doors\_module\_qualifier, doors\_baseline\_major, doors\_baseline\_minor, doors\_baseline\_suffix.

key\*

string For EXCEL requirement kind, the following keys are mandatory: excel\_file\_path, projectName\_attr, excel\_id\_attr. The optional setting keys are: excel\_start\_row, excel\_parent\_id. For DOORS requirement kind, the following keys are mandatory: projectName\_attr, doors\_module\_qualifier. The optional setting keys are: doors\_baseline\_major, doors\_baseline\_minor, doors\_baseline\_suffix. For POLARION requirement kind, the following keys are mandatory: host, port, username, pwd, project\_id. The optional setting key is: filter, by default empty string.

value\* string Setting value }] }

STATUS CODE - 500: Internal server error

**RESPONSE MODEL - text/plain** 

string

### 37.4 GET /ep/requirements-import/polarion

#### Get the Polarion™ configuration template

Get the configuration with default settings for importing Polarion requirements.

#### REQUEST

No request parameters

#### **RESPONSE**

### STATUS CODE - 200: OK

### RESPONSE MODEL - application/json

kind\* ALLOWED: EXCEL, DOORS, POLARION enum

The kind of imported requirements. Allowed

types: EXCEL, DOORS and POLARION.

nameAttribute\* string The name of imported requirements. Required for

DOORS, EXCEL and POLARION import.

descriptionAttribute The description of imported requirements. string

Required for DOORS and EXCEL import. Optional

for Polarion, by default is 'Description'.

additionalAttributes

[string]

A list with additional attributes.

settings\* [{

Array of object: A list with requirement settings. For EXCEL requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, excel\_file\_path, projectName\_attr (or excel\_sheet\_name), excel\_id\_attr, excel\_start\_row, excel\_parent\_id.For DOORS requirement kind, the following keys can be: name\_attr\_value, desc\_attr\_value, additional\_attr, modification\_date, projectName\_attr, doors\_module\_qualifier, doors\_baseline\_major, doors\_baseline\_minor, doors\_baseline\_suffix.

key\*

For EXCEL requirement kind, the following keys are mandatory: excel\_file\_path, projectName\_attr, excel\_id\_attr. The optional setting keys are: excel\_start\_row, excel\_parent\_id. For DOORS requirement kind, the following

keys are mandatory: projectName\_attr, doors\_module\_qualifier. The optional setting keys are: doors\_baseline\_major, doors\_baseline\_minor, doors\_baseline\_suffix. For POLARION requirement kind, the following keys are mandatory: host, port, username, pwd, project\_id. The optional setting key is: filter, by default empty string.

```
value* string Setting value
}]
}
```

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string

# 38. SCOPES

Handle Scopes.

### 38.1 GET /ep/scopes/{scope-uid}

#### Get a scope

Get a specific scope by providing its UID.

### **REQUEST**

### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope to be returned.

### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
     uid
                      string
                                 The unique identifier (UID) of this object.
     name
                      string
                                 The scope name.
                      boolean True if scope is a toplevel scope.
     topLevel
     kind
                                 ALLOWED:SUT, DUMMY, ENVIRONMENT, HIDDEN_INTERNAL, VIRTUAL
                      enum
                                 Scope kind.
     path
                      string
                                 Scope path.
     architecture string
                                 The corresponding architecture of the scope.
     sampleTime {
     The sample time of the scope.
                   string The unique identifier (UID) of this object.
        seconds string The sample time as a value given in seconds.
     }
  }
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
```

### 38.2 GET /ep/scopes

### Get a list of scopes

Get a list of scopes by a query which filters by path and top-level.

### **REQUEST**

string

#### **OUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
path	string	Enter the path of the scope you would like to search for. If null, then all scopes will be returned.
top-level	boolean	Specifies, if only top level scopes shall be returned. scopes will be returned. scopes will be returned. scopes will be returned, including the top level. scopes will be returned. scopes will be returned, including the top level. scopes will be returned. scopes
architecture- uid	string	Specifies from which architecture the scopes are being collected. If null, then the first imported architecture will be used.

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [{
  Array of object:
     uid
                                 The unique identifier (UID) of this object.
                      string
     name
                      string
                                 The scope name.
     topLevel
                      boolean True if scope is a toplevel scope.
     kind
                      enum
                                 ALLOWED:SUT, DUMMY, ENVIRONMENT, HIDDEN_INTERNAL, VIRTUAL
                                 Scope kind.
     path
                      string
                                 Scope path.
     architecture string
                                 The corresponding architecture of the scope.
     sampleTime {
     The sample time of the scope.
                   string The unique identifier (UID) of this object.
        seconds string The sample time as a value given in seconds.
     }
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# 39. SIGNALS

Handle signals' operations.

# 39.1 GET /ep/scopes/{scope-uid}/signals

### Get all signals from a scope

Get all signals from the given scope

### **REQUEST**

### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*scope-uid	string	The scope for which to get the signals.

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  [ {
  Array of object:
     uid
                   string READ-ONLY
                             The unique identifier (UID) of this object.
     identifier string READ-ONLY
                             The signal identifier.
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

# **40. STIMULI VECTORS**

Handle stimuli vectors.

### 40.1 GET /ep/stimuli-vectors/{stimuli-vector-uid}

#### Get a stimuli vector

Get a specific stimuli vector by UID.

### **REQUEST**

### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*stimuli-vector-uid	string	The UID of the stimuli vector to be returned.

### **RESPONSE**

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
     uid
                   string
                              READ-ONLY
                              The unique identifier (UID) of this object.
     name
                   string
                              The name of the StimuliVector.
     length
                   integer The length of the vector.
     folderUID string
                              The unique identifier of the folder the StimuliVector belongs to
     scopeUID string
                              The unique identifier of the scope the StimuliVector belongs to.
  }
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

### 40.2 DELETE /ep/stimuli-vectors/{stimuli-vector-uid}

### Delete a stimuli vector

Delete a stimuli vector by its UID.

### **REQUEST**

### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*stimuli-vector-uid	string	The UID of the stimuli vector to be deleted.

```
STATUS CODE - 200: OK

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

### 40.3 POST /ep/stimuli-vectors-export

### **Export Stimuli Vectors**

<b>Long running task</b> Export single or multiple Stimuli Vector(s) by providing the list of the stimuli vectors which will be exported, the export directory, the export format and a list of additional options for export.

### **REQUEST**

```
REQUEST BODY - application/json
{
   UIDs*
                              [string]
                                            List with the UIDs of the elements which will be exported
   exportDirectory* string
                                            Directory where to export the elements
   exportFormat
                                            ALLOWED: EXCEL, CSV
                              enum
                                            The format of the exported stimuli vectors. It can be: "EXCEL" or "CSV". Default value is EXCEL.
   additionalOptions {
       csvDelimiter
                                enum
                                            ALLOWED:SEMICOLON, COMMA, COLON, PIPE
                                            Relevant only for CSV export format. It can have one of the following values: "SEMICOLON",
                                             "COMMA", "COLON", "PIPE". Default value is "SEMICOLON".
       singleFile
                               boolean
                                            Relevant only for CSV export format: false - each vector will be exported in it's own file; true - all
                                             vectors will be exported in same file. Default is 'false'
       architectureUid string
                                             Relevant only for Excel export format. It specifies the UID of the architecture on which the
                                             interfaces of the vectors will be exported. Default is the master architecture
   }
   overwritePolicy
                              enum
                                            ALLOWED: EXTEND_NAME, OVERWRITE, SKIP
                                            Overwrite policy: allowed values (not case-sensitive) are: EXTEND_NAME, in which case if the
                                            exported file exists on disk, its name will be extended and the original file on disk will be kept,
                                            OVERWRITE, in which case the original file on disk is overwritten, if it exists. Default value is
                                            EXTEND NAME
}
```

#### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}
STATUS CODE - 400: Bad Request
RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
```

### RESPONSE MODEL - text/plain

```
string
```

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

STATUS CODE - 500: Internal server error

**RESPONSE MODEL - text/plain** 

string

### 40.4 GET /ep/stimuli-vectors

### Get all stimuli vectors

Get all stimuli vectors.

### **REQUEST**

No request parameters

#### **RESPONSE**

```
STATUS CODE - 200: OK
```

```
RESPONSE MODEL - application/json
```

```
[{
Array of object:
   uid
                   string
                               READ-ONLY
                                The unique identifier (UID) of this object.
   name
                               The name of the StimuliVector.
                   string
   length
                   integer The length of the vector.
   folderUID string
                               The unique identifier of the folder the StimuliVector belongs to
   scopeUID
                   string
                               The unique identifier of the scope the StimuliVector belongs to.
}]
```

STATUS CODE - 500: Internal server error

**RESPONSE MODEL - text/plain** 

string

### 40.5 PUT /ep/stimuli-vectors

### Import stimuli vectors

<b>Long running task</b> Import multiple stimuli vectors from external files into a Folder by providing their path and the Folders UID. Can either overwrite or skip stimuli vectors that are already imported.

### **REQUEST**

```
REQUEST BODY - application/json
{
   paths*
                           [string]
                                        The paths to all stimuli vectors you'd like to import.
   vectorKind
                           enum
                                        ALLOWED:TC, EXCEL
                                        The stimuli vector type. Default value is "TC"
   folderUID
                                        The UID of the folder you want to import into.
                           string
   delimiter
                           enum
                                        ALLOWED: SEMICOLON, COMMA, COLON, PIPE
                                        The CSV file delimiter, can be: "SEMICOLON", "COMMA", "COLON", "PIPE". Default value is
                                        "SEMICOLON"
```

Decides what happens in case of duplicate names. Can be "EXTEND\_NAME", "OVERWRITE" or "SKIP". Default is "SKIP".

}

### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 403: Forbidden
    RESPONSE MODEL - text/plain
    string

STATUS CODE - 500: Internal server error
    RESPONSE MODEL - text/plain
    string
```

### 40.6 GET /ep/folders/{folder-uid}/stimuli-vectors

### Get all stimuli vectors from a folder

Get all stimuli vectors from the specified folder.

### **REQUEST**

### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*folder-uid	string	The UID of the folder from which to get stimuli vectors.

### **RESPONSE**

```
STATUS CODE - 200: OK
```

### **RESPONSE MODEL - application/json**

```
Array of object:
   uid
                   string
                               READ-ONLY
                               The unique identifier (UID) of this object.
   name
                               The name of the StimuliVector.
                   string
   length
                   integer The length of the vector.
   folderUID string
                                The unique identifier of the folder the StimuliVector belongs to.
   scopeUID
                   string
                               The unique identifier of the scope the StimuliVector belongs to.
}]
```

```
STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error
```

RESPONSE MODEL - text/plain

string

### 40.7 GET /ep/scopes/{scope-uid}/stimuli-vectors

### Get all stimuli vectors from a scope

Get all stimuli vectors from the specified scope.

### **REQUEST**

### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*scope-uid	string	The UID of the scope from which to get stimuli vectors.

```
STATUS CODE - 200: OK
  RESPONSE MODEL - application/json
  Array of object:
     uid
                   string
                              READ-ONLY
                               The unique identifier (UID) of this object.
     name
                   string
                             The name of the StimuliVector.
     length
                   integer The length of the vector.
     folderUID string
                               The unique identifier of the folder the StimuliVector belongs to.
     scopeUID
                              The unique identifier of the scope the StimuliVector belongs to.
                   string
  }]
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

# **41. TEST**

# 41.1 GET /ep/test

Test the connection to the REST server

### **REQUEST**

No request parameters

### **RESPONSE**

STATUS CODE - 200: Request successfully sent.

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string

# 42. TEST CASE/STIMULI VECTOR SIMULATION

Simulate TestCases.

### 42.1 POST /ep/folders/{folder-uid}/testcase-simulation

#### Simulates all Test Cases/StimuliVectors from a folder

<br/> <b>Long running task </b>Simulates all Test Cases/StimuliVectors from a given folder for the specified execution kinds.<br/> Optionally, simulation can be forced to not re-use any previous results.

### **REQUEST**

#### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*folder-uid	string	The Folder UID for which the Test Cases/Stimuli Vectors are simulated.

```
REQUEST BODY - application/json
{
    execConfigNames* [string] List of execution kinds (example: SIL, TL MIL, SL MIL, etc.) for which to simulate. Not casesensitive.
    forceExecute boolean Specify (optional) if the simulation should be forced (all previous results will be discarded).
    Default is 'false'.
}
```

### **RESPONSE**

```
RESPONSE MODEL - application/json
    jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

### 42.2 POST /ep/folders/testcase-simulation

#### Simulates all Test Cases/StimuliVectors from a list of folders

<br/> <b>Long running task </b>Simulates all Test Cases/StimuliVectors from a given list of folders for the specified execution kinds. Optionally, simulation can be forced to not re-use any previous results.

### **REQUEST**

```
REQUEST BODY - application/json
{
    execConfigNames* [string] List of execution kinds (example: SIL, TL MIL, SL MIL, etc.) for which to simulate. Not casesensitive.
    forceExecute boolean Specify (optional) if the simulation should be forced (all previous results will be discarded).
        Default is 'false'.
    UIDs* [string] List with unique identifiers of the objects.
}
```

### **RESPONSE**

**STATUS CODE - 202**: Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

### 42.3 POST /ep/scopes/{scope-uid}/testcase-simulation

### Simulates all Test Cases/StimuliVectors from a scope

<b>Long running task </b>Simulates all Test Cases/StimuliVectors from a given scope for the specified execution kinds. Optionally, simulation can be forced to not re-use any previous results.

### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-uid	string	The Scope UID for which the Test Cases/Stimuli Vectors are simulated.

```
REQUEST BODY - application/json {
```

```
execConfigNames* [string] List of execution kinds (example: SIL, TL MIL, SL MIL, etc.) for which to simulate. Not case-
sensitive.
forceExecute boolean Specify (optional) if the simulation should be forced (all previous results will be discarded).
Default is 'false'.
}
```

#### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
     jobID string READ-ONLY
                     The ID of a job.
  }
STATUS CODE - 400: Bad Request
  RESPONSE MODEL - text/plain
string
STATUS CODE - 403: Forbidden
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error
  RESPONSE MODEL - text/plain
string
```

### 42.4 POST /ep/scopes/testcase-simulation

#### Simulates all Test Cases/StimuliVectors from a list of scopes

<b>Long running task </b>Simulates all Test Cases/StimuliVectors from a given list of scopes for the specified execution kinds. Optionally, simulation can be forced to not re-use any previous results.

### **REQUEST**

```
REQUEST BODY - application/json
{
    execConfigNames* [string] List of execution kinds (example: SIL, TL MIL, SL MIL, etc.) for which to simulate. Not case-
    sensitive.
    forceExecute boolean Specify (optional) if the simulation should be forced (all previous results will be discarded).
        Default is 'false'.
    UIDs* [string] List with unique identifiers of the objects.
}
```

### **RESPONSE**

```
RESPONSE MODEL - application/json

{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain
string
```

### 42.5 POST /ep/test-cases/{testcase-uid}/testcase-simulation

#### Simulates a Test Case/Stimuli Vector

<br/> <b>Long running task </b>Simulates a Test Case/Stimuli Vector for the specified execution kinds. Optionally, also the test execution can be forced to not re-use any previous results.

### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*testcase-uid	string	The Test Case/Stimuli VectorUID to simulate.

```
REQUEST BODY - application/json
{
    execConfigNames* [string] List of execution kinds (example: SIL, TL MIL, SL MIL, etc.) for which to simulate. Not case-
    sensitive.
    forceExecute boolean Specify (optional) if the simulation should be forced (all previous results will be discarded).
    Default is 'false'.
}
```

### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string
```

```
STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Not found

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

### 42.6 POST /ep/test-cases/testcase-simulation

#### Simulates all Test Cases/StimuliVectors

<b>Long running task </b>Simulates all Test Cases/StimuliVectors on the specified execution kinds. Optionally, simulation can be forced to not re-use any previous results.

### **REQUEST**

```
REQUEST BODY - application/json
{
    execConfigNames* [string] List of execution kinds (example: SIL, TL MIL, SL MIL, etc.) for which to simulate. Not case-
    sensitive.
    forceExecute boolean Specify (optional) if the simulation should be forced (all previous results will be discarded).
        Default is 'false'.

UIDs* [string] List with unique identifiers of the objects.
}
```

### **RESPONSE**

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request
RESPONSE MODEL - text/plain
string

STATUS CODE - 403: Forbidden
RESPONSE MODEL - text/plain
string

STATUS CODE - 500: Internal server error
RESPONSE MODEL - text/plain
string
```

# 43. TOLERANCES

Import, reset and retrieve global and local tolerances.

### 43.1 POST /ep/profiles/export-global-tolerances

#### **Export global tolerances**

Use this command to export the global tolerances per usecase.

### **REQUEST**

```
REQUEST BODY - application/json
{
    path* string toleranceUseCase* enum toleranceUseCase* enum ALLOWED:B2B, RBT
    The use case of the tolerances for which tolerances should be applied. Allowed values are RBT and B2B.
}
```

### **RESPONSE**

**STATUS CODE - 202:** Long running operation started. The status of the operation can be reviewed by using the <a href='#get-/ep/progress'>Progress</a> i.e. GET '/ep/progress?progress-id={progress-id}' using the id received by this command.

```
RESPONSE MODEL - application/json
{
    jobID string READ-ONLY
    The ID of a job.
}

STATUS CODE - 400: Bad Request

RESPONSE MODEL - text/plain

string

STATUS CODE - 403: Forbidden

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error

RESPONSE MODEL - text/plain

string
```

### 43.2 GET /ep/scopes/{scope-id}/global-tolerances

#### Get the global tolerances

Use this command to retrieve the global tolerances. A valid scope uid and use case must be specified. The lead-lag-unit can be either Seconds or Steps.

### **REQUEST**

### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*scope-id	string	The scope from which to retrieve the global tolerances.

### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION	
*kind	enum ALLOWED: B2B, RBT	The use case kind. Can be either RBT or B2B.	
lead-lag- unit	enum ALLOWED: SECONDS, STEPS	For existing tolerances, lead and lag values should be displayed as either SECONDS or STEPS. Default is STEPS.	

### **RESPONSE**

```
STATUS CODE - 200: Global tolerances retrieved.
```

```
RESPONSE MODEL - application/json
  [ {
  Array of object:
    uid
             string READ-ONLY
                      The unique identifier (UID) of this object.
    name string
     lead string
    lag
            string
    absTol string
     relTol string
    kind
             string
  }]
STATUS CODE - 400: Bad request.
  RESPONSE MODEL - text/plain
string
STATUS CODE - 404: Not found.
  RESPONSE MODEL - text/plain
string
STATUS CODE - 406: Not acceptable.
  RESPONSE MODEL - text/plain
string
STATUS CODE - 500: Internal server error.
  RESPONSE MODEL - text/plain
string
```

## 43.3 PUT /ep/profiles/global-tolerances

### Import the global tolerances

Use this command to import the global tolerances.

### **REQUEST**

```
REQUEST BODY - application/json
     path*
                             string The path to the xml file to use for import or export of tolerances.
     toleranceUseCase* enum
                                       ALLOWED: B2B, RBT
                                       The use case of the tolerances for which tolerances should be applied. Allowed values are RBT and
  }
RESPONSE
  STATUS CODE - 200: Global tolerances imported.
  STATUS CODE - 400: Bad request.
    RESPONSE MODEL - text/plain
  string
  STATUS CODE - 406: Not acceptable.
    RESPONSE MODEL - text/plain
  string
  STATUS CODE - 500: Internal server error.
    RESPONSE MODEL - text/plain
  string
```

### 43.4 DELETE /ep/profiles/global-tolerances

### Reset the global tolerances

Use this command to reset the global tolerances for the profile.

### **REQUEST**

### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION
*kind	enum ALLOWED: B2B, RBT	The use case kind. Can be either RBT or B2B.

```
STATUS CODE - 200: Global tolerances reset.

STATUS CODE - 400: Bad request.

RESPONSE MODEL - text/plain

string

STATUS CODE - 406: Not acceptable.

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string
```

### 43.5 GET /ep/test-cases/{test-case-id}/local-tolerances

#### Get the local tolerances

Use this command to retrieve the local tolerances. A valid test case uid must be specified. The lead-lag-unit can be either Seconds or Steps. Setting the create-if-missing to true will create local tolerances from the global tolerances.

### **REQUEST**

#### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*test-case-id	string	The UID of the test case for which local tolerances will be retrieved.

### **QUERY PARAMETERS**

NAME	TYPE	DESCRIPTION	
lead-lag-unit	enum ALLOWED: SECONDS, STEPS	For existing tolerances, lead and lag values should be displayed as either SECONDS or STEPS. Default is STEPS.	
create-if- missing	boolean	If true, the local tolerances will be created if they do not exist yet. Default is: false.	

#### **RESPONSE**

```
STATUS CODE - 200: Local tolerances retrieved.
```

```
RESPONSE MODEL - application/json
Array of object:
   uid
            string READ-ONLY
                     The unique identifier (UID) of this object.
   name
            string
   lead
            string
   lag
            string
   absTol string
   relTol string
   kind
            string
}]
```

STATUS CODE - 400: Bad request.

**RESPONSE MODEL - text/plain** 

string

STATUS CODE - 404: Test case not found.

RESPONSE MODEL - text/plain

string

STATUS CODE - 406: Not acceptable.

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string

### 43.6 PUT /ep/test-cases/{test-case-id}/local-tolerances

### Import the local tolerances

Import local tolerances for a given test case.

**REQUEST BODY - application/json** 

### **REQUEST**

### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*test-case-id	string	The UID of the test case for which local tolerances will be imported.

```
{
    path* string The path to the xml file to use for import or export of local tolerances.
}

RESPONSE

STATUS CODE - 200: Local tolerances imported.

STATUS CODE - 400: Bad request.

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Test case not found.

RESPONSE MODEL - text/plain

string

STATUS CODE - 406: Not acceptable.

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain

string
```

### 43.7 POST /ep/test-cases/{test-case-id}/local-tolerances

### **Export local tolerances**

Export local tolerances for a given test case.

### **REQUEST**

### **PATH PARAMETERS**

NAME	TYPE	DESCRIPTION
*test-case-id	string	The UID of the requirement-based Test Case to export the local tolerances for.

```
REQUEST BODY - application/json {
```

```
path* string The path to the xml file to use for import or export of local tolerances.
}

RESPONSE

STATUS CODE - 200: Local tolerances exported.

STATUS CODE - 400: Bad request.

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Test case not found.

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain
```

### 43.8 DELETE /ep/test-cases/{test-case-id}/local-tolerances

#### Reset the local tolerances

Remove the local tolerances for a test case.

### **REQUEST**

string

### PATH PARAMETERS

NAME	TYPE	DESCRIPTION
*test-case-id string		The UID of the test case for which local tolerances will be removed.

### **RESPONSE**

string

```
STATUS CODE - 200: Local tolerances removed.

STATUS CODE - 400: Bad request.

RESPONSE MODEL - text/plain

string

STATUS CODE - 404: Test case not found.

RESPONSE MODEL - text/plain

string

STATUS CODE - 406: Not acceptable.

RESPONSE MODEL - text/plain

string

STATUS CODE - 500: Internal server error.

RESPONSE MODEL - text/plain
```