BayesCMD Documentation *Release*

Joshua Russell-Buckland

CONTENTS:

1	bcmdModel	3	
	1.1 Running the BCMD Model	3	
	1.1 Running the BCMD Model 1.2 Input Creation	6	
2	abc 2.1 Distances	9 9	
3 jsonParsing			
4	Miscellaneous 4.1 Utility Functions	15 15 15	
5	5 Indices and tables		
Ру	thon Module Index	23	
In	lex	25	

BayesCMD is a package intended to expand the capabilities of the Brain/Circulation Modelling (BCMD) framework. It introduces the ability to obtain posterior distributions for model parameters by using Approximate Bayesian Computation (ABC).

CONTENTS: 1

2 CONTENTS:

CHAPTER

ONE

BCMDMODEL

1.1 Running the BCMD Model

The BCMD model can be run in a number of ways, both using the command lines and the WeBCMD interface. Over time, both the BayesCMD package and the WeBCMD package are expected to merge. As a result, the BCMD model class has been designed to allow flexibility and compatibility with both the current BayesCMD framework and the WeBCMD framework.

1.1.1 bcmd_model

Configure and run a BCMD model.

The BCMD Model class is used to configure and run a BCMD model. It is done by passing a number of configuration variables, creating a model input file and then running the model. Models can also be run from a pre-existing input file and input files can be written to file for later access also.

```
bayescmd.bcmdModel.bcmd model.TIMEOUT
```

int – Max number of seconds for a simulation to run before being cancelled. Default is 30 seconds.

```
bayescmd.bcmdModel.bcmd model.BASEDIR
```

str – Path to Base directory, which should be 'BayesCMD'. It is found by running the <code>bayescmd.util.findBaseDir</code> method, passing either an environment variable or a string to the method.

Use to create inputs, run simulations and parse outputs.

Parameters

- model_name (str) Name of model. Should match the modeldef file for model being generated i.e. model_name of 'model' should have a modeldef file 'model1.modeldef'.
- **inputs** (dict or None, optional) Dictionary of model inputs and their values. Has form {'names': list of str, 'values': list of list of float} where *names* should be a list of each model input name, matching up to the model inputs and *values* would be a list of lists, where each sublist is the input values for that time point. With this in mind, the length of *inputs['values']'* should equal length of *times*. Default is None.
- params (dict of str: float or None, optional) Dictionary of {'parameter': param_value}. Default is None

- **times** (list of float or int or None, optional) List of times at which measurement data has been collected and needs to be simulated. Default is None.
- outputs (list of str or None, optional) List of model outputs to return. Default is None.
- burn_in (float or int, optional) Length of burn in period at start of the simulation.

 Default is 999
- create_input (boolean, optional) Boolean indicator as to whether an input file needs creating. Default is True.
- input_file (str or None, optional) Path to existing input file or to where one needs creating. Default is None.
- **suppress** (boolean, optional) Indicates if console output should be suppressed during model runs. This will prevent writing of both stderr and stdout. Default is False.
- workdir (str or None, optional) Path to working directory if one exists. If not set, it will default to a temporary directory in 'tmp/'. If you wish to write input files and similar to file, it is recommended that the working directory is set manually by the user.
- deleteWorkdir (boolean, optional) Indicates if the working directory should be deleted after finishing. Default is False.
- **timeout** (float or int, optional) Maximum length in seconds to let model run before cancelling. Default is *TIMEOUT*.
- basedir (str, optional) Path to base 'BayesCMD' directory. By default it is set to BASEDIR.
- debug (boolean, optional) Indicates if debugging information should be written to console.
- **testing** (boolean, optional) If True, appends '_test' to coarse and detailed model output. Useful if you wish to test settings and want to avoid test results becoming mixed in with real result files.

model name

str - Name of model. Should match the modeldef file for model being generated i.e. model_name of 'model' should have a modeldef file 'model1.modeldef'.

inputs

dict or None – Dictionary of model inputs and their values. Has form {'names': list of str, 'values': list of float} where *names* should be a list of each model input name, matching up to the model inputs and *values* would be a list of lists, where each sublist is the input values for that time point. With this in mind, the length of *inputs['values']'* should equal length of *times*. Default is None.

params

dict of str: float or None - Dictionary of {'parameter': param_value}. Default is None

times

list of float or int or None – List of times at which measurement data has been collected and needs to be simulated. Default is None.

outputs

list of str or None – List of model outputs to return. Default is None.

burn_in

float or int – Length of burn in period at start of the simulation. Default is 999

create_input

boolean – Boolean indicator as to whether an input file needs creating. Default is True.

input file

str – Path to existing input file or to where one needs creating. If <code>create_input</code> is True and no path is given, the input file will be written to <code>workdir</code> as <code>model name.input</code>.

suppress

boolean – Indicates if console output should be suppressed during model runs. This will prevent writing of both stderr and stdout. Default is False.

DEVNULL

_io.BufferedWriter - If suppress is set to True, this will be an io buffer that redirects stderr and stdout to the null device.

workdir

str or None – Path to working directory if one exists. If not set, it will default to a temporary directory in 'tmp/'. If you wish to write input files and similar to file, it is recommended that the working directory is set manually by the user.

If no working directory is given, the <code>deleteWorkdir</code> attribute will be set to True in order to ensure that the file space does not become excessively full during batch runs.

deleteWorkdir

boolean – Indicates if the working directory should be deleted after finishing. Default is False, but this will always be set to True if workdir is set to None.

timeout

float or int - Maximum length in seconds to let model run before cancelling. Default is TIMEOUT.

basedir

str – Path to base 'BayesCMD' directory. By default it is set to BASEDIR.

debug

boolean - Indicates if debugging information should be written to console

program

str - Path to the compiled model file. This is expected to be in 'basedir/build', with the name model name.model.

output_{coarse, detail}

str – Location to write coarse and detailed output files to. This will be the working directory, with coarse output files having the suffix '.out' and detailed output files having the suffix '.detail'.

output_dict

```
collections.defaultdict(:obj:`list)'
```

_cleanupTemp()

Delete working directory.

create_default_input()

Method to create input file and write to string buffer for access direct from memory.

create_initialised_input()

Method to create input file and write to string buffer for access direct from memory.

get_defaults()

Obtain default model configuration.

output_parse()

Function to parse the output files into a dictionary.

write_default_input()

Write a default input to file.

Take a configured input file and write to the file specified by <code>input_file</code>.

write initialised input()

Function to write a default input to file.

1.2 Input Creation

Input files are required by the BCMD model. A special class has been created that will create a correctly formatted input file for a variety of use cases.

1.2.1 input creation

Create input files for use with a BCMD model.

Input files are needed in order to set model parameters and provide driving inputs.

class bayescmd.bcmdModel.InputCreator(times, inputs, outputs=None, params=None, filename=None)

Create an input file by passing relevant information to the class.

This input file is then used to create an input file that can either be written to file or kept in buffer and passed directly to the model.

Parameters

- times (list of float or int) List of times at which measurement data has been collected and needs to be simulated.
- inputs (dict) Dictionary of model inputs and their values. Has form {'names': list of str, 'values': list of float} where names should be a list of each model input name, matching up to the model inputs and values would be a list of lists, where each sublist is the input values for that time point. With this in mind, the length of inputs['values']' should equal length of times.
- **filename** (str, optional) Name of the input file to be written to if writing to file is required. Default is None.
- params (dict of str: float, optional) Dictionary of { 'parameter': param_value}
- outputs (list of str, optional) List of model outputs to return.

times

list of float or int - List of times at which measurement data has been collected and needs to be simulated.

inputs

dict — Dictionary of model inputs and their values. Has form {'names': list of str, 'values': list of float} where names should be a list of each model input name, matching up to the model inputs and values would be a list of lsits, where each sublist is the input values for that time point. With this in mind, the length of inputs['values']' should equal length of times.

f out

StringIO() – String buffer object to which the input file will be written.

filename

str – Name of the input file to be written to if writing to file is required. Default is None.

params

dict of str: float. - Dictionary of {'parameter': param_value}

outputs

list of str - List of model outputs to return.

default_creation()

Create a default input file from given arguments.

Assumes parameters remain unchanged from default values.

Returns Returns the input file as a String.IO() buffer object.

Return type String.IO()

$initialised_creation(burn_in)$

Create an input file from given arguments.

Creates an input file thatcan have non-default parameter values and outputs, as well as a burn in period. Assumes parameters remain constant for the full duration of the simulation.

Parameters burn_in (float or int) - Length of burn in period at start of the simulation.

Returns Returns the input file as a String.IO() buffer object.

Return type String.IO()

input_file_write()

Write input file from buffer to file.

1.2. Input Creation 7

CHAPTER

TWO

ABC

The *abc* subpackage is used to handle the Approximate Bayesian Computation (ABC) specific components of BayesCMD. This includes running the model multiple times in a batch process, calculating distances between datasets and generating priors for parameters.

2.1 Distances

Use to generate distance measures between simulated and real time series.

bayescmd.abc.distances.DISTANCES

dict – Dictionary contianing the distance aliases, mapping to the functions.

exception bayescmd.abc.distances.Error

Base class for exceptions in this module.

exception bayescmd.abc.distances.ZeroArrayError

Exception raised for errors in the zero array.

bayescmd.abc.distances.check_for_key (dictionary, target)

Check that a dictionary contains a key, and if so, return its data.

Parameters

- **dictionary** (*dict*) Dictionary to check for *target* key.
- **target** (str) String containing the target variable that is expected to be found in *dictionary*

Returns data – List of data found in *dictionary*. This is likely to be the time series data collected experimentally or generated by the model.

Return type list

bayescmd.abc.distances.euclidean_dist(data1, data2)

Get the euclidean distance between two numpy arrays.

Parameters

• data1 (np.ndarray) – First data array.

The shape should match that of data2 and the number of rows should match the number of model outputs i.e. 2 model outputs will be two rows.

• data2 (np.ndarray) – Second data array.

The shape should match that of data1 and the number of rows should match the number of model outputs i.e. 2 model outputs will be two rows.

Returns d – Euclidean distance measure

Return type float

bayescmd.abc.distances.get_distance(actual_data, sim_data, targets, zero_flag, distance='euclidean', normalise=False)

Obtain distance between two sets of data.

Get a distance as defined by distance between two sets of data as well as between each signal in the data.

Parameters

- actual_data (dict) Dictionary of actual data, as generated by bayescmd.abc. data_import.import_actual_data()
- sim_data (dict) Dictionary of simulated data, as created by bayescmd. bcmdModel.ModelBCMD.output_parse()
- targets (list of str) List of model targets, which should all be strings.
- **zero_flag** (dict) Dictionary of form target(str): bool, where bool indicates whether to zero that target.

Note: zero_flag keys should match targets list.

- **distance** (str, optional) Name of distance measure to use. One of ['euclidean', 'manhattan', 'MAE', 'MSE'], where default is 'euclidean'.
- **normalise** (bool, optional) Boolean flag to indicate whether the signals need normalising, default is False. Current normalisation is done using z-score but that is likely to change with time.

Returns

distances -

Dictionary of form: {'TOTAL': summed distance of all signals, 'target1: distance of 1st target', ... 'targetN': distance of Nth target }

Return type dict

bayescmd.abc.distances.manhattan_dist(data1, data2)

Get the Manhattan distance between two numpy arrays.

Parameters

• data1 (np.ndarray) – First data array.

The shape should match that of data2 and the number of rows should match the number of model outputs i.e. 2 model outputs will be two rows.

• data2 (np.ndarray) – Second data array.

The shape should match that of data1 and the number of rows should match the number of model outputs i.e. 2 model outputs will be two rows.

Returns d – Manhattan distance measure

Return type float

bayescmd.abc.distances.mean_absolute_error_dist(data1, data2)

Get the normalised manhattan distance between two numpy arrays.

Parameters

10 Chapter 2. abc

• data1 (np.ndarray) - First data array.

The shape should match that of data2 and the number of rows should match the number of model outputs i.e. 2 model outputs will be two rows.

• data2 (np.ndarray) - Second data array.

The shape should match that of data1 and the number of rows should match the number of model outputs i.e. 2 model outputs will be two rows.

Returns d – Normalised Manhattan distance measure

Return type float

bayescmd.abc.distances.mean_square_error_dist(data1, data2)

Get the Mean Square Error distance between two numpy arrays.

Parameters

• data1 (np.ndarray) - First data array.

The shape should match that of data2 and the number of rows should match the number of model outputs i.e. 2 model outputs will be two rows.

• data2 (np.ndarray) - Second data array.

The shape should match that of data1 and the number of rows should match the number of model outputs i.e. 2 model outputs will be two rows.

Returns d – Mean Square Error distance measure

Return type float

bayescmd.abc.distances.zero_array(array, zero_flag)

Zero an array of data with its initial values.

Parameters

- array (list) List of data
- zero_flags (bool) Boolean indicating if data needs zeroing

Returns zerod – Zero'd list

Return type list

2.1. Distances

12 Chapter 2. abc

CHAPTER
THREE

JSONPARSING

.. automodule :: bayes cmd. js on Parsing. model JSON

CHAPTER

FOUR

MISCELLANEOUS

Here you will find a number of useful functions that are used throughout the general BayesCMD package.

4.1 Utility Functions

Miscellaneous utility functions used throughout BayesCMD.

This module contains a number of utility functions that are used throughout the different BayesCMD subpackages.

```
bayescmd.util.findBaseDir(basename, max_depth=5, verbose=False)
```

Get relative path to a BASEDIR. :param basename: Name of the basedir to path to :type basename: str

Returns Relative path to base directory.

Return type StringIO

bayescmd.util.round_sig(x, sig=1)

Round a value to N sig fig.

Parameters

- **x** (float) Value to round
- sig(int, optional) Number of sig figs, default is 1

Returns Rounded value

Return type float

4.2 Processing Results

Process results obtained using BayesCMD.

Process the various results obtained using BayesCMD, such as the *parameters.csv* file. It is also possible to concatenate a number of different *parameters.csv* files obtained using parallel batch runs into a single parameters file.

```
bayescmd.results_handling.BAYESCMD
str-Absolute path to base directory. Found using bayescmd.util.findBaseDir

bayescmd.results_handling.data_import(pfile, nan_sub=100000, chunk_size=10000, verbose=True)

Import a parameters file produced by a batch process.
```

Parameters

• **pfile** (str) – Path to the file of parameters and distances

- nan_sub (int or float, optional) Number to substitute for NaN distances/params. Default of 100000
- chunk_size (int, optional) Size of chunks to load for dataframe. Default of 10000
- **verbose** (bool, optional) Boolean as to whether include verbose information. Default of True

Returns result – Dataframe containing all the parameters and distances, with NaN swapped for nan_sub

Return type pd.DataFrame

bayescmd.results_handling.data_merge (parent_directory, verbose=True)

Merge a set of parameters.csv files into one.

Parameters

- **parent_directory** (list of str) Parent directory to a set of directories each containing model runs and a parameters.csv file.
- **verbose** (boolean, optional) Boolean indicator of whether to print extra information.

Returns Concatenated will be written to file in *parent_directory*

Return type None

bayescmd.results_handling.diag_kde_plot(x, **kws)

Plot univariate KDE and barplot with median of distribution marked on.

Includes median of distribution as a line and as text.

Parameters

- **x** (array-like) Array-like of data to plot.
- **kws** (*key*, *value pairings*.) Other keyword arguments to pass to sns. distplot.

Returns ax – AxesSubplot object of univariate KDE and bar plot with median marked on as well as text.

Return type matplotlib. Axes Subplot

bayescmd.results handling.frac calculator (df, frac)

Calculate the number of lines for a given fraction.

Parameters

- **df** (pd.DataFrame) Data frame to find fraction of. Normally the output of data_import
- **frac** (float) The fraction of results to consider. Should be given as a percentage i.e. 1=1%, 0.1=0.1%

Returns Number of lines that make up the fraction.

Return type int

bayescmd.results_handling.get_output (model_name, p, times, input_data, d0, targets, distance='euclidean', zero_flag=None)

Generate model output and distances.

Parameters

• model_name (str) - Name of model

- p (dict) Dict of form {'parameter': value} for which posteriors are being investigated.
- times (list of float) List of times at which the data was collected.
- input_data (dict) Dictionary of input data as generated by abc.inputParse.
- targets (list of str) List of model outputs against which the model is being optimised.
- distance (str) Distance measure. One of 'euclidean', 'manhattan', 'MAE', 'MSE'.
- **zero_flag** (dict) Dictionary of form target(str): bool, where bool indicates whether to zero that target.

Note: zero_flag keys should match targets list.

Returns A tuple of (p, model output data).

Return type tuple

```
bayescmd.results_handling.histogram_plot(df, distance='euclidean', fraction=1, n\_bins=100)
```

Plot histogram of distance values.

Plot a histogram showing the distribution of distance values for a given fraction of all distances in the dataframe. Distance values will have been calculated during the batch process.

Parameters

- df (pandas.DataFrame) Dataframe of distances and parameters, generated using data_import()
- **distance** (str, optional) Distance measure. One of 'euclidean', 'manhattan', 'MAE', 'MSE'. Default is 'euclidean'.
- **fraction** (float, optional) Fraction of all distances to plot. Varies from 0 to 1. Default is 1.
- n_bins (int, optional) Number of histogram bins. Default is 100.

Returns AxesSubplotobject that contains histogram of distance values.

Return type matplotlib.AxesSubplot

```
bayescmd.results_handling.kde_plot (df, params, frac, plot_param=1, n_ticks=6, d='euclidean', verbose=False)

Plot the model parameters pairwide as a KDE.
```

Parameters

- **df** (pandas.DataFrame) Dataframe of distances and parameters, generated using data_import()
- params (list of str) List of model parameters to compare pairwise.
- **frac** (float) Fraction of results to consider. Should be given as a percentage i.e. 1=1%, 0.1=0.1%
- plot_param (int) Which group to plot:
 - 0: Outside posterior 1: Inside posterior 2: Failed run
- n_ticks (int, optional) Number of x-axis ticks. Useful when a large number of parameters are bring compared, as the axes can become crowded if the number of ticks is too high.
- d (str, optional) Distance measure. One of 'euclidean', 'manhattan', 'MAE', 'MSE'.

Note: Should be given as a raw string if latex is used i.e. r'MAE'.

• verbose (boolean, optional) – Boolean to indicate verbosity. Default is False.

Returns g – Seaborn pairgrid object is returned in case of further formatting.

Return type seaborn.PairGrid

```
bayescmd.results_handling.plot_repeated_outputs(df, model_name, parameters, in-
put_path, inputs, openopt_path,
targets, n_repeats, frac, dis-
tance='euclidean', zero_flag=None)
```

Generate model output and distances multiple times.

Parameters

- model_name (str) Name of model. Should match the modeldef file for model being generated i.e. model_name of 'model' should have a modeldef file 'model1.modeldef'.
- parameters (list of str) List of parameters for which posteriors are being investigated.
- input_path (str) Path to the true data file
- inputs (list of str) List of model inputs.
- targets (list of str) List of model outputs against which the model is being optimised.
- n_repeats Number of times to generate output data
- **frac** (float) Fraction of results to consider. Should be given as a percentage i.e. 1=1%, 0.1=0.1%
- **distance** (str) Distance measure. One of 'euclidean', 'manhattan', 'MAE', 'MSE'.
- **zero_flag** (dict) Dictionary of form target(str): bool, where bool indicates whether to zero that target.

Note: zero_flag keys should match targets list.

Returns

Return type None

```
bayescmd.results_handling.run_model(model)
```

Run a BCMD Model.

Parameters model (bayescmd.bcmdModel.ModelBCMD) – An initialised instance of a ModelBCMD class.

Returns output – Dictionary of parsed model output.

Return type dict

```
bayescmd.results_handling.scatter_dist_plot(df, params, frac, n_ticks=6, d='euclidean', verbose=False)
```

Plot distribution of parameters as a scatter PairPlot.

Parameters

- **df** (pandas.DataFrame) Dataframe of distances and parameters, generated using data_import()
- params (list of str) List of model parameters to compare pairwise.

- **frac** (float) Fraction of results to consider. Should be given as a percentage i.e. 1=1%, 0.1=0.1%
- n_ticks (int, optional) Number of x-axis ticks. Useful when a large number of parameters are bring compared, as the axes can become crowded if the number of ticks is too high.
- d (str, optional) Distance measure. One of 'euclidean', 'manhattan', 'MAE', 'MSE'.

 Note: Should be given as a raw string if latex is used i.e. *r'MAE'*.
- verbose (boolean, optional) Boolean to indicate verbosity. Default is False.

Returns g – Seaborn pairgrid object is returned in case of further formatting.

Return type seaborn.PairGrid

CHAPTER

FIVE

INDICES AND TABLES

- genindex
- modindex
- search

PYTHON MODULE INDEX

b

bayescmd.abc, 9
bayescmd.abc.distances, 9
bayescmd.bcmdModel.bcmd_model, 3
bayescmd.bcmdModel.input_creation, 6
bayescmd.results_handling, 15
bayescmd.util, 15

BayesCMD	Documentation	, Release
-----------------	----------------------	-----------

24 Python Module Index

INDEX

Symbols	DISTANCES (in module bayescmd.abc.distances), 9
_cleanupTemp() (bayescmd.bcmdModel.ModelBCMD method), 5	E
В	Error, 9 euclidean_dist() (in module bayescmd.abc.distances), 9
basedir (bayescmd.bcmdModel.bcmd_model.ModelBCMD attribute), 5	'F
BASEDIR (in module bayescmd.bcmdModel.bcmd_model), 3 BAYESCMD (in module bayescmd.results_handling), 15 bayescmd.abc (module), 9 bayescmd.abc.distances (module), 9	f_out (bayescmd.bcmdModel.input_creation.InputCreator attribute), 6 filename (bayescmd.bcmdModel.input_creation.InputCreator attribute), 6 findBaseDir() (in module bayescmd.util), 15
bayescmd.bcmdModel.bcmd_model (module), 3 bayescmd.bcmdModel.input_creation (module), 6	frac_calculator() (in module bayescmd.results_handling), 16
bayescmd.results_handling (module), 15 bayescmd.util (module), 15	G
burn_in (bayescmd.bcmdModel.bcmd_model.ModelBCMI attribute), 4	Oget_defaults() (bayescmd.bcmdModel.ModelBCMD method), 5
С	get_distance() (in module bayescmd.abc.distances), 10 get_output() (in module bayescmd.results_handling), 16
check_for_key() (in module bayescmd.abc.distances), 9 create_default_input() (bayescmd.bcmdModel.ModelBCM	DH
method), 5 create_initialised_input() (bayescmd.bcmdModel.ModelBCMD method), 5	histogram_plot() (in module bayescmd.results_handling), 17
create_input (bayescmd.bcmdModel.bcmd_model.ModelB attribute), 4	GMPalised_creation() (bayescmd.bcmdModel.InputCreator method), 7
D	$input_file~(bayescmd.bcmdModel.bcmd_model.ModelBCMD\\attribute),~4$
data_import() (in module bayescmd.results_handling), 15 data_merge() (in module bayescmd.results_handling), 16 debug (bayescmd.bcmdModel.bcmd_model.ModelBCMD attribute), 5	input_file_write() (bayescmd.bcmdModel.InputCreator method), 7 InputCreator (class in bayescmd.bcmdModel), 6 inputs (bayescmd.bcmdModel.bcmd_model.ModelBCMD
default_creation() (bayescmd.bcmdModel.InputCreator method), 7	attribute), 4 inputs (bayescmd.bcmdModel.input_creation.InputCreator
deleteWorkdir (bayescmd.bcmdModel.bcmd_model.Model attribute), 5	
DEVNULL (bayescmd.bcmdModel.bcmd_model.ModelB0 attribute), 5	
diag_kde_plot() (in module bayescmd.results_handling), 16	kde_plot() (in module bayescmd.results_handling), 17

attribute), 5

```
M
                                                  write default input() (bayescmd.bcmdModel.ModelBCMD
                                                          method), 5
manhattan_dist() (in module bayescmd.abc.distances), 10
                                                  write initialised input() (bayescmd.bcmdModel.ModelBCMD
mean absolute error dist()
                                          module
                               (in
                                                          method), 5
        bayescmd.abc.distances), 10
mean square error dist()
                                          module
                                                  Z
        bayescmd.abc.distances), 11
ZeroArrayError, 9
        attribute), 4
ModelBCMD (class in bayescmd.bcmdModel), 3
0
output dict (bayescmd.bcmdModel.bcmd model.ModelBCMD
        attribute), 5
                (bayescmd.bcmdModel.ModelBCMD
output parse()
        method), 5
outputs (bayescmd.bcmdModel.bcmd model.ModelBCMD
        attribute), 4
outputs (bayescmd.bcmdModel.input creation.InputCreator
        attribute), 6
Р
params (bayescmd.bcmdModel.bcmd model.ModelBCMD
        attribute), 4
params (bayescmd.bcmdModel.input creation.InputCreator
        attribute), 6
plot_repeated_outputs()
                             (in
                                          module
        bayescmd.results handling), 18
program (bayescmd.bcmdModel.bcmd model.ModelBCMD
        attribute), 5
R
round sig() (in module bayescmd.util), 15
run_model() (in module bayescmd.results_handling), 18
S
scatter_dist_plot()
                                          module
        bayescmd.results_handling), 18
suppress\ (bayescmd.bcmdModel.bcmd\_model.ModelBCMD
        attribute), 5
Т
timeout (bayescmd.bcmdModel.bcmd_model.ModelBCMD
        attribute), 5
TIMEOUT
                        (in
                                          module
        bayescmd.bcmdModel.bcmd model), 3
times (bayescmd.bcmdModel.bcmd model.ModelBCMD
        attribute), 4
times (bayescmd.bcmdModel.input_creation.InputCreator
        attribute), 6
W
workdir (bayescmd.bcmdModel.bcmd_model.ModelBCMD
```

26 Index