Sensorbot Birdhouse

sensorbot.org

## IMPORTANT: Bottlebot Instructions: https://tinyurl.com/ydxv7hfe Birdhouse Instructions: https://tinyurl.com/ybv8ey5l


Cut this nameplate out (a small white border looks nice), and affix as follows:

Bottlebot: Tape or glue to outside of PM sensor so it can been seen from the outside. Note orientation: screw holes are on the outside; connector socket is on top


Birdhouse: Glue to inside of back panel near the peak; ensure enough room for the nail hole used to hang the device.

Cut template along dashed lines; tape to the back of ESP8266 so that USB port is aligned with template marking; each 'x' should align with a connector pin.


Device\_key: PuaqCIXYDy0uhbj58s3t



Template 1: For devices with no external LEDs (e.g. Bottlebot)



Template 2: For devices with external LEDs (e.g. Birdhouse)



Template 3: For devices with external LEDs and larger NodeMCU (e.g. Birdhouse)

Sensorbot Birdhouse

sensorbot.org

## IMPORTANT: Bottlebot Instructions: https://tinyurl.com/ydxv7hfe Birdhouse Instructions: https://tinyurl.com/ybv8ey5l


Cut this nameplate out (a small white border looks nice), and affix as follows:

Bottlebot: Tape or glue to outside of PM sensor so it can been seen from the outside. Note orientation: screw holes are on the outside; connector socket is on top


Birdhouse: Glue to inside of back panel near the peak; ensure enough room for the nail hole used to hang the device.

Cut template along dashed lines; tape to the back of ESP8266 so that USB port is aligned with template marking; each 'x' should align with a connector pin.


Device\_key: y0x0CC0y64h61xbr3Q2V



Template 1: For devices with no external LEDs (e.g. Bottlebot)



Template 2: For devices with external LEDs (e.g. Birdhouse)



Template 3: For devices with external LEDs and larger NodeMCU (e.g. Birdhouse)