

# **AXI VDMA Reference Design for the Kintex KC705 Evaluation Board**

Author: Dinesh Kumar

## **Summary**

This application note demonstrates how to use the LogiCORE™ IP AXI Video DMA (VDMA) core in a typical video application. It describes hardware and software APIs. The hardware system uses two VDMAs with both MM2S and S2MM paths shorted.

You can refer to this design and use the API in video applications that use VDMA. This application note demonstrates VDMA in loopback mode, but the MM2S and S2MM can also each be connected to separate video IP.

You can download the <u>Reference Design Files</u> for this application note from the Xilinx® website. For detailed information about the design files, see <u>Reference Design</u>.

# **Included Systems**

The reference design is created and built using Vivado® IP Integrator v2014.1, which is part of Vivado System Edition. The IP integrator is an interactive design and verification environment that you can use to create and verify a hierarchical system by graphically connecting Xilinx, third-party, or proprietary IP, using interface-level connections. It provides a device- and platform-aware, interactive environment that supports intelligent auto-connection of key IP interfaces, one-click IP subsystem generation, real-time DRCs, interface change propagation, and powerful debug capability.

The design also includes software built using the Xilinx Software Development Kit (SDK). The software runs on the MicroBlaze™ processor subsystem and implements control, status, and monitoring functions. Complete Vivado tools and SDK project files are provided with the reference design to allow you to examine and rebuild the design or to use as a template for a new design.



## Introduction

The Xilinx AXI VDMA IP core implements a high-performance, video-optimized DMA engine with frame buffering and two-dimensional (2D) DMA features. Together, the AXI interconnect and AXI MIG implement a multiport memory controller (MPMC) for sharing data from multiple sources through a common memory device, typically DDR3 SDRAM. The AXI VDMA transfers the buffered video data streams to and from memory and operates under dynamic software control. A clock generator and processor system reset block supplies clocks and resets throughout the system.

Xilinx IP cores implement various functions for many video applications. AXI is a standardized IP interface protocol based on the Advanced Microcontroller Bus Architecture (AMBA®) specification. The AXI interfaces used in the reference design consist of AXI4, AXI4-Lite, and AXI4-Stream interfaces as described in the AMBA AXI4 specifications. These interfaces provide a common IP interface protocol framework for building the design.

The Kintex®-7 FPGA KC705 evaluation kit provides a comprehensive, high-performance development and demonstration platform using the Kintex-7 FPGA family for high-bandwidth and high-performance applications in multiple market segments. For more information about this evaluation board, see the *Kintex-7 FPGA KC705 Evaluation Kit Getting Started Guide* [Ref 2].

# **Setup Requirements**

Following are the hardware and software requirements.

#### **Software**

Vivado Design Suite 2014.1

#### **Hardware**

Kintex-7 FPGA KC705 Evaluation Kit Base Board (Figure 1):

- 1. One KC705 board with power adapters
- 2. Two USB platform cables (1 mini and 1 micro)






Figure 1: KC705 Evaluation Kit

# **Reference Design Specifics**

## **Hardware**

In addition to a MicroBlaze processor, the reference design include following cores:

- MDM
- LMB block RAM
- AXI\_INTERCONNECT
- Clock Generator
- PROC\_SYS\_RESET
- AXI\_UARTLITE
- AXI\_INTC
- Memory Interface Generator (MIG)
- Video Direct Memory Access (VDMA)

Figure 2 shows an IP integrator block diagram of the reference system.






Figure 2: IP Integrator Block Diagram

The block diagram shows the system divided into the following modular blocks:

- Multiport memory controller
- Processor subsystem
- Two VDMAs
- Two processor system resets



#### **Multiport Memory Controller**

The multiport memory controller consist of an AXI interconnect and a MIG system (Figure 3). The frequency and data width of the MIG and AXI interconnect are set to meet the bandwidth requirement of a typical video application.




Figure 3: Multiport Memory Controller



#### **Processor Subsystem**

The processor subsystem consists of a MicroBlaze processor and the IP required for the system to function correctly (Figure 4). An AXI interconnect connects peripherals including local memory, UART Lite, and the interrupt controller to the processor. It also includes a clocking block and a microprocessor debug module (MDM) to enable downloading and debugging through the Xilinx microprocessor debugger (XMD). A reset block manages reset synchronization.




Figure 4: Processor Subsystem

#### **VDMAs**

The system uses two VDMAs. The MM2S path of one VDMA is connected to its S2MM path. The VDMAs are configured to allow programming of a frame counter and frame counter interrupt by setting C\_ENABLE\_DEBUG\_INFO\_7 and C\_ENABLE\_DEBUG\_INFO\_15. The VDMA is configured according to the following specifications:

- 200 MHz AXIS clocks
- 200 MHz AXI clocks
- 50 MHz AXI Lite clock
- 1920 by 1080 frame size
- Three frame buffers in circular mode
- S2MM in SOF on TUSER mode, and MM2S in free-run mode
- Dynamic genlock mode with the S2MM side as the master and MM2S as the slave
- Tdata widths of 24 bits
- · MM data width of 32 bits



- DRE disabled; accesses must be properly aligned
- Error interrupts optionally enabled in the software application
- Frame count interrupt enabled to assert every frame in the software application

Using two VDMAs shows that the APIs used in the design are modular and that the same API can be called repeatedly to configure each VDMA.

#### **Processor System Reset**

Processor system reset blocks are used to synchronize resets across various clocks used in system.

#### Software

The software package consists of BSP, system.xml files, and the following application files.

#### vdma\_api.c

The main file, consisting of APIs to initialize, configure, and start VDMA.

The API prototype is:

int run\_triple\_frame\_buffer(XAxiVdma\* InstancePtr, int DeviceId, int
hsize, int vsize, int buf\_base\_addr, int number\_frame\_count, int
enable\_frm\_cnt\_intr);

- instancePtr AXI VDMA driver instance pointer.
- DeviceId Device ID for VDMA to allow the function to work for multiple VDMAs in a system.
- hsize Horizontal size in pixels. The actual data transfer is (hsize) x (tdatawidth).
- vsize Vertical size in lines.
- number\_frame\_count The number of frames after which the application expects an interrupt from the VDMA.
- enable\_frm\_cnt\_intr Enable frame count interrupts.

The API returns XST\_SUCCESS or XST\_FAILURE based on the configuration of the VDMA.

#### vdma api.h

The file containing the prototype of the API; can be added in the application.

#### vdma.c

Consists of the VDMA application to demonstrate how to use the VDMA triple buffer API.



#### vdma.h

Includes various files required for the application.

# **Executing the System on the Board**

## Creating the Bit File and ELF File

The package consists of all.tcl and the software. Complete the following steps to create the bit file and elf file:

- 1. Unzip the folder to the desired directory.
- 2. Launch Vivado Design Suite.
- 3. Source all.tcl in the Vivado IDE Tcl Console. This creates the IP integrator block diagram.
- 4. Generate the bitstream by clicking **Generate Bitstream** on the left side of the Vivado IDE. This creates the file design\_1\_wrapper.bit file at ./project\_1/project\_1.runs/impl\_1.
- 5. Export the design:
  - a. Click File > Export > Export Hardware for SDK.
  - b. Select Export Hardware and Launch SDK.
- 6. The SDK opens with the created project and compiles the software. If you receive an error or warning from the SDK, click **Yes** or **OK**.
- 7. In the SDK, select **Project > Clean** to clean the pre-generated file. The file app.elf is created in the ./sw/app/Debug folder.

### **Running the System**

- 1. Open the hyper-terminal (serial port) for baud rate of 9600.
- 2. Start the Xilinx Microprocessor Debugger (XMD) tool:

% xmd

3. Download the bitstream inside XMD:

```
XMD% fpga -f design 1 wrapper.bit
```

4. Connect to the processor inside XMD:

XMD% connect mb mdm

5. Download the processor code (ELF) file:

XMD% dow app.elf



6. Run the application:

XMD% run

The results are shown in Figure 5.




Figure 5: Application Run Output

The multiple callbacks indicate that frame counter interrupt occurs for read and write channels. Add code in these callbacks to create a complete system.



# **Reference Design**

The reference design has been fully verified and tested on hardware. The design includes details on the various functions of the different modules and includes all functions required to implement a complete VDMA design. You can download the <u>Reference Design Files</u> for this application note from the Xilinx website.

Table 1 shows the reference design matrix.

Table 1: Reference Design Matrix

Parameter	Description	
General		
Developer name	Dinesh Kumar	
Target devices (stepping level, ES, production, speed grades)	Kintex7 (KC705) FPGA	
Source code provided	Yes	
Source code format	VHDL/Verilog (some sources encrypted)	
Design uses code/IP from existing Xilinx application note/reference designs, CORE Generator software, or 3rd-party	Reference designs provided uses core generated from Vivado 2014.1	
Implementation		
Synthesis software tools/version used	Vivado 2014.1	
Implementation software tools/versions used	Vivado Design Suite 2014.1	
Static timing analysis performed	Y (passing timing in)	
Hardware Verification		
Hardware verified	Y	
Hardware platform used for verification	KC705 board	

## References

- 1. AMBA AXI4 specifications
- 2. Kintex-7 FPGA KC705 Evaluation Kit Getting Started Guide (UG883)
- 3. LogiCORE IP AXI Interconnect Product Guide (PG059)
- 4. LogiCORE IP AXI Video Direct Memory Access Product Guide (PG020)
- 5. 7 Series FPGAs Memory Interface Solutions (DS176)



## **Revision History**

The following table shows the revision history for this document.

Date	Version	Revision
08/29/2014	1.0	Initial Xilinx release.

# **Please Read: Important Legal Notices**

The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of Xilinx's limited warranty, please refer to Xilinx's Terms of Sale which can be viewed at <a href="http://www.xilinx.com/legal.htm#tos">http://www.xilinx.com/legal.htm#tos</a>; IP cores may be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in such critical applications, please refer to Xilinx's Terms of Sale which can be viewed at <a href="https://www.xilinx.com/legal.htm#tos">https://www.xilinx.com/legal.htm#tos</a>.

© Copyright 2014 Xilinx, Inc. Xilinx, the Xilinx logo, Artix, ISE, Kintex, Spartan, Virtex, Vivado, Zynq, and other designated brands included herein are trademarks of Xilinx in the United States and other countries. AMBA, AMBA Designer, ARM, ARM1176JZ-S, CoreSight, Cortex, and PrimeCell are trademarks of ARM in the EU and other countries. All other trademarks are the property of their respective owners.