HydraNFC Modes & Pinout

5U PC15 PC14 PC13 PC12 PC11 PC18 PC9 PC8 3U3
ГМ

PC

Hydra NFC Pin	TRF7970A Pin	HydraBus Mode SPI With SS
PC0	IO2	+3V3 or TX SDM (Data En) out
PC1	IO4_CS	SPI2 CS Master <b>out</b>
PC2	IO6_MISO	SPI2 MISO Master or RX DM1 in
PC3	IO7_MOSI	SPI2 MOSI Master <b>out</b>
PC4	IO5	TX SDM or RX DM1 CLK in
PC5	IO3	TX SDM out
PB1	ASK_OOK	TX SDM or Direct Mode 0 out
PB10	DATA_CLK	SPI2 CLK Master <b>out</b>
PB11	EN (Chip En)	+3V3 out
PA1	IRQ	IRQ Input in
PA2	IO1	+3V3 out
PA3	IO0	GND <b>out</b>
PA5	SYS_CLK (Out)	SPI1 CLK Slave (sniffer) in
PA7	MOD	SPI1 MOSI Slave (sniffer) in

IO2: TX SDM Enable (TRF7970A Data Enable input)

IO3: TX SDM Data (TRF7970A Data Bit input)

IO5: TX SDM Clock or RX DM1 Clock (TRF7970A Data Clock output)

IO6: SPI MISO or RX DM1 Data (TRF7970A Data Bit output) or Direct Mode 0 (output) subcarrier signal (digitized RF envelope signal)

MOD: External data modulation input for Direct Mode 0 or 1

ASK/OOK: Selection between ASK and OOK modulation (0 = ASK, 1 = OOK) for Direct Mode 0 or 1. Can be configured as an output to provide the received analog signal output.

SYS\_CLK: Options with 13.56-MHz crystal: Off, 3.39 MHz, 6.78 MHz, or 13.56 Mhz

RX DM1 = Receive Direct Mode 1 (TRF7970A receive), TX SDM = Transmit Special Direct Mode (TRF7970A transmit) TRF7970A Pin 16 is used to supply the I/O interface pins (I/O\_0 to I/O\_7), IRQ, SYS\_CLK, and DATA\_CLK pins of the reader.