

# LILLEN CHECKLISTS

AND TROUBLESHOOTING GUIDES

# Contents

Pre-Departure	2
On Arrival	2
Pre-Return	3
Battery and Water Control Panel	3
Troubleshooting Guides	4
Electric bed	4
House Power Enabled	4
Electrical Cable Connectors	4
Fuse Box	4
Manual Operation	4

Pr	e-Departure
	Ensure that the rooftop tv antenna is retracted and secured
	Ensure awning is retracted and secured properly
	Ensure sunroof hatch is closed. Including in the bathroom
	Ensure bike rack is secure
	Ensure that Button 1-4 on the Battery and Water Control Panel are off
	Ensure that the hot water heater is off
	(Buttons are located on the left-hand side back lounge area)
	, , ,
	(Dial is located on the left-hand side back lounge area) Disconnect 240v electricity if applicable
	Disconnect grey water if applicable
	Ensure LPG gas bottles are turned off
	Ensure that the windows are securely closed and locked
	Ensure everything in the kitchen have been put away and is rattle-proof
	Secure all drawers and doors
	Secure all loose objects for travel
	Start the engine for warm up
	Ensure that the refrigerator (in auto mode) has shifted back 12v
Or	n Arrival
	Select as flat and level a parking site as possible. Use leveling blocks if
	required.  Connect 240v electricity if applicable
	Connect 240v electricity <i>if applicable</i> Connect city water <i>if applicable</i>
	Connect grey water if applicable
	Ensure LPG gas bottle is open
	Turn on button 1-3 on the Battery and Water Control Panel.
	Turn the water pump on, if not connected to city water ( button on the BWCP)
	Turn the hot water heater on using either 240v or LPG gas.
	Ensure the refrigerator (in auto mode) switch to either 240v or LPG gas.
	Please note! If using LPG gas, it can take up 20 minutes before the fridge turns on. The
	refrigerator must be level and will not operate if not parked on a flat surface.
	If using LPG gas, turn the refrigerator fan on.


### Pre-Return

- ☐ Full Tank of Diesel
- ☐ Empty Toilet Cassette
- ☐ Empty grey water tank

## Battery and Water Control Panel

The Battery and Water Control Panel is located near the main door. As a rule of thumb, while stationary button 1-4 should be switched ON.

**Important!** All buttons must be switched **OFF** while driving.



- 1. Main battery button
- 2. Turns on auxiliary power. (Required for the powering the Bed, TV etc)
- 3. Enables the lighting
- 4. Turns on the water pump (Not required if connected to city water)
- 5. Checks the water tank levels
- 6. Grey water tank
- 7. Fresh water tank
- 8. Check the 12v battery power levels
- 9. The house battery
- 10. The car battery
- 11. Light indicating that external 240v electricity is operational

# **Troubleshooting Guides**

### Electric bed

In the unfortunate event that the bed has stopped working please follow these 3 steps.

#### House Power Enabled

First check that button 1 and 2 on the Battery and Water Control Panel are turned on.

#### **Electrical Cable Connectors**

Secondary, check that the electrical cables that hang down on the inside of the storage hatch on the left rear side are properly connected. It's easy to accidentally knock them out when removing the camping chairs and other large objects.

#### Fuse Box

If the cables are properly connected, the next place to check is the fuse box that is located under the passenger couch behind the driver seat. There is a Spare Fuses Kit inside the storage hatch at the rear on the right side (where the water hoses are stored).

### Manual Operation

According to the electric bed manual, there is an option for manual operation of the bed. It is a two-man job and it seem to be a complicated procedure. **Do not attempt this without first contacting the owner or Camplify support.**