

LILLEN CHECKLISTS

AND GUIDES

Contents

Checklists	2
Pre-Departure	2
On Arrival	3
Pre-Return	4
Bad Weather	4
Guides	5
Battery and Water Control Panel	5
Electric bed	6
Step 1 - House Power Enabled	6
Step 2 - Electrical Cable Connectors	6
Step 3 - Fuse Box	6
Manual Operation	6

Checklists

Pre-Departure Ensure that the roo

Ш	Ensure that the rooftop tv antenna is retracted and secured
	Ensure awning is retracted and secured properly
	Ensure sunroof hatch is closed. Including in the bathroom
	Ensure bike rack is secure
	Ensure that Button 1-4 on the Battery and Water Control Panel are off
	Ensure that the hot water heater is off
	(Buttons are located on the left-hand side back lounge area)
	Ensure that the diesel heater is off if applicable
	(Dial is located on the left-hand side back lounge area)
	Disconnect 240v electricity if applicable
	Disconnect city water if applicable
	Disconnect grey water if applicable
	Ensure LPG gas bottles are turned off
	Ensure that the windows are securely closed and locked
	Ensure everything in the kitchen have been put away and is rattle-proof
	Secure all drawers and doors
	Secure all loose objects for travel
	Start the engine for warm up
	Ensure that the refrigerator (in auto mode) has shifted back 12v

On Arrival

Select as flat and level a parking site as possible. Use leveling blocks if
required.
Connect 240v electricity if applicable
Connect city water if applicable
Connect grey water if applicable
Ensure LPG gas bottle is open
Turn on button 1-3 on the Battery and Water Control Panel
\square Turn the water pump on, if not connected to city water (\lozenge button on the BWCP)
Turn the hot water heater on using either 240v or LPG gas.
☐ Ensure the refrigerator (in auto mode) switch to either 240v or LPG gas.
☐ If using LPG gas, turn the refrigerator fan on.

Please note! If using LPG gas, it can take up **20 minutes** before the fridge turns on.

The refrigerator must be level and will not operate if not parked on a flat surface.

Pre	e-Return
	Full Tank of Diesel
	Empty Toilet Cassette
	Empty grey water tank
Ва	d Weather
Befo	ore bad weather arises, please ensure the following:
	Ensure awning is packed away
	Ensure sunroof hatch is closed. Including in the bathroom
	Ensure external storage hatches are closed
	Important! Do not leave awning out overnight or unattended.

Guides

Battery and Water Control Panel

The Battery and Water Control Panel is located near the main door. As a rule of thumb, while stationary button 1-4 should be switched ON.

Important! All buttons must be switched OFF while driving.



LEGEND

- 1. Main battery button
- 2. Turns on auxiliary power. (Required for the powering the Bed, TV etc)
- 3. Enables the lighting
- 4. Turns on the water pump (Not required if connected to city water)
- 5. Checks the water tank levels
- 6. Grey water tank
- 7. Fresh water tank
- 8. Check the 12v battery power levels
- 9. The house battery
- 10. The car battery
- 11. Light indicating that external 240v electricity is operational

Electric bed

In the unfortunate event that the bed has stopped working please follow these 3 steps.

Step 1 - House Power Enabled

First check that button 1 and 2 on the Battery and Water Control Panel are turned on.

Step 2 - Electrical Cable Connectors

Secondary, check that the electrical cables that hang down on the inside of the storage hatch on the left rear side are properly connected. It's easy to accidentally knock them out when removing the camping chairs and other large objects.

Step 3 - Fuse Box

If the cables are properly connected, the next place to check is the fuse box that is located under the passenger couch behind the driver seat. There is a Spare Fuses Kit inside the storage hatch at the rear on the right side (where the water hoses are stored).

Manual Operation

According to the electric bed manual, there is an option for manual operation of the bed. It is a two-man job and it seem to be a complicated procedure. **Do not attempt this without first contacting the owner or Camplify support.**