CET 241: Day 2

Dr. Noori KIM

Agenda

- Review: Hardware overview Generalized computer organization
- Programmer's model for ARM emphasizing on CPU register (i.e., Data structures, size, Core registers...):
- Outside of CPU: Memories and Memory map
- Software processing overview: Program execution flow - ARM ISA, assembling brief


- Computer parts: C__, M____, I/_, B___ - CPU or processor: • C_____ • A • R – Memory: • D (i.e., RAM, volatile) • P (i.e., ROM, non-volatile)
 - Bus: collection of signals (wires)
 - D___ (Read/write data from RAM or I/O, fetch opcodes from RAM),
 - I_____ (Fetch opcodes from ROM)

- I/O ports: physical connections between the computer and the world
 - Information enters (I ports) and exits (O ports)
 - A port: a collection of pins which can be used for either input or output
 - A pin: a place of input or output where an actual signal is connected to the microcontroller
- I/O interfaces
 - Hardware components (external to the computer, the input port) + software
 - All together perform the I/O function.

Computer Architecture


Von-Neumann

Instructions and data are stored in the same memory.




Harvard

Data and instructions are stored into separate memories.



A side bar: ARM Cortex-M Series Family





Programmer's model for ARM emphasizing on CPU register (i.e., Data structures, size, Core registers...):


A programmer's model: People program based on the given hardware/software structure and rules.

Programmer's model (for ARM)-Brief

- Data Sizes and Instruction Sets
 - The ARM is a 32-bit architecture.
 - -1 Byte = 8 bits, 1 Word = 32 bits ...
- Most ARM's implement two instruction sets
 - 32-bit ARM Instruction Set
 - 16-bit Thumb Instruction Set
 - Or Thumb 2
- Processor Modes
 - The ARM has seven basic operating modes, we are using User mode
- Registers use details








We have talked about this MCU ARM chip.
Registers are located inside of this chip

Registers?

- What are they?
 - Small but the fastest, a kind of "memory" in the
 CPU chip
 - Temporal storage spaces for computing
- How fast (in general)?
 - More than 100 times fasters than RAM
 - 10 times than cache
 - (ROM? Not worthy to be mentioned i.t.o. speed)
- Base components for manufacturing?
 - Mostly, (D) flip-flop

A very important component

An oversimplified description of a D flip-flop




- How many core registers?
 - Depending on a chip, but not many (countable)
- When we categorize 32-bits MCU or 16-bits MCU


http://www.mouser.sg/Semiconductors/Embedded-Processors-Controllers/Microcontrollers-MCU/_/N-a85i8



 It refers to the size of registers and buses, or word size


Ex) Cortex-M4's core register structure





PC: address of the **nex**t instruction to be fetched from the memory

Cortex-M4: State Register (SR)




PSR - PROGRAM STATUS REGISTER, COMBINATION OF

- APPLICATION PSR
- INTERRUPT PSR, AND
- EXECUTION PSR

Q – SATURATION BIT
ICI – INTERRUPT CONTINUABLE INSTRUCTION
IT – IF/THEN INSTRUCTION BLOCK

Condition bits are directly tested in Assembly language (flags)

Condition Code Bits		<u>Indicates</u>	
N	negative	Result is negative	
Z	zero	Result is zero	
V	overflow	Signed overflow	
C	carry	Unsigned overflow	




Outside of CPU: How does CPU access peripherals? → Memories and Memory map structure

Examples of I/O Devices

Device	Input/Output		Date Rate (Kbytes/s)
Keyboard			0.01
Mouse			0.02
Microphone			0.02
Scanner			200
Speaker			0.5
Laser printer			100
Graphics display			30,000
Local area network			200 – 20,000
Optical disk			500
Magnetic tape			2,000
Magnetic disk			2,000


I/O Configurations (1 of 2)

Keyboard Core (CPU) Mouse Voice input (microphone) Scanner **Provides** Voice output (speaker) I/O modules interfaces between Dot-matrix printer **CPU** and memory Pins Laser printer CPU and I/O devices **Graphics display** I/O devices By means of peripheral Local area network I/O registers Optical disk Magnetic tape Magnetic disk




- Vol2, page 76
- Vol1, page 145
- LaunchPadUsersManual.pdf page 20

J1 and J2 provide compatability with
Booster Packs designed for MSP430 Launchpad
J3 and J4 sit 100 mils inside J1 and J2 to provide
extended functions specific to this board.




I/O Configurations (2 of 2)



Basic concepts of I/O


- Input signal mapping
 - Zero volt to logic level false (0)
 - 3.3 volt to logic level true (1)
- Output signal mapping: same
- Four types of I/O interfaces
 - Parallel: a bunch of bits at the same time
 - Serial: one bit at a time on a single line
 - Time: data are encoded as a period, freq, pulse width, or phase shift
 - Analog: data are decoded as an electrical voltage, current, or power
- We focus on the Parallel interface: GPIO ports

Recap: Decoder, Flip-flops, Adder, subtractor.... (logic gate implementations) You have a breadboard and many IC chips



+5V (power) 0V (GND)

*MCU is just a tiny bread board *You can make a MCU if you have a Singapore size breadboard



+5V (power) 0V (GND)

Types of I/O modules


- Two possibilities
 - Memory-mapped I/O
 - I/O-mapped I/O


I/O-Mapped I/O

- Memory and I/O...
 - Occupy different "spaces"
 - Are accessed by unique instructions
- Differentiated by instructions
 - i.e.,8086

```
IN AL, 19H ;8-bits are saved to AL from I/O port 19H. IN EAX, DX ;32-bits are saved to EAX. OUT BX, EAX ;32-bits are written to port DX from EAX. OUT 19H, AX ;16-bits are written to I/O port 0019H.
```

Memory Maps (I/O mapped I/O)






+5V (power) 0V (GND)


Memory-Mapped I/O

- Memory and I/O...
 - reside in the same "space"
 - are accessed in the same manner
- Differentiated only by their addresses

Memory Map (Memory-Mapped I/O)




A simplest view of memory




Memory map: TM4C123

- Memory map is arranged as a series of "locations"
 - e.g. the memory location at address
 0x080001B0 contains the byte value 0x70,
 i.e., 112
- The number of locations in memory is limited
 - e.g. 4 GB of RAM, 1 Gigabyte (GB) = 2^{30} bytes
 - -2^{32} locations → 4,294,967,296 locations!
- Address is represented with 32-bit size
 - 0x00000000 (the lowest memory location.)
 - OxFFFFFFFF (the highest memory location)
- Byte addressable memory:
 - A unique address for each byte
 - Each location holds 8 bits of information




Little/Big Endian: ways to store data



ENDIANESS:

- BIG ENDIAN MSB STORED IN SMALLEST ADDRESS
- LITTLE ENDIAN LSB STORED IN SMALLEST ADDRESS

Little endian memory access




LE/BE examples

Figure out followings:

- 1. The number of bytes (or bits) to store each of the following variables;
- 2. How the variables are stored for both big and little Endian;
- char x = -120;
 short x = 0x82BA;
 int x[2];
 x[0] = 0x9381DC7E;
 x[1] = 0x274B1A9D;

Input/Output: TM4C123



- 6 General-Purpose I/O (GPIO) ports:
- Four 8-bit ports(A, B, C, D)
- One 6-bit port (E)
- One 5-bit port (F)

TM4C123 I/O Pins Characteristics

 Can be employed as an n-bit parallel interface: Set AFSEL to 0

– Pins also provide alternative functions (Set AFSEL to 1):

UART Universal Asynchronous Receiver/Transmitter

SSI Synchronous Serial Interface

• I²C Inter-Integrated Circuit

Timer Periodic interrupts, input capture, and output compare

PWM Pulse Width Modulation

ADC Analog to Digital Converter, measure analog signals

Analog Compare two analog signals comparator

QEI
 Quadrature Encoder Interface

USB Universal Serial Bus

• Ethernet High speed network

CAN Controller Area Network

- UART: used for serial, asynchronous, and simultaneous communication
- SSI or SPI (Serial peripheral interface): used for medium-speed I/O devices such as graphic display
- I²C: a simple I/O bus to interface low speed peripheral devices
- PWM: used to apply variable power to a motor interfaces or to create a DAC

- ADC: important in data acquisition systems and used to measure the amplitude of analog signals.
- USB: a high speed serial communication channel
- Ethernet: used to bridge the MCU to the Internet or a local area network.
- CAN: creates a high-speed communication channel between microcontrollers

Software processing overview (brief)

- What is a C program?
 - Simply just a text file




- Contains only human readable characters
- Can be opened with notepad
- Computer stores characters via ASCII code mapping
 - Every character is represented by bits

A heart of computers (the generalization of computing process)

- 1. Fetch: instructions
 - From memory into CU
- 2. Decode: split instructions
 - Opcode, Operand..
 - Pass values to ALU
- $\mathsf{ALU} \operatorname{\mathsf{--}} \mathsf{--} \mathsf{--}$
 - (4. Write back)

Three-state pipeline: Fetch, Decode, Execution (Cortex-M3)


- Pipelining allows hardware resources to be fully utilized
- One 32-bit instruction or two 16-bit instructions can be fetched.




Pipeline of 32-bit instructions

Levels of Program Code

C Program



Assembly Program



Machine Program

Assemble

High-level language

- Level of abstraction closer to problem domain
- Provides for productivity and portability

Assembly language

Textual representation of instructions

Hardware representation

- Binary digits (bits)
- Encoded instructions and data

C Code

```
int main(void){
   int a = 0;
   int b = 1;
   int c;
   c = a + b;
   return 0;
}
```

compiler

Assembly Code

```
MOVS r1, #0x00 ; int a = 0

MOVS r2, #0x01 ; int b = 1

ADDS r3, r1, r2 ; c = a + b

MOVS r0, 0x00 ; set return value

BX lr ; return
```

Machine Code


```
In Binary
```

```
2100
2201
188B
2000
4770
```


```
; MOVS r1, #0x00
; MOVS r2, #0x01
; ADDS r3, r1, r2
; MOVS r0, #0x00
; BX lr
```

In Hex

In short, the C program execution flow



Each process requires F-D-E process



- 1. Fetch instructions
- 2. Decode via ISA
- 3. Execute
- (4. Write back)

Instruction Set Architecture: ISA

Machine language	Assembly language
Encoding 0's and 1's: binary	Writing in textual form
Copy the value from "Register 9" into "Register 3."	
1110 0001 1010 0000 0011 0000 0000 1001	MOV R3, R9
Assembler	

ISA: The design of the machine language encoding