

Cooler Master HAF 700 EVO User Manual



Quick Links

[Installation](#)

Table of Contents

[Installation](#)

[Remove side panels](#)

[Install power supply](#)

[Adjust angle](#)

[WARRANTY](#)


[Other ManualsLib Projects](#)



Make It Yours.

HAF 700 EVO

USER MANUAL



User manual / English

Инструкция за експлоатация / Български

安装说明 / 简体中文

安裝說明 / 繁體中文

Handuch / Deutsch

Manual de Usuario / Español

Manuel de l'utilisateur / Français

Manuale d'uso / Italiano

ユーザーズマニュアル / 日本語

Handleiding / Nederlands

Instrukcja Użytkownika / Polski

CONTENTS

Package Content	2
Front I/O & Buttons	3
Compatibility	3
Suggested builds	4
1 Remove side panels	6
2 Install power supply	6
3 Install motherboard	7
4 Install GPU	8
5 Install 3.5" drives	11
6 Install 2.5" drives	14
7 Install case fans and radiators	16
8 Pump Installation	20
9 Install Infinity Mirror	22
10 Connect IRIS display and ARGB Gen 2 controller	24
11 Cable Management	25
12 Cleaning dust filters	27
13 Completing installation	28
Warranty information	29


Net Weight		24.7kg / 54.5lb
Available Color		Titanium Grey, Black
Materials		Exterior: Mesh, Steel, Plastic Left Side Panel: Tempered Glass, Steel, Plastic
Dimensions (LxWxH)		666 x 291 x 626mm / 26.22 x 11.46 x 24.65inch
Motherboard Support		Mini-ITX, Micro-ATX, ATX, E-ATX, SSI-CEB, SSI-EEB
Expansion Slots		8
Drive Bays	2.5"/3.5"	12 (4*HDD bracket, 8*Screw+Rubber)
I/O Port		USB3.2 Gen2 x 1 USB3.2 Gen1(3.0) x 4 3.5mm Headset Jack (Audio+Mic) x 1 3.5mm Mic Jack x 1
Pre-installed Fan(s)	Front	200mm PWM Fan x 2 (Speed: 1000RPM / Connector: 4Pin PWM)
	Rear	120mm PWM ARGB Fan x 2 (Speed: 1800RPM / Connector: 4Pin PWM)
	Bottom radiator bracket	120mm PWM ARGB Fan x 1 (Speed: 1800RPM / Connector: 4Pin PWM)
Fan Support	Top	2x200mm / 3x140mm / 6x120mm (remove 480mm radiator bracket)
	Front	2x200mm
	Front radiator bracket	3x140mm / 3x120mm (remove drive/pump bracket)
	Rear	2x120mm
	Bottom radiator bracket	3x140mm / 3x120mm
	MB Tray / side mount	3x140mm / 4x120mm (remove tempered glass mirror)
Liquid Cooling Support	Front radiator bracket	120mm, 140mm, 240mm, 280mm, 360mm, 420mm
	Top	2x120mm/240mm/360mm, 1x140mm/280mm
	Rear	120mm, 140mm
	Bottom radiator bracket	120mm, 140mm, 240mm, 280mm, 360mm, 420mm
	MB Tray / side mount	120mm, 140mm, 240mm, 280mm, 360mm, 420mm, 480mm (remove Tempered glass mirror)
Clearances	CPU Cooler	166mm
	GPU	490mm
Power Supply Support		ATX PSU

Package Content / 包装内含物品清单 / 包装内含物品明细 / Verpackungsinhalt / Contenido del paquete / Contenu de l'emballage / Contenuto della confezione / Szczegółowa zawartość paczki / Inbgrepen / Содержание упаковки / パッケージ内容

	Figure	Name	Q'ty	Used for
1		#6-32*6mm screw	23	Motherboard & other
2		#6-32*10mm screw	4	Installing 3.5" HDD
3		M3*4mm screw	16	SSD / locking in SSD pockets
4		HDD screw	32	Installing 3.5" drives and Tempered glass mirror toollessly
5		SSD screw	32	Installing SSD toollessly
6		Stand-off	3	Motherboard tray mATX/SSI-EEB
7		Stand-off socket	1	Motherboard stand-off installation
8		φ5*10mm screw	12	Installing fans
9		φ3*7mm screw	1	Locking Add-in cards with screw
10		Cleaning Cloth	1	Cleaning glass
11		Cable Tie	10	Cable management
12		Velcro Tie	3	Cable management
13		Universal Vertical Graphics Card Holder Kit V2 (PCIe4.0)	1	For mounting Graphics card vertically
14		Drive / Pump Bracket	1	Installing 3.5" HDD/SSD/Pump


- [EN]** Front I/O & Buttons
- [CHS]** 前面板接口及按键说明
- [CHT]** 前面板接口及按键說明
- [DE]** Front I/O & Tasten
- [ES]** Frontal I/O & Botones
- [FR]** Boutons sur le panneau E/S de façade

- [IT]** Pulsanti e I/O frontali
- [JP]** フロントI/O パネル
- [NL]** Bedieningspaneel
- [PL]** Przedni panel I/O & Przyciski
- [RU]** Фронтальные кнопки и панель ввода/вывода




- [EN]** Compatibility
- [CHS]** 兼容性
- [CHT]** 相容性
- [DE]** Kompatibilität
- [ES]** Compatibilidad
- [FR]** Compatibilité



- [IT]** Compatibilità
- [JP]** パーツ互換性
- [NL]** Compatibiliteit
- [PL]** Zgodność
- [RU]** Совместимость



Maximum height for CPU cooler




Maximum length for Graphics card




- EN** Suggested builds
- CHS** 建议配置
- CHT** 建議配置
- DE** Empfohlene Layouts
- ES** Layouts recomendados
- FR** Dispositions recommandées

- IT** Layout Consigliati
- JP** お薦めの配置
- NL** Voorbeeld configuraties
- PL** Rekomendowane Layouts
- RU** Рекомендуемые планировки

A Stock layout recommended for horizontal GPU




B Recommended layout for vertical GPU




C

Recommended single radiator position




D

Maximum liquid cooling build




E

Mirror water tank



F

Angle mirror GPU






Installation Guide

組装说明 / 組装説明 / Installationsanleitung / Guía para la instalación / Guide d'installation / Guida per l'installazione /
Installatie-instructies / Instrukcja instalacji / Руководство пользователя / 製品の使い方

1 Remove side panels

- CHS 移除側板
CHT 移除側板
DE So entfernen Sie das Seitenpanel
ES Como extraer el panel lateral
FR Comment retirer le panneau latéral





- IT Come rimuovere il pannello laterale
JP サイドパネルの取り外し方法
NL Verwijderen van het zijpaneel
PL Jak zdjąć pokrywę boczną
RU Как снять боковую панель



2 Install power supply

- CHS 安裝電源
CHT 安裝電源
DE So installieren Sie das Netzteil
ES Como instalar la fuente de alimentación
FR Comment installer l'alimentation

- IT Come installare l'alimentatore
JP 電源ユニットの取り付け方法
NL Installeren van de voeding
PL Jak podłączyć zasilanie
RU Как установить блок питания



3 Install motherboard

CHS 安装主板

CHT 安裝主機板

DE So installieren Sie das Motherboard

ES Como instalar la placa base

FR Comment installer la carte mère

IT Come installare la motherboard



JP マザーボードの取り付け方法

NL Installeren van het moederbord



PL Jak zamontować płytę główną

RU Как установить материнскую плату

A Installing ATX motherboard



B Installing SSI-EEB motherboard



*For other motherboard sizes please refer to motherboard manual.

4 Install GPU

[CHS] 安裝显卡

[CHT] 安裝顯示卡

[DE] So installieren Sie Erweiterungskarten

[ES] Como instalar tarjetas adicionales

[FR] Comment installer les cartes supplémentaires

[IT] Come installare le schede aggiuntive





[JP] 拡張カードの取り付け方法

[NL] Installeren van de extra kaarten



[PL] Jak podłączyć karty rozszerzeń







[RU] Как установить карты расширения

A Regular position



B Vertical GPU Holder









For locking with screws


5 Install 3.5" drives

- CHS 安装3.5"装置
 CHT 安装3.5"装置
 DE So installieren Sie 3,5 Zoll Geräte
 ES Como instalar los dispositivos de 3.5"
 FR Comment installer les périphériques 3.5 pouces

- IT Come installare le unità da 3.5"
 JP 3.5インチデバイス (HDDなど) の取り付け方法
 NL Installeren van de 3.5" apparaten
 PL Jak zamontować urządzenia 3.5 "
 RU Как установить 3,5" устройства


A In drive cage

A5



x 4

A6




[OPTIONAL]

For locking




A7




B On cable cover

B1




**TOOL
LESS**





B2




C On drive / pump bracket

C1






Available positions



Available positions









6 Install 2.5" drives

- [CHS] 安裝2.5"裝置
- [CHT] 安裝2.5"裝置
- [DE] So installieren Sie 2,5 Zoll Geräte
- [ES] Como instalar los dispositivos de 2.5"
- [FR] Comment installer les périphériques 2.5 pouces



- [IT] Come installare le unità da 2.5"
- [JP] 2.5インチデバイス (SSDなど) の取り付け方法
- [NL] Installeren van de 2.5" apparaten
- [PL] Jak zamontować urządzenia 2.5"
- [RU] Как установить 2,5" устройства

A In drive cage








B On cable cover



C On drive / pump bracket




C3




Available positions

C5




C4



Available positions

C6



7 Install case fans and radiators

CHS 安装风扇和水冷排

CHT 安裝風扇和水冷排

DE So installieren Sie Lüfter und Radiatoren

ES Como instalar ventiladores de caja y radiadores

FR Comment installer les ventilateurs et radiateurs

IT Come Installare ventole e radiatori







JP ケースファンとラジエーターの取り付け方法

NL Installeren van de ventilatoren en radiatoren


PL Jak zamontować wentylatory i radiatory

RU Как установить корпусные вентиляторы и радиаторы


A Rotatable radiator bracket




A6 Flip over




A7




A8



A9



A10




Adjust angle




Available positions

A11



B Install 480mm radiator


B1



Fan: 4 x 120mm/3 x 140mm
Radiators: 240/280/360/420/480mm


C Install 240/280mm radiator

C1A



240/280mm


C1B



240/280mm


D Install rear radiator

D1



120mm


D2






240mm

E Install top radiator

E1






8 Pump Installation

- [CHS]** 水泵安装指南
- [CHT]** 幫浦安裝指南
- [DE]** Pump enmontage
- [ES]** Instalación de la bomba
- [FR]** Installation d'une pompe

- [IT]** Installazione Pompa
- [JP]** ポンプインストール
- [NL]** Pomp Installatie
- [PL]** Montaż pompy
- [RU]** Установка насоса


A Perpendicular installation

A1




Drive / Pump bracket


A2



A3




A4




Available positions

A5




B Parallel installation


B1a




B1b



B2




B3



Available positions







B4



9 Install Infinity Mirror

- CHS 安装无限魔镜
- CHT 安裝無限魔鏡
- DE Einbau von Innenspiegeln
- ES Instalación de espejos interiores
- FR Installation des rétroviseurs intérieurs

- IT Installazione specchio interno
- JP インフィニティミラーを取り付けます
- NL Installeer Gehard glazen spiegel
- PL Montaż lusterek wewnętrznych
- RU Установка внутреннего зеркала



10 Connect IRIS display and ARGB Gen 2 controller

[CHS] 连接IRIS显示助理与二代ARGB控制器

[CHT] 連接IRIS顯示助理與二代ARGB控制器

[DE] Anschluss von IRIS-Displays und ARGB Gen2-Controllern

[ES] Conexión de pantallas IRIS y controladores ARGB Gen2

[FR] Connexion des écrans IRIS et des contrôleurs ARGB Gen2

[IT] Connettere display IRIS e controller ARGB Gen2





[JP] IRIS ディスプレイとARGB Gen2のコントローラーを接続します



[NL] Verbind IRIS display en ARGB gen 2 controller

[PL] Podłączanie wyświetlaczy IRIS i kontrolerów ARGB Gen2


[RU] Подключение дисплеев IRIS и контроллеров ARGB Gen2

A Fan/ARGB Hub



B ARGB Controller Gen2**B2**

* Max. 5 ARGB devices per port

B3

Download Master Plus :
<https://masterplus.coolermaster.com>




Master Plus software for controlling ARGB gen 2 lighting and Iris LCD display.

11 Cable management


CHS	线缆整理
CHT	線纜整理
DE	Kabel-management
ES	Gestión de cable
FR	Gestion des câbles

IT	Cable Management
JP	配線収納
NL	Kabel management
PL	Zarządzanie kablami
RU	Кабель менеджмент


1




2




3




4



5



6





12. Cleaning dust filters



CHS	清洁防尘滤网
CHT	清潔防塵濾網
DE	Filterreinigung
ES	Limpieza de filtros
FR	Nettoyage des filtres

IT	Pulizia dei filtri
JP	クリーニングダストフィルター
NL	Stof filters schoonmaken
PL	Czyszczenie filtra
RU	Очистка фильтра


A Bottom dust filter



B Front dust filter




B3




D Top panel fine mesh

D1



C Side panel filters

C1



13 Completing installation

- CHS** 完成組裝
- CHT** 完成組裝
- DE** So schliessen Sie die Installation ab
- ES** Completar la instalación
- FR** Terminer l'installation

- IT** Completamento dell'installazione
- JP** 完成図
- NL** Installatie voltooid
- PL** Kończenie instalacji
- RU** Завершение сборки

WARRANTY INFORMATION

English (EN)

Cooler Master guarantees that this device is free of defect in material and workmanship, and provides a two-year limited hardware warranty for the device commencing from the date of purchase. Please keep your receipt for proof of purchase. This product is designed for computer usage only. Using this device in any other capacity voids the warranty. If you are not familiar with computer hardware installation, please ask for professional assistance.

The warranty offered covers normal use. Defect or damage that result from improper operation, storage, misuse or abuse, accident or neglect, which are not the fault of Cooler Master, are excluded from warranty coverage.

Note: the warranty is voided by removal or alternation of product or parts identification labels.

- *All OEM/bulk packaging product come with one year limited warranty
- *In case of conflict between the warranty provided by the country of point of sale and this manual, the warranty of the actual country of point of sale shall be the prevailing document.
- *In case of malfunction of electronic components or need of accessories purchase during the warranty period, please return to the original store of purchase.

Türkçe (TR)

Cooler Master bu cihazda malzeme ve işçilik hatası bulunmadığını garanti eder ve cihaz için satın alma tarihinden başlı ayan iki yıla sınırlı bir donanım garantisi verir. Alımı belgelemek için lütfen makbuzunuzu saklayın. Bu ürün yalnızca bilgisayar kullanımı için tasarlanmıştır. Bu cihazın başka bir kapsamda kullanılması garantiyi geçersiz kılar. Bilgisayar donanımı montajını bilmiyorsanız, lütfen profesyonel yardım talep edin.

Verilen garanti normal kullanım içindir. Cooler Master'ın hatası olmayan uygunsuz kullanım, depolama, yanlış kullanım veya kötü kullanım, kaza ya da ihmalden kaynaklanan arıza ya da hasarlar garanti kapsamının dışındadır. Dikkat: Ürün ya da parça tanıma etiketlerinin sökülmesi ya da değiştirilmesi garantiyi geçersiz kılar.

- * Tüm OEM/ambalajsız ürünler bir yıl sınırlı garanti ile gelir
- * Garanti verilen ülkedeki satış noktası ve bu kullanma
- * kılavuzu arasında bir çelişki olursa, satış noktasının bulunduğu ülkedeki garanti hükümleri öncelik taşır. Elektronik bileşenlerin arızalanması ya da garanti süresinde aksesuarların satın alınması gerekirse, lütfen ürünü satın aldığınız mağazaya başvurunuz.

简体中文 (ZHS)

Cooler Master 保证本设备之材质及功能无瑕疵，并提供本设备二年之硬件有限保固服务，自购买日算起。请把您的收据放在安全之处，以免 Cooler Master 要求您提供本证明。本产品专为计算机设计。一旦将本设备用于其它用途，则保固无效。若您不熟悉硬件安装程序，请寻求专家之协助。保固服务仅适用于正常使用下之故障情形。若本公司发现设备毁损之原因为滥用、改造、误用、疏忽、电压供应错误、空气及水污染意外和自然灾害，则保固无效。

注意：重贴或条形码遭毁损而无法辨识保固期限者，则不在此限。

- *所有 OEM 及工业包装的产品皆保固一年。
- *如果销售国家所提供的保固与本说明互有冲突时，应以实际销售国家之保固为准。
- *保固期内遇有电子零件故障或配件购买需求，请洽原购买商店。

繁體中文 (ZHT)

Cooler Master 保證本設備之材質及做工無瑕疵，並提供本設備二年之硬體有限保固服務，自購買日算起。請把您的收據放在安全之處，以免 Cooler Master 要求您提供本證明。本產品專為電腦設計。一旦將本設備用於其他用途，則保固無效。若您不熟悉硬體安裝程式，請尋求專家之協助。保固服務僅適用於正常使用下之故障情形。若本公司發現設備毀損之原因為濫用、改造、誤用、疏忽、電壓供應錯誤、空氣及水污染意外和自然災害，則保固無效。

注意: 重貼或條碼遭毀損而無法辨識保固期限者，則不在此限。

*所有 OEM 及工業包裝的產品皆保固一年。

*如果銷售國家所提供的保固與本說明互有衝突時，應以實際銷售國家之保固為準。

*保固期內遇有電子零件故障或配件購買需求，請洽原購買商店。

部件名稱	有毒有害物質或元素					
	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 [Cr(VI)]	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
機箱組	×	○	○	○	○	○
面板組	×	○	○	○	○	○
I/O 模組	×	○	○	○	○	○
風扇	×	○	○	○	○	○
零件包	×	○	○	○	○	○
電源	×	○	○	○	○	○
本表格依據 SJ/T 11364 的規定編制。 ○: 表示該有害物質在該部件所有均質材料中的含量均在 GB/T 26572 規定的限量要求以下。 ×: 表示該有害物質至少在該部件的某一均質材料中的含量超出 GB/T 26572 規定的限量要求。						

Note: The form is only applied to China law.

Cooler Master Products: Limited Warranty

This document describes the warranty terms for all Cooler Master product sold in Australia

For Australia only:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. (Cooler Master Technology Inc., 7F., No. 398, Xinhua 1st Rd., Neihu Dist., Taipei City 114065, Taiwan (R.O.C.).)

Telephone: +886-2-2225-3517 (standard international call charges apply.)

Who the Warranty Protects:

This Warranty is valid to the original purchaser only.

What the warranty protects:

This warranty is valid only for the Cooler Master Products distributed by authorized dealer(s) in Australia. Please contact Cooler Master for warranty information and services:

• Cooler Master Support: account.coolermaster.com

What Is and Is Not Covered

It is important to note that our warranty is not an unconditional guarantee for the duration of the Program. Any replaced parts become the property of Cooler Master. The Program does not apply to the software component of a product or a product which has been damaged due to accident, misuse, abuse, improper installation, usage not in accordance with product specifications and instructions, natural or personal disaster, or unauthorized alterations, repairs or modifications.

The Program does not cover any events such as below:

• Any damages unrelated to manufacturing defects.

• Any unsuitable environment or use of the product in Cooler Master Opinion.

• Any product which has been modified without official permission from Cooler Master, or on which the serial number or warranty sticker has been defaced, modified, or removed.

Damage, deterioration or malfunction resulting from:

• Accident, abuse, misuse, neglect, fire, water, lightning, or other acts of nature, commercial or industrial use, unauthorized product modification or failure to follow instructions included with the product.

• Third party products using Cooler Master Components will not be covered by warranty. See your vendor or the manufacturer for information about servicing.

• Repair or attempted repair by anyone not authorized by Cooler Master, Inc.

- Any shipment damages (claims must be made with the carrier).
- Unauthorized repairs to a Cooler Master product will void the warranty offered by the Program. Cooler Master reserves the right to refuse to service any product which has been altered, modified or repaired by non-Cooler Master Service personnel.
- Cooler Master does not warrant that this product will meet your requirements. It is your responsibility to determine the suitability of this product for your purpose.
- Removal or installation charges.
- You are responsible for the cost of shipping the product to Cooler Master. Cooler Master pays the cost of returning a product to you.
- Cooler Master reserves the right to replace the product with a service product at their sole discretion at any time.
- Product malfunction or damage resulting from liquids or moisture.
- All accessories that malfunction due to physical damage such as: USB cables, extension cables, adapter cables, adapters, power cords, screws, retention brackets, ear cups, and all other similar accessories.

Limitation of implied warranties:

THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, WHICH EXTEND BEYOND THE DESCRIPTION CONTAINED HEREIN INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Exclusion of damages

COOLER MASTER'S LIABILITY IS LIMITED TO THE COST OF REPAIR OR REPLACEMENT OF THE PRODUCT. COOLER MASTER SHALL NOT BE LIABLE FOR:

- DAMAGE TO OTHER PROPERTY CAUSED BY ANY DEFECT IN THE PRODUCT, DAMAGES BASED UPON INCONVENIENCE, LOSS OF USE OF THE PRODUCT, LOSS OF TIME, LOSS OF PROFITS, LOSS OF BUSINESS OPPORTUNITY, LOSS OF GOODWILL, INTERFERENCE WITH BUSINESS RELATIONSHIPS OR OTHER COMMERCIAL LOSS, EVEN IF ADVISED OF THEIR POSSIBILITY OF SUCH DAMAGES.
- ANY OTHER DAMAGES, WHETHER INCIDENTAL, CONSEQUENTIAL OR OTHERWISE
- ANY CLAIM AGAINST THE CUSTOMER BY ANY OTHER PARTY

Warranty Information:

If the goods is found with reasonable defect within the period of (refer to Table A,) starting on the first day of purchase (with proof of invoice), this is what you must do, to claim the warranty from the above address.

Procedures:

1. Consumers should return to the shop where he/she has bought the goods. After confirming with the shop with a valid invoice, they may approach the distributor for RMA claim.
2. After confirmed by the distributor that the goods was damaged due to natural causes, replacement and repair will be done by distributor (including brand new or refurbished goods)
3. All faulty goods must return to the distributor, expenses for returning the faulty goods will be covered by the consumer, and distributor will cover the cost involved in the transporting of parts or repaired goods to the consumer.

Regarding all the expenses incurred in making the claim, and this is how you would claim:

1. Within the valid warranty date, starting from the first day of issuing invoice, Retail shops will assist in confirmation with distributor for the consumer for the following.

A. If the damage was caused by the consumer, then the consumer should cover all expenses in fixing the product, if the product still can't be fixed, we would suggest consumer in buying a brand new product.

B. Product defect caused under natural use, expenses will be covered by the distributor.

2. Faulty products with expired warranty dates, we would suggest consumer to purchase a brand new products, without undergoing for repairs.

Table A:

Cooler Master Products

Please check your user manual for the exact warranty period terms for products that are not shown below.

For more warranty information, please visit our official website: <http://www.coolermaster.com/service/warranty.html>

Chassis

Product Name	Warranty Term
All Chassis Series (Only Electronic Parts)	2 year
C+P (Chassis + PSU)	1 year

- (EN) Limited warranty period: <http://www.coolermaster.com/service/warranty.html>
- (AR) المحدود الضمان فترة : <http://www.coolermaster.com/service/warranty.html>
- (BG) Период на ограничена гаранция: <http://www.coolermaster.com/service/warranty.html>
- (CS) Období omezené záruky: <http://www.coolermaster.com/service/warranty.html>
- (DA) Begrænset garanti: <http://www.coolermaster.com/service/warranty.html>
- (DE) Beschränkter Garantiezeitraum: <http://www.coolermaster.com/service/warranty.html>
- (EL) Περίοδος περιορισμένης εγγύησης: <http://www.coolermaster.com/service/warranty.html>
- (ES) Periodo de garantía limitada: <http://www.coolermaster.com/service/warranty.html>
- (FA) مدت زمان گارانتی : <http://www.coolermaster.com/service/warranty.html>
- (FI) Rajoitettu takuujakso: <http://www.coolermaster.com/service/warranty.html>
- (FR) Période de garantie limitée: <http://www.coolermaster.com/service/warranty.html>
- (HU) Korlátozott jótállási időszak: <http://www.coolermaster.com/service/warranty.html>
- (HR) Razdoblje ograničenog jamstva: <http://www.coolermaster.com/service/warranty.html>
- (ID) Masa garansi terbatas: <http://www.coolermaster.com/service/warranty.html>
- (IT) Periodo di garanzia limitata: <http://www.coolermaster.com/service/warranty.html>
- (JA) 限定保証期間 : <http://www.coolermaster.com/service/warranty.html>
- (KO) 제한 보증 기간 : <http://www.coolermaster.com/service/warranty.html>
- (KK) Кенілдік мерзімі: <http://www.coolermaster.com/service/warranty.html>
- (NL) Beperkte garantieperiode: <http://www.coolermaster.com/service/warranty.html>
- (NO) Garantiperiode begrenset garanti: <http://www.coolermaster.com/service/warranty.html>
- (PL) Okres ograniczonej gwarancji: <http://www.coolermaster.com/service/warranty.html>
- (PT) Período de garantia limitada: <http://www.coolermaster.com/service/warranty.html>
- (RU) Ограниченный гарантийный срок: <http://www.coolermaster.com/service/warranty.html>
- (SR) Period ograničene garancije: <http://www.coolermaster.com/service/warranty.html>
- (SV) Begränsad garantiperiod: <http://www.coolermaster.com/service/warranty.html>
- (TR) Sınırlı garanti süresi: <http://www.coolermaster.com/service/warranty.html>
- (UK) Обмежений гарантійний термін: <http://www.coolermaster.com/service/warranty.html>
- (ZHT) 有限保固期間 : <http://www.coolermaster.com/service/warranty.html>



Make It Yours.

Asia Pacific - Cooler Master Technology Inc.
7F., No. 398, Xinhua 1st Rd., Neihu Dist., Taipei
City 114065, Taiwan (R.O.C.)
Tel: +886-2-2225-3517

China - Cooler Master China
Room 112, Building 9, No. 327, Songjin Road, Jinshanwei Town,
Jinshan Dist., Shanghai City, China
Tel: +86-21-51872177

Europe - Cooler Master Europe B.V.
Lodewijkstraat 1b, 5652AC Eindhoven, The Netherlands
Tel: +31-(0)40-702-0900

North America - Cooler Master NA
1 N Indian Hill Blvd Suite D200 Claremont, CA 91711 USA
Tel: +1-888-624-5099

South America
E-mail: Soporte_Latam@coolermaster.com.tw



Product Page and Manual
Visit Product Page for information,
manual and other downloads



Technical Support
Just visit: account.coolermaster.com

512004921-GP Ver 2.0: 2022/02 

The color and specification are subject to be changed without further notification.
Please visit our website for updated information: www.coolermaster.com

©2022 Cooler Master Technology Inc. All Rights Reserved. All trademarks are registered to their respective owners.

Other ManualsLib Projects

 www.manualslib.com

 www.manualslib.de

 www.manualslib.es

 www.manualslib.fr

 www.manualslib.nl

 www.manualslib.mx

 www.manualslib.tech 30+ Languages