Lecture 21: Process modeling & balance laws

- Process modeling, structure and methodology
- Balance laws
 - Mass balances
 - Mass balances for multi-component systems

Book: 10.4, 11.1-11.4

What are process modeling and balance laws used for?







Process modeling & balance laws:

- Basically, modeling of anything that changes in the physical world.
- In this context, we will be concerned with fluids (liquids and gas) in (chemical) process systems




Autoignition of hydrogen in a turbulent hot air coflow

Process modeling: Structure and methodology

- Goal of process modeling: Construct mathematical models of the process under study.
- These mathematical models consists of process variables (variables and parameters) and the equations that link these

Process



Process variables

(variables and parameters)

- Level
 - Variability: Variable
 - Symbol: h
 - Value: 1.1
 - Unit: m
 - ..
- Area
 - Variability: Parameter
 - Symbol: A
 - Value: 2.2
 - Unit: m²
 - ..
- •

Process equations

$$\frac{\mathrm{d}h}{\mathrm{d}t} = \frac{1}{A} (q_i - q_o)$$
$$q_o = C\sqrt{p - p_0}$$
$$p = p_0 + \rho g h$$

Number of equations must match number of (unknown) variables.

Process equations

- Balance laws
 - Mass
 - Momentum
 - Energy
 - ...

- Constitutive equations
 - For (generalized) flows
 - Thermodynamic equations of state
 (e.g. ideal gas law)
 - Phenomenological relationships (e.g. between friction force and flow in a pipe)
 - ..

- Constraints
 - Geometric relationships
 - Equilibrium conditions
 - ..

Also called «closure relations» as they «close» the balance laws (such that #equations = #variables)

Example Tank:

$$\frac{\mathrm{d}h}{\mathrm{d}t} = \frac{1}{A} \left(q_i - q_o \right)$$

$$q_o = C\sqrt{p - p_0}$$
$$p = p_0 + \rho g h$$

$$V = Ah$$

Process variables

- Thermodynamic state variables
 - Mass, pressures, levels, ...
 - Velocities
 - Temperatures
 - ...

- (Generalized) flows
 - Transport (single phase)
 - Exchange (between phases)
 - Sources (reactions)
 - ...

- Phenomenological coefficients
 - Viscosity
 - Reaction rates
 - Valve constants
 - ..


- Geometric dimensions
 - Lengths,Areas,Volumes
 - ...

Example Tank:


$$h, \rho, p, p_0$$


$$q_i, q_o$$


$$\frac{\mathrm{d}h}{\mathrm{d}t} = \frac{1}{A} (q_i - q_o)$$
$$q_o = C\sqrt{p - p_0}$$
$$p = p_0 + \rho g h$$



Example: Tank







BALANCE LAWS

Physical balance principles are based on

Conservation laws

That a physical property is *conserved*, means that it will remain constant in a closed system


The following physical quantities are conserved:

- Mass
- Energy
- Momentum (norsk: impuls)
 - Linear and angular

No one has ever observed that conservation laws have been violated

Conservation laws are <u>exact laws</u>

The basic physical principles



Consider a volume consisting of a fixed number of fluid particles, with total mass m, total momentum \vec{p} and total energy E. From basic physics (conservation laws), we know the following principles hold:

Conservation of mass (mass balance):

$$\frac{\mathrm{d}m}{\mathrm{d}t} = 0$$

Newton's second law (momentum balance)

$$\frac{{}^{i}\mathrm{d}\vec{p}}{\mathrm{d}t} = \vec{F}$$

Also holds for angular momentum, $\vec{h} = \vec{r} \times \vec{p}$:

$$\frac{^{i}\mathbf{d}}{\mathbf{d}t}\vec{h} = \vec{r} \times \vec{F} = \vec{T}$$

• First law of thermodynamics (conservation of energy, energy balance):

Rate of heat flowing into volume

Rate of heat flowing into volume from surroundings $\frac{\mathrm{d}E}{\mathrm{d}t} = \dot{Q} - \dot{W}$ Rate at which work is done by the

body at surroundings

State variables for process systems

- What variables are relevant as state variable(s) for balance laws based on conservation of mass (that is, mass balances)?
 - Mass
 - Density
 - Moles, and mole concentration
 - Derived quantities: Pressure, level, ...
 - (number of particles, etc.)
- For energy balances:
 - Internal energy
 - Temperature
- For momentum balances
 - Linear or angular momentum
 - Velocities


Extensive and intensive properties

- We must choose properties (thermodynamic variables) to describe our process, and these are either *intensive* or *extensive*
- Intensive properties are scale invariant (does not change if we divide a volume in two), while extensive variables are proportional to amount of material
- In this course, we use mostly *mass-intensive* properties/variables (that is, we measure amount of material with mass):

Extensive properties	Symbol	Unit	Intensive properties	Symbol	Unit
mass	m	kg	1	-	-
volume	V	m³	specific volume	v	m³/kg
internal energy	U	J	specific internal energy	u	J/kg
enthalpy	H	J	specific enthalpy	h	J/kg
entropy	S	J/K	Specific entropy	s	J/K/kg


- What alternatives are there to mass-intensive?
- Is temperature an intensive or extensive property? Pressure? (yes and no...)

P-h-diagram for water



The concept of control volume

- We use a control volume for separating what we are interested in from the rest of the world (surroundings)
- Generally, material flow into (or out of) the control volume, across the surface



Extensive Property B of one particle

$$dB = \rho(\mathbf{x})\beta(\mathbf{x}, t)dV$$

Summed over all particles in ${\cal V}_c(t)$

$$B = \iiint_{V_c(t)} \rho(\mathbf{x}) \beta(\mathbf{x}, t) dV$$

- We are interested in
 - knowing how the extensive property B varies inside the control volume
 - **or** (equivalently?) how the intensive property $\beta(\mathbf{x},t)$ varies inside the volume
- Control volumes can move or change shape, but we will assume they are fixed (more on this in fluid mechanics)

Lumped vs distributed modeling

 If we do *lumped modeling*, we assume that intensive properties are constant (or averaged) over the control volume


$$B = \iiint_{V_c} \rho \beta(\mathbf{x}) dV = \iiint_{V_c} \rho \bar{\beta} dV = \bar{\beta} \iiint_{V_c} \rho dV = m\bar{\beta}$$

- The balance laws used for lumped modeling are the *integral* (or macroscopic) balance laws
 - Formulated for extensive (e.g. mass), or averaged intensive (e.g. average temperature), variables
- The alternative to lumped modeling is *distributed* modeling, where we are interested in how $\beta(\mathbf{x},t)$ varies as a function of position \boldsymbol{x}
- The balance laws for distributed modeling are the differential balance laws

(This course: Mainly lumped modeling and integral balance laws)

The balance laws

Assume a fixed control volume (of arbitrary size and shape),
 where fluid flows across the control volume




The general integral (macroscopic) balance law for B is

$$\frac{\mathrm{d}}{\mathrm{d}t}B = \left\{ \begin{array}{c} \text{transfer of } B \text{ through} \\ \text{surface } \partial V_c \text{ by} \\ \text{fluid flow (convection)} \end{array} \right\} + \left\{ \begin{array}{c} \text{other effects that} \\ \text{transfer } B \text{ into } V_c \\ \text{(indep. of fluid flow)} \end{array} \right\}$$

The balance laws

Mass balance (without reactions/phase transfer)

$$\frac{\mathrm{d}}{\mathrm{d}t}m = \left\{ \begin{array}{c} \text{transfer of mass into} \\ V_c \text{ by fluid flow} \\ \text{across surface } \partial V_c \end{array} \right\}$$



Momentum (note: momentum is a vector)

$$\frac{\mathrm{d}}{\mathrm{d}t}\mathbf{p} = \left\{ \begin{array}{c} \text{transfer of momentum into} \\ V_c \text{ by fluid flow} \\ \text{across surface } \partial V_c \end{array} \right\} + \left\{ \begin{array}{c} \text{generation of momentum} \\ \text{in } V_c \text{ due to forces} \\ \text{acting on } V_c \end{array} \right\}$$

Energy

$$\frac{\mathrm{d}}{\mathrm{d}t}E = \left\{ \begin{array}{c} \text{transfer of energy into} \\ V_c \text{ by fluid flow} \\ \text{across surface } \partial V_c \end{array} \right\} + \left\{ \begin{array}{c} \text{transfer of energy into} \\ V_c \text{ by heat transfer} \\ \text{and by work} \end{array} \right\}$$

Mathematical formulation of convection

$$\frac{\mathrm{d}}{\mathrm{d}t}B = \left\{ \begin{array}{l} \text{transfer of } B \text{ through} \\ \text{surface } \partial V_c \text{ by} \\ \text{fluid flow (convection)} \end{array} \right\} + \left\{ \begin{array}{l} \text{other effects that} \\ \text{transfer } B \text{ into } V_c \\ \text{(indep. of fluid flow)} \end{array} \right\}$$
$$- \iint_{\partial V_c} \rho \beta \vec{v} \cdot \vec{n} \mathrm{d}A$$

(draw blackboard)

Mathematical formulation of mass balance

• For mass, the intensive variable is $\beta(\mathbf{x},t)=1$

$$B = \iiint_{V_c} \rho \beta dV$$

$$\frac{\mathrm{d}}{\mathrm{d}t}m = \left\{ \begin{array}{c} \text{transfer of mass into} \\ V_c \text{ by fluid flow} \\ \text{across surface } \partial V_c \end{array} \right\}$$

$$-\iint_{\partial V_c} \rho \beta \vec{v} \cdot \vec{n} \mathrm{d}A$$

$$\frac{\mathrm{d}}{\mathrm{d}t}m = \frac{\mathrm{d}}{\mathrm{d}t} \iiint_{V_c} \rho \mathrm{d}V = -\iint_{\partial V_c} \rho \vec{v} \cdot \vec{n} \mathrm{d}A$$

- (Example: Flow in pipe)
- Often, we have one (or more) «point inflows» $w_{\text{in},i}$, and outflows $w_{\text{out},i}$. Then mass balance can be formulated as

$$\frac{\mathrm{d}}{\mathrm{d}t}m = \sum_{i} w_{\mathrm{in},i} - \sum_{i} w_{\mathrm{out},i}$$

(Example: Tank)

Mass-type balance laws with generation

- Assume B is an extensive variable «equivalent to» mass
 - that is, mass of a component in a volume, or number of molecules of a component, number of particles, etc.
- These types of mass balance laws can have *internal generation*:

$$\frac{\mathrm{d}}{\mathrm{d}t}B = \sum_{i} W_{\mathrm{in},i} - \sum_{i} W_{\mathrm{out},i} + W_{\mathrm{generated}}$$

• More generally, if the local rate of generation of B is r_B :

$$\frac{\mathrm{d}}{\mathrm{d}t}B = \frac{\mathrm{d}}{\mathrm{d}t} \iiint_{V_c} \rho \beta \mathrm{d}V = -\iint_{\partial V_c} \rho \beta \vec{v} \cdot \vec{n} \mathrm{d}A + \iiint_{V_c} r_B \mathrm{d}V$$

(Notes on multi-component systems)

Next time

- Momentum and energy balances
- Closure relations
- Distributed process modeling: Differential balance laws