

AN216783

WICED ANCS Library

Associated Part Family: CYW20706, CYW20735, CYW20719

WICED™ Studio 4

To get the latest version of this application note, please visit www.cypress.com/AN216783

This document describes the WICED Apple Notification Center Service (ANCS) library that can be used in WICED applications to access ANCS functionality in iOS devices via Bluetooth Low Energy (BLE) links.

Contents

1	Introduction1	5.9 ANCS Stop Complete Callback	4
2	IoT Resources1	5.10 ANCS Client Connection Up	4
3	Design and Architecture1	5.11 ANCS Client Connection Down	5
4	ANCS Application and ANCS Library2	5.12 ANCS Client Write Response	5
5	Library Reference2	5.13 ANCS Notification Callback	5
	5.1 ANCS Client Initialize2	5.14 ANCS Perform Action	5
	5.2 ANCS Client Discover2	6 References	6
	5.3 ANCS Discovery Complete Callback	Document History	7
	5.4 ANCS Client Discovery Result3	Worldwide Sales and Design Support	8
	5.5 ANCS Client Discovery Complete3	Products	8
	5.6 ANCS Client Start3	PSoC® Solutions	8
	5.7 ANCS Start Complete Callback4	Cypress Developer Community	8
	5.8 ANCS Client Stop4	Technical Support	8

1 Introduction

This document describes the functionality of the WICED ANCS library that can be used in various applications. The library can be used to utilize the functionality of the Apple Notification Center Service [2] running on an iOS device. The document provides information on how the library can be accessed to discover characteristics of the ANCS service, how to register to receive notifications, process notifications and send commands to the iOS device for positive or negative action for control. It is assumed that the reader is familiar with the Bluetooth Core Specification [1].

2 IoT Resources

Cypress provides a wealth of data at http://www.cypress.com/internet-things-iot to help you to select the right IoT device for your design, and quickly and effectively integrate the device into your design. Cypress provides customer access to a wide range of information, including technical documentation, schematic diagrams, product bill of materials, PCB layout information, and software updates. Customers can acquire technical documentation and software from the Cypress Support Community website (http://community.cypress.com/).

3 Design and Architecture

WICED Studio provides 'ancs' and 'watch' sample applications that utilize the functionality of the WICED ANCS library. While the applications themselves provide generic WICED application functionality, they use the WICED ANCS library to access the ANCS service on the iOS device over the Bluetooth Low Energy (BLE) GATT profile.

4 ANCS Application and ANCS Library

The WICED Studio 'ancs' sample application together with the WICED ANCS library provides an implementation of the ANCS client protocol to access the ANCS service on an iOS device.

The application typically performs in a GAP peripheral role. At startup, it advertises as a peripheral device and allows an iOS device to connect. The application shall call the **wiced_bt_ancs_client_connection_up** and the **wiced_bt_ancs_client_connection_down** functions to notify the library about the connection state.

When a connection is established, the application performs the GATT discovery of the primary services of the connected device. If the application finds the ANCS service, it instructs the library to perform the discovery of the characteristics and descriptors of the ANCS service by calling the <code>wiced_bt_ancs_client_discover</code> function. When the discovery is completed, the library executes the <code>wiced_bt_ancs_discovery_complete_callback</code> function, passing the status of the discovery operation. During the discovery process, the application should pass the discovery result and discovery complete events to the library using the <code>wiced_bt_ancs_client_discovery_result</code> and the <code>wiced_bt_ancs_client_discovery_complete</code> function calls.

The application can instruct the library to start using the ANCS service by calling the wiced_bt_ancs_client_start function. At that time, the library registers with the iOS device to receive various notifications. Similarly, the application can deregister from the ANCS service on the iOS device by calling the wiced_bt_ancs_client_stop function. The results of the registration and deregistration are passed back to the application using wiced_bt_ancs_start_complete_callback and wiced_bt_ancs_stop_complete_callback functions.

While the library is performing the discovery or registrations with the iOS device, the application should not send any GATT requests to the iOS device on its own. Similarly, the application should not try to initialize two or more libraries at the same time.

Notifications received by the application on the handles that belong to the ANCS service should be forwarded to the ANCS library for processing. The library talks to the ANCS server on the iOS device to extract information and concludes by calling the application with the full ANCS notification event using wiced_bt_ancs_notification_callback.

The ANCS notification event includes the titles of ANCS positive and negative actions. For example, when the iOS device forwards the notification about an incoming call, the positive action will be to answer the call and the negative action will be to decline. The application can call **wiced_bt_ancs_perform_action** to perform selected actions, as demonstrated in the WICED Studio 'ancs' application.

5 Library Reference

5.1 ANCS Client Initialize

The application should call this function to register application callbacks.

Prototype

void wiced_bt_ancs_client_initialize (wiced_bt_ancs_reg_t *p_reg)

Parameters

p_reg : Registration control block that includes ANCS application callbacks.

Returns

none

5.2 ANCS Client Discover

The application should call this function when it discovers that a connected central device contains the ANCS service. The function initializes the ANCS library and starts the GATT discovery of ANCS characteristics.

After the application starts the discovery and until it receives the discovery complete callback (see Section 5.3), it shall pass the discovery results (see Section 5.4) and discovery complete events (see Section 5.5) to the library.

Prototype

wiced_bool_t wiced_bt_ancs_client_discover (uint16_t conn_id, uint16_t s_handle, uint16_t e_handle)

Parameters

conn_id : GATT connection ID.

s_handle: Start GATT handle of the ANCS service.e handle: End GATT handle of the ANCS service.

Returns

WICED_TRUE if the library started discovery successfully; WICED_FALSE otherwise.

5.3 ANCS Discovery Complete Callback

This callback is executed when the ANCS library completes the discovery of the ANCS service characteristics and descriptors.

Prototype

typedef void(* wiced_bt_ancs_discovery_complete_callback_t) (uint16_t conn_id, wiced_bool_t
success)

Parameters

conn id : GATT connection ID.

status : WICED_TRUE if initialization completed successfully; WICED_FALSE otherwise.

Returns

none

5.4 ANCS Client Discovery Result

While the library performs the GATT discovery, the application shall pass the discovery results received from the stack to the ANCS library. The library must locate all the characteristics that belong to the ANCS service and associated client characteristic configuration descriptors.

Prototype

void wiced bt ancs client discovery result (wiced bt gatt discovery result t *p data)

Parameters

p_data : Discovery result data as passed from the stack.

Returns

none

5.5 ANCS Client Discovery Complete

While the library performs the GATT discovery, the application shall pass the discovery complete callbacks to the ANCS library. As the GATT discovery consists of multiple steps, this function initiates the next discovery request or write request to configure the ANCS service on the iOS device.

Prototype

void wiced bt ancs client discovery complete(wiced bt gatt discovery complete t *p data)

Parameters

p_data : Discovery complete data as passed from the stack.

Returns

none

5.6 ANCS Client Start

The application calls this function to start an ANCS client. The GATT discovery should be completed before this function is called. The start function configures the ANCS server on the iOS device for notification and configuration information that the client wants to monitor.

Prototype

wiced_bool_t wiced_bt_ancs_client_start (uint16_t conn_id)

Parameters

conn_id : GATT connection ID.

Returns

WICED_TRUE if the operation has been initiated successfully; WICED_FALSE otherwise.

5.7 ANCS Start Complete Callback

This callback is executed when the ANCS library completes a startup operation of the ANCS.

Prototype

typedef void (*wiced_bt_ancs_start_complete_callback_t) (uint16_t conn_id, wiced_bool_t
success)

Parameters

conn id : GATT connection ID.

status : WICED_TRUE if initialization completed successfully; WICED_FALSE otherwise.

Returns

none

5.8 ANCS Client Stop

The application calls this function to deregister with the ANCS server on the iOS device.

Prototype

wiced_bool_t wiced_bt_ancs_client_start (uint16_t conn_id)

Parameters

conn id : GATT connection ID.

Returns

WICED_TRUE if the operation has been initiated successfully; WICED_FALSE otherwise.

5.9 ANCS Stop Complete Callback

This callback is executed when the ANCS library completes the deregistration with the ANCS server on the iOS device.

Prototype

typedef void (*wiced_bt_ancs_stop_complete_callback_t) (uint16_t conn_id, wiced_bool_t
success)

Parameters

conn id : GATT connection ID.

status : WICED_TRUE if operation completed successfully; WICED_FALSE otherwise.

Returns

none

5.10 ANCS Client Connection Up

The application should call this function when a BLE connection with a peer device has been established.

Prototype

void wiced_bt_ancs_client_connection_up (wiced_bt_gatt_connection_status_t *p_conn_status)

Parameters

p_conn_status : pointer to a GATT connection status structure that includes the address and connection ID.

Returns

none

5.11 ANCS Client Connection Down

The application should call this function when a BLE connection with a peer device has been disconnected.

Prototype

void wiced_bt_ancs_client_connection_down (wiced_bt_gatt_connection_status_t *p_conn_status)

Parameters

p conn status : pointer to a GATT connection status structure that includes the address and connection ID.

Returns

none

5.12 ANCS Client Write Response

The application should call this function when it receives a GATT Write Response for an attribute handle that belongs to the ANCS service.

Prototype

void wiced_bt_ancs_client_write_rsp (wiced_bt_gatt_operation_complete_t *p_data)

Parameters

p data : Pointer to a GATT operation complete data structure.

Returns

none

5.13 ANCS Notification Callback

The ANCS library executes this callback when it receives a complete notification from the iOS device with a new ANCS event.

Prototype

typedef void (*wiced_bt_ancs_notification_callback_t) (uint16_t conn_id, ancs_event_t event)

Parameters

conn_id : GATT connection ID.
event : Received ANCS event.

Returns

none

5.14 ANCS Perform Action

The application calls this function to send the command to the iOS device to perform a specified action. The action command (for example: answer the call, or clear notification), is sent as a response to a notification. The UID of the notification is passed back in this function along with the action ID.

Prototype

wiced_bt_gatt_status_t wiced_bt_ancs_perform_action (uint16_t conn_id, uint32_t uid, uint32_t
action id)

Parameters

conn_id : GATT connection ID.

: Unique ID of the notification that the action is in response to.

action id : Positive or negative action ID.

Returns

WICED_TRUE if action command is successfully passed to the iOS device; WICED_FALSE otherwise.

6 References

- [1] Bluetooth Core Specification, Version 4.2 (see Bluetooth Core Specification 4.2)
- [2] Apple Notification Center Service (ANCS) Specification. (See Apple Notification Center Service)





Document History

Document Title: AN216783 - WICED ANCS Library

Document Number: 002-16783

Revision	Submission Date	Description of Change
*A	01/12/2017	Updated for template and formatting - Preliminary
**	10/12/2016	Initial release - Preliminary



Worldwide Sales and Design Support

Cypress maintains a worldwide network of offices, solution centers, manufacturer's representatives, and distributors. To find the office closest to you, visit us at Cypress Locations.

Products

ARM® Cortex® Microcontrollers cypress.com/arm

Automotive cypress.com/automotive

Clocks & Buffers cypress.com/clocks
Interface cypress.com/interface

Internet of Things cypress.com/iot

Memory cypress.com/memory

Microcontrollers cypress.com/mcu

PSoC cypress.com/psoc

Power Management ICs cypress.com/pmic
Touch Sensing cypress.com/touch

USB Controllers cypress.com/usb

Wireless Connectivity cypress.com/wireless

PSoC® Solutions

PSoC 1 | PSoC 3 | PSoC 4 | PSoC 5LP

Cypress Developer Community

Forums | WICED IOT Forums | Projects | Videos | Blogs | Training | Components

Technical Support

cypress.com/support

All other trademarks or registered trademarks referenced herein are the property of their respective owners.



Cypress Semiconductor 198 Champion Court San Jose, CA 95134-1709

© Cypress Semiconductor Corporation, 2016. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.