Support Careers How To Buy Contact Us Sign In

PRODUCTS SOLUTIONS COMMUNITY RESOURCES FREE TRIALS

Documentation / FPGA Design / ... / Infrared Communic... / NEC Infrared Transmission Protocol

## **NEC Infrared Transmission Protocol**

Frozen Content Modified by on 13-Sep-2017



The NEC IR transmission protocol uses pulse distance encoding of the message bits. Each pulse burst (mark – RC transmitter ON) is 562.5µs in length, at a carrier frequency of 38kHz (26.3µs). Logical bits are transmitted as follows:

- Logical '0' a 562.5µs pulse burst followed by a 562.5µs space, with a total transmit time of 1.125ms
- Logical '1' a 562.5µs pulse burst followed by a 1.6875ms space, with a total transmit time of 2.25ms

When transmitting or receiving remote control codes using the NEC IR transmission protocol, the WB\_IRRC performs optimally when the carrier frequency (used for modulation/demodulation) is set to 38.222kHz.

When a key is pressed on the remote controller, the message transmitted consists of the following, in order:

- a 9ms leading pulse burst (16 times the pulse burst length used for a logical data bit)
- a 4.5ms space
- the 8-bit address for the receiving device
- the 8-bit logical inverse of the address
- the 8-bit command
- the 8-bit logical inverse of the command
- a final 562.5µs pulse burst to signify the end of message transmission.

The four bytes of data bits are each sent least significant bit first. Figure 1 illustrates the format of an NEC IR transmission frame, for an address of 00h (00000000b) and a command of ADh (10101101b).




Figure 1. Example message frame using the NEC IR transmission protocol.

Notice from Figure 1 that it takes:

- 27ms to transmit both the 16 bits for the address (address + inverse) and the 16 bits for the command (command + inverse). This comes from each of the 16 bit blocks ultimately containing eight '0's and eight '1's giving (8 \* 1.125ms) + (8 \* 2.25ms).
- 67.5ms to fully transmit the message frame (discounting the final 562.5µs pulse burst that signifies the end of message).

This sitREPEATOROBE Simprove your user experience and to provide you with content we believe will be of

interest to you. Detailed information if the eyon the remote controller is kept depressed, a repeat code will be issued, typically around 40ms after the pulse but shifted gnife ends be and of on the the message. A repeat code will continue to be sent out at 108ms intervals, until the key is in ally released. The repeat code consists of the following, in the use of our cookies.

ALTIUM DESIGNER FREE TRIAL

- a 9ms leading pulse burst
- · a 2.25ms space
- $\cdot$  a 562.5 $\mu$ s pulse burst to mark the end of the space (and hence end of the transmitted repeat code).

Figure 2 illustrates the transmission of two repeat codes after an initial message frame is sent.




Figure 2. Example repeat codes sent for a key held down on the transmitting remote controller.

Printer-friendly version PDF version

| COMPANY                  | PRODUCTS             | COMMUNITY          | RESOURCES                                                                               |          |
|--------------------------|----------------------|--------------------|-----------------------------------------------------------------------------------------|----------|
| About Altium             | Altium Designer      | Forum              | Documentation                                                                           |          |
| Our Customers            | CircuitMaker         | Blog               | Design Content                                                                          |          |
| Investor News            | CircuitStudio        | Bug Crunch         | Video Library                                                                           |          |
| Publications and Reports | Altium Subscription  | Beta Program       | Support                                                                                 |          |
| Investor Center          | TASKING              |                    | Downloads                                                                               |          |
| Partners and Alliances   | Altium DXP Developer | NEWSROOM           |                                                                                         |          |
| Newsroom                 | How To Buy           | Press Releases     | ALTIUM UNITED STATES                                                                    |          |
| SOLUTIONS                | CAREERS              | Altium in the News | Sales (United States)                                                                   |          |
|                          |                      | Media Contacts     | 1-800-544-4186 (toll free)<br>1-858-864-1798<br>sales.na@altium.com                     |          |
| By Role                  | Career at Altium     |                    |                                                                                         |          |
| By Industry              | Open Positions       |                    |                                                                                         |          |
| By Technology            |                      |                    | Support (United States) 1-800-488-0681 (toll free) 1-858-864-1797 support.na@altium.com |          |
|                          |                      |                    |                                                                                         |          |
|                          |                      |                    |                                                                                         |          |
|                          |                      |                    | suppor cha@attum.com                                                                    | 1        |
| You Tube                 | Linked in            | Google+ t          | witter                                                                                  | facebook |

Copyright © 2018 Altium LLC / Copyrights and Trademark / Privacy Policy / Cookie Policy / Terms of Use / End-User License Agreement / Legal Notice / Sitemap

This site uses cookies to improve your user experience and to provide you with content we believe will be of interest to you. Detailed information

on the use of cookies on this website is provided in our Privacy Policy. By using this website, you consent to the use of our cookies.

Ok, don't show me this again

ALTIUM DESIGNER FREE TRIAL