

# PICASO-SGC Command Set

## **Software Interface Specification**

Document Date: 28<sup>th</sup> March 2012

Document Revision: 11.0

**Note:** This manual applies to the PICASO-SGC Revision 21 PmmC files and above.

## **Table of Contents**

1.Host Interface	
1.1 Command Protocol : Flow Control	5
1.2 Power-up and Reset	5
1.3 Splash Screen on Power Up	6
1.4 Auto Run Memory Card Script Program	6
1.5 FAQs About PICASO-SGC	6
2. 4DSL Scripting Language	7
3. Command Set	8
3.1 General Commands	9
3.1.1 AutoBaud - 55hex	10
3.1.2 Set new Baud Rate - 51hex	11
3.1.3 Version-Device Info Request - 56hex	12
3.1.4 Display Resolution - 64hex	13
3.1.5 Replace Background Colour - 42hex	14
3.1.6 Clear Screen - 45hex	15
3.1.7 Display Control Functions - 59hex	16
3.1.8 Set Volume - 76hex	18
3.1.9 Sleep - 5Ahex	19
3.1.10 Read GPIO Pin - 69hex	20
3.1.11 Write to GPIO Pin - 79hex	21
3.1.12 Read GPIO Bus - 61hex	
3.1.13 Write to GPIO Bus - 57hex	23
3.2 Graphics Commands	
3.2.1 Add User Bitmap Character - 41hex	
3.2.2 Draw User Bitmap Character - 44hex	
3.2.3 Draw Circle - 43hex	
3.2.4 Draw Triangle - 47hex	
3.2.5 Draw Image-Icon - 49hex	
3.2.6 Set Background colour - 4Bhex	
3.2.7 Draw Line – 4Chex	
3.2.8 Draw Polygon - 67hex	
3.2.9 Draw Rectangle - 72hex	
3.2.10 Draw Ellipse - 65hex	
3.2.11 Draw Pixel - 50hex	
3.2.12 Read Pixel - 52hex	
3.2.13 Screen Copy-Paste - 63hex	
3.2.14 Replace Colour - 6Bhex	
3.2.15 Set Pen Size - 70hex	
3.3 Text Commands	
3.3.1 Set Font - 46hex	
3.3.2 Set Transparent-Opaque Text - 4Fhex	
3.3.3 Draw ASCII Character (text format) - 54hex	
3.3.4 Draw ASCII Character (graphics format) - 74hex.	
3.3.5 Draw "String" of ASCII Text (text format) - 73hex	
3.3.6 Draw "String" of ASCII Text (graphics format) - 53hex	
3.4 Touch Screen Commands	
3.4 IUUUI SUEEN CUIIIIIalius	48

3.4.1 Get Touch Coordinates - 6Fhex	49
3.4.2 Wait Until Touch - 77hex	50
3.4.3 Detect Touch Region – 75hex	51
3.5 SD Memory Card Commands (Low-Level/RAW)	52
3.5.1 Initialise Memory Card - @69hex	
3.5.2 Set Address Pointer of Card (RAW) - @41hex	
3.5.3 Read Byte Data from Card (RAW) - @72hex	
3.5.4 Write Byte Data to Card (RAW) - @77hex	
3.5.5 Read Sector Block Data from Card (RAW) - @52hex	
3.5.6 Write Sector Block Data to Card (RAW) - @57hex	
3.5.7 Screen Copy – Save to Card (RAW) - @43hex	
3.5.8 Display Image-Icon from Card (RAW) - @49hex (New Image Format)	
3.5.9 Display Image-Icon from Card (RAW) - @49hex (Old Image Format)	
3.5.10 Display Object from Card (RAW) - @4Fhex	
3.5.11 Display Video-Animation Clip from Card (RAW) - @56hex (New Image Format)	
3.5.12 Display Video-Animation Clip from Card (RAW) - @56hex (Old Image Format)	
3.5.13 Run Script (4DSL) Program from Card (RAW) - @50hex	
3.6 SD Memory Card Commands (FAT-Level/DOS)	
3.6.1 Initialise Memory Card - @69hex	
3.6.2 Read File from Card (FAT) - @61hex	
3.6.3 Write File to Card (FAT) - @74hex	
3.6.4 Erase File from Card (FAT) - @65hex	
3.6.5 List Directory of Card (FAT) - @64hex	
3.6.6 Screen Copy – Save to Card (FAT) - @63hex	
3.6.7 Open GCI (FAT) - @47hex	
3.6.8 Set GCI Entry (FAT) - @45hex	
3.6.9 Display Frame (FAT) - @46hex	
3.6.10 Display Image-Icon from Card (FAT) - @6Dhex	
3.6.11 Play Audio WAV file from Card (FAT) - @6Chex	
3.6.12 Run Script (4DSL) Program from Card (FAT) - @70hex	
4. 4DSL Script Specific Commands	
4.1 Script Control Commands (4DSL - Script Language)	
4.1.1 Delay - 07hex	
4.1.2 Set Counter - 08hex	88
4.1.3 Decrement Counter - 09hex	89
4.1.4 Jump to Card Address If Counter Not Zero - OAhex	
4.1.5 Jump to Card Address - OBhex	
4.1.6 Exit-Terminate Script Program - OChex	92
4.2 Directives (4DSL - Script Language)	
4.2.1 #Compile	
4.2.2 #define	95
4.2.3 #Include	96
4.2.4 #origin	97
4.2.5 #run	
4.3 Macros (4DSL - Script Language)	
4.3.1 \$4DGLLoadprogram	
4.3.2 \$LoadPmmC	
4.3.3 \$Message	
<u> </u>	

	4.3.4 \$ReadBytes	103
	4.3.5 \$ReadFATImage	104
	4.3.6 \$ReadFile	105
	4.3.7 \$ReadSectors	106
	4.3.8 \$ReaduSDImage	107
	4.3.9 \$StartSave	108
	4.3.10 \$WriteFile	109
	4.3.11 \$WriteSectors	110
	4.3.12 Extended Macros	111
	4.4 4DSL Keywords	112
	4.5 Summary List of Commands available for Scripting	114
5.	Appendix A: Development and Support Tools	117
	5.1 PmmC Loader – PmmC File Programming Software Tool	117
	5.2 microUSB – PmmC Programming Hardware Tool	117
	5.3 Display Initialisation Setup Personality (DISP) – Software Tool	118
	5.4 Graphics Composer – Software Tool	118
	5.5 FONT Tool – Software Tool	119
	5.6 FAT Controller – Software Test Tool	119
	5.7 RMPET – Software Tool	
	5.8 Evaluation Display Modules	121
6.	Appendix B: Using the FAT-Controller to Compose Script Programs	122
	6.1 Getting Started	
	6.2 Starting a Script	122
	6.3 Running the Script	122
	6.4 Running the .4ds Script Program from the Memory Card	
	6.5 Running the Auto-Run Script Slide Show	
	6.6 Running Graphics Composer GCI files from the Memory Card	
	roprietary Information	
Di	isclaimer of Warranties & Limitation of Liability	125

#### 1. Host Interface

The PICASO-SGC chip is a slave peripheral device and it provides a bidirectional serial interface to a host controller via its UART. All communications between the host and the device occur over this serial interface. The protocol is simple and easy to implement.



Serial Data Format: 8 Bits, No Parity, 1 Stop Bit. Serial data is true and not inverted.

#### 1.1 Command Protocol: Flow Control


The PICASO-SGC is a slave device and all communication and events must be initiated by the host. Each command is made up of a sequence of data bytes. When a command is sent to the device and the operation is completed, it will always return a response. For a command that has no specific response the device will send back a single acknowledge byte called the ACK (06hex), in the case of success, or NAK (15hex), in the case of failure.

Commands having specific responses may send back varying numbers of bytes, depending upon the command and response. It will take the device a certain amount of time to respond, depending on the command type and the operation that has to be performed. If the PICASO-SGC chip receives a command that it does not understand it will reply back with a negative acknowledge called the NAK (15hex). Since a command is only identified by its position in the sequence of data bytes sending incorrect data can result in wildly incorrect operation.

#### 1.2 Power-up and Reset

When the PICASO-SGC device comes out of a power up or external reset, a sequence of events must be observed before attempting to communicate with the module:

- Allow up to 500ms delay after power-up or reset for the PICASO-SGC to settle. Do not attempt to communicate with the device during this period. The device may send garbage on its TX Data line during this period, the host should disable its Rx Data reception.
  - **Note**: For applications that utilise memory cards with large capacity, allow up to 3 seconds for the card initialisation.
- The host must send the Auto-Baud command, capital 'U' (55hex), at 9600 baud and wait for an ACK (06hex) from the PICASO-SGC. The default baud rate of the PICASO-SGC is 9600 bps and the host must communicate initially with the device at this speed. The "Set new Baud-Rate" command can then be used to change to a different baud-rate if desired.
  - **Note**: Unlike the GOLDELOX-SGC, the PICASO-SGC does not have an Auto-Baud feature. To maintain compatibility, the Auto-Baud command must still be sent (at 9600 baud) for the PICASO-SGC.
- Once the host receives the ACK, the PICASO-SGC is now ready to accept commands from the host.



#### 1.3 Splash Screen on Power Up

The PICASO-SGC will wait up to 5 seconds with its screen blank for the host to transmit the Auto-Baud command ('U', 55hex). If the host has not transmitted the Auto-Baud command by the end of this period the PICASO-SGC will display a built-in splash screen. If the host has transmitted the Auto-Baud command, the screen will remain blank. This wait period is for those customer specific applications where the splash screen is undesired.

#### 1.4 Auto Run Memory Card Script Program

The PICASO-SGC has a feature that will auto run a preloaded script program on power-up. The PICASO-SGC device is equipped to accept memory cards and when using the FAT file system, upon power-up, if a 4DSL script program file called 'autoexec.4ds' exists on the memory card, the PICASO-SGC will automatically run this script program. This is a useful feature for those stand alone applications where the device does not require a host controller to send commands to the PICASO-SGC to play a slide show of images, video clips, etc.

The user will have to create and upload a slide show composition to the card to benefit from this auto play feature.

Refer to 'Section 4: Appendix B' at the end of this document for a quick guide to creating scripting files using the FAT-Controller software tool available from 4D Labs.

#### 1.5 FAQs About PICASO-SGC

**Note**: All the Frequently asked Questions about PICASO-SGC and related Display modules are available in the <u>FAQ section</u> of the Support Forum.

#### 2. 4DSL Scripting Language

The complete command set for the PICASO-SGC device is listed in section 3 of this document. The command execution is not only limited to the host sending these via the serial interface. The majority of them can be composed as a script and written into memory card. A 4DSL script program is a sequence of those commands that reside and can be executed from inside the memory card and these can be a combination of graphics, text, image, video and audio commands. Complete list of commands available for the scripting program is listed in section 4.

4DSL is a Scripting language developed to provide the SGC modules, which are labelled as Slave devices, some degree of independence. The syntax of the commands is simple and easy to use. 4DSL commands can be saved on the uSD card in the form of a File called 4DSL scripting file. The script files can be called from a host controller or they can be saved as autoexec.4DS file to run automatically on power up.

For quick start and slide show scripting FAT Controller can be used. However it doesn't provide a text editor to write a detailed script. 4D Workshop3 IDE or above are set to provide complete text editor to write a detailed 4DSL script. You can also test your script using the IDE while the module is connected to the PC via suitable interface.

4DSL command syntax or keywords are unique while the arguments are mostly the same as normal serial commands. Some of the commands can be run from the PC only which are named as Macros. They can be used for testing/debugging and to copy data to and from the SGC modules to enable field updating and or customisation..

Scripts can be run on a Windows PC from within the Workshop 3 IDE, or from the command prompt, thus they can be embedded within .BAT files to enable 'simple' use In the field.


**Note:** Details of Testing/Debugging a 4DSL Script using the 4D Workshop3 IDE is provided on the "4D-Workshop3-IDE-User-Guide-rev3.pdf" or above.

**Note**: The downloaded (<u>4D Workshop3 IDE</u>) setup application will create the required 4D-Workshop3 folders and install all the required files. Note that in-line with current Microsoft philosophy all the 4DSL sample Scripts and demos are located in the 'All Users\Shared Documents\4D Labs\Scripts' folder (XP) or 'Users\Public\Documents\4D Labs\Scripts' folder (Vista and Windows 7).

**Note**: The **4DSL Example** gives reference to the 4DSL sample scripts installed with the 4D Workshop3 IDE. Each script can be found in the folders as notified above.

#### 3. Command Set

The Serial command interface between the PICASO-SGC and the host is via the serial interface. Easy to learn commands provide complete access to all the available functions of the PICASO-SGC. The simplified command set also means that very low overheads are imposed on the host controller. Commands and responses can be either single bytes or many bytes. All commands return a response, either an acknowledge or data.



#### The command set is grouped into following sections:

- General Commands
- Graphics Commands
- Text Commands
- Touch Screen Commands
- SD Memory Card Commands (Low-Level/RAW)
- SD Memory Card Commands (FAT-Level/DOS)
- Script Control (4DSL Scripting Language) Commands

Each Command set is described in detail in the following sections. Syntaxes for a Serial as well as 4DSL command are provided followed by a Serial Example and reference to a 4DSL Example script.

Separation characters such as commas ',' or spaces ' ' or brackets'(' ')' between bytes that are shown in the command/response syntax descriptors are purely for legibility purposes and must not be considered as part of any transmitted/received data unless specifically stated.

#### 3.1 General Commands

#### **Summary of Commands in this section:**

- AutoBaud **55hex**
- Set new Baud-Rate **51hex**
- Version-Device Info Request **56hex**
- Display Resolution **64hex**
- Replace Background Colour **42hex**
- Clear Screen **45hex**
- Display Control Functions 59hex
- Set Volume **76hex**
- Sleep **5Ahex**
- Read GPIO Pin 61hex
- Write GPIO Pin 69hex
- Read GPIO Bus 79hex
- Write GPIO Bus **57hex**

#### **3.1.1** AutoBaud - 55hex

Serial Cmd	cmd	
4DSL Cmd	AutoBaud	
	cmd	<b>55</b> (hex) or <b>U</b> (ascii) : Command header byte
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte
Description	This must be the very first command sent to the PICASO-SGC (at 9600 baud) after power-up or reset.	
Serial Example	Command Data: 55hex Send Autobaud command.	
4DSL Example	Refer to the General.4DScript sample script file.	

#### 3.1.2 Set new Baud Rate - 51hex

C. 1.1.01		
Serial Cmd	cmd, rate	
4DSL Cmd	SetBaud(rate)	
	cmd	<b>51</b> (hex) or <b>Q</b> (ascii) : Command header byte
	rate	<b>00</b> hex : 110 Baud
		<b>01</b> hex : 300 Baud
		<b>02</b> hex : 600 Baud
		<b>03</b> hex : 1200 Baud
		<b>04</b> hex : 2400 Baud
		<b>05</b> hex : 4800 Baud
		<b>06</b> hex : 9600 Baud
		<b>07</b> hex : 14400 Baud
		<b>08</b> hex : 19200 Baud
		<b>09</b> hex : 31250 Baud
		<b>0A</b> hex : 38400 Baud
		<b>0B</b> hex : 56000 Baud
		<b>0C</b> hex : 57600 Baud
		<b>0D</b> hex : 115200 Baud
		<b>0E</b> hex : 128000 Baud (It is actually 129032Baud)
		OFhex: 256000 Baud (It is actually 282353Baud)
		<b>10hex</b> : 128000 Baud
		11hex: 256000 Baud
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if successful
		15(hex): NAK byte if unsuccessful
Description	This command	d changes the Baud-Rate on the fly.
Serial Example	Command Data:	
	51hex, 07hex	
	Change Baud	rate to 14400.
4DSL Example	Refer to the G	eneral.4DScript sample script file.

## **3.1.3** Version-Device Info Request - 56hex

Serial Cmd	cmd, Output	
4DSL Cmd	Version(Output)	
	cmd	<b>56</b> (hex) or <b>V</b> (ascii) : Command header byte
	Output	<b>00hex</b> : Outputs the version and device info to the serial port only. <b>01hex</b> : Outputs the version and device info to the serial port as well as to the screen.
Response	device_type, h	ardware_rev, firmware_rev, horizontal_res, vertical_res
	device_type	This response indicates the device type. <b>00hex</b> = micro-OLED. <b>01hex</b> = micro-LCD. <b>02hex</b> = micro-VGA.
	hardware_rev	This response indicates the device hardware version
	firmware_rev	This response indicates the device firmware version.
	horizontal_res	This response indicates the horizontal resolution of the display.  22hex: 220 pixels  28hex: 128 pixels  32hex: 320 pixels  60hex: 160 pixels  64hex: 64 pixels  76hex: 176 pixels  96hex: 96 pixels  FF hex: Unknown
	vertical_res	This response indicates the vertical resolution of the display. See horizontal_res above for resolution options.  22hex: 220 pixels  28hex: 128 pixels  32hex: 320 pixels  60hex: 160 pixels  64hex: 64 pixels  76hex: 176 pixels  96hex: 96 pixels  FF hex: Unknown
Description		d requests all the necessary information from the device about its
		and capability.
4DSL Example	Refer to the Ge	eneral.4DScript sample script file.

## **3.1.4** Display Resolution - 64hex

Serial Cmd	cmd			
4DSL Cmd	GetResolution			
	cmd	<b>64</b> (hex) or <b>d</b> (ascii) : Command header byte		
Response	x,y			
	x	X-Resolution of the display.		
	y Y-Resolution of the display.			
Description	This command returns the X and Y resolutions of the display.			
Serial Example	Command Data: 64hex Let's suppose the screen is 240x320 resolution.  Response: 0xF0, 0x140			
4DSL Example	Refer to the General.4DScript sample script file.			

## 3.1.5 Replace Background Colour - 42hex

Serial Cmd	cmd, colour(msb:lsb)	
4DSL Cmd	ReplaceBackground(colour)	
	cmd	42(hex) or B(ascii): Command header byte
	colour	2 bytes (16 bits) define the background colour in RGB format:  R4R3R2R1R0G5G4G3G2G1G0B4B3B2B1B0 where:  msb: R4R3R2R1R0G5G4G3  lsb: G2G1G0B4B3B2B1B0
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if operation successful <b>15</b> (hex) : NAK byte if unsuccessful
Description	This command changes the current background colour. Once this command is sent, only the background colour will change. Any other object on the screen with a different colour value will not be affected.	
Serial Example	Command Data:	
	42hex, FFhex	
	This example sets the background colour value to FFFFhex (White).	
4DSL Example	Refer to the General.4DScript sample script file.	

## 3.1.6 Clear Screen - 45hex

Serial Cmd	cmd	
4DSL Cmd	Clear	
	cmd	<b>45</b> (hex) or <b>E</b> (ascii) : Command header byte
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if successful
		15(hex): NAK byte if unsuccessful
Description	This command clears the entire screen using the current background colour	
Serial Example	Command Data: 45hex	
	Clear the screen.	
4DSL Example	Refer to the General.4DScript sample script file.	

#### 3.1.7 Display Control Functions - 59hex

Serial Cmd	cmd, mod	cmd, mode, value		
4DSL Cmd	Control(m	Control(mode, value)		
	cmd	<b>59</b> (hex) or <b>Y</b> (ascii) : Command header byte		
	mode	00hex : Backlight Control (Does not apply to uVGA-II)		
		value = 00hex : BACKLIGHT OFF		
		value = 01hex : BACKLIGHT ON		
		<b>01hex : Display ON/OFF</b> (Does not apply to uVGA-II)		
		value = 00hex : DISPLAY OFF		
		value = 01hex : DISPLAY ON		
		<b>02hex : Contrast Adjust</b> (Does not apply to uVGA-II)		
		value = 00hex – 0Fhex : CONTRAST RANGE		
		03hex : Display PowerUp-Shutdown (low power mode)		
		value = 00hex : DISPLAY SHUTDOWN		
		value = 01hex : DISPLAY POWERUP		
		04hex: Display Orientation (Does not apply to uVGA-II)		
		value = 01hex : 90 Degree rotation (LANDSCAPE if Native is Portrait)		
		value = 02hex : 270 Degree rotation (LANDSCAPE_R if Native is Portrait) value = 03hex : Native orientation		
		value = 04hex : 180 Degree rotation (PORTRAIT_R if Native is Portrait)		
		value - 0411ex : 100 Degree Totation (FORTIGATI_R II Native is Fortially		
		Note: The orientation command is effective for all graphics and text		
		functions except for images and video. For example, if the natural		
		orientation of the display is PORTRAIT and the orientation was set to		
		LANDSCAPE, images and video will remain in the PORTRAIT mode.		
		To achieve a true LANDSCAPE format display, the DISP software tool		
		must be used to set the proper display hardware parameters which is		
		then programmed into the PICASO-SGC. For some displays it is		
		necessary to change the PmmC		
		<b>05hex : Touch Control</b> (Does not apply to uVGA-II)		
		value = 00hex : Enable Touch Screen		
		value = 01hex : Disable Touch Screen		
		value = 02hex: Reset the Active region to the entire Screen		
		O6hex: Image Format (for @43hex and @49hex commands) value = 00hex: New Format, includes header (type2)		
		value = 01hex : Old Format, no header (type1)		
		08hex : Protect FAT		
		value = 01hex : PROTECT		
		value = 00hex : UNPROTECT		
		<b>Note:</b> This command protects the FAT file system (if present) on the card		
		from being read or written to by low level (RAW) commands. If the		
		memory card contains any FAT (FAT16 or FAT32) partition, when the		
		initialise command is executed or the device comes out of a reset, FAT		
		Protection is turned ON automatically. This means the host will not be		
		able to access the card using Low-Level (RAW) read or write commands		
		unless it subsequently turns off the FAT protection.		
		For a 'Non Standard' card containing two partitions, one FAT and one		

T		
	RAW (Partition type <b>DA</b> hex), the default is "PROTECT". In this case FAT	
	reads and writes will occur to the FAT partition and RAW reads and	
	writes will be offset into the RAW partition. i.e. a write to sector 0 will	
	write to sector 0 in the raw partition.	
	FAT32 is currently not supported. If you mount a FAT32 formatted disk,	
	you will not be able to access it at all, both FAT and RAW commands will	
	fail. You can either reformat the memory card as FAT or unprotect the	
	card and replace sector 0 with 512 hex 00s.	
	09hex : Display Page Select(Applies to uVGA-II only)	
	value = Depends on resolution selected.	
	e.g. value = 00hex to 04hex for 320x240 resolution	
	OAhex: Read Page Select (Applies to uVGA-II only)	
	value = Depends on resolution selected.	
	e.g. value = 00hex to 04hex for 320x240 resolution	
	OBhex: Write Page Select (Applies to uVGA-II only)	
	value = Depends on resolution selected.	
	e.g. value = 00hex to 04hex for 320x240 resolution	
	OChex: Screen Resolution (Applies to uVGA-II only)	
	value = 00hex : 320 x 240 resolution	
	value = 01hex : 640 x 480 resolution	
	value = 02hex : 800 x 480 resolution	
	value = XXhex : Custom resolution set through DISP tool	
	ODhex: Screen saver startup delay (Applies to uVGA-II only)	
	value = 00hex – FFhex :Value in seconds	
	OEhex: Screen Saver 'next line' delay (Applies to uVGA-II only)	
	value = 00hex – FFhex :Value in seconds	
	Note: On the uVGA-II pages start scrolling as soon as the Screen Saver	
	Startup Delay expires since the last command sent.	
valu	See mode description above.	
-	wledge	
ackr	wledge <b>06</b> (hex): ACK byte if successful	
	15(hex): NAK byte if unsuccessful	
<b>Description</b> This	ommand has multiple features. Refer to individual notes above.	
•	mand Data:	
59h	59hex, 00hex, 00hex	
Turr	the Backlights off.	
4DSL Example Refe	to the General.4DScript sample script file.	

#### **3.1.8** Set Volume - 76hex

Serial Cmd	cmd. volume	cmd, volume	
4DSL Cmd	-	Volume(volume)	
	cmd	<b>76</b> (hex) or <b>v</b> (ascii) : Command header byte	
	volume	Volume is in the range of 8 – 127 (08hex - 7Fhex)	
		08hex : Minimum Volume.	
		<b>7Fhex :</b> Maximum Volume.	
		Special Values:	
		00hex: Mute.	
		01hex : Volume Down 8.	
		03hex : Volume Down.	
		FDhex: Volume Up.	
		FEhex: Volume Up 8.	
		FFhex: Mute Off.	
Response	acknowledge		
	acknowledge	<b>06</b> (hex) : ACK byte if successful	
		15(hex): NAK byte if unsuccessful	
Description	This comman	d sets the volume level of the AUDIO pin output.	
Serial Example	Command Data:		
	76hex, FEhex Increase the volume up by 8 units.		
4DSL Example	Refer to the F	Refer to the FAT.4DScript sample script file.	

#### **3.1.9** Sleep - **5**Ahex

Serial Cmd	cmd, options	, sleep_time
4DSL Cmd	Sleep(option	s, sleep_time)
	cmd	<b>5A</b> (hex) or <b>Z</b> (ascii) : Command header byte
	options	<b>80</b> hex : Turn off uSD (must reinit manually) ( <i>Does not apply to uVGA-II</i> )
		<b>40</b> hex : Turn off Audio ( <i>Does not apply to uVGA-II</i> )
		(Automatically turns on when used)
		<b>20</b> hex : Turn off Touch ( <i>Does not apply to uVGA-II</i> )
		<b>08</b> hex : Wake-Up on P1 state change
		<b>04</b> hex : Wake-Up on P0 state change
		<b>02</b> hex : Wake-Up on Touch ( <i>Does not apply to uVGA-II</i> )
		<b>01</b> hex : Wake-Up on Serial
	sleep_time	1 byte sleep time in seconds:
		<b>0</b> : Sleep forever (wake up on P0 or P1 or RESET).
		1-255: Seconds to Sleep.
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte when wake-up on event
		15(hex): NAK byte if unsuccessful
Description	Puts parts of	the PICASO-SGC into a lower power state to conserve power and optionally
	waits for cer	tain conditions to wake it up. If it is desired to turn off the display then do
	this first usin	g "Display Control Functions - 59hex" command (mode 1 option).
Serial Example	Command D	ata:
	5Ahex, 04hex	x, 32hex
	Sleep for 50s	ec unless pin PO State changed.
4DSL Example	Refer to the O	General.4DScript sample script file.

#### **3.1.10** Read GPIO Pin - 69hex

Serial Cmd	cmd, pin	cmd, pin			
4DSL Cmd	ReadPin(pin)				
	cmd	<b>69</b> (hex) or <b>i</b> (ascii) : Command header byte			
	pin	Select one of P0 – P15 pins: <b>0 - 15</b> : P0 - P15			
Response	pin_status				
	pin_status	Returns 1 byte: <b>00</b> (hex): Pin is Low <b>01</b> (hex): Pin is High			
Description	Reads the state of the selected GPIO pin (P0-P15). Returns 0 or 1.				
Serial Example	Command Data: 69hex, OAhex Read GPIO pin P10				
4DSL Example	Refer to the	General.4DScript sample script file.			

#### 3.1.11 Write to GPIO Pin - 79hex

Serial Cmd	cmd, pin, value				
4DSL Cmd	WritePin(pin,	value)			
	cmd	<b>79</b> (hex) or <b>y</b> (ascii) : Command header byte			
	pin	Select one of P0 – P15 pins:			
		<b>0 - 15</b> : P0 - P15			
	value	0 : write Low to pin			
		1 : write High to pin			
Response	acknowledge	cknowledge			
	acknowledge	<b>06</b> (hex) : ACK byte if successful			
		15(hex): NAK byte if unsuccessful			
Description	Writes a LOW or HIGH to the specified GPIO pin (P0-P15).				
Serial Example	Command Data:				
	79hex, 0Chex	x, 00hex			
	Write Low to	pin P12			
4DSL Example	Refer to the G	General.4DScript sample script file.			

#### **3.1.12** Read GPIO Bus - 61hex

Serial Cmd	cmd			
4DSL Cmd	ReadBus			
	cmd	<b>61</b> (hex) or <b>a</b> (ascii) : Command header byte		
Response	bus_status			
	bus_status	Returns 1 byte BUSO-BUS7 status.		
Description	Reads the sta	Reads the state of the GPIO Bus (BUSO-BUS7 or P8-P15).		
Serial Example	Command D	ata:		
	61hex			
	Read GPIO B	us status.		
4DSL Example	Refer to the	General.4DScript sample script file.		

#### **3.1.13** Write to GPIO Bus - 57hex

Serial Cmd	cmd, value		
4DSL Cmd	WriteBus(valu	ue)	
	cmd	<b>57</b> (hex) or <b>W</b> (ascii) : Command header byte	
	value	1 byte value to write to GPIO Bus (BUSO-BUS7).	
Response	acknowledge		
		<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful	
Description	Writes a byte	to the GPIO Bus (BUSO-BUS1 or P8-P15).	
Serial Example	Command Data: 57hex, 56hex Write 01010110b or 56hex to the GPIO Bus.		
4DSL Example	Refer to the G	eneral.4DScript sample script file.	

#### **3.2** Graphics Commands

#### **Summary of Commands in this section:**

- Add User Bitmap Character **41hex**
- Draw User Bitmap Character **44hex**
- Draw Circle **43hex**
- Draw Triangle **47hex**
- Draw Image-Icon **49hex**
- Set Background colour 4Bhex
- Draw Line 4Chex
- Draw Polygon **67hex**
- Draw Rectangle **72hex**
- Draw Ellipse **65hex**
- Draw Pixel **50hex**
- Read Pixel 52hex
- Screen Copy-Paste 63hex
- Replace colour 6Bhex
- Set Pen Size 70hex

#### 3.2.1 Add User Bitmap Character - 41hex

Serial Cmd	cmd, group	o, cha	r_idx,	data	a1, d	ata2	, ,	data	N		
4DSL Cmd	AddUserBi	tmap	16(ch	ar_io	dx, d	ata1	, dat	a2,	, c	itaN) <i>(For 8x8 bitr</i> lataN) (For 16x16 lataN) <i>(For 32x32 l</i>	bitmap format)
	cmd	41	(hex)	or <b>A</b>	(asci	i) : C	omn	nand	he	ader byte	
	group	00 01	hex : hex :	sele sele	cts th	ne 8x ne 16	8 bit 6x16	map bitm	fo ap	ormat rmat format format	
	char_idx	0 t	:o 63 :o 15	( <b>00</b> h ( <b>00</b> h	ex to	3 <b>F</b> h 0 <b>F</b> h	ex): ex):	64 cł 16 cł	nara nara	acters of 16x16 for	at for group = <b>00</b> hex mat for group = <b>01</b> hex nat for group = <b>02</b> hex
	data1data	ma Th ma Th wh Th	apped e 8x8 akes N e 16x nich n	d cha 3 bitr N = 1 <16 k nake:	map x8 = oitma s N = oitma	com 8. ap co 2x1 ap co	positompo ompo 6 = 3 ompo	tion ositio	s 1 n i	byte wide (8bits) s 2 bytes wide (10	by 8 bytes deep which bits) by 16 bytes deep 2bits) by 32 bytes deep
Response	acknowled	lge									
	acknowled	-	(hex) (hex)							l	
Description	There are	3 diffe	rent	size l	bitm	aps a	availa	able,	8x8		to the internal memory. rmat and 32x32 format. in 'group'.
	b		b5	b4	b3	b2	b1	b0		← Data Bits	
										data1 (18hex)	
										data2 (24hex)	
										data3 (42hex)	
										data4 (81hex)	
										data5 (81hex)	
										data6 (42hex)	
										data7 (24hex)	
										data8 (18hex)	
	Exa	ample	of 8x	8 Us	er de	efine	d bit	tmap			J
Serial Example		nex, 01	Lhex,							ex, 81hex, 42hex, 2 pp 0) as character i	24hex, 18hex ndex 1 into memory.
4DSL Example	Refer to th									• •	
	1.0.0. to th	- J. ul		·-· ·			۲	2 301	٠,٢٠	•	

#### 3.2.2 Draw User Bitmap Character - 44hex

Serial Cmd	cmd, group, char_idx, x(msb:lsb), y(msb:lsb), colour(msb:lsb)					
4DSL Cmd	DrawUserBitr	map8(char_idx, x, y, colour) <i>(8x8 bitmap)</i> map16(char_idx, x, y, colour) <i>(16x16 bitmap)</i> map32(char_idx, x, y, colour) <i>(32x32 bitmap)</i>				
	cmd	<b>44</b> (hex) or <b>D</b> (ascii) : Command header byte				
	group	Selects the appropriate bitmap format <b>00</b> hex: selects the 8x8 bitmap format <b>01</b> hex: selects the 16x16 bitmap format <b>02</b> hex: selects the 32x32 bitmap format				
	char_idx	Bitmap character index to draw from the previously added bitmap characters into memory.  0 to 63 ( <b>00</b> hex to <b>3F</b> hex): 64 characters of 8x8 format when group = <b>00</b> hex  0 to 15 ( <b>00</b> hex to <b>0F</b> hex): 16 characters of 16x16 format when group = <b>01</b> hex  0 to 7 ( <b>00</b> hex to <b>07</b> hex): 4 characters of 32x32 format when group = <b>02</b> hex				
	х	Horizontal display position of the bitmap character (2 bytes).				
	у	Vertical display position of the bitmap character (2 bytes).				
	colour	2 bytes bitmap colour value.				
Response	acknowledge					
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful				
Description	character at bitmaps allow	d draws the previously defined user bitmap location (x, y) on the screen. User defined w drawing & displaying unlimited graphic kly & effectively.				
Serial Examples						
Serial Examples	44hex, 00hex, (Display 8x8 b) Command Da 44hex, 00hex (Display 8x8 b) Command Da 44hex, 00hex	of thex, 00hex, 00hex, 00hex, 00hex, F8hex, 00hex,				

#### **3.2.3** Draw Circle - 43hex

	1	
Serial Cmd	cmd, x(msb:ls	sb), y(msb:lsb), radius(msb:lsb), colour(msb:lsb)
4DSL Cmd	Circle(x, y, ra	dius, colour)
	cmd	<b>43</b> (hex) or <b>C</b> (ascii) : Command header byte
	х	Horizontal position of the circle centre (2 bytes).
	у	Vertical position of the circle centre (2 bytes).
	radius	Radius of the circle (2 bytes).
	colour	2 bytes define the circle colour.
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful
Description	the value set depending or when Pen Size	and will draw a coloured circle centred at (x, y) with a radius determined by in the 'radius' byte. The circle can be either solid or wire frame (empty) in the value of the Pen Size (see Set Pen Size command).  Example = 0 : circle is solid  Example = 1 : circle is wire frame
		rad  pensize=0
Serial Example	Command Da 43hex, 00hex	ata: , 3Fhex, 00hex, 3Fhex, 00hex, 22hex, 00hex, 1Fhex
		circle (001Fhex) centred at $x = 63$ dec (003Fhex) and $y = 63$ dec (003Fhex) of 34dec (0022hex).
4DSL Example	Refer to the C	GraphicsPt1.4DScript sample script file.

## 3.2.4 Draw Triangle - 47hex

Serial Cmd	cmd, x1(msb:lsb), y1(msb:lsb), x2(msb:lsb), y2(msb:lsb), x3(msb:lsb), y3(msb:lsb), color(msb:lsb)
4DSL Cmd	Triangle(x1, y1, x2, y2, x3, y3, color)
	cmd 47(hex) or G(ascii) : Command header byte
	x1, y1, x2, y2, 3 vertices of the triangle. These must be specified in an anti-clockwise fashion (2 bytes per each parameter).
	color 2 bytes triangle colour value.
Response	acknowledge
	acknowledge 06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful
Description	This command draws a Solid/Wire-Frame triangle. The vertices must be specified in an anti-clock wise manner, i.e.  x2 < x1 : x3 > x2 : y2 > y1 : y3 > y1  A solid or a wire frame triangle is determined by the value of the Ben Size setting.
	A solid or a wire frame triangle is determined by the value of the Pen Size setting. when Pen Size = 0: triangle is solid when Pen Size = 1: triangle is wire frame
	x1,y1  pensize=0  x2,y2  x1,y1  x3,y3  x2,y2  pensize=1
Serial Example	Command Data:
	47hex, 00hex, 0Ahex, 00hex, 0Ahex, 00hex, 2Ahex, 00hex, 2Ahex, 00hex, 03hex, 00hex,
	2Ahex, F8hex, 00hex
	Draw a red triangle between vertices (10, 10), (42, 42) and (3, 42).
4DSL Example	Refer to the GraphicsPt1.4DScript sample script file.

#### 3.2.5 Draw Image-Icon - 49hex

	cmd, x(msb:l pixelN	sb), y(msb:lsb), width(msb:lsb), height(msb:lsb), colourMode, pixel1,
4DSL Cmd	Image(x, y, wi	idth, height, colourMode, pixel1, pixelN)
	cmd	49(hex) or I(ascii): Command header byte
	х	Image horizontal start position (top left corner, 2 bytes).
	У	Image vertical start position (top left corner, 2 bytes).
	width	Horizontal size of the image (2 bytes).
	height	Vertical size of the image (2 bytes).
	colourMode	<b>08</b> (hex): 256 colour mode, 8bits/1byte per pixel. <b>10</b> (hex): 65K colour mode, 16bits/2bytes per pixel.
	pixel1pixelN	Image pixel data where N is the total number of pixels.  N = width x height (when colourMode = 08hex)  N = 2 x width x height (when colourMode = 10hex)
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful
	command is	I the size of the image specified by width and height parameters. This more effective than using the "Put Pixel" command, where there are no specifying the x, y location of each pixel.  x,y
		width

## **3.2.6** Set Background colour - 4Bhex

Serial Cmd	cmd, colour(	msb:lsb)	
4DSL Cmd	SetBackgroui	nd(colour)	
	cmd	4B(hex) or K(ascii): Command header byte	
	colour	2 bytes (16 bits) define the background colour in RGB format: R4R3R2R1R0G5G4G3G2G1G0B4B3B2B1B0 where:	
		msb: R4R3R2R1R0G5G4G3 lsb: G2G1G0B4B3B2B1B0	
Response	acknowledge		
	acknowledge	06(hex): ACK byte if operation successful 15(hex): NAK byte if unsuccessful	
Description	This command sets the background colour for the next erase and draw(refers to opaque mode text in Set Transparent-Opaque Text – 4Fhex) commands to be sent. Once this command is sent, the background colour will only change when it is rewritten. Nothing on the screen will be affected.		
Serial Example	Command Day 4Bhex, FFhex This example		
4DSL Example	Refer to the C	General.4DScript sample script file.	

#### **3.2.7 Draw Line – 4Chex**

cmd 4C(hex) or L(ascii): Command header byte x1 Top left horizontal start position of line (2 bytes). y1 Top left vertical start position of line (2 bytes). x2 Bottom right horizontal end position of line (2 bytes). y2 Bottom right vertical end position of line (2 bytes). colour 2 bytes define the Line colour.  esponse acknowledge acknowledge 06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful This command will draw a coloured line from point (x1, y1) to point (x2, y2) on the screen.	4DSL Cmd	Lino(v1 v1 v	:lsb), y1(msb:lsb), x2(msb:lsb), y2(msb:lsb), colour(msb:lsb)
Top left horizontal start position of line (2 bytes).  y1 Top left vertical start position of line (2 bytes).  x2 Bottom right horizontal end position of line (2 bytes).  y2 Bottom right vertical end position of line (2 bytes).  colour 2 bytes define the Line colour.  esponse acknowledge  acknowledge 06(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful  This command will draw a coloured line from point (x1, y1) to point (x2, y2) on the screen.		Lille(XI, YI, X	2, y2, colour)
y1 Top left vertical start position of line (2 bytes). x2 Bottom right horizontal end position of line (2 bytes). y2 Bottom right vertical end position of line (2 bytes). colour 2 bytes define the Line colour.  esponse acknowledge acknowledge O6(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful This command will draw a coloured line from point (x1, y1) to point (x2, y2) on the screen.		cmd	4C(hex) or L(ascii): Command header byte
Bottom right horizontal end position of line (2 bytes).  y2 Bottom right vertical end position of line (2 bytes).  colour 2 bytes define the Line colour.  esponse  acknowledge acknowledge  acknowledge  15(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful This command will draw a coloured line from point (x1, y1) to point (x2, y2) on the screen.		x1	Top left horizontal start position of line (2 bytes).
y2 Bottom right vertical end position of line (2 bytes).  colour 2 bytes define the Line colour.  esponse acknowledge acknowledge   06(hex) : ACK byte if successful   15(hex) : NAK byte if unsuccessful   15(hex) : NAK byte if unsuccessful   15 (hex) : NAK byte		y1	Top left vertical start position of line (2 bytes).
colour  2 bytes define the Line colour.  esponse  acknowledge acknowledge  15(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful  This command will draw a coloured line from point (x1, y1) to point (x2, y2) on the screen.		x2	Bottom right horizontal end position of line (2 bytes).
acknowledge acknowledge 06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful This command will draw a coloured line from point (x1, y1) to point (x2, y2) on the screen.		y2	Bottom right vertical end position of line (2 bytes).
acknowledge 06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful  This command will draw a coloured line from point (x1, y1) to point (x2, y2) on the screen.		colour	2 bytes define the Line colour.
This command will draw a coloured line from point (x1, y1) to point (x2, y2) on the screen.	Response	acknowledge	
screen.		acknowledge	
x2,y2			×1,y1
	Serial Example	4Chex, 00hex Draws a WHI	ata: x, 00hex, 00hex, 00hex, 00hex, 7Fhex, 00hex, 7Fhex, FFhex

## 3.2.8 Draw Polygon - 67hex

Serial Cmd		cmd, vertices, x1(msb:lsb), y1(msb:lsb),, xn(msb:lsb), yn(msb:lsb), colour(msb:lsb)		
4DSL Cmd		Polygon(vertices, x1, y1,, xn, yn, colour)		
	cmd	67(hex) or g(ascii): Command header byte		
	vertices	Number of vertices from 3 to 7. This byte specifies the number of vertices of the polygon.		
	x1,y1,xn, yn	Vertices of the Polygon. These can be specified in any fashion. Each parameter is 2 bytes.		
	colour	2 bytes Polygon colour value.		
Response	acknowledge			
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful		
Description	A solid or a wwhen Pen Size	d draws an Empty/Wire-Frame polygon. Up to 7 vertices can be specified in Currently only a wire frame polygon is supported.  Fire frame Polygon is determined by the value of the Pen Size setting.  Secondary of		
4DSL Example	Refer to the G	GraphicsPt2.4DScript sample script file.		
or Example	1.0.0.0	stapinost car isostipe sample some		

## 3.2.9 Draw Rectangle - 72hex

Serial Cmd	cmd, x1(msb:lsb), y1(msb:lsb), x2(msb:lsb), y2(msb:lsb), colour(msb:lsb)		
4DSL Cmd	Rectangle(x1, y1, x2, y2, colour)		
	cmd	72(hex) or r(ascii) : Command header byte	
	x1	Top left horizontal start position of rectangle (2 bytes).	
	y1	Top left vertical start position of rectangle (2 bytes).	
	x2	Bottom right horizontal end position of rectangle (2 bytes).	
	y2	Bottom right vertical end position of rectangle (2 bytes).	
	colour	2 bytes define the rectangle colour.	
Response	acknowledge		
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful	
Serial Example	screen. If cold	x1,y1  pensize=1  x2,y2  x1,y1  pensize=0  x2,y2	
Seriai Example		ata: , OFhex, O0hex, OFhex, O0hex, 1Fhex, O0hex, 7Fhex, FFhex, FFhex	
		rectangle between vertices (15, 15) and (31, 127).	
4DSL Example	Refer to the GraphicsPt2.4DScript sample script file.		

## **3.2.10 Draw Ellipse - 65hex**

	Linpse - oone		
Serial Cmd		sb), y(msb:lsb), rx(msb:lsb), ry(msb:lsb), colour(msb:lsb)	
4DSL Cmd	Ellipse(x, y, rx, ry, colour)		
	cmd	<b>65</b> (hex) or <b>e</b> (ascii) : Command header byte	
	x	Horizontal position of the ellipse centre (2 bytes).	
	У	Vertical position of the ellipse centre (2 bytes).	
	rx	Radius in the x-axis (2 bytes).	
	ry	Radius in the y-axis (2 bytes).	
	colour	2 bytes define the ellipse colour.	
Response	acknowledge		
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful	
Serial Example	the values of frame (empty Pen Size = 0 :	ellipse is wire frame.  Ty rx  pensize=1  pensize=0	
Seriai Example	65hex, 00hex	ata: , 64hex, 00hex, A0hex, 00hex, 0Fhex, 00hex, 1Ehex, 04hex, 00hex se with centre at (100, 160), 15 pixels Radius in X-Axis and 30 pixels Radius in	
4DSL Example		GraphicsPt2.4DScript sample script file.	
•		· · · · · · · · · · · · · · · · · · ·	

## **3.2.11 Draw Pixel - 50hex**

Serial Cmd	cmd, x(msb:lsb), y(msb:lsb), colour(msb:lsb)		
4DSL Cmd	Pixel(x, y, colo	our)	
	cmd	<b>50</b> (hex) or <b>P</b> (ascii) : Command header byte	
	х	Horizontal position of the pixel (2 bytes).	
	у	Vertical position of the pixel (2 bytes).	
	colour	2 bytes (16 bits) define the pixel colour in RGB format:	
		R4R3R2R1R0G5G4G3G2G1G0B4B3B2B1B0 where:	
		msb: R4R3R2R1R0G5G4G3 lsb: G2G1G0B4B3B2B1B0	
Response	acknowledge	13D . G2G1G0B4B3B2B1B0	
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful	
Description	This command will draw a coloured pixel at location (x, y) on the screen.		
		×.y •	
Serial Example	Command Da 50hex, 00hex,	ta: 01hex, 00hex, 0Ahex, FFhex, FFhex	
		E pixel (FFFFhex) at location (x = 0001hex, y = 000Ahex).	
4DSL Example	Refer to the G	raphicsPt2.4DScript sample script file.	

## **3.2.12** Read Pixel - **52**hex

Serial Cmd	cmd, x(msb:lsb), y(msb:lsb)		
4DSL Cmd	ReadPixel( x, y)		
	cmd	52(hex) or R(ascii): Command header byte	
	х	Horizontal position of the pixel (2 bytes).	
	У	Vertical position of the pixel (2 bytes).	
Response	colour(msb:lsb)		
	colour	Returns back 2 bytes (16 bits) pixel colour in RGB format:  R4R3R2R1R0G5G4G3G2G1G0B4B3B2B1B0 where:  msb: R4R3R2R1R0G5G4G3 (msb is 1 <sup>st</sup> byte)  lsb: G2G1G0B4B3B2B1B0 (lsb is 2 <sup>nd</sup> byte)	
Description	This command will read the colour value of a pixel at location (x, y) on the screen and return it to the host. This is a useful command when for example a white pointer is moved across the screen and the host can read the colour on the screen and switch the colour of the pointer when it's on top of a light coloured area.		
Serial Example	Command Data: 52hex, 00hex, 01hex, 00hex, 0Ahex PICASO-SGC Response: 00hex, 1Fhex Reads a BLUE pixel (001Fhex) at location (x = 0001hex, y = 000Ahex).		
4DSL Example	Refer to the GraphicsPt2.4DScript sample script file.		

## 3.2.13 Screen Copy-Paste - 63hex

Serial Cmd	cmd, xs(msb:lsb), ys(msb:lsb), xd(msb:lsb), yd(msb:lsb), width(msb:lsb), height(msb:lsb)		
4DSL Cmd	ScreenCopyP	ScreenCopyPaste(xs, ys, xd, yd, width, height)	
	cmd	<b>63</b> (hex) or <b>c</b> (ascii) : Command header byte	
	xs	Top left horizontal start position of screen area to be copied (source, 2bytes).	
	ys	Top left vertical start position of screen area to be copied (source, 2 bytes).	
	xd	Top left horizontal start position of where copied area is to be pasted (destination, 2 bytes).	
	yd	Top left vertical start position of where copied area is to be pasted (destination, 2 bytes).	
	width	Width of screen area to be copied (source, 2 bytes).	
	height	Height of screen area to be copied (source, 2 bytes).	
Response	acknowledge		
	acknowledge	<b>06</b> (hex) : ACK byte if successful	
		15(hex): NAK byte if unsuccessful	
Description	This command copies a specified area of the screen as a bitmap block. The start location of the block to be copied is represented by <b>xs</b> , <b>ys</b> (top left corner) and the size of the area to be copied is represented by <b>width</b> and <b>height</b> parameters. The start location of where the block is to be pasted (destination) is represented by <b>xd</b> , <b>yd</b> (top left corner). This is a very powerful feature for animating objects, smooth scrolling, implementing a windowing system or copying patterns across the screen to make borders or tiles.		
Serial Example	Command Data: 63hex, 00hex, 00hex, 00hex, 00hex, 3Ahex, 00hex, 3Ahex, 00hex, 00hex, 00hex, 00hex, 00hex 0Ahex Copy a rectangular from (0,0) to (58, 58) of size 10pixels wide and 10pixels high.		
4DSL Example	Refer to the G	GraphicsPt2.4DScript sample script file.	

# 3.2.14 Replace Colour - 6Bhex

Serial Cmd	cmd, x1(msl	b:lsb), <b>y1</b> (msb:lsb), <b>x2</b> (msb:lsb), <b>y2</b> (msb:lsb), <b>old colour</b> (msb:lsb), <b>new</b> sb)	
4DSL Cmd	ReplaceColor(x1, y1, x2, y2, old colour, new colour)		
	cmd	6B(hex) or k(ascii): Command header byte	
	x1	Top left horizontal start position. (2 bytes)	
	y1	Top left vertical start position. (2 bytes)	
	x2	Bottom right horizontal end position. (2 bytes)	
	y2	Bottom right vertical end position. (2 bytes)	
	old colour	2 bytes (16 bits) define the background colour in RGB format:  R4R3R2R1R0G5G4G3G2G1G0B4B3B2B1B0 where:  msb: R4R3R2R1R0G5G4G3  lsb: G2G1G0B4B3B2B1B0	
	new colour	2 bytes (16 bits) define the background colour in RGB format:  R4R3R2R1R0G5G4G3G2G1G0B4B3B2B1B0 where:  msb: R4R3R2R1R0G5G4G3  lsb: G2G1G0B4B3B2B1B0	
Response	acknowledge		
	acknowledge	<b>06</b> (hex): ACK byte if operation successful <b>15</b> (hex): NAK byte if unsuccessful	
Description	This command replaces the old colour of the selected rectangular region to the new specified colour.		
Serial Example	Command Data: 6Bhex, 00hex, 00hex, 00hex, 00hex, 3Ahex, 00hex, 3Ahex, F8hex, 00hex, FFhex FFhex Change Red colour in the rectangular area between (0,0) and (58, 58) to white.		
4DSL Example	Refer to the C	General.4DScript sample script file.	

## **3.2.15** Set Pen Size - **70hex**

Serial Cmd	cmd, size		
4DSL Cmd	Pen(size)	Pen(size)	
	cmd	<b>70</b> (hex) or <b>p</b> (ascii) : Command header byte	
	size	Selects one of the 2 options: <b>00</b> hex : All graphics objects are drawn solid	
		<b>01</b> hex : All graphics objects are drawn wire-frame	
		Note: Does not apply to polygon command.	
Response	acknowledge		
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful	
Description	This command determines if certain graphics objects are drawn in solid or wire frame fashion.		
Serial Examples	Command Data:		
	70hex, 00hex		
	(All objects will be drawn solid).		
	Command Data:		
	70hex, 01hex		
	(All objects w	ill be drawn wire-frame).	
4DSL Example	Refer to the G	raphicsPt2.4DScript sample script file.	

#### 3.3 Text Commands

The PICASO-SGC is shipped with 4 internal fonts. These fonts can be altered, deleted and replaced with new fonts. The **FONT-Tool** is a free software tool that can assist in the conversion of any Windows fonts into the bitmap format that can be used by the PICASO-SGC. The converted font set can then be exported into the **DISP-Tool** utility which can then be downloaded into the PICASO-SGC on-chip flash memory. Both the FONT-Tool and the DISP-Tool are available free from <a href="https://www.4dsystems.com.au">www.4dsystems.com.au</a>

## **Summary of Commands in this section:**

- Set Font 46hex
- Set Transparent-Opaque Text 4Fhex
- Draw ASCII Character (text format) 54hex
- Draw ASCII Character (graphics format) 74hex
- Draw "String" of ASCII Text (text format) 73hex
- Draw "String" of ASCII Text (graphics format) 53hex
- Draw Text Button 62hex

## 3.3.1 Set Font - 46hex

Serial Cmd	cmd, fontSet		
4DSL Cmd	Font(fontSet)		
	cmd	<b>46</b> (hex) or <b>F</b> (ascii) : Command header byte	
	fontSet	Selects one of internal fonts. The supplied 3 fonts are:  00hex: 5x7 small size font set  01hex: 8x8 medium size font set  02hex: 8x12 large size font set  03hex: 12x16 largest size font set  These fonts can be altered and other fonts can be added with the aid of the FONT-Tool and the DISP-Tool software tools.	
Response	acknowledge		
-	_	06(hex) : ACK byte if successful 15(hex) : NAK byte if unsuccessful	
Description	command is swas.  NOTE: The Ii.e. Space to existing fonts limited resou	d selects one of the available internal fonts. Changes take place after the sent. Any character on the screen with the previous font set will remain as it PICASO-SGC is shipped with 4 fonts displaying the characters 0x20 to 0x7f'. the character after the tilde. The user can alter the number of fonts, delete s, and, or, add extra fonts, up to the amount of available user flash (a very arce). A font does not need to start at 0x20, or end at 0x7f. It could, for that 0x30 ('0') and end at 0x39 ('9').	
Serial Examples	-		
	46hex, 00hex (Select small	0 1 2 3 4 5 6 7 8 9 : ; < = > ?	
	Command Da	ta:	
	46hex, 01hex	p q r s t u v w x ч z {   } ~ ■ ! " # \$ % & ' ( ) * + , /	
	(Select medic		
	Command Da	B C B C T H H H V H Z T N 1 A	
	46hex, 02hex	'ahcdafahiikl mpa	
	(Select large	10 0 7 5 T H U W X U Z 3 + F H	
	Command Da	0123456789:;<=>? nta:	
	46hex, 03hex		
	-	t 12x16 font).  pqrstuvwxyz{ }~~  !"#\$%%'()*+,/ 0123456789:; <=>?  @ABCDEFGHIJKLMN0	
		PQRSTUVWXYZ[\]^_ 'abcdefghijklmno pqrstuvwxyz{ }~△	
4DSL Example	Refer to the 1	ext.4DScript sample script file.	

# 3.3.2 Set Transparent-Opaque Text - 4Fhex

Serial Cmd	cmd, mode	
4DSL Cmd	Opacity(mod	e)
	cmd	<b>4F</b> (hex) or <b>O</b> (ascii) : Command header byte
	mode	Select one of the following options for text appearance:
		<b>00</b> hex : Transparent, objects behind text are visible.
		<b>01</b> hex : Opaque, objects behind text blocked by background.
Response	acknowledge	
Пооролюс	_	<b>06</b> (hex) : ACK byte if successful
	acknowledge	15(hex): NAK byte if unsuccessful
Description	This comman	d will change the attribute of the text so that an object behind the text can
		cked or transparent. Changes take place after the command is sent.
Serial Examples	Command Da	ita:
	4Fhex, 00hex	
	(Transparent	text mode).
	Command Da 4Fhex, 01hex	
	(Opaque text	
	(Opaque text	modej.
		transparent
		opaque
4DSL Example	Refer to the T	ext.4DScript sample script file.

# 3.3.3 Draw ASCII Character (text format) - 54hex

cmd char  colun row char  Response acknow acknow  Description This of the v Use t  Serial Example Composition	rColour : nowledge nowledge coordinat vertical po the "Set F mand Dat ex, 41hex,	<b>06</b> (hex): ACK byte if successful <b>15</b> (hex): NAK byte if unsuccessful  d will draw/display an ASCII character anywhere on the screen in character tes. The horizontal position of the character is specified by the <b>column</b> and osition is specified by the <b>row</b> parameters.  Font - 46hex" command to select the desired font.
char  column row char(  Response acknow acknow  Description This of unit of the v Use t  Serial Example Community 54he	rColour : nowledge nowledge : coordinat vertical po the "Set F nmand Dat ex, 41hex,	Inbuilt standard ASCII character. range: 32dec – 127dec (20hex - 7Fhex).  Horizontal position of the character (character units).  Vertical position of the character (character units).  2 bytes define the character colour.  06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful d will draw/display an ASCII character anywhere on the screen in character tes. The horizontal position of the character is specified by the column and osition is specified by the row parameters.  Font - 46hex" command to select the desired font.  Ita: 100hex, 00hex, FFhex, FFhex
coluntrow charces acknown ackn	rColour : nowledge nowledge coordinat vertical po the "Set F mand Dat ex, 41hex,	range: 32dec – 127dec (20hex - 7Fhex).  Horizontal position of the character (character units).  Vertical position of the character (character units).  2 bytes define the character colour.  06(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful  d will draw/display an ASCII character anywhere on the screen in character tes. The horizontal position of the character is specified by the column and osition is specified by the row parameters.  Font - 46hex" command to select the desired font.  ita:  , 00hex, 00hex, FFhex, FFhex
Response acknown ackno	rColour : nowledge nowledge command coordinat vertical po the "Set F nmand Dat ex, 41hex,	Horizontal position of the character (character units).  Vertical position of the character (character units).  2 bytes define the character colour.  06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful d will draw/display an ASCII character anywhere on the screen in character tes. The horizontal position of the character is specified by the column and osition is specified by the row parameters.  Font - 46hex" command to select the desired font.  Ita:  O0hex, O0hex, FFhex, FFhex
Response acknown ackno	rColour : nowledge nowledge command coordinat vertical po the "Set F nmand Dat ex, 41hex,	Vertical position of the character (character units).  2 bytes define the character colour.  06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful d will draw/display an ASCII character anywhere on the screen in character tes. The horizontal position of the character is specified by the column and osition is specified by the row parameters.  Font - 46hex" command to select the desired font.  ita:  , 00hex, 00hex, FFhex, FFhex
Response acknown acknown acknown acknown acknown the volume of the volum	nowledge nowledge command coordinat vertical po the "Set F nmand Datex, 41hex,	2 bytes define the character colour.  06(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful d will draw/display an ASCII character anywhere on the screen in character tes. The horizontal position of the character is specified by the column and osition is specified by the row parameters.  Font - 46hex" command to select the desired font.  Ita:  O0hex, 00hex, FFhex, FFhex
Response acknown ackno	nowledge nowledge command coordinat vertical po the "Set F nmand Dat ex, 41hex,	O6(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful d will draw/display an ASCII character anywhere on the screen in character tes. The horizontal position of the character is specified by the column and osition is specified by the row parameters. Font - 46hex" command to select the desired font. ita: , 00hex, 00hex, FFhex, FFhex
Description This of unit of the volume to Use the Serial Example  Serial Example  54he	command coordinat vertical po the "Set F mand Dat ex, 41hex,	O6(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful d will draw/display an ASCII character anywhere on the screen in character tes. The horizontal position of the character is specified by the column and position is specified by the row parameters. Font - 46hex" command to select the desired font.  Ita: 100hex, 00hex, FFhex, FFhex
Description This ounit of the v Use t  Serial Example 54he	command coordinat vertical po the "Set F nmand Dat ex, 41hex,	d will draw/display an ASCII character anywhere on the screen in character tes. The horizontal position of the character is specified by the <b>column</b> and osition is specified by the <b>row</b> parameters.  Font - 46hex" command to select the desired font.  Ita:  Ohex, Ohex, FFhex, FFhex
unit of the v Use t  Serial Example Comi 54he	coordinat vertical po the "Set F nmand Dat ex, 41hex,	tes. The horizontal position of the character is specified by the <b>column</b> and osition is specified by the <b>row</b> parameters.  Font - 46hex" command to select the desired font.  Ita:  Ohex, Ohex, FFhex, FFhex
54he	ex, 41hex,	, 00hex, 00hex, FFhex, FFhex
		AAAAA row

## 3.3.4 Draw ASCII Character (graphics format) - 74hex

4501.6	cmd, char, x(msb:lsb), y(msb:lsb), charColour(msb:lsb), width, height	
4DSL Cmd	AsciiCharG(ch	ar, x, y, charColour, width, height)
	cmd	74(hex) or t(ascii): Command header byte
	char	Inbuilt standard ASCII character. range: 32dec – 127dec (20hex - 7Fhex).
	х	Horizontal position of the character (pixel units, 2 byte parameter).
	У	Vertical position of the character (pixel units, 2 byte parameter).
	charColour	2 bytes define the character colour.
	width	This byte defines the width or horizontal size (multiplier) of the character.
	height	This byte defines the height or vertical size (multiplier) of the character.
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful
	format)' comn	pecified by x and y parameters. Unlike the 'Draw ASCII Character (text nand, this option allows text of any size (determined by width and height) to any position. The font of the character is determined by the 'Set Font'  x,y  height

# 3.3.5 Draw "String" of ASCII Text (text format) - 73hex

Serial Cmd	cmd, column,	row, font, stringColour(msb:lsb), "string", terminator
4DSL Cmd	String(column, row, font, stringColour, 'string')	
	cmd	73(hex) or s(ascii): Command header byte
	column	Horizontal start position of the string (character units).
	row	Vertical start position of the string (character units).
	font	This byte specifies which internal font set to use for the string. The supplied
		fonts are:
		0 : 5x7 internal font 1 : 8x8 internal font
		2 : 8x12 internal font
		3: 12x16 internal font
		These fonts can be altered and other fonts can be added. <b>OR</b> ing the fonts
		with 0x10 will cause the string to be displayed in a proportional manner (eg
	ctringColour	0x10 is font 0 proportional, 0x11 is font 1 proportional, etc).  2 bytes define the string text colour.
	stringColour "string"	
	terminator	String of ASCII characters to be displayed (max. 256 characters).  The string must be terminated with <b>00</b> hex.
Response	acknowledge	The string must be terminated with <b>ou</b> nex.
Response	acknowledge	06(hex) : ACK byte if successful
	acknowledge	15(hex): NAK byte if unsuccessful
Description	ASCII text a character unit start position column and the by the row paterminated wastring is longer of characters	d will draw/display a string of nywhere on the screen in t coordinates. The horizontal of the string is specified by the he vertical position is specified arameters. The string must be with 00hex. If the length of the er than the maximum number per line, a wrap around will he next line. Maximum string bytes.
4DSL Example	Refer to the Te	ext.4DScript sample script file.

# 3.3.6 Draw "String" of ASCII Text (graphics format) - 53hex

Serial Cmd	cmd, x(msb:ls	cmd, x(msb:lsb), y(msb:lsb), font, stringColour(msb:lsb), width, height, "string", terminator	
4DSL Cmd	StringG(x, y, fo	ont, stringColour, width, height, 'string')	
	cmd	53(hex) or S(ascii): Command header byte	
	x	Top left horizontal start position of the string (pixel units). 2 byte parameter.	
	у	Top left vertical start position of the string (pixel units). 2 byte parameter.	
	font	This byte specifies which internal font set to use for the string. The supplied fonts are:  0:5x7 internal font 1:8x8 internal font	
		2: 8x12 internal font	
		<b>3</b> : 12x16 internal font These fonts can be altered and other fonts can be added. <b>OR</b> ing the fonts with 0x10 will cause the string to be displayed in a proportional manner (eg 0x10 is font 0 proportional, 0x11 is font 1 proportional, etc).	
	stringColour	2 bytes define the string text colour.	
	width	This byte defines the width or horizontal size multiplier of the character in the string. Effects the total width of the string. 1 byte parameter.	
	height	This byte defines the height or vertical size multiplier of the character in the string. Effects the total height of the string. 1 byte parameter.	
	"string"	String of ASCII characters to be displayed (max. 256 characters).	
	terminator	The string must be terminated with <b>00</b> hex.	
Response	acknowledge		
	acknowledge	<b>06</b> (hex): ACK byte if successful <b>15</b> (hex): NAK byte if unsuccessful	
Description	This command will draw/display a string of ASCII text anywhere on the screen in pixel coordinates specified by <b>x</b> and <b>y</b> parameters. The horizontal start position of the string is specified by <b>x</b> and the vertical position is specified by <b>y</b> . The string must be <b>terminated</b> with <b>00</b> hex. The size of the characters are determined by the <b>width</b> and <b>height</b> parameters. If the length of the string is longer than the maximum number of characters per line, a wrap around will occur on to the next line. Maximum string length is <b>512 bytes</b> .		
4DSL Example		ext.4DScript sample script file.	

## 3.3.7 Draw Text Button - 62hex

Serial Cmd	cmd. state. x(	msb:lsb), y(msb:lsb), buttonColour(msb:lsb), font, stringColour(msb:lsb),	
Serial Cilia	· ·	width, height, "string", terminator	
4DSL Cmd	Button(state,	x, y, buttonColour, font, stringColour, width, height, 'string')	
	cmd	<b>62</b> (hex) or <b>b</b> (ascii) : Command header byte	
	state	This byte specifies whether the displayed button is drawn <b>UP</b> (not pressed) or <b>DOWN</b> (pressed). <b>0</b> : Button Down (pressed) <b>1</b> : Button Up (not pressed)	
	X	Top left horizontal start position of the button (2 bytes).	
	у	Top left vertical start position of the button (2 bytes).	
		2 bytes define the button colour.	
	font	This byte specifies which internal font set to use for the string. The supplied fonts are:  0:5x7 internal font 1:8x8 internal font	
		2: 8x12 internal font 3: 12x16 internal font These fonts can be altered and other fonts can be added.	
	stringColour	2 bytes define the string text colour.	
	width	This byte defines the width or horizontal size (x magnification) of the character in the string. Effects the total width of the string and button.	
	height	This byte defines the height or vertical size (y magnification) of the character in the string. Effects the total height of the string and button.	
	"string"	String of ASCII characters displayed inside the button. Limit the string to a single line width.	
	terminator	The string must be terminated with <b>00</b> hex.	
Response	acknowledge		
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful	
Description	ones used in refers to the to of the button the screen with the button. (button not position by s'state' byte. S	d will place a Text button similar to the a PC Windows environment. The (x, y) cop left corner of the button and the size is automatically calculated and drawn on the the string text relatively justified inside The button can be displayed in an UP pressed) or DOWN (button pressed) specifying the appropriate value in the separate button and text colours provide ans in appearance and format.	
4DSL Example	Refer to the To	ext.4DScript sample script file.	

## 3.4 Touch Screen Commands

The following commands are related to Touch Screen support of the PICASO-SGC and they are described in this section.

## **Summary of Commands in this section:**

- Get Touch Coordinates 6Fhex
- Wait Until Touch 77hex
- Detect Touch Region 75hex

Touch screen must be enabled to be able to use the touch commands. To enable touch screen, See section 2.1.6.

## 3.4.1 Get Touch Coordinates - 6Fhex

Serial Cmd	cmd, mode	cmd, mode	
4DSL Cmd	GetTouch(mo	de)	
	cmd	<b>6F</b> (hex) or <b>o</b> (ascii) : Command header byte	
	mode	<b>00hex</b> : Wait until any touch activity	
		01hex: Wait until Touch press	
		02hex: Wait until Touch release	
		03hex: Wait until Touch Moving	
		<b>04hex</b> : Get Touch status	
		<b>05hex</b> : Get Touch coordinates	
Response	x_coord(msb:	lsb), y_coord(msb:lsb)	
	x_coord	2 byte value for x-coordinates of the touch screen.	
		For mode = 04hex only, returns the following:	
		<b>0</b> : No Touch Activity	
		1 : Touch Press	
		2 : Touch Release	
		3 : Touch Moving	
	y_coord	2 byte value for y-coordinates of the touch screen.	
Description	This command returns the x and y coordinate of a touch to the screen for <b>00hex to 0</b> 3		
	and <b>05hex</b> .		
		"mode = 05hex" the coordinates relate to the last touch activity i.e. they will	
	be same as the coordinates returned to the touch command with mode <b>00hex - 03</b>		
	coordinates detected for the touch command with "mode = 04hex" when touch activit		
	occurred.		
Serial Exampl	e Command Da	ta:	
	6Fhex, 04hex		
	PICASO-SGC F	Response:	
	02hex	tura. Taurah malagasa mamambad	
		tus, Touch release reported.	
4DSL Example	Refer to the To	ouch.4DScript sample script file.	

## 3.4.2 Wait Until Touch - 77hex

Carial Cread	(delideen) end (delide)		
Serial Cmd	cmd, value(msb:lsb)		
4DSL Cmd	WaitTouch(va	VaitTouch(value)	
	cmd	77(hex) or w(ascii): Command header byte	
	value	2 byte wait time in milliseconds. Maximum value of 65,535 msec or 65.5 seconds.	
Response	acknowledge		
	acknowledge	06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful	
Description	When objects from the memory card such as images are displayed sequentially, a delay can be inserted between subsequent objects. A delay basically has the same effect as a NOP (No Operation) which can be used to determine how long the object stays on the screen before the next object is displayed. If the user touches the display during the delay period, the delay will end immediately. The touch region, if used, is taken into account.		
Serial Example	Command Da 77hex, 27hex, Wait for 10sed	10hex	
4DSL Example	Refer to the To	ouch.4DScript sample script file.	

# **3.4.3** Detect Touch Region – **75**hex

	Touch Region	. 70116X		
Serial Cmd	cmd, x1(msb:lsb), y1(msb:lsb), x2(msb:lsb), y2(msb:lsb)			
4DSL Cmd	DetectRegion	DetectRegion(x1, y1, x2, y2)		
	cmd	<b>75</b> (hex) or <b>u</b> (ascii) : Command header byte		
	x1	Top left horizontal start position of the region (2 bytes).		
	y1	Top left vertical start position of the region (2 bytes).		
	x2	ottom right horizontal end position of the region (2 bytes).		
	y2	Bottom right vertical end position of the region (2 bytes).		
Response	acknowledge			
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful		
Description  Social Example	on the screen touch activity touch activity returned by 6Fhex" comm	touch region x2,y2		
Serial Example	75hex, 00hex,	ta:  OAhex, OOhex, 1Ahex, OOhex, 7Fhex, OOhex, 7Fhex ectangular region between (15, 26) and (127, 127).		
4DSL Example	Refer to the To	ouch.4DScript sample script file.		
	•			

## 3.5 SD Memory Card Commands (Low-Level/RAW)

The commands detailed in this section utilise the SD/microSD memory card which must be connected to the SPI port of the PICASO-SGC. The memory card is used as the storage medium for all multimedia objects such as images, icons, animations and video clips which can be accessed and displayed. The memory card can also be used by the host controller as a general purpose storage medium such as data logging applications.

The following commands are related to Low-Level memory card operations and they are described in this section.

## **Summary of Commands in this section:**

- Initialise Memory Card @69hex
- Set Address Pointer of Card (RAW) @41hex
- Read Byte Data from Card (RAW) @72hex
- Write Byte Data to Card (RAW) @77hex
- Read Sector Block Data from Card (RAW) @52hex
- Write Sector Block Data to Card (RAW) @57hex
- Screen Copy-Save to Card (RAW) @43hex
- Display Image-Icon from Card (RAW) @49hex (New Image Format)
- Display Image-Icon from Card (RAW) @49hex (Old Image Format)
- Display Object from Card (RAW) @4Fhex
- Display Video-Animation Clip from Card (RAW) @56hex (New Image Format)
- Display Video-Animation Clip from Card (RAW) @56hex (Old Image Format)
- Run Script (4DSL) Program from Card (RAW) @50hex

# 3.5.1 Initialise Memory Card - @69hex

Serial Cmd	ext_cmd, cmd	
4DSL Cmd	InituSD	
	ext_cmd	40(hex) or @(ascii): Extended Command header byte
	cmd	<b>69</b> (hex) or i(ascii): Command header byte
Response	acknowledge	
	acknowledge	<b>06</b> (hex): ACK byte if successful <b>15</b> (hex): NAK byte if unsuccessful or card not present.
Description	This command initialises the memory card. The memory card is always initialised upon Power-Up or Reset cycle, if the card is present. If the card is inserted after the power up or a reset then this command must be used to initialise the card.	
Serial Example	Note! There is no card insert/remove auto detect facility.  Command Data:	
Serial Example	40hex, 69hex, Initialise the memory card	
4DSL Example	Refer to the R	aw.4DScript sample script file.

# 3.5.2 Set Address Pointer of Card (RAW) - @41hex

Serial Cmd	ext_cmd, cmd, Address(Umsb:Ulsb:Lmsb:Llsb)		
4DSL Cmd	SetAddress(Address)		
	ext_cmd	40(hex) or @(ascii): Extended Command header byte	
	cmd <b>41</b> (hex) or <b>A</b> (ascii) : Command header byte		
	Address	A 4 byte card memory address (big endian) for byte wise access.	
Response	acknowledge		
	acknowledge	<b>06</b> (hex): ACK byte if successful <b>15</b> (hex): NAK byte if unsuccessful or card not present.	
	This command sets the internal memory address pointer for byte wise reads and writes. After a byte read or write, the memory Address pointer is automatically incremented internally to the next byte address location.		
Serial Example	Command Data: 40hex, 41hex, 00hex, 00hex, 04hex, 00hex Set Internal memory address pointer to 00000400hex.		
4DSL Example	Refer to the R	aw.4DScript sample script file.	

# 3.5.3 Read Byte Data from Card (RAW) - @72hex

Serial Cmd	ext_cmd, cmd		
4DSL Cmd	ReadByte		
	ext_cmd	40(hex) or @(ascii): Extended Command header byte	
	cmd	<b>72</b> (hex) or <b>r</b> (ascii) : Command header byte	
Response	data_byte		
	data_byte	. byte of card data	
Description	This command provides a means of reading a single byte of data back from the card. Before this command can be used, memory address location must be set using the "Set Address Pointer of Memory Card" command. Once this command is sent, the device will return 1 byte of data relating to that memory location set by the memory address pointer. The memory address location pointer is automatically incremented to the next byte address location.		
Serial Example	40hex, 41hex, PICASO-SGC R 06hex Command Da 40hex, 72hex PICASO-SGC R FChex	00hex, 00hex, 04hex, 00hex Response: Response:	
		byte of data from address 00000400hex on the uSD card .	
4DSL Example	Refer to the R	aw.4DScript sample script file.	

# 3.5.4 Write Byte Data to Card (RAW) - @77hex

Serial Cmd	ext_cmd, cmd	l, data	
4DSL Cmd	WriteByte(Data)		
	ext_cmd	40(hex) or @(ascii): Extended Command header byte	
	cmd <b>77</b> (hex) or <b>w</b> (ascii) : Command header byte		
	data	1 byte of card data	
Response	acknowledge		
	acknowledge	<b>06</b> (hex): ACK byte if successful <b>15</b> (hex): NAK byte if unsuccessful or card not present.	
Description	This command permits writing single bytes of data to the card. This is useful for writi small chunks of data at irregular intervals quickly. For large data blocks it is more efficient to use the "Write Sector Block Data to Memory Card" command described previously.		
	Before this command can be used, the card memory address location must be set using the "Set Address Pointer of Memory Card" command. Once the Write Byte command is sent a single byte of data will be stored to that memory location set by the memory address pointer. The memory address pointer is automatically incremented to the next location.		
	Only the data byte is written. Other bytes in the command message are not stored.		
Serial Example	Command Data: 40hex, 41hex, 00hex, 00hex, 04hex, 00hex PICASO-SGC Response: 06hex Command Data: 40hex, 77hex, 34hex		
	Write a single	byte of data (34hex) to address 00000400hex on the uSD card.	
4DSL Example	Refer to the Ra	aw.4DScript sample script file.	

# 3.5.5 Read Sector Block Data from Card (RAW) - @52hex

Serial Cmd	ext_cmd, cmd, SectorAdd(hi:mid:lo)			
4DSL Cmd	ReadSector(SectorAdd)			
	ext_cmd	40(hex) or @(ascii): Extended Command header byte		
	cmd	cmd <b>52</b> (hex) or <b>R</b> (ascii) : Command header byte		
	SectorAdd	3 bytes (big endian) sector address. Sector address range from 0 t 16,777,215 depending on the capacity of the card. Each sector is 512 byte in size. There are 2048 sectors per every 1Mb of card memory.		
Response	data(1512)			
	data	lata 512 bytes of sector data		
Description	This command will return 512 bytes of data relating to a sector.			
Serial Example	Command Data: 40hex, 52hex, 00hex, 0Ahex, 00hex Read one sector from sector address 000A00hex.			
4DSL Example	Refer to the R	aw.4DScript sample script file.		

# 3.5.6 Write Sector Block Data to Card (RAW) - @57hex

Serial Cmd	ext cmd, cmd	, SectorAdd(hi:mid:lo), data(1512)			
4DSL Cmd	WriteSector(SectorAdd, data(1512))				
	ext_cmd	ext_cmd <b>40</b> (hex) or <b>@</b> (ascii) : Extended Command header byte			
	cmd	md 57(hex) or W(ascii) : Command header byte			
	SectorAdd	dd 3 bytes (big endian) sector address.			
	data	512 bytes of sector data. Data length must be 512 bytes.			
Response	acknowledge				
	acknowledge	<b>06</b> (hex): ACK byte if successful <b>15</b> (hex): NAK byte if unsuccessful or card not present.			
	This command allows downloading and writing blocks of sector data to the card. The data block must always be 512 bytes in length. For large volumes of data such as images, the data must be broken up into multiple sectors (chunks of 512 bytes) and this command then maybe used many times until all of the data is written. If the data block to be written is less than 512 bytes in length, then make sure the rest of the remaining data are padded with 00hex or FFhex (it can be anything).				
	If only few bytes of data are to be written then the "Write Byte Data to Card - @77hex" command can be used.  Once this command is sent, the device will take a few milliseconds to write the data into its memory card and at the end of which it will respond.				
	Only <b>data</b> (1512) are written to the sector. Other bytes in the command message do not get written.				
4DSL Example	Refer to the Ra	w.4DScript sample script file.			

# 3.5.7 Screen Copy – Save to Card (RAW) - @43hex

	ext_cmd, SectorAdd(hi	cmd,	<b>x</b> (msb:lsb),	<b>y</b> (msb:lsb),	width(msb:lsb),	height(msb:lsb),
	ScreenCopyuSD(x,y,width,height, SectorAdd)					
	ext_cmd 40(hex) or @(ascii) : Extended Command header byte					
	cmd	<b>43</b> (hex)	or <b>C</b> (ascii) : Co	mmand header	byte	
	х	Top left horizontal start position of screen area to be copied (2 bytes).				
	У	Top left vertical start position of screen area to be copied (2 bytes).				
	width	Width c	of screen area t	o be copied (sou	ırce, 2 bytes).	
	height	Height of screen area to be copied (source, 2 bytes).				
	SectorAdd 3 bytes (big endian) sector address where the copied screen ar saved.					reen area is to be
Response	acknowledge					
	acknowledge		: ACK byte if su : NAK byte if u			
	This command copies an area of the screen of specified size. The start location of the block to be copied is represented by x, y (top left corner) and the size of the area to be copied is represented by width and height parameters. This is similar the "Screen Copy-Paste" command but instead of the copied screen area being pasted to another location on the screen it is stored into the memory card. The stored screen image can then be later recalled from the memory card and redisplayed onto the screen at the same or different location by using the "Display Image-Icon from Card" command.  This is a very powerful feature for animating objects, smooth scrolling, or implementing a windowing system.  Notes:  The "Screen Copy-Save to Card" command always stores that part of the screen as a 16 bit image, i.e. 2 bytes per pixel.  The images or icons when stored into the memory card must be sector boundary					
	aligned, i.e. the object start location must be at the start of a sector boundary.  Command Data:  40hex, 43hex, 00hex, 00hex, 00hex, 00hex, 00hex, F0hex, 01hex, 40hex, 00hex, 00hex  Save 240x320 screen area on the uSD card at sector address 000400hex.					
			cript sample sci			

# 3.5.8 Display Image-Icon from Card (RAW) - @49hex (New Image Format)

Serial Cmd	ext_cmd, cmd, x(msb:lsb), y(msb:lsb), SectorAdd(hi:mid:lo)			
4DSL Cmd	NewUsdImage(x, y, SectorAdd)			
	ext_cmd	40(hex) or @(ascii): Extended Command header byte		
	cmd	49(hex) or I(ascii): Command header byte		
	x	Image horizontal start position (top left corner, 2 bytes).		
	У	Image vertical start position (top left corner, 2 bytes).		
	SectorAdd	3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.		
Response	acknowledge			
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful		
Description	Image should be loaded to the SD card using "4DGL, SGC Picaso - uSD Raw - GCI at Specified Offset" Build Output option on the Graphics Composer 3.			
	This command displays an image on the screen that has been previously stored at a particular sector address in the memory card. Position of the image to be displayed is specified by (x, y). Other parameters can be extracted from the text file(.Txt) created in the Graphics Composer 3 after writing the slide show on the SD card.			
	Display Control Function (Syntax: cmd, mode, value) should be used to set "Image Format" to			
	"New format" i.e mode = 06hex. Value = 00hex. Refer to Sec 2.1.6. Image format is "Old Format" by default.			
		: The image parameters such as width, height and colour-mode are built into the image er file and do not need to be specified by the host.		
Serial Example1	With FAT Protection on:			
Examples	Partition a 4GB card such that first NonFs sector is 3872257. Set the offset address, under "4DGL, SGC Picaso - uSD Raw - GCI at Specified Offset", to 3. Sector address to display the image will be 0000(MSW), 0003(LSW).			
	Command Data: 59hex, 06hex, 00hex Picaso-SGC Response: 06hex Command Data: 40hex, 49hex, 00hex, 00hex, 00hex, 00hex, 00hex, 03hex			
	Set the Image format to New Image Format, then display the image at (0, 0) from seaddress 000003hex within the Raw Partition.			
	Note: FAT Prot	ection is On by default.		

## Serial Example2

## With FAT Protect off (not recommended):

Partition a 4GB card such that first NonFs sector is 3872257. Set the offset address, under "4DGL, SGC Picaso - uSD Raw - GCI at Specified Offset", to 3. Sector address to display the Image will be 003B(MSW), 1604(LSW).

#### **Command Data:**

59hex, 06hex, 00hex

Picaso-SGC Response:

06hex

**Command Data:** 

59hex, 08hex, 00hex

**Picaso-SGC Response:** 

06hex

**Command Data:** 

40hex, 49hex, 00hex, 00hex, 00hex, 3Bhex, 16hex, 04hex

Set the Image format to New Image Format, UPROTECT FAT and then display the image at (0, 0) from sector address 3B1604hex.

**4DSL Example** Refer to the Raw.4DScript sample script file.

# 3.5.9 Display Image-Icon from Card (RAW) - @49hex (Old Image Format)

torAdd(hi:rilmage(x, y, y, cmd) th th ght burMode torAdd nowledge nowledge ge should l phics Comp	width, height, colourMode, SectorAdd)  40(hex) or @(ascii): Extended Command header byte  49(hex) or I(ascii): Command header byte  Image horizontal start position (top left corner, 2 bytes).  Image vertical start position (top left corner, 2 bytes).  Horizontal size of the image (2 bytes).  Vertical size of the image (2 bytes).  08(hex): 256 colour mode, 8bits/1byte per pixel.  10(hex): 65K colour mode, 16bits/2bytes per pixel.  3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.  06(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful  be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
cmd d th ght burMode torAdd nowledge nowledge ge should I phics Comp	49(hex) or @(ascii): Extended Command header byte  49(hex) or I(ascii): Command header byte  Image horizontal start position (top left corner, 2 bytes).  Image vertical start position (top left corner, 2 bytes).  Horizontal size of the image (2 bytes).  Vertical size of the image (2 bytes).  08(hex): 256 colour mode, 8bits/1byte per pixel.  10(hex): 65K colour mode, 16bits/2bytes per pixel.  3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.  06(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful  be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
th ght ourMode torAdd nowledge nowledge ge should I phics Comp	49(hex) or I(ascii): Command header byte Image horizontal start position (top left corner, 2 bytes). Image vertical start position (top left corner, 2 bytes). Horizontal size of the image (2 bytes). Vertical size of the image (2 bytes).  08(hex): 256 colour mode, 8bits/1byte per pixel. 10(hex): 65K colour mode, 16bits/2bytes per pixel. 3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.  06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
th ght purMode torAdd nowledge nowledge ge should I phics Comp	Image horizontal start position (top left corner, 2 bytes).  Image vertical start position (top left corner, 2 bytes).  Horizontal size of the image (2 bytes).  Vertical size of the image (2 bytes).  O8(hex): 256 colour mode, 8bits/1byte per pixel.  10(hex): 65K colour mode, 16bits/2bytes per pixel.  3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.  O6(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful  be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
ght burMode torAdd nowledge nowledge ge should I phics Comp	Image vertical start position (top left corner, 2 bytes).  Horizontal size of the image (2 bytes).  Vertical size of the image (2 bytes).  O8(hex): 256 colour mode, 8bits/1byte per pixel.  10(hex): 65K colour mode, 16bits/2bytes per pixel.  3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.  O6(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful  be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
ght burMode torAdd nowledge nowledge ge should I phics Comp	Horizontal size of the image (2 bytes).  Vertical size of the image (2 bytes).  O8(hex): 256 colour mode, 8bits/1byte per pixel.  10(hex): 65K colour mode, 16bits/2bytes per pixel.  3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.  O6(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful  be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
ght burMode torAdd nowledge nowledge ge should I phics Comp	Vertical size of the image (2 bytes).  08(hex): 256 colour mode, 8bits/1byte per pixel.  10(hex): 65K colour mode, 16bits/2bytes per pixel.  3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.  06(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
nowledge nowledge ge should I phics Comp	08(hex): 256 colour mode, 8bits/1byte per pixel. 10(hex): 65K colour mode, 16bits/2bytes per pixel. 3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.  06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
nowledge nowledge ge should I phics Comp	10(hex): 65K colour mode, 16bits/2bytes per pixel.  3 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.  06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
nowledge nowledge ge should I phics Comp	about to be displayed.  06(hex): ACK byte if successful  15(hex): NAK byte if unsuccessful be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
nowledge  ge should I  phics Comp	15(hex): NAK byte if unsuccessful be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
ge should I phics Comp	15(hex): NAK byte if unsuccessful be loaded to the SD card using "SGC - uSD Raw" Build Output option on the poser 3.	
phics Comp	poser 3.	
Graphics Composer 3.  This command displays a bitmap image or an icon on the screen that has been previously stored at a particular sector address in the memory card using "Screen Copy-Save to Card" or an image saved through the Graphics Composer.  Position of the image to be displayed is specified by (x, y). Other parameters can be extracted from the text file (.Txt) created on the Graphics Composer 3 after writing the slide show on the SD card.  If the previously stored image was in 8 bit colour format (1 byte per pixel) or 16 bits (2 bytes per pixel) then this must be specified in the colourMode byte parameter. Do not store an image/icon in one colour format then display it in another colour format, this will result in a corrupted image.  Display Control Function (Syntax: cmd, mode, value) should be used to set "Image Format"		
to "Old format" i.e mode = 06hex. Value = 01hex. Refer to Sec 2.1.6.		
Image format is "Old Format" by default.		
es: • The "S a 16 bi	creen Copy-Save to Card" command always stores that part of the screen as it image, i.e. 2 bytes per pixel.  nages or icons when stored into the memory card must be sector boundary	
	acted from w on the SI e previously pixel) then ge/icon in cupted image blay Controld format" i. ge format is a 16 bi	

Serial	With FAT Protection on:			
Example1				
	Partition a 4GB card such that first NonFs sector is 3872257. Set the offset address, under "SGC - uSD Raw", to 3. Sector address to display the image will be 0000(MSW), 0003(LSW).			
	Command Data:			
	59hex, 06hex, 01hex			
	Picaso-SGC Response:			
	06hex			
	Command Data:			
	40hex, 49hex, 00hex, 00hex, 00hex, 00hex, F0hex, 01hex, 40hex, 10hex, 00hex, 00hex, 03hex			
	Set the Image format to Old Image Format if it is not, then display the image at (0, 0) from sector address 000003hex within the Raw Partition.			
	Note: FAT Protection is On by default.			
Serial Example2	With FAT Protect off (not recommended):			
	Partition a 4GB card such that first NonFs sector is 3872257. Set the offset address, under "SGC - uSD Raw", to 3. Sector address to display the Image will be 003B(MSW), 1604(LSW).			
	Command Data:			
	59hex, 06hex, 01hex			
	Picaso-SGC Response:			
	06hex			
	Command Data:			
	59hex, 08hex, 00hex			
	Picaso-SGC Response:			
	06hex			
	Command Data:			
	40hex, 49hex, 00hex, 00hex, 00hex, 00hex, F0hex, 01hex, 40hex, 10hex, 3Bhex, 16hex, 04hex			
	Set the Image format to Old Image Format if it is not, UPROTECT FAT and then display the image at (0, 0) from sector address 3B1604hex.			
4DSL Example	Refer to the Raw.4DScript sample script file.			

# 3.5.10 Display Object from Card (RAW) - @4Fhex

Serial Cmd	ext_cmd, cmo	d, Address(Umsb:Ulsb:Lmsb:Llsb)		
4DSL Cmd	Object(Addre	Object(Address)		
	ext_cmd	40(hex) or @(ascii): Extended Command header byte		
	cmd <b>4F</b> (hex) or <b>O</b> (ascii) : Command header byte			
	Address	A 4 byte card memory address (big endian) of a previously stored Object that		
		is about to be displayed.		
Response	acknowledge			
	acknowledge	acknowledge <b>06</b> (hex): ACK byte if successful		
		15(hex): NAK byte if unsuccessful or card not present.		
Description	Some of the commands can be stored as objects in the memory card which can be later recalled by the host on demand and displayed or executed. The user must make sure the 32 bit address of each stored command/object is known before using this feature. For example, a series of images can be stored as icons and later displayed as the application requires them. The table at the end of this section lists all of the commands that can be stored as objects within the memory card.			
4DSL Example	Refer to the R	aw.4DScript sample script file.		

## 3.5.11 Display Video-Animation Clip from Card (RAW) - @56hex (New Image Format)

Serial Cmd	ext_cmd, cmd, x(msb:lsb), y(msb:lsb), delay, SectorAdd(hi:mid:lo)			
4DSL Cmd	NewVideo(x,	y, delay, SectorAdd)		
	ext_cmd	40(hex) or @(ascii): Extended Command header byte		
	cmd	<b>56</b> (hex) or <b>V</b> (ascii) : Command header byte		
	х	Video horizontal start position (top left corner, 2 bytes).		
	У	Video vertical start position (top left corner, 2 bytes).		
	delay	1 byte inter-frame delay in milliseconds. This parameter can be used to determine the speed of the video playback.		
	SectorAdd	3 bytes (big endian) sector address of a previously stored video-animation clip that is about to be displayed.		
Response	acknowledge			
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful		
Description	Video/Animation should be loaded to the SD card using "4DGL, SGC Picaso - uSD Raw - GCI at Specified Offset" Build Output option on the Graphics Composer 3.			
	This command displays a video/Animation on the screen that has been previously stored at a particular sector address in the memory card. Position of the image to be displayed is specified by (x, y). Other parameters can be extracted from the text file(.Txt) created in the Graphics Composer 3 after writing the slide show on the SD card.			
	Display Control Function (Syntax: cmd, mode, value) should be used to set "Image to "New format" i.e mode = 06hex. Value = 00hex. Refer to Sec 2.1.6. Image format is "Old Format" by default.			
		deo/Animation parameters such as width, height and colour-mode are built header file and do not need to be specified by the host.		
Serial	With FAT Prot	ection on:		
Example1	Partition a 4GB card such that first NonFs sector is 3872257. Set the offset address, under "4DGL, SGC Picaso - uSD Raw - GCI at Specified Offset", to 3. Sector address to display the Video/Animation will be 0000(MSW), 0003(LSW).			
	Command Da 59hex, 06hex, Picaso-SGC Re 06hex Command Da 40hex, 56hex,	00hex esponse:		
	Set the Video	/Animation format to New Image Format, then display the Video/Animation sector address 000003hex within the Raw Partition.		

## Serial Example2

Note: FAT Protection is On by default.

With FAT Protect off (not recommended):

Partition a 4GB card such that first NonFs sector is 3872257. Set the offset address, under "4DGL, SGC Picaso - uSD Raw - GCI at Specified Offset", to 3. Sector address to display the Video/Animation will be 003B(MSW), 1604(LSW).

**Command Data:** 

59hex, 06hex, 00hex

**Picaso-SGC Response:** 

06hex

**Command Data:** 

59hex, 08hex, 00hex

Picaso-SGC Response:

06hex

**Command Data:** 

40hex, 56hex, 00hex, 00hex, 00hex, 00hex, 3Bhex, 16hex, 04hex

Set the Video/Animation format to New Image Format, UPROTECT FAT and then display the Video/Animation at (0, 0) from sector address 3B1604hex.

**4DSL Example** Refer to the Raw.4DScript sample script file.

# 3.5.12 Display Video-Animation Clip from Card (RAW) - @56hex (Old Image Format)

Serial Cmd		nd, x(msb:lsb), y(msb:lsb), width(msb:lsb), height(msb:lsb), colourMode,	
	delay, frames(msb:lsb), SectorAdd(hi:mid:lo)		
4DSL Cmd	Video(x, y, width, height, colourMode, delay, frames, SectorAdd)		
	ext_cmd	40(hex) or @(ascii): Extended Command header byte	
	cmd	<b>56</b> (hex) or <b>V</b> (ascii) : Command header byte	
	x	Video horizontal start position (top left corner, 2 bytes).	
	У	Video vertical start position (top left corner, 2 bytes).	
	width	Width of the video/animation, 2 bytes	
	height	Height of the video/animation, 2 bytes	
	colourMode	08(hex): 256 colour mode, 8bits/1byte per pixel. 10(hex): 65K colour mode, 16bits/2bytes per pixel.	
	delay	1 byte inter-frame delay in milliseconds. This parameter can be used to determine the speed of the video playback.	
	frames	Number of frames to be displayed, 2 bytes	
	SectorAdd	3 bytes (big endian) sector address of a previously stored video-animation clip that is about to be displayed.	
Response	acknowledge		
	acknowledge	06(hex): ACK byte if successful 15(hex): NAK byte if unsuccessful	
Description	option on the <b>Graphics Composer 3</b> .  This command plays a Video or an Animation clip on the screen that has been previously stored at a particular sector address in the memory card. Position of the clip to be displayed is specified by <b>(x, y)</b> . Other parameters can be extracted from the text file (.Txt) created in the Graphics Composer 3 after writing the slide show on the SD card.  If the previously stored clip was in 8 bit colour format (1 byte per pixel) or 16 bits (2 bytes per pixel) then this must be specified in the <b>colourMode</b> byte parameter. Do not store a Video/Animation in one colour format then display it in another colour format, this will result in a corrupted clips.  Display Control Function ( <i>Syntax: cmd, mode, value</i> ) should be used to set "Image Format" to "Old format" i.e mode = 06hex. Value = 01hex. Refer to Sec 2.1.6.  Video/Animation format format is "Old Format" by default.		
Serial Example1		tection on:  GB card such that first NonFs sector is 3872257. Set the offset address, under aw", to 3. Sector address to display the Video/Animation will be 0000(MSW),	
	0003(LSW).	, , , , , , , , , , , , , , , , , , , ,	

#### **Command Data:**

59hex, 06hex, 01hex

## **Picaso-SGC Response:**

06hex

#### **Command Data:**

40hex, 56hex, 00hex, 00hex, 00hex, 00hex, 00hex, F0hex, 01hex, 40hex, 10hex, 01hex, 00hex, FFhex, 00hex, 00hex, 03hex

Set the Image format to Old Image Format if it is not, then display the Video/Animation at (0, 0) from sector address 000003hex within the Raw Partition.

Note: FAT Protection is On by default.

## Serial Example2

## With FAT Protect off (not recommended):

Partition a 4GB card such that first NonFs sector is 3872257. Set the offset address, under "SGC - uSD Raw", to 3. Sector address to display the Video/Animation will be 003B(MSW), 1604(LSW).

#### **Command Data:**

59hex, 06hex, 01hex

## **Picaso-SGC Response:**

06hex

## **Command Data:**

59hex, 08hex, 00hex

#### **Picaso-SGC Response:**

06hex

## **Command Data:**

40hex, 56hex, 00hex, 00hex, 00hex, 00hex, 00hex, F0hex, 01hex, 40hex, 10hex, 01hex, 00hex, FFhex, 3Bhex, 16hex, 04hex

Set the Video/Animation format to Old Image Format if it is not, UPROTECT FAT and then display the Video/Animation at (0, 0) from sector address 3B1604hex.

**4DSL Example** Refer to the Raw.4DScript sample script file.

# 3.5.13 Run Script (4DSL) Program from Card (RAW) - @50hex

ext_cmd 40(hex) or @(ascii): Extended Command header byte  cmd 50(hex) or P(ascii): Command header byte  Address A 4 byte card memory start address (big endian) of a 4DSL (4D Scripting Language) program.  Response acknowledge  acknowledge There is no response to a successful command, as potentially the command may never end.  15(hex): NAK byte if unsuccessful or card not present.  The majority of the commands can be composed as a script and written into memory card A 4DSL script program is a sequence of those commands that reside and can be executed from inside the memory card and these can be a combination of graphics, text, image video and audio commands. Complete list of commands available for the scripting program is listed in section 2.8.  This command forces the 32bit internal memory pointer to jump to the specified address and automatically start executing a 4DSL script program, from the memory card withou any further interaction by the host processor. It will sequentially execute any valid 4DS instruction and commands until it gets to the end of the program.  Serial A sample script program inside the memory card:	Serial Cmd	ext_cmd, cmd	, Address(Umsb:Ulsb:Lmsb:Llsb)	
cmd 50(hex) or P(ascii): Command header byte  Address A 4 byte card memory start address (big endian) of a 4DSL (4D Scripting Language) program.  Response acknowledge acknowledge There is no response to a successful command, as potentially the command may never end.  15(hex): NAK byte if unsuccessful or card not present.  Description The majority of the commands can be composed as a script and written into memory card A 4DSL script program is a sequence of those commands that reside and can be executed from inside the memory card and these can be a combination of graphics, text, image video and audio commands. Complete list of commands available for the scripting program is listed in section 2.8.  This command forces the 32bit internal memory pointer to jump to the specified address and automatically start executing a 4DSL script program, from the memory card withou any further interaction by the host processor. It will sequentially execute any valid 4DS instruction and commands until it gets to the end of the program.  Serial A sample script program inside the memory card:  A sample script program inside the memory card:  Address Command Commands  00000000 45 Erase Screen  00000000 45 Erase Screen  00000000 70 30 E8 Delay(1second)  00000000 72 00 00 00 00 00 3C 00 3C 07 E0 Draw Rectangle  00000001 43 00 64 00 32 00 10 00 00 00 00 00 00 00 00 00 00 00	4DSL Cmd	RunScript(Address)		
Address A 4 byte card memory start address (big endian) of a 4DSL (4D Scripting Language) program.  acknowledge  acknowledge  There is no response to a successful command, as potentially the command may never end.  15(hex): NAK byte if unsuccessful or card not present.  The majority of the commands can be composed as a script and written into memory card A 4DSL script program is a sequence of those commands that reside and can be executed from inside the memory card and these can be a combination of graphics, text, image video and audio commands. Complete list of commands available for the scripting program is listed in section 2.8.  This command forces the 32bit internal memory pointer to jump to the specified address and automatically start executing a 4DSL script program, from the memory card withou any further interaction by the host processor. It will sequentially execute any valid 4DS instruction and commands until it gets to the end of the program.  Serial  Example  A sample script program inside the memory card:  Comment  00000000  45  Comment  000000000  Draw Circle  00000000  000000000  72 00 00 00 00 00 00 00 00 00 00 00 00 00		ext_cmd	40(hex) or @(ascii) : Extended Comma	and header byte
Language) program.    Comment   Comm		cmd	50(hex) or P(ascii) : Command header	byte
acknowledge There is no response to a successful command, as potentially the command may never end.  15(hex): NAK byte if unsuccessful or card not present.  The majority of the commands can be composed as a script and written into memory card A 4DSL script program is a sequence of those commands that reside and can be executed from inside the memory card and these can be a combination of graphics, text, image video and audio commands. Complete list of commands available for the scripting program is listed in section 2.8.  This command forces the 32bit internal memory pointer to jump to the specified address and automatically start executing a 4DSL script program, from the memory card withou any further interaction by the host processor. It will sequentially execute any valid 4DS instruction and commands until it gets to the end of the program.  Serial  A sample script program inside the memory card:  Address  Command  00000000  45  Erase Screen  00000001  43 00 64 00 32 00 14 00 1F  Draw Circle  0000000A  07 03 E8  Delay(1second)  0000000B  000000B  72 00 00 00 00 00 00 00 3C 00 3C 07 E0  Draw Rectangle  0000001  00000029  0B 00 00 00 00  0D Goto Address 00000000		Address		s (big endian) of a 4DSL (4D Scripting
may never end.  15(hex): NAK byte if unsuccessful or card not present.  The majority of the commands can be composed as a script and written into memory card A 4DSL script program is a sequence of those commands that reside and can be executed from inside the memory card and these can be a combination of graphics, text, image video and audio commands. Complete list of commands available for the scripting program is listed in section 2.8.  This command forces the 32bit internal memory pointer to jump to the specified address and automatically start executing a 4DSL script program, from the memory card withou any further interaction by the host processor. It will sequentially execute any valid 4DS instruction and commands until it gets to the end of the program.  Serial  A sample script program inside the memory card:  Address  Command  00000000 45  Erase Screen  00000001 43 00 64 00 32 00 14 00 1F  00000000 45  Erase Screen  00000000 72 00 00 00 00 00 3C 00 3C 07 E0  00000000 Play 05 60 00 00 00 00 00 00 00 00 Play video from card  0A 02 5F 00 10 00  00000000 Goto Address 00000000	Response	acknowledge	acknowledge	
A 4DSL script program is a sequence of those commands that reside and can be executed from inside the memory card and these can be a combination of graphics, text, image video and audio commands. Complete list of commands available for the scripting program is listed in section 2.8.  This command forces the 32bit internal memory pointer to jump to the specified address and automatically start executing a 4DSL script program, from the memory card withou any further interaction by the host processor. It will sequentially execute any valid 4DS instruction and commands until it gets to the end of the program.  Serial  A sample script program inside the memory card:  Address  Command  00000000  45  Erase Screen  00000001  43 00 64 00 32 00 14 00 1F  Draw Circle  0000000A  07 03 E8  Delay(1second)  0000000D  72 00 00 00 00 00 00 00 00 00 12 10  Draw Rectangle  00000018  40 56 00 00 00 00 00 00 46 00 32 10  Play video from card  0A 02 5F 00 10 00  00000029  0B 00 00 00 00 00  Goto Address 00000000		acknowledge	may never end.	
A sample script program inside the memory card:   Address   Command   Comment	Description	A 4DSL script program is a sequence of those commands that reside and can be executed from inside the memory card and these can be a combination of graphics, text, image, video and audio commands. Complete list of commands available for the scripting program is listed in section 2.8.  This command forces the 32bit internal memory pointer to jump to the specified address and automatically start executing a 4DSL script program, from the memory card without any further interaction by the host processor. It will sequentially execute any valid 4DSL		
Example         Address         Command         Comment           00000000         45         Erase Screen           00000001         43 00 64 00 32 00 14 00 1F         Draw Circle           0000000A         07 03 E8         Delay(1second)           0000000D         72 00 00 00 00 00 3C 00 3C 07 E0         Draw Rectangle           00000018         40 56 00 00 00 00 00 46 00 32 10         Play video from card           0A 02 5F 00 10 00         O0000029         0B 00 00 00 00         Goto Address 00000000	Serial		<del>_</del>	, -
	Example	00000000 00000001 0000000A 0000000D 00000018	45 43 00 64 00 32 00 14 00 1F 07 03 E8 72 00 00 00 00 00 3C 00 3C 07 E0 40 56 00 00 00 00 00 46 00 32 10 0A 02 5F 00 10 00	Erase Screen Draw Circle Delay(1second) Draw Rectangle Play video from card
	4DSL Example			

## 3.6 SD Memory Card Commands (FAT-Level/DOS)

The commands detailed in this section utilise the SD/microSD memory card which must be connected to the SPI port of the PICASO-SGC. The memory card is used as the storage medium for all multimedia objects such as images, icons, animations and video clips which can be accessed and displayed. The memory card can also be used by the host controller as a general purpose storage medium such as data logging applications.

The following commands are related to FAT-Level memory card operations and they are described in this section. Currently only the FAT (FAT16) format is supported. FAT32 is not supported and if a FAT32 formatted card is used then all access (both RAW and FAT16 commands) to the card will fail.

**Note:** The PICASO-SGC also supports high capacity HC memory cards (4Gb and above). The available capacity of SD-HC cards varies according to the way the card is partitioned and the commands used to access it.

The FAT partition is always first (if it exists) and can be up to the maximum size permitted by FAT16. Windows will format FAT16 up to 2Gb and the Windows command prompt will format FAT16 up to 4Gb.

For the RAW partition, byte reads and writes can access 2^32 (i.e. 4gb) of the card, Sector reads and writes can access 2^24 sectors (of 512 bytes, i.e. 8gb). The total amount of the card usable is the sum of the FAT and RAW partitions.

#### **Summary of Commands in this section:**

- Initialise Memory Card @69hex
- Read File from Card (FAT) @61hex
- Write File to Card (FAT) @74hex
- Erase file from Card (FAT) @65hex
- List Directory from Card (FAT) @64hex
- Screen Copy-Save to Card (FAT) @63hex
- Open GCI (FAT) @G
- Set GCI Entry (FAT) @E
- Display Frame (FAT) @F
- Display Image-Icon from Card (FAT) @6Dhex
- Play Audio WAV file from Card (FAT) @6Chex
- Run Script (4DSL) Program from Card (FAT) @70hex

# 3.6.1 Initialise Memory Card - @69hex

Serial Cmd	ext_cmd, cmd	
4DSL Cmd	InituSD	
	ext_cmd	40(hex) or @(ascii): Extended Command header byte
	cmd	<b>69</b> (hex) or <b>i</b> (ascii) : Command header byte
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if successful
		15(hex): NAK byte if unsuccessful or card not present.
·	This command initialises the memory card. The memory card is always initialised upon Power-Up or Reset cycle, if the card is present. If the card is inserted after the power up or a reset then this command must be used to initialise the card.	
	Note! There is	no card insert/remove auto detect facility.
Serial Example	Command Dar 40hex, 69hex	ta:
4DSL Example	Refer to the Ra	aw.4DScript sample script file.

# 3.6.2 Read File from Card (FAT) - @61hex

4DSL Cmd ex	ee \$ReadFile ext_cmd md andshaking ile_name erminator ile_size(Umsb	in Sec. 3.3.6  40(hex) or @(ascii): Extended Command header byte  61(hex) or a(ascii): Command header byte  How often the host sends an ACK(06hex) to request more data during transmission:-  00 – No handshaking, Use only for small files (<= 512 bytes)  01 – Once for each byte  02 – Once for each two bytes   50(32hex), maximum allowed  The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified in the filename.  The file_name string must be terminated with a NULL, 00(hex).	
cr h:	md  andshaking  ile_name  erminator  ile_size(Umsb	How often the host sends an ACK(06hex) to request more data during transmission:-  00 – No handshaking, Use only for small files (<= 512 bytes)  01 – Once for each byte  02 – Once for each two bytes   50(32hex), maximum allowed  The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified in the filename.  The file_name string must be terminated with a NULL, 00(hex).	
h:	ile_name erminator ile_size(Umsb	How often the host sends an ACK(06hex) to request more data during transmission:-  00 – No handshaking, Use only for small files (<= 512 bytes)  01 – Once for each byte  02 – Once for each two bytes  50(32hex), maximum allowed  The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified in the filename.  The file_name string must be terminated with a NULL, 00(hex).	
fil	ile_name erminator ile_size(Umsb	transmission:-  00 – No handshaking, Use only for small files (<= 512 bytes)  01 – Once for each byte  02 – Once for each two bytes   50(32hex), maximum allowed  The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified in the filename.  The file_name string must be terminated with a NULL, 00(hex).	
	erminator ile_size(Umsb	there is not one specified in the filename.  The file_name string must be terminated with a NULL, <b>00</b> (hex).	
te	ile_size(Umsb		
		:Ulsb:Lmsb:Llsb), file_data(1N), acknowledge	
Response fi	ا مرزی ما	- · · · -	
fil	116_3146	4 bytes of file size (big endian format).	
fil	_	Complete file data block: No Handshaking Block of file data: block size determined by value set in handshaking.	
a	-	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful	
Both the infile of the control of th	Using this command, the host can read a DOS compatible (FAT) file from the memory card. Because the time taken to process the read bytes varies, a technique is required to ensure that the host communications buffer does not overflow and data is not lost. This is implemented by a simple <i>handshaking</i> protocol where the PICASO-SGC will break up the file into smaller data blocks. When the host receives a block, it sends an ACK(06hex) to request the next block of data. The size of the data block is initially set by the host in the command packet, specified by the value in the "handshaking" byte. The larger the value the better, as long as the host system can buffer the incoming block size. Setting this value too low will slow the transfer.		
of in of de	The first 4 bytes sent by the device, after receiving the command packet, represent of the requested file (Umsb:Ulsb:Lmsb:Llsb). The host then responds with an ACK(0 indicate it wants the file, or NAK(15hex) if it wishes to terminate the receive. The fir of data bytes (block size set by the handshaking value) of the file are then sent fidevice, the host then responds with another ACK(06hex) to receive the next block of This process continues until all of the file data has been received.		
		sponds with a final ACK if the transfer completes successfully, otherwise it a NAK. The final ACK is not part of the handshaking.	
N	lote: Refer to	Diagram1 and Diagram2 on the next page.	
	Ohex, 61hex,	a: 00hex, 54hex, 65hex, 78hex, 74hex, 2Ehex, 74hex, 78hex, 74hex, 00hex ile without handshaking.	
4DSL Example Se	ee \$ReadFile	in Sec. 3.3.6	




Diagram 1: Read File - No Handshaking




Diagram 2: Read File - Handshaking other than 0

### 3.6.3 Write File to Card (FAT) - @74hex

Serial Cmd		nd, options, "file_name", terminator, filesize(Umsb:Ulsb:Lmsb:Llsb),
Seriai Cmu	file_data(1	
4DSL Cmd		ile in Sec. 3.3.10
	ext_cmd	40(hex) or @(ascii): Extended Command header byte
	cmd	<b>74</b> (hex) or <b>t</b> (ascii) : Command header byte
	options	Controls handshaking (how often the device sends an ACK to request more data from the host) and whether an existing file is appended to.  Handshaking:  00 – No handshaking, limit this to small files (<= 100 bytes)  01 – Once for each byte  02 – Once for each two bytes  50(32hex), maximum allowed  Append Mode:  00(hex)–No Append, file will be created (or overwritten if it exists).  80(hex)–Append mode, file will be appended to (or created if it doesn't exist).  Performance Mode:  00(hex)–High performance. Two ACKS will be sent after the filesize. This
		keeps transmission running at a high speed, as no time is spent waiting for the return ACK. The same total number of ACKs doesn't change (i.e the last ACK is missing). For simple un-buffered serial ports this may lead to loss of the second ACK.  40(hex)— Low performance. Only a single ACK is sent at a time. This is for un-buffered serial port controllers.
		Note:  The two option are added or <b>OR</b> ed together to produce the final options, e.g. <b>82</b> (hex) would indicate handshaking for every two bytes and Append mode.
	file_name	The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified in the filename.
	terminator	The file_name string must be terminated with a NULL, <b>00</b> (hex).
	file_size	4 bytes of file size (big endian format).
	file_data	Complete file data block: No Handshaking Block of file data: block size determined by value set in handshaking.
Response	acknowledge	е
	acknowledge	e <b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful
Description	This command allows the host to write a DOS compatible (FAT) file to the memory card. The PICASO-SGC device serial port (UART), has a buffer size of 100 bytes for capturing incoming data from the host. If this buffer fills up and overflows, data will be lost. Therefore the host must allow the device enough time to write its buffer to the memory card so it can their receive further file data from the host. For small files (less than 100 bytes in the appendix	

mode) the host can send the complete file data in one attempt. However, for larger files a simple *handshaking* protocol is implemented where the host sends the file data in small blocks. Using this handshaking method, the host always waits for an ACK from the device before sending the next block of data. The size of the data block is initially set by the host in the command packet, specified by the handshaking value in the "options" byte. The larger the value the better. Setting it too low will slow the transfer. The first ACK is always sent by the device, after the filesize parameter is transmitted by the host, or this could also be a NAK in which case one of the parameters is invalid or a file system error occurred.

Note: Do not set handshaking to zero if the file size is larger than 100 bytes.

Note: Refer to Diagram3 and Diagram4 on the next page.

4DSL Example See \$WriteFile in Sec. 3.3.10




Diagram 3: Write File - No Handshaking




Diagram 4: Write File - Handshaking Other than 0

# 3.6.4 Erase File from Card (FAT) - @65hex

Serial Cmd	ext_cmd, cm	d, "file_name", terminator
4DSL Cmd	EraseFile('file	e_name')
	ext_cmd	40(hex) or @(ascii): Extended Command header byte
	cmd_hdr	<b>65</b> (hex) or <b>e</b> (ascii) : Command header byte
	file_name	The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified the filename.
	terminator	The file_name string must be terminated with a NULL, <b>00</b> (hex)
Response	acknowledge	
	acknowledge	<b>06</b> (hex): ACK byte if file deleted successfully <b>15</b> (hex): NAK byte if file not found or an error has occurred
Description	Erases the file specified in the "file_name".	
Serial Example		x, 52hex, 65hex, 61hex, 64hex, 6Dhex, 65hex, 2Ehex, 74hex, 78hex, 74hex,
4DSL Example	Refer to the F	AT.4DScript sample script file.

# 3.6.5 List Directory of Card (FAT) - @64hex

Serial Cmd	ext_cmd, cmd	, "file_name", terminator
4DSL Cmd	Dir('file_name	e')
	ext_cmd	40(hex) or @(ascii): Extended Command header byte
	cmd_hdr	<b>64</b> (hex) or <b>d</b> (ascii) : Command header byte
	file_name	The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified the filename. Wild cards such as '*' and '?' are allowed.
	terminator	The file_name string must be terminated with a NULL, <b>00</b> (hex)
Response	"fileName1",	delimiter, , "fileNameN", delimiter, acknowledge
	fileName	Character string of the file name in the memory card. Maximum of 12 character bytes (including '.' separator) are returned in the string for the file name. This will be repeated for all files in the directory. An empty directory with no files or the result of an unsuccessful file name or wild card search will only return an ACK.
		<b>Note:</b> At present the PICASO-SGC chip only supports a single directory structure. Future enhancements will support nested directories.
	delimiter	<b>0A</b> (hex) : newline
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if an error has occurred
Description	"file_name" d	ctory listing (stream of characters) consisting of the files names matching the elimited by a Newline( <b>OA</b> hex) character. Always responds with an ACK at the a listing. Responds with a NAK if a file error occurs.
	• • •	ectory with no files or the result of an unsuccessful file name or wild card y return an ACK.
Serial Example	40hex, 64hex,	
4DSL Example	Refer to the FA	AT.4DScript sample script file.

# 3.6.6 Screen Copy – Save to Card (FAT) - @63hex

Serial Cmd	ext_cmd, cmc terminator	l, x(msb:lsb), y(msb:lsb), width(msb:lsb), height(msb:lsb), "file_name",	
4DSL Cmd	ScreenCopyFAT(x, y, width, height, 'file_name')		
	ext_cmd	40(hex) or @(ascii): Extended Command header byte	
	cmd	<b>63</b> (hex) or <b>c</b> (ascii) : Command header byte	
	x	Top left horizontal start position of screen area to be copied (2 bytes).	
	у	Top left vertical start position of screen area to be copied (2 bytes).	
	width	Width of screen area to be copied (source, 2 bytes).	
	height	Height of screen area to be copied (source, 2 bytes).	
	file_name	The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified the filename.	
	terminator	The file_name string must be terminated with a NULL, <b>00</b> (hex)	
Response	acknowledge		
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful	
	to be copied i represented by command but screen it is st stored screen the screen at (FAT)" commathis is a very windowing system.	powerful feature for animating objects, smooth scrolling, or implementing a	
	40hex, 63hex 67hex, 31hex,	ta: , 00hex, 00hex, 00hex, 00hex, 00hex, F0hex, 01hex, 40hex, 69hex, 6Dhex, 2E, 72hex, 61hex, 77hex, 00hex screen area in the img1.raw file.	
		AT.4DScript sample script file.	

# 3.6.7 Open GCI (FAT) - @47hex

Serial Cmd	ext_cmd, cmc	l, "file_name", terminator	
4DSL Cmd	OpenGCI		
	ext_cmd	40(hex) or @(ascii): Extended Command header byte	
	cmd	47(hex) or G(ascii): Command header byte	
	file_name	The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if	
		there is not one specified the filename.	
	terminator	The file_name string must be terminated with a NULL, <b>00</b> (hex)	
Response	acknowledge	acknowledge	
	acknowledge	cknowledge <b>06</b> (hex) : ACK byte if successful	
		15(hex): NAK byte if unsuccessful	
Description	Opens a GCI file for use with 'Set GCI Entry' and 'Display Frame' commands.		
Serial Example	See section 3.	See section 3.6.9	
4DSL Example	Refer to the G	CI.4DScript sample script file.	

# 3.6.8 Set GCI Entry (FAT) - @45hex

Serial Cmd	ovt emd eme	I, option, offset, x(msb:lsb), y(msb:lsb)
		i, option, onset, x(msb.isb), y(msb.isb)
4DSL Cmd	SetGCI	
	ext_cmd	40(hex) or @(ascii): Extended Command header byte
	cmd	<b>45</b> (hex) or <b>E</b> (ascii) : Command header byte
	option	<b>00:</b> Don't display first (or only) image
		01: Display first (or only) image
	offset	4 byte offset into GCI file.
	x	Image horizontal start position (top left corner).
	У	Image vertical start position (top left corner).
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if successful
		15(hex): NAK byte if unsuccessful
Description	Sets the GCI	entry which can be followed by the Display frame command to display a
	specific frame in the GCI file.	
Serial Example	<b>Command Da</b>	ta:
	See section 3.	6.9
4DSL Example	Refer to the G	CI.4DScript sample script file.

# **3.6.9** Display Frame (FAT) - @46hex

Serial Cmd	ext_cmd, cmc	I, frame
4DSL Cmd	DisplayFrame	
	ext_cmd	40(hex) or @(ascii): Extended Command header byte
	cmd	46(hex) or F(ascii): Command header byte
	frame	2 bytes frame number.
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful
Description	Displays frame GCI Entry" cor	e within current GCI file and Entry, opened and set using "Open GCI" and "Set mmands.
Serial Example	40hex, 47hex 43hex, 49hex, 40hex, 45hex, 40hex, 46hex, Display frame	, 47hex, 46hex, 58hex, 32hex, 44hex, 45hex, 4Dhex, 4Fhex, 2Ehex, 47hex,
4DSL Example		CI.4DScript sample script file.

# 3.6.10 Display Image-Icon from Card (FAT) - @6Dhex

Serial Cmd	ext_cmd, cmc	I, "file_name", terminator, x(msb:lsb), y(msb:lsb), imagePos(msw:lsw)
4DSL Cmd	FATImage('file	e_name', x, y, imagePos)
	ext_cmd	40(hex) or @(ascii): Extended Command header byte
	cmd	<b>6D</b> (hex) or <b>m</b> (ascii) : Command header byte
	file_name	The filename is 1-12 chars long with an assumed '.' between chars 8 and 9, if
		there is not one specified the filename.
	terminator	The file_name string must be terminated with a NULL, <b>00</b> (hex)
	х	Image horizontal start position (top left corner).
	У	Image vertical start position (top left corner).
	imagePos	4 bytes (big endian) sector address of a previously stored Image-Icon that is about to be displayed.
Response	acknowledge	
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful
Description	previously sto	d displays a bitmap image or an icon on to the screen that has been red in the FAT file (specified by "filename") on the memory card. The screen image to be displayed is specified by (x, y).
		Screen Copy-Save to Card (FAT)" command always stores that part of the bit image, i.e. 2 bytes per pixel.
	the <b>Graphics</b> image parame don't need to loaded to the	Composer 3 by using "4DGL, SGC Picaso - GCI - FAT Selected Folder". The eters such as width, height and colour-mode are built into the GCI file; they be specified by the host controller. All you need is GCI filename which is SD card, and the pointer to the multimedia object which can be found from reated by the Graphics Composer along with the GCI file.
		ould not attempt to use "Display Image-Icon from Card (FAT) - @6Dhex" lisplay video, it may work, but it will be extremely slow.
Serial Example	40hex, 6Dhex 43hex, 49hex,	ta: , 47hex, 46hex, 58hex, 32hex, 44hex, 45hex, 4Dhex, 4Fhex, 2Ehex, 47hex, 00hex, 00hex, 00hex, 00hex, 00hex, 00hex, 01hex, A8hex, 00hex age in GFX2DEMO.GCI file at address location 0001A800hex at position (0, 0)
4DSL Example	Refer to the FA	AT.4DScript sample script file.

### 3.6.11 Play Audio WAV file from Card (FAT) - @6Chex

Serial Cmd	ext_cmd.cm	d, option, "file_name", terminator
4DSL Cmd	_	on, 'file_name')
120201110	ext_cmd	40(hex) or @(ascii) : Extended Command header byte
	cmd	<b>6C</b> (hex) or <b>I</b> (ascii) : Command header byte
	option	This byte specifies the available options for the WAV file:
	орион	<b>00hex</b> : Return when playing complete
		<b>01hex</b> : Return immediately
		<b>02hex</b> : STOP currently playing WAV file
		<b>03hex</b> : PAUSE currently playing WAV file
		<b>04hex</b> : RESUME currently playing WAV file
		<b>05hex</b> : LOOP playing until stopped
		Note: Option 02hex (STOP currently playing WAV file) turns off the PWM as well.
	file_name	The name of the WAV file in the memory card. The file name is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified the filename.
	terminator	The file_name string must be terminated with a NULL, <b>00</b> (hex)
Response	acknowledge	
	acknowledge	06(hex): ACK byte if successful
	-1 .	15(hex): NAK byte if unsuccessful
Description	data bandwid wont work. U format. The ideal sam Any higher sa the PWM will	d plays a WAV file from the memory card. Wave files should be mono to keep ith to a minimum, and should be 'canonic' format. Lots of windows formats Use something like 'Cool Edit' or similar to tailor the wav files to a suitable apple rate of the WAV file is 16Khz-Mono and the maximum should be 22Khz. Imple rate will extremely slow down the system. Sample rates below 12Khz, cause aliasing (filtering is a bare minimum).
		card are important, most 2Gb cards should be fine, 64mb cards fail all but the
Serial Example	40hex, 6Chex 00hex	Ata:  description:  descriptio
4DSL Example	-	AT.4DScript sample script file.

# 3.6.12 Run Script (4DSL) Program from Card (FAT) - @70hex

Serial Cmd	ext cmd, cmc	I, "file_name", terminator
	RunScriptFAT(	
	ext_cmd	40(hex) or @(ascii): Extended Command header byte
	cmd	<b>70</b> (hex) or <b>p</b> (ascii) : Command header byte
	file_name	The file name of the scripting file in the memory card. The file name is 1-12 chars long with an assumed '.' between chars 8 and 9, if there is not one specified the filename.
	terminator	The file_name string must be terminated with a NULL, <b>00</b> (hex)
Response	acknowledge	
	acknowledge	<b>06</b> (hex): ACK byte if successful <b>15</b> (hex): NAK byte if unsuccessful or card not present.
	further intera and display of Program or the ensure there at The PICASO-S auto run a pr power-up, if a automatically for those star send comman	mand executes the specified file name from the memory card without any ction by the host processor. It will sequentially execute all valid commands bejects until it gets to the end of the file. It is advisable to have the Exit ne Jump to Address commands at the end of the user composed program to are no undesirable results at the end of the file.  GC device is equipped to accept memory cards and has a feature that will eloaded script program on power-up. When using the FAT file system, upon a file called 'autoexec.4ds' exists on the memory card, the PICASO-SGC will execute this script program from the memory card. This is a useful feature and alone applications where the device does not require a host controller to add to the PICASO-SGC to play a slide show of images, video clips, etc. have to create and upload a slide show composition to the card to benefit o play feature.
	49hex, 70hex 53hex, 00hex	te: , 53hex, 63hex, 72hex, 69hex, 70hex, 74hex, 31hex, 2Ehex, 34hex, 44hex, DS script from the uSD card.
	-	AT.4DScript sample script file.

### 4. 4DSL Script Specific Commands

### 4.1 Script Control Commands (4DSL - Script Language)

The commands detailed in this section must reside in the SDHC/SD/microSD memory card. They form the heart of a simple Scripting Language that can be sequentially executed and run from the card. Majority of the commands described in the previous sections can also be included and executed within the script. Additional commands are under development to expand the scripting language and these will be released in due course.

#### **Summary of Commands in this section:**

- Delay **07hex**
- Set Counter **08hex**
- Decrement Counter 09hex
- Jump to Card Address If Counter Not Zero OAhex
- Jump to Card Address OBhex
- Exit-Terminate Script Program **OChex**

# 4.1.1 Delay - 07hex

4DSL Cmd	Delay(value)	
	value	2 byte (big endian) delay value in milliseconds.
·	When commands are executed within the script program a delay can be inserted between subsequent commands. A delay basically has the same effect as a NOP (No Operation) which can be used as a pause between drawing objects or displaying images-videos etc.	
<b>4DSL Example</b>	Refer to the AE	3C.4DScript sample script file.

### **4.1.2** Set Counter - 08hex

4DSL Cmd	SetCounter(value	ne)
	te	byte counter value that can be used with "Decrement Counter" and "Jump o Address If Counter Not Zero" commands to form loops. Practical values hould be between 2 and 255.
Description	over to achieve "Decrement Couser to determine For example, we of the Globe at are displayed seed display the 10 in a number of timend of the last for the Identity of the counter Not pointer will jum Zero" command	Is that might be part of an animation may need to be redisplayed over and the lengthy viewing. This command when used in conjunction with the sunter" and "Jump to Address If Counter Not Zero" commands allow the me exactly how many times the series of images are looped. It is may want to animate the Globe rotating. Let's say we have 10 image slides different rotated positions residing in the memory card. When the images equentially, the effective duration will only be the length of time it takes to mage frames. We can increase that length by looping through the animation has depending on the value set in the counter. When the display reaches the frame and encounters the Decrement Counter followed by Jump to Address Zero commands, the counter will be decremented and then the internal up to the memory Address specified in the "Jump to Address If Counter Not did. This sequence will repeat until the value in the counter reaches zero. The
	Address 00000000 00000002 00000015 00000025	nstrates how this maybe used:  Comment  Set Counter (value = 25),  Display Image from Memory Card (image1),  Delay(10ms),  Display Image from Memory Card (image2),  Delay(10ms),
	 00000119 00000129 00000132 00000134	Display Image from Memory Card (image10), Delay(10ms), Decrement Counter Jump to Address if Counter Not Zero (Address = 00000002)
	memory card a	ve example is typical of how a series of commands might be loaded into the nd then executed by using the Run Program from Memory Card command. would of course be the series of hex codes.
		C.4DScript sample script file.

### 4.1.3 Decrement Counter - 09hex

4DSL Cmd	Decrement
•	Decrements the Counter. See detailed description on how this command can be used effectively in the "Set Counter" command section.
4DSL Example	Refer to the ABC.4DScript sample script file.

# **4.1.4** Jump to Card Address If Counter Not Zero - OAhex

4DSL Cmd	JumpNotZero	umpNotZero(Address)		
	Address	A 4 byte (big endian) card memory jump address if counter is not zero.		
Description	address. If the Please see de	f the internal counter is not zero the program pointer will jump to the specified card address. If the counter is zero then it will continue executing the next script command. Please see detailed description on how this command can be used effectively in the "Set Counter" command section.		
4DSL Example	Refer to the A	BC.4DScript sample script file.		

# 4.1.5 Jump to Card Address - OBhex

4DSL Cmd	GoTo(Address)										
	Address	A 4 byt	e (big e	endia	n) card m	emo	ry ju	mp addres	s.		
-	This comman unconditionally								•	•	
4DSL Example	Refer to the AE	C.4DSc	ript sar	nple	script file	·.					

# **4.1.6** Exit-Terminate Script Program - OChex

4DSL Cmd	Exit
Description	This command forces the program to stop executing from the memory card and ready to accept and execute commands from the host via the serial interface. When the internal program memory pointer encounters this command it will force the command execution from memory card to terminate. It can also be sent, by the host, via the serial link to terminate a program currently executing from the memory card.
4DSL Example	Refer to the ABC.4DScript sample script file.

### 4.2 Directives (4DSL - Script Language)

Directives are lines included in the program but are not program statements. These lines are always preceded by a hash sign (#). They are executed before the actual compilation of code begins.

They extend only across a single line of code. As soon as a newline character is found, the directive is considered to end. No semicolon ";" is expected at the end of the directive..

#### **Summary of Commands in this section:**

- #Compile
- #Define
- #Include
- #Origin
- #Run

# 4.2.1 #Compile

4DSL Cmd	#compile("P	latform", "Comport", "Speed", "WrapCol", "WrapTrunc")			
	Platform	Picaso or Goldelox			
	Comport	The comm port to use			
	Speed The maximum speed of the Comm port, used during downloads, 9600 used normally.				
	WrapCol	WrapCol The number of bytes after which wrapping or truncation occcurs in the compile listing			
	WrapTrunc	Wrap or Trunc. Specifies whether the compile listing is wrapped or truncated when Wrapcol is reached			
Description	Set script cor	Set script compile and options.			
		This must be the first line of a script. it can be changed using the buttons in the workshop window. The comm port may be set manually.			
Serial Example	#Compile(Pic	#Compile(Picaso,COM4,9600,5,Wrap)			
4DSL Example	Most of the	4DS Script Samples.			

### 4.2.2 #define

4DSL Cmd	#define ("Nar	define ("Name", "Substitution")		
	Name	Source to be substituted		
	Substitution	The replacement text or value		
Description	This can be u command line	This can be used to define replacement for parameters so that they can be set from the command line		
Serial Example	#define red	0xf800		
	OR			
	#define file	" <u>C:\test.fle</u> "		
4DSL Example	Refer to the 4	DScript_16bitColours.inc file.		

### 4.2.3 #Include

4DSL Cmd	finclude("Filename")		
	Filename	Name of the file to be included	
Description	This can be used to include other files into the script		
Serial Example	#include	"4DScript_16bitColours.inc"	
4DSL Example	Most of the	4DS Script Samples.	

# 4.2.4 #origin

4DSL Cmd	#origin("Ori	torigin("Origin")		
	Origin	The start address of this script		
	This defines	Use this to specify the start address of a script. Only one #origin statement is permitted. This defines the start of the script when it is written to a uSD card in RAW mode. Or the filename when the file is written in FAT mode		
Serial Example	#Origin 0x40	#Origin 0x400 // start on sector 2		
4DSL Example	Refer to the	ABC400.4DScript sample script file.		

### 4.2.5 #run

4DSL Cmd	#run("Platfo	orm", "Comport", "Speed", "WrapCol", "WrapTrunc")			
	Platform	Picaso or Goldelox			
	Comport	The comm port to use			
	Speed	<b>d</b> The maximum speed of the Comm port, used during downloads, 9600 is used normally.			
	WrapCol	The number of bytes after which wrapping or truncation occcurs in the compile listing			
	WrapTrunc	Wrap or Trunc. Specifies whether the compile listing is wrapped or truncated when Wrapcol is reached			
Description	Set script ru	Set script run and options.			
		This must be the first line of a script. it can be changed using the buttons in the workshop window. The comm port may be set manually.			
Serial Example	#run(Picaso,	#run(Picaso,COM4,9600,5,Wrap); //Line 1 set script run and options			
4DSL Example	Most of the	4DS Script Samples.			

### 4.3 Macros (4DSL - Script Language)

Given below is the detailed command set for Macros that are executed from the PC while the display module is connected to it. These commands begin with a \$ sign. They also include some of the general serial commands that can be executed with PC acting as a host controller such as \$ReadFile and \$WriteSectors etc.

### **Summary of Commands in this section:**

- \$4DGLLoadprogram
- \$LoadPmmC
- \$Message
- \$ReadBytes
- \$ReadFATImage
- \$ReadFile
- \$ReadSectors
- \$ReaduSDImage
- \$StartSave
- \$WriteFile
- \$WriteSectors
- \$4DGLAttn
- \$4DGLExit
- \$AbortOnError
- \$CloseComPort
- \$EndSave
- \$FlushBuffer
- \$IgnoreErrors
- \$OpenComport
- \$OpenInit
- \$ReadCSD
- \$TimeOff
- \$TimeOn

# 4.3.1 \$4DGLLoadprogram

4DSL Cmd	\$4DGLLoadpro	4DGLLoadprogram("4DGLprogram", ram flash)		
	4DGLprogram	The filename of a compiled 4DGL program to be loaded onto a display		
	ram flash	am: Target is RAM on the processor.		
		Flash: Target is Flash on the processor.		
Response	acknowledge			
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful		
Description	Loads the specified program onto the display. The file extension must not be specified.			
Serial Example	\$4DGLLoadProgram("c:\Documents and Settings\All Users\Documents\4D Labs\PICASO GFX2\Picaso – Graphics\worm",Ram)			
4DSL Example	Refer to the Lo	ad4DGLProgram .4DScript sample script file.		

# 4.3.2 \$LoadPmmC

4DSL Cmd	\$LoadPmmC("PmmCName")					
	PmmCName	The filename of the PmmC to be loaded.				
Response	acknowledge	acknowledge				
	_	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful				
Description	Loads a Pmm(	Loads a PmmC file on the processor.				
Serial Example	\$LoadPmmC("c:\Documents and Settings\All Users\Documents\4D Labs\PICASO GFX2\Picaso – Graphics\worm",Ram)					
4DSL Example	Refer to the Lo	padPmmC .4DScript sample script file.				

# 4.3.3 \$Message

4DSL Cmd	\$Message('St	Message('String')		
	String	The string of text to be displayed .		
	the console a	Displays a message to the user. If run from the command line the message is displayed on the console and the console waits for a key to be pressed, If run from workshop a message pox is displayed.		
Serial Example	\$Message('Al	Message('About to halve Volume')		
4DSL Example	Refer to the F	AT.4DScript sample script file.		

# 4.3.4 \$ReadBytes

4DSL Cmd	\$ReadBytes("Filename", "#Bytes")	
	Filename	The file to write the bytes to
	#Bytes	The number of bytes to read
Response	data_byte	
	data_byte	1 byte of card data
Description	Reads number of from the uSD card at the current address and saves them to the file Filename.	
Serial Example	\$Readbytes('50bytes.hex',50)	
4DSL Example	Refer to the Raw.4DScript sample script file.	

# 4.3.5 \$ReadFATImage

4DSL Cmd	\$ReadFATImage("uSDFile", "PCFile")	
	uSDFile	The image file on the uSD card.
	PcFile	The name of the output BMP file on the PC.
Description	Reads an image file from the uSD card and converts it to a Bitmap file and saves it on the PC.	
Serial Example	\$ReadFATImage('scrncopy','scrncopy.bmp')	
4DSL Example	Refer to the FAT.4DScript sample script file.	

# 4.3.6 \$ReadFile

4DSL Cmd	\$ReadFile("Handshaking", "uSDFile", "StartAcks", "pcFile")	
	Handshaking	The handshaking to use 0-50.
	uSDFile	The name of the file on the uSD Card to read.
	StartAcks	The number of ACKS to send at the start, Double or Single, Double gives the best performance, but will not work on all controllers.
	pcFile	The destination file on the PC
Description	This reads a FAT file from the uSD card and saves it on the PC.	
Serial Example	\$ReadFile(50,'scrncopy',double,'scrncopy.raw')	
4DSL Example	Refer to the FAT.4DScript sample script file.	

# 4.3.7 \$ReadSectors

4DSL Cmd	\$ReadSectors("pcFile", "StartSector", "#Sectors")	
	pcFile	The handshaking to use 0-50.
	startsector	The name of the file on the uSD Card to read.
	#sectors	The number of ACKS to send at the start, Double or Single, Double gives the best performance, but will not work on all controllers.
Description	This reads #sectors from the uSD card starting at the specified sector and saves them to the pc with the specified Filename.	
Serial Example	\$readsectors('Sector0.hex',1,1)	
4DSL Example	Refer to the Raw.4DScript sample script file.	

# 4.3.8 \$ReaduSDImage

4DSL Cmd	\$ReaduSDImage("startSector", "width", "height","pcFile")	
	startsectors	The starting sector of the image on the uSD card.
	width	The width of the image on the uSD card or -1 for New Format, includes header (type2) images.
	height	The height of the image on the uSD card or -1 for New Format, includes header (type2) images.
	PcFile	The name of the output BMP file on the PC.
Description	This reads an image file from the uSD card and converts it to a Bitmap file and saves it on the PC.	
Serial Example	\$ReaduSDImage(0,-1,-1,'ImageNew.bmp')	
4DSL Example	Refer to the Raw.4DScript sample script file.	

# 4.3.9 \$StartSave

4DSL Cmd	\$StartSave("pcFile")	
	PcFile	The name of the output file on the PC
Description	This causes the results of all subsequent commands to be written to the specified file until the \$EndSave command is used.	
Serial Example	\$startsave('pixel.hex')	
	:	
	:	
	\$endsave	
4DSL Example	Refer to the	GraphicsPt2.4DScript sample script file.

# 4.3.10 \$WriteFile

4DSL Cmd	\$WriteFile("Handshaking", "AppRep", "startacks", "uSDFile", "pcFile")		
	Handshaking	The handshaking to use 0-50.	
	apprep	Append or Replace	
	StartAcks	The number of ACKS to send at the start, Double or Single, Double gives the best performance, but will not work on all controllers.	
	uSDFile	The name of the file on the uSD Card to read.	
	pcFile	The destination file on the PC	
Response	acknowledge		
	acknowledge	<b>06</b> (hex) : ACK byte if successful <b>15</b> (hex) : NAK byte if unsuccessful	
Description	This writes a FAT file to the uSD card.		
Serial Example	\$WriteFile(50,Replace,double,'test1.gci','\\resources\copy to usd\test1.gci');		
	OR		
	\$WriteFile(50,Replace,double,'abc.4ds','abc.4DScrpObj');		
4DSL Example	Refer to the FAT.4DScript sample script file.		

# 4.3.11 \$WriteSectors

4DSL Cmd	\$WriteSectors("pcFile", "StartSector")		
	pcFile	The file to read the sectors from	
	startsector	TThe starting sector to Write to	
Response	acknowledge		
	acknowledge	<b>06</b> (hex) : ACK byte if successful	
		15(hex): NAK byte if unsuccessful	
Description	This reads a FAT file from the uSD card and saves it on the PC. This reads #sectors from t		
	uSD card starting at the specified sector and saves them to the pc with the specified		
	Filename.		
Serial Example	\$WriteSectors("\\resources\Misc\NemoNewFmt.hex",500)		
4DSL Example	Most of the 4DSL Scripts		

# 4.3.12 Extended Macros

	Externaca macre				
\$4DGLAttn	Use this to get attention of the 4DGL hypervisor to enable the use of the read and write sectors commands.				
	4DSL Example	Refer to the Load4DGLuSD.4DScript sample script file.			
\$4DGLExit	Use this to exit from the 4DGL hypervisor				
	4DSL Example	Refer to the Load4DGLuSD.4DScript sample script file.			
	-				
\$AbortOnError	This causes the script to abort if a command resturns a NAK or other unexpected result. This is the default. The opposite is \$IgnoreErrors				
	4DSL Example	Refer to the General.4DScript sample script file.			
	1				
\$CloseComPort	This closes the com port, if it is open.				
	4DSL Example	Refer to the General.4DScript sample script file.			
	•				
\$EndSave	This closes the file previously openned with \$StartSave.				
	4DSL Example	Refer to the GraphicsPt2.4DScript sample script file.			
		The state of the s			
\$FlushBuffer	This flushes the Comms buffer.				
7110011201101	4DSL Example	Refer to the Raw.4DScript sample script file.			
	i z z z z z z z z z z z z z z z z z z z	Note: Co.			
\$IgnoreErrors	This causes the script to continue if a command resturns a NAK or other unexpected result. The opposite is \$AbortonError				
	4DSL Example	Refer to the General.4DScript sample script file.			
	-				
\$OpenComport	This Opens the c	om port, no checking is done. See \$OpenInit for a verified open			
	4DSL Example	Refer to the General.4DScript sample script file.			
	•				
\$OpenInit	This Opens the com port and sends autobaud('U') and checks for an ACK. Up to 10				
, - , -	retries are performed.				
	4DSL Example	Most of the 4DSL Scripts			
	-				
\$ReadCSD	This reads CSD record from the uSD card and displays the card's capacity.				
	4DSL Example	Refer to the Raw.4DScript sample script file.			
	1 2 2 2 2 2 2	The second of th			
\$TimeOff	This turns off logging of times for each command (default).				
7111112011	4DSL Example	Refer to the General.4DScript sample script file.			
	-DOL LAMINPIC	neier to the deficial about pt sample sample sample.			
\$TimeOn	This turns on log	ging of times for each command.			
y i iiiieOii	4DSL Example	Refer to the General.4DScript sample script file.			
	+DOL EXAMINE	meter to the deficial.4D3Cript sample Stript file.			

### 4.4 4DSL Keywords

#### #run, #compile option

'Picaso' The target platform for 4DSL Script

'Wrap' Sets the compile listing to be wrapped when Wrapcol is reached.
'Trunc' Sets the compile listing to be truncated when Wrapcol is reached.

#### **4DGL program Load option**

'Ram' Program is loaded to RAM.
'Flash' Program is loaded to Flash.

#### **Button option**

'Down' Button Down (pressed)
'Up' Button Up (not pressed)

#### Font size option

'small' 5x7 small size font set
'medium' 8x8 medium size font set
'large' 8x12 large size font set
'xlarge' 12x16 largest size font set

#### Font magnification option

'Mag1' Multiply the width by 1.
'Mag2' Multiply the width by 2.
'Mag3' Multiply the width by 3.

## **Opacity option**

**'Opaque'** Opaque, objects behind text blocked by background.

'Transparent' Transparent, objects behind text are visible.

#### **Pen Size Option**

Solid All graphics objects are drawn solid

Outline All graphics objects are drawn wire-frame

#### **PlayWav Option**

WaitComplete Return when playing complete

**Return** Return immediately

StopSTOP currently playing WAV filePausePAUSE currently playing WAV fileResumeRESUME currently playing WAV file

**LOOP** LOOP playing until stopped

#### **Volume Option**

'min' Minimum Volume.
'max' Maximum Volume.

'mute' Mute

**'down'** Volume Down **'down8'** Volume Down 8

'up' Volume Up 'up8' Volume Up 8 'muteoff' Mute Off

#### WriteFile option

**Append** Append mode, file will be appended to (or created if it doesn't exist)

**Replace** No Append, file will be created (or overwritten if it exists).

### WriteFile, ReadFile option

Single The number of ACKS to send at the start or ReadFile/WriteFile, Double or Single, Double

gives the best performance, but will not work on all controllers.

**Double** The number of ACKS to send at the start or ReadFile/WriteFile, Double or Single, Double

gives the best performance, but will not work on all controllers.

### 16 bit Colours keywords

'AQUA' 0x07FF
'BLACK' 0x0000
'GREEN' 0x0400

Refer the 4DScript\_16bitColours.inc file for complete list.

Note: Refer to the 4DSL Script Samples for details on usage of above keywords.

## 4.5 Summary List of Commands available for Scripting

The commands listed below are all of the available commands for composing a script program that can be executed within the memory card.

#### General Commands

- AutoBaud 55hex.
- Set new Baud Rate 51hex
- Version-Device Info Request 56hex.
- Display Resolution 64hex.
- Replace Background Colour 42hex.
- Clear Screen 45hex.
- Display Control Functions 59hex.
- Set Volume 76hex
- Sleep 5Ahex
- Read GPIO Pin 69hex
- Write to GPIO Pin 79hex
- Read GPIO Bus 61hex
- Write to GPIO Bus 57hex
- Switch-Buttons-Joystick Status 4Ahex.
- Wait for Switch-Buttons-Joystick Status 6Ahex.
- Sound 4Ehex.
- Tune 6Ehex

#### Graphics Commands

- Add User Bitmap Character 41hex.
- Draw Circle 43hex.
- Draw User Bitmap Character 44hex.
- Draw Triangle 47hex.
- Draw Image-Icon 49hex.
- · Set Background colour 4Bhex
- Draw Line 4Chex.
- Draw Pixel 50hex.
- Read Pixel 52hex.
- Screen Copy-Paste 63hex.
- Draw Polygon 67hex.
- Replace Colour 6Bhex
- Set Pen Size 70hex.
- Draw Rectangle 72hex.
- Draw Ellipse 65hex

#### Text Commands

- Set Font 46hex.
- Set Transparent-Opaque Text 4Fhex.
- Draw "String" of ASCII Text (graphics format) 53hex.
- Draw ASCII Character (text format) 54hex.
- Draw Text Button 62hex.
- Draw "String" of ASCII Text (text format) 73hex.

Draw ASCII Character (graphics format) - 74hex.

#### Touch Screen Commands

- Get Touch Coordinates 6Fhex
- Wait Until Touch 77hex
- Detect Touch Region 75hex

#### SD Memory Card Commands (Low-Level/RAW)

- Set Address Pointer of Memory Card @41hex.
- Screen Copy Save to Memory Card @43hex.
- Display Image-Icon from Memory Card @49hex. (New Image Format)
- Display Image-Icon from Memory Card @49hex. (Old Image Format)
- Display Object from Memory Card @4Fhex.
- Run Script (4DSL) Program from Memory Card @50hex.
- Read Sector Block Data from Memory Card @52hex.
- Display Video-Animation Clip from Memory Card @56hex.(New Image Format)
- Display Video-Animation Clip from Memory Card @56hex.(Old Image Format)
- Write Sector Block Data to Memory Card @57hex.
- Initialise Memory Card @69hex.
- Read Byte Data from Memory Card @72hex.
- Write Byte Data to Memory Card @77hex.

#### SD Memory Card Commands (FAT-Level/DOS)

- Erase File from Card (FAT) @65hex.
- List Directory of Card (FAT) @64hex.
- Screen Copy Save to Card (FAT) @63hex.
- Open GCI (FAT) @47.
- Set GCI Entry (FAT) @45.
- Display Frame (FAT) @46.
- Display Image-Icon from Card (FAT) @6Dhex.
- Play Audio WAV file from Card (FAT) @6Chex.
- Run Script (4DSL) Program from Card (FAT) @70hex.

#### Script Control Commands (4DSL - Script Language)

- Delay 07hex.
- Set Counter 08hex.
- Decrement Counter 09hex.
- Jump to Address If Counter Not Zero OAhex.
- Jump to Address OBhex.
- Exit-Terminate Script Program OChex.

#### Directives

- #compile
- #define
- #include
- #origin
- #run

#### Macros (4DSL - Script Language)

- \$4DGLAttn
- \$4DGLExit
- \$4DGLLoadprogram

- \$AbortOnError
- \$CloseComPort
- \$EndSave
- \$FlushBuffer
- \$IgnoreErrors
- \$LoadPmmC
- \$Message
- \$OpenComport
- \$OpenInit
- \$ReadBytes
- \$ReadCSD
- \$ReadFATImage
- \$ReadSectors
- \$ReaduSDImage
- \$StartSave
- \$TimeOff
- \$TimeOn
- \$WriteSectors

# Appendix A : Development and Support Tools


## 5.1 PmmC Loader - PmmC File Programming Software Tool

The 'PmmC Loader' is a free software tool for Windows based PC platforms. Use this tool to program the latest PmmC file into the PICASO-SGC chip embedded in your application board. It is available for download from the 4D Systems website, <a href="https://www.4dsystems.com.au">www.4dsystems.com.au</a>



## 5.2 microUSB - PmmC Programming Hardware Tool

The micro-USB module is a USB to Serial bridge adaptor that provides a convenient physical link between the PC and the PICASO-SGC device. A range of custom made micro-USB devices such as the  $\mu$ USB-MB5 and the  $\mu$ USB-CE5 are available from 4D Systems <u>www.4dsystems.com.au.</u> The micro-USB module is an essential hardware tool for all the relevant software support tools to program, customise and test the PICASO-SGC chip.






## 5.3 Display Initialisation Setup Personality (DISP) - Software Tool

**DISP** is a free software tool for Windows based PC platforms. Use this tool to:-


- Configure the PICASO-SGC chip to work with a specific display.
- Modify the way the chip initially sets up the display, e.g. screen saver, brightness, etc.
- Construct the splash screens.
- Replace or modify the embedded fonts.

It is available for download from the 4D Systems website, www.4dsystems.com.au.



## 5.4 Graphics Composer – Software Tool


The Graphics Composer is a free software tool for Windows. This software tool is an aid to composing a slide show of images/animations/movie-clips (multi-media objects) which can then be downloaded into the SDHC/SD/micro-SD/MMC memory card that is supported by the PICASO-SGC. The host simply sends commands to the PICASO-SGC to display the multimedia objects.



#### 5.5 FONT Tool – Software Tool


Font-Tool is a free software utility for Windows based PC platforms. This tool can be used to assist in the conversion of standard Windows fonts (including True Type) into the bitmap fonts used by the PICASO-SGC chip. It is available for download from the 4D Systems website, <a href="https://www.4dsystems.com.au">www.4dsystems.com.au</a>.

**Disclaimer:** Windows fonts may be protected by copyright laws. This software is provided for experimental purposes only.



### 5.6 FAT Controller – Software Test Tool


The 4D FAT Controller is a free software tool to test all of the functionality of the GOLDELOX-DOS, GOLDELOX-SGC and the PICASO-SGC devices and their respective modules. It is useful in learning about how to communicate with the chips and the modules. For the GOLDELOX-SGC and the PICASO-SGC it can also simulate most of the operation of the device and assist in the creation of simple scripts, either simulating the execution of those scripts and / or downloading them into a micro-SD/micro-SDHC card for execution on the display.



#### 5.7 RMPET – Software Tool

micro-SD/SD/SDHC memory cards nearly always come pre-partitioned with a single partition. Windows only accesses the first partition on the card and ignores any other partitions. **RMPET** (Removable Media Partition Edit Tool) can split a large card into two partitions, the first partition for use as a FAT16 partition and the second partition for use as a RAW partition. RMPET allows setting of the first partition to a percentage of the card, the 2GB maximum of the FAT16 Windows format program, or the 4GB maximum of FAT16 when the command prompt format command is used.


It is available for download from the 4D Systems website, www.4dsystems.com.au.




# 5.8 Evaluation Display Modules

The following modules, available from 4D Systems, can be used for evaluation purposes to discover what the PICASO-SGC processor has to offer.








# Appendix B: Using the FAT-Controller to Compose Script Programs

## 6.1 Getting Started

- Download and run the FAT-Controller software (for PC Windows) from the <u>www.4dsystems.com.au</u> website.
- You will need a USB to Serial converter module to provide a serial link between the FAT-Controller running on your PC and the PICASO-SGC application display module. 4D Systems has a range of appropriate modules such μUSB-CE5 and μUSB-MB5.

### 6.2 Starting a Script

- Before starting to construct your script, click the "Clear Script" command button, otherwise the script log will start from the time Com port is opened.
- Run all the appropriate commands you need for the script composition and click "Save Script" to save the script with .4dScpObj extension.



### **6.3** Running the Script

- Click Load button under the "Script Execution Section" under the "Script Commands" tab. A
  dialogue box will open up.
- Select your saved script file and click Run to run the script.

## 6.4 Running the .4ds Script Program from the Memory Card


- Under the "Fat" tab look for the "@p Run Program as from MC FAT" option.
- Insert the memory card into the PICASO-SGC based application display module with. Make sure the .**4ds** script file is saved on to the memory card.
- Now click Execute Program. This command will run the slide show with the command sent to the PICASO-SGC via the serial port.

### 6.5 Running the Auto-Run Script Slide Show

- To make an Auto-Run script file, rename the created script file (described previously) to autoexec.4ds and save it to the memory card.
- Insert the memory card into the application display module and power up the module. The autoexec.4ds script file will now run automatically.


### 6.6 Running Graphics Composer GCI files from the Memory Card

- The Graphics Composer is a separate software tool that will convert all standard image and video files into a format that can be used by the PICASO-SGC device. It can be downloaded from www.4dsystems.com.au
- The Graphics Composer will create bot a GCI and DAT file. Load both of these files into the memory card.
- Open the DAT file with a text editor and note the the image/video file names and their corresponding addresses in the memory card. See snapshot below:



- Note the addresses on the DAT file are LSW (Least Significant Word), MSW (Most Significant Word)
   e.g. for "scen1.jpg" the LSW = 5A00(hex) and the MSW = 0002(hex).
- Under the "Fat" tab look for the "Display Image @m" command. Enter the GCI file name along with its extension.
- Enter the screen position you wish to display the image.
- Enter the address location of the image in the GCI file. Note that the entry is in decimal. For example for "scen1.jpg" Index H = 2 (0002hex), Index L = 23040 (5A00hex).

• Click the "Display Image" button. The image will now be displayed on the target display module. Make sure the memory card is first inserted into the display module.



# **Proprietary Information**

The information contained in this document is the property of 4D Labs Pty. Ltd. and may be the subject of patents pending or granted, and must not be copied or disclosed with out prior written permission.

4D Labs endeavours to ensure that the information in this document is correct and fairly stated but does not accept liability for any error or omission. The development of 4D Labs products and services is continuous and published information may not be up to date. It is important to check the current position with 4D Labs. 4D Labs reserves the right to modify, update or make changes to Specifications or written material without prior notice at any time.

All trademarks belong to their respective owners and are recognised and acknowledged.

# Disclaimer of Warranties & Limitation of Liability

4D Labs makes no warranty, either express or implied with respect to any product, and specifically disclaims all other warranties, including, without limitation, warranties for merchantability, non-infringement and fitness for any particular purpose.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications.

In no event shall 4D Labs be liable to the buyer or to any third party for any indirect, incidental, special, consequential, punitive or exemplary damages (including without limitation lost profits, lost savings, or loss of business opportunity) arising out of or relating to any product or service provided or to be provided by 4D Labs, or the use or inability to use the same, even if 4D Labs has been advised of the possibility of such damages.

4D Labs products are not fault tolerant nor designed, manufactured or intended for use or resale as on line control equipment in hazardous environments requiring fail – safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines or weapons systems in which the failure of the product could lead directly to death, personal injury or severe physical or environmental damage ('High Risk Activities'). 4D Labs and its suppliers specifically disclaim any expressed or implied warranty of fitness for High Risk Activities.

Use of 4D Labs' products and devices in 'High Risk Activities' and in any other application is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless 4D Labs from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any 4D Labs intellectual property rights..

#### Copyright 4D Labs Pty. Ltd. 2000-2012.

Revision History						
Revision Number	Revision Content	Revision Date				
1.0	First Release	12 <sup>th</sup> September 2009				
11.0	1-Added "Display Resolution" command, Sec 3.1.4. 2-Added new Baud Rates, Sec 3.1.2. Rate 10hex and 11hex.	28 <sup>th</sup> March 2012				
	3-Added a Note in Sec 3.1.2 about the PWM. 4-Added "Open GCI" command, Sec 3.6.7. 5-Added "Set GCI Entry" command, Sec 3.6.8. 6-Added "Display Frame" command, Sec 3.6.9.					