INSTRUCTIONS:
Fill out the hazard analysis and risk assessment below.
HA-001 should be for the lane departure warning function as discussed in the lecture.
HA-002 should be for the lane keeping assistance function as discussed in the lecture.
Then come up with your own shustons and hazards for the lane sesilations evitien. Fill in the HA-003 and HA-004 rows.
When finished, export your spreadshed as a pdf file so that a reviewer can easily see your work.

Hazar	<u> </u>	Situational Analysis							Hazard Identification						Hazardous Event Classification						Determin	nation of ASIL and Safety Goals			
	Oper	rational Mode	Operational Scenario	Environmental Details	Situation Details	Other Details (optional)	Item Usage (function)	Situation Description	Function	Deviation	Deviation Details	Hazardous Event (resulting effect)	Event Details	Hazardous Event Description	Exposure (of situation)	Rationale (for exposure)	Severity (of potential harm)	Rationale (for severity)	Controllability (of hazardous event)	Rationale (for controllability)	ASIL Determination	Safety Goal			
HA-00	1 OM03	- Normal driving	OS04 - Highwa	EN06 - Rain (slippery road)	SD02 - High speed		IU01 - Correctly used	Normal Driving on a Highway at High Speed during Rain with active Lane Departure Warning function	Lane Departure Warning (LDW) function shall apply an oscillating steering torque to provide the driver with haptic feedback	offect is too	Oscillating steering torque exceeds limit	EV08 - Collision with other vehicle	Vehicle crashes into traffic or road infrastructure with injury to driver and any others present	Driver loses control of vehicle	E3 - Medium probability	Activation of the lane departure warning system during highway driving at high speed is a medium probability event.	S3 - Life-threatening or fatal injuries	On highway, speed of vehicle is expected to be high	C3 - Difficult to control or uncontrollable	Since the steering wheel rotates uncontrollably, will be difficult for the average driver to control the vehicle at high speed in the rain	С	The oscillating steering torque from the LDW function shall be limited			
HA-00	2 OM03	- Normal driving	OS04 - Highwa	EN01 - Normal conditions	SD02 - High speed		IU02 - Incorrectly used	Normal Driving on a Highway at High Speed	Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane	always	LKA is always active. Driver is taking hands off the wheel.	EV08 - Collision with other vehicle	Vehicle crashes into traffic or road infrastructure with injury to driver and any others present	Driver loses control of vehicle	E2 - Low probability	Driver abusing the LKA as Autopilot during highway driving at high speeds is a low probability event	S3 - Life-threatening or fatal injuries	On highway, speed of vehicle is expected to be high	C3 - Difficult to control or uncontrollable	Since driver has his hands off the wheel, he cannot control the vehicle	В	The LKA function shall be time limited and the additional steering torque shall end after a given time interval			
HA-00	3 OM03	- Normal driving	OS04 - Highwa	EN04 - Snowfall (degraded view)	SD02 - High speed		IU01 - Correctly used	Normal Driving on a Highway at High Speed during Snowfall with active Lane Keeping Assistance function	Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane	DV10 - Actor effect is reverse	Steering torque applied, but in the wrong direction	EV08 - Collision with other vehicle	Vehicle crashes into traffic or road infrastructure with injury to driver and any others present	Driver loses control of vehicle	E2 - Low probability	Activation of the lane departure system while driving on highway during snowfall at high speed is alow probability event	S3 - Life-threatening or fatal injuries	Collision at high speed in highly constrained space	C3 - Difficult to control or uncontrollable	Since LKA generates an entirely unexpected steering input and with little time to react, a driver will typically not be able to control the vehicle	В	The LKA function shall be deactivated during snowfall (degraded view) conditions			
HA-00	4 OM03	- Normal driving	OS03 - Country Road	EN06 - Rain (slippery road)	SD03 - Low speed		IU01 - Correctly used	Normal Driving on a Country Road at Low Speed during Rain with active Lane Keeping Assistance function	Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane		LKA corrects driver input while driver attempts to evade obstacle	EV11 - Car spins out of control	Vehicle crashes into traffic or road infrastructure with injury to driver and any others present	Driver loses control of vehicle	E1 - Very Low probability	Evading obstacle on a country road in the rain at low speed is a very low probability event	S3 - Life-threatening or fatal injuries	Speed of vehicle is high while attempting to evade obstacle	C3 - Difficult to control or uncontrollable	Driver does not expect extra torque in steering wheel and loses control in already difficult to control situation	А	The LKA function shall be deactivated during heavy steering			