# VFPIX Silicon Telescope Custom Electronics & DAQ Design

#### Caleb Fangmeier


Univ. of Nebraska - Lincoln

August 31, 2015


- System Overview
- 2 Constraints and Freedoms
- 3 Datarates, Analog vs. Digital Domain
- 4 Parts Selection
- PCB Examples
- 6 Software Tools

- System Overview
- Constraints and Freedoms
- Batarates, Analog vs. Digital Domain
- 4 Parts Selection
- 5 PCB Examples
- 6 Software Tools

# Telescope Block Diagram



## The Back Plane Board



# The Back Plane Board(Previous Iteration)




- System Overview
- 2 Constraints and Freedoms
- 3 Datarates, Analog vs. Digital Domair
- 4 Parts Selection
- 5 PCB Examples
- 6 Software Tools

#### What parts of the system are fixed?


- Type and number of Micro-Strip Sensors
- APC128 Readout Chip
- Testbeam Constraints
  - Radiation Exposure
  - Mechanical Sizes

# Micro-Strip Sensor


- 512 Strips per Sensor
- Adjacent Strips read out on opposite sides by APC128 Chips




# Analog Pipeline Chip 128



# Analog Pipeline Chip 128






#### What parts are flexible?

- ADC location, precision(bitness), and sample rate
- Cabling
- Number/type of readout channels(Serial/Parallel, Analog/Digital)
- Digital Controller(FPGA,CPLD,Microcontroller, ...)
- Amplifiers, DACs, Capacitors, Resistors, . . .
- PCB layouts of all boards including
  - Sensor Mount Card
  - Back-Plane Board
  - DAQ Card

- System Overview
- Constraints and Freedoms
- 3 Datarates, Analog vs. Digital Domain
- 4 Parts Selection
- 5 PCB Examples
- 6 Software Tools

- 8 Sensors \* 512 Strips/Sensor = 4096 Strips
- Each APC128 serializes 128 Strips
- ullet ightarrow 32 Analog Channels with 128 Strips/Channel
- lacktriangle More serialization ightarrow fewer cables/ADCs, but slower readout
- Faster readout is critical to data rate!

# Where to Digitize?



- Any stateful electronics(e.g. ADCs, DACs, RAM, etc.) must be out of beam to avoid SEUs.
- Op-amps and other linear electronics are OK.
- However, less distance between sensor and ADC means less noise and, potentially, faster readout.
- Compromise is to place ADC on DAQ board  $\approx$ 0.5m from telescope, but out of beam.

- System Overview
- Constraints and Freedoms
- Parts Selection
- 5 PCB Examples
- 6 Software Tools



# APC128 Buffer/Line Driver

- Previous designs required APC128 to drive signal line directly.
- APC128 output very weak.  $\approx 800\Omega$  output impedance.
- Cable capacitance resulted in slow rise times.
- Place buffer amp close to APC128


#### Choice of amp is the Analog Devices AD8138

- Very low noise,  $5nV/\sqrt{Hz}$
- Appropriate bandwidth(300MHz) & slew rate(1150V/ $\mu$ s)
- Differential output suitable for sending down a high-speed cable. e.g.
  CAT-5



## ADC

#### Choice of ADC is the Analog Devices AD9219



- Sample speed up to 40MHz(will plan on oversampling signal)
- 10-bit precision
- 4-Channel differential inputs
- Requires a clock at sample frequency. Generates own readout clock.
- Must optimize PCB environment to achieve maximum performance.

#### Controller

#### Choice of Controller is Opal Kelly ZEM4310



- Integrated Module including
  - Altera Cyclone IV FPGA
  - USB 3.0
  - 128 MiB DDR2 SDRAM
  - 2xHSMC Expansion Header(on back)
- Appropriate for deserializing all 32 ADC channels in parallel
- Helps avoid design of difficult and expensive custom FPGA board

## **General Comments**

- The design must incorporate parts one can actually order.
- Digikey is your friend!
- Keep a Bill-of-Materials with specific part numbers.
- Get used to reading datasheets.

# PCB Design Gotchas


- Make sure the device pinout matches what you think it is. Sometimes multiple parts share a datasheet.
- There is no charge for extra writing on the silkscreen. *Use it!*
- Check part's datasheet for a recommended PCB footprint. Don't trust the built-in footprint library!
- Give some thought to how the board will be assembled. e.g. Avoid SMT parts on both sides.
- Respect the design rules of your PCB house. e.g. Min trace/via sizes
- Calculate power requirements and give yourself a 2x safety factor with your supplies.




- System Overview
- 2 Constraints and Freedoms
- 3 Datarates, Analog vs. Digital Domair
- 4 Parts Selection
- 5 PCB Examples
- 6 Software Tools



# NIM-TTL Level Translator Board



# APC128 Testboard



- System Overview
- 2 Constraints and Freedoms
- 3 Datarates, Analog vs. Digital Domair
- 4 Parts Selection
- 5 PCB Examples
- 6 Software Tools



#### ■ Electronic Simulation - QUCS

- Free & Open Source
- Great support for Linux.
- Intuitive UI, Integrated Simulation Views
- Good Support for Generic Simulation
- Poor Integration of Spice Models

#### Circuit Design & PCB Layout - KiCAD

- Free & Open Source
- No Limit on Board Size or Number of Layers
- Under Active Development
- Lacks some advanced features of commercial software

#### ■ FPGA Design - Quartus II

- Proprietary
- Developed By Altera (Same Company as FPGAs)
- Can Develop Firmware Either Graphically with Block Diagrams or with an HDL (e.g. Verilog)



#### **Custom Tools**

#### PatternGen

- A Tool for converting ASCII waveform files to Verilog
- Useful for generating multi-channel bit patterns with an FPGA

#### ■ Make\_Mapping

A tool for mapping pins along a connection chain



#### References

All custom tools available here:

https://github.com/cfangmeier/Small

All Circuit/PCB Designs available here:

https://github.com/frmeier/VFPIX-telescope-PCB