# $P4_{16}$ Portable Switch Architecture (PSA) (draft)

The P4.org language consortium May 15, 2017

#### Abstract

P4 is a language for expressing how packets are processed by the data plane of a programmable network forwarding element. P4 programs specify how the various programmable blocks of a target architecture are programmed and connected. The Portable Switch Architecture (PSA) is target architecture that describes common capabilities of network switch devices which process and forward packets across multiple interface ports.

# 1. Target Architecture Model

The Portable Switch Architecture (PSA) Model has six programmable P4 blocks and two fixed-function blocks, as shown in Figure 1. Programmable blocks are hardware blocks whose function can be programmed using the P4 language. The Packet buffer and Replication Engine (PRE) and the Buffer Queuing Engine (BQE) are target dependent functional blocks that may be configured for a fixed set of operations.

Incoming packets are parsed and have their checksums validated and are then passed to an ingress match action pipeline, which makes decisions on where the packets should go. After the ingress pipeline, the packet may be buffered and/or replicated (sent to multiple egress ports). For each such egress port, the packet passes through an egress match action pipeline and a checksum update calculation before it is deparsed and queued to leave the pipeline.



Figure 1. Portable Switch Pipeline

A programmer targeting the PSA is required to instantiate objects for the programmable blocks that conform to these APIs. Note that the programmable block APIs are templatized on user defined headers and metadata. In PSA, the user can define a single metadata type for all controls.

When instantiating the main package object, the instances corresponding to the programmable blocks are passed as arguments.

# 2. PSA Data types

# 2.1. PSA type definitions

These types need to be defined before including the architecture file and the macro protecting them should be defined.

```
typedef bit<unspecified> PortId_t;
typedef bit<unspecified> MulticastGroup_t;
typedef bit<unspecified> PacketLength_t;
typedef bit<unspecified> EgressInstance_t;
typedef bit<unspecified> ParserStatus_t;
typedef bit<unspecified> ParserErrorLocation_t;
typedef bit<unspecified> timestamp_t;
const PortId_t PORT_CPU = unspecified;
```

# 2.2. PSA supported metadata types

```
enum InstanceType_t { NORMAL_INSTANCE, CLONE_INSTANCE }
struct psa_parser_input_metadata_t {
 PortId t
                           ingress_port;
  InstanceType\_t
                           instance_type;
struct psa_ingress_input_metadata_t {
 PortId_t
                           ingress_port;
 InstanceType_t
                           instance_type; /// Clone or Normal
 /// set by the runtime in the parser, these are not under programmer control
  ParserStatus_t
                          parser_status;
  ParserErrorLocation_t
                           parser_error_location;
  timestamp_t
                           ingress_timestamp;
}
struct psa_ingress_output_metadata_t {
 PortId_t
                           egress_port;
struct psa_egress_input_metadata_t {
 PortId_t
                           egress_port;
                        instance_type; /// Clone or Normal
instance; /// instance coming
 InstanceType_t
                                           /// instance coming from PRE
 EgressInstance_t
  timestamp_t
                           egress_timestamp;
2.3. Match kinds
Additional supported match kind types
match_kind {
    range,
             /// Used to represent min..max intervals
    selector /// Used for implementing dynamic_action_selection
2.4. Cloning methods
enum CloneMethod t {
  /// Clone method
                           Packet source
                                                      Insertion point
  Ingress2Ingress, /// original ingress,
                                                      Ingress parser
  Ingress2Egress,
                   /// post parse original ingress, Buffering queue
                    /// post deparse in egress,
 Egress2Ingress,
                                                      Ingress parser
  Egress2Egress
                   /// inout to departer in egress, Buffering queue
```

### 3. PSA Externs

# 3.1. Packet Replication Engine

The PacketReplicationEngine extern represents the non-programmable part of the PSA pipeline.

}

Even though the PRE can not be programmed using P4, it can be configured both directly using control plane APIs and by setting intrinsic metadata. In this specification we opt to define the operations available in the PRE as method invocations. A target backend is responsible for mapping the PRE extern APIs to the appropriate mechanisms for performing these operations in the hardware.

The PRE extern object has no constructor, and thus it cannot be instantiated in the user's P4 program. The architecture instantiates it exactly once, without requiring the user's P4 program to instantiate it. The PRE is made available to the Ingress programmable block using the same mechanism as packet\_in. A corresponding Buffering and Queuing Engine (BQE) extern is defined for the Egress pipeline (see 3.2).

**Note to implementers**: some of these operations may not be implemented as native operations on a certain target. However, the goal is that all operations should be implementable as a combination of native and non-native operations. Target documentation should highlight such implementations, so that application programmers are aware of the potentially significant performance penalties.

Semantics of behavior for multiple calls to PRE APIs

The semantics of calling the PRE APIs is equivalent to setting intrinsic metadata fields/bits and assuming that the PRE looks up the fields in the following order: drop, truncate, multicast, clone, output\_port.

Following this semantics, examples of the behaviors are:

- any call to drop in the pipeline will cause the packet, and all potential clone copies (see below) to drop.
- any call to truncate, will cause the packet (and its clones \todo: check) to be truncated.
- multiple calls to send to port the last call in the ingress pipeline sets the output port.
- multiple calls to multicast the last in the ingress pipeline sets the multicast group
- interleaving send\_to\_port and multicast the semantics of multicast is defined as below (https://github.com/p4lang/tutorials/issues/22): if (multicast\_group!= 0)

```
multicast_to_group(multicast_group);
else
  send_to_port(output_port);
```

From this, it follows that if there is a call that sets the multicast\_group, the packet will be multicast to the group that last set the multicast group. Otherwise, the packet will be sent to the port set by send to port.

- multiple clone invocations will cause the packet to be cloned to the corresponding port. Any drop call in the pipeline will cause the packet to drop, and no clone will be created (following the analogy with intrinsic metadata bit fields, drop bits are processed before clone bits are looked up).
- resubmit
- recirculate

extern PacketReplicationEngine {

\TODO: finalize the semantics of calling multiple of the PRE APIs

```
// PacketReplicationEngine(); /// No constructor. PRE is instantiated /// by the architecture.
```

#### 3.1.1. PRE Methods

#### **3.1.1.1.** Unicast operation Sends packet to a port.

Targets may implement this operation by setting the appropriate intrinsic metadata or through some other mechanism of configuring the PRE.

The port parameter is the output port. If the port is PORT\_CPU the packet will be sent to CPU.

```
void send_to_port (in PortId_t port);
```

#### **3.1.1.2.** Multicast operation Sends packet to a multicast group or a port.

Targets may implement this operation by setting the appropriate intrinsic metadata or through some other mechanism of configuring the PRE.

The multicast\_group parameter is the multicast group id. The control plane must program the multicast groups through a separate mechanism.

```
void multicast (in MulticastGroup_t multicast_group);
```

# **3.1.1.3. Drop operation** Do not forward the packet.

The PSA implements drop as an operation in the PRE. While the drop operation can be invoked anywhere in the pipeline (ingress or egress), the semantics supported by the PSA is that the drop will be at the end of the pipeline (ingress or egress). Any other operations invoked in the pipeline, whether on the packet or any externs (e.g. counter updates, meter updates, register writes) will execute, until the packet reaches the end of the pipeline. Operations in the egress pipeline will not execute if drop is called in ingress.

```
void drop ();
```

#### **3.1.1.4.** Clone operation Create a copy of the packet and send it to the specified port.

The PSA specifies four types of cloning, with the packet sourced from different points in the pipeline and sent back to ingress or to the buffering queue in the egress (see 2.4). \TODO: needs both source and destination data

Parameters:

- clone method The type of cloning.
- port The port to send the cloned packet to.

```
void clone (in CloneMethod_t clone_method, in PortId_t port);
```

**3.1.1.5.** Clone with extra data operation Create a copy of the packet with additional data and send it to the specified port.

The PSA specifies four types of cloning, with the packet sourced from different points in the pipeline and sent back to ingress or to the buffering queue in the egress (see 2.4). \TODO: needs both source and destination data

Parameters:

- clone method The type of cloning.
- port The port to send the cloned packet to.
- data additional header data attached to the packet

```
void clone<T> (in CloneMethod_t clone_method, in PortId_t port, in T data);
```

**3.1.1.6. Resubmit operation** Send a packet to the ingress port with additional data appended. This operation is intended for recursive packet processing. \TODO: needs both source and destination data

Parameters:

- data A header definition that can be added to the set of packet headers.
- port The input port at which the packet will be resubmitted.

```
void resubmit<T>(in T data, in PortId_t port);
```

**3.1.1.7.** Recirculate operation Send a post deparse packet to the ingress port with additional data appended.

This operation is intended for recursive packet processing.  $\backslash TODO$ : needs both source and destination data

Parameters:

- data A header definition that can be added to the set of packet headers.
- port The input port at which the packet will be resubmitted.

```
void recirculate<T>(in T data, in PortId_t port);
```

**3.1.1.8.** Truncate operation Truncate the payload of the outgoing packet to the specified length. The length parameter represents the desired payload length in bytes. To remove the payload one may invoke truncate(0).

```
void truncate(in bit<32> length);
```

# 3.2. Buffering Queuing Engine

The BufferingQueueingEngine extern represents the other non-programmable part of the PSA pipeline (after Egress).

Even though the BQE can not be programmed using P4, it can be configured both directly using control plane APIs and by setting intrinsic metadata. In this specification we opt to define the operations available in the BQE as method invocations. A target backend is responsible for mapping the BQE extern APIs to the appropriate mechanisms for performing these operations in the hardware.

The BQE extern object has no constructor, and thus it cannot be instantiated in the user's P4 program. The architecture instantiates it exactly once, without requiring the user's P4 program to instantiate it. The BQE is made available to the Egress programmable block using the same mechanism as packet\_in. A corresponding Packet Replication Engine (PRE) extern is defined for the Ingress pipeline (see 3.1).

Note to implementers: some of these operations may not be implemented as primitive operations on a certain target. However, the goal is that all operations should be implementable as a combination of other operations. Target documentation should highlight such implementations, so that application programmers are aware of the potentially significant performance penalties.

The ordering semantics of multiple calls to BQE APIs is identical to the semantics ordering of PRE invocations, for the subset of functions supported in the BQE.

#### 3.2.1. BQE Methods

# **3.2.1.1. Drop operation** Do not forward the packet.

The PSA implements drop as an operation in the BQE. While the drop operation can be invoked anywhere in the ingress pipeline, the semantics supported by the PSA is that the drop will be at the end of the pipeline (ingress or egress).

3.3. Hashes 3. PSA EXTERNS

```
void drop
               ();
3.2.1.2. Truncate operation Truncate the outgoing packet to the specified length
   The length parameter represents the packet length.
void truncate(in bit<32> length);
3.3. Hashes
Supported hash algorithms:
enum HashAlgorithm {
  identity,
  crc32,
  crc32_custom,
  crc16,
  crc16_custom,
  ones_complement16, /// One's complement 16-bit sum used for IPv4 headers,
                       /// TCP, and UDP.
  target_default
                      /// target implementation defined
3.3.1. Hash function
Example usage:
parser P() {
  Hash<bit<16>>(HashAlgorithm.crc16) h;
  bit<16> hash_value = h.getHash(buffer);
}
Parameters:
   • algo The algorithm to use for computation (see 3.3).
   • O The type of the return value of the hash.
extern Hash<0> {
  /// Constructor
  Hash(HashAlgorithm algo);
  /// Compute the hash for data.
  /// @param data The data over which to calculate the hash.
  /// @return The hash value.
  0 getHash<D>(in D data);
  /// Compute the hash for data, with modulo by max, then add base.
  /// @param base Minimum return value.
  /// @param data The data over which to calculate the hash.
  /// Cparam max The hash value is divided by max to get modulo.
  ///
             An implementation may limit the largest value supported,
             e.g. to a value like 32, or 256.
  /// @return (base + (h \% max)) where h is the hash value.
  O getHash<T, D>(in T base, in D data, in T max);
```

# 3.4. Checksum computation

Checksums and hash value generators are examples of functions that operate on a stream of bytes from a packet to produce an integer. The integer may be used, for example, as an integrity check for a packet or as a means to generate a pseudo-random value in a given range on a packet-by-packet or flow-by-flow basis.

Parameters:

• W The width of the checksum

#### 3.5. Counters

Counters are a mechanism for keeping statistics. The control plane can read counter values. A P4 program cannot read counter values, only update them. If you wish to implement a feature involving sequence numbers in packets, for example, use Registers instead (Section 3.7).

Direct counters are counters associated with a particular P4 table, and are implemented by the extern DirectCounter. There are also indexed counters, which are implemented by the extern Counter. The primary differences between direct counters and indexed counters are:

- Number of independently updatable counter values:
  - A single instantiation of a direct counter always contains as many independent counter values as the number of entries in the table with which it is associated (TBD: see below for what this means for tables that use action profiles).
  - You must specify the number of independent counter values for an indexed counter when instantiating it. This number of counters need not be the same as the size of any table.
- Where counter updates are allowed in the P4 program:
  - For a direct counter, you may only invoke its count method from inside the actions of the table with which it is associated, and this always updates the counter value associated with the matching table entry.
  - For an indexed counter, you may invoke its count method anywhere in the P4 program where extern object method invocations are permitted (e.g. inside actions, or directly inside a control's apply block), and every such invocation must specify the index of the counter value to be updated.

Counters are only intended to support packet counters and byte counters, or a combination of both called packets\_and\_bytes. The byte counts are always increased by some measure of the packet length, where the packet length used might vary from one PSA implementation to another. For example, one implementation might use the Ethernet frame length, including the Ethernet header and FCS bytes, as the packet arrived on a physical port. Another might not include the FCS bytes in its definition of the packet length. Another might only include the Ethernet payload length. Each PSA implementation should document how it determines the packet length used for byte counter updates.

If you wish to keep counts of other quantities, or to have more precise control over the packet length used in a byte counter, you may use Registers to achieve that (Section 3.7).

# 3.5.1. Counter types

```
enum CounterType_t {
    packets,
    bytes,
   packets_and_bytes
}
3.5.2. Counter
/// Indirect counter with n_counters independent counter values, where
/// every counter value has a data plane size specified by type W.
extern Counter<W, S> {
  Counter(bit<32> n_counters, CounterType_t type);
  void count(in S index);
  /*
  /// The control plane API uses 64-bit wide counter values. It is
  /// not intended to represent the size of counters as they are
  /// stored in the data plane. It is expected that control plane
  /// software will periodically read the data plane counter values,
  /// and accumulate them into larger counters that are large enough
  /// to avoid reaching their maximum values for a suitably long
  /// operational time. A 64-bit byte counter increased at maximum
  /// line rate for a 100 gigabit port would take over 46 years to
  /// wrap.
  @ControlPlaneAPI
    bit<64> read
                     (in S index);
    bit<64> sync_read (in S index);
    void set
                      (in S index, in bit<64> seed);
    void reset
                      (in S index);
    void start
                      (in S index);
                      (in S index);
    void stop
  }
}
```

See below for pseudocode of an example implementation for the Counter extern.

The example implementation for next\_counter\_value is not intended to restrict PSA implementations. In particular, the storage format for packets\_and\_bytes type counters is just one example of how it could be done. Implementations are free to store state in other ways, as long as the control plane API returns the correct packet and byte count values.

Two common techniques for counter implementations in the data plane are:

- wrap around counters
- saturating counters, that 'stick' at their maximum possible value, without wrapping around.

This specification does not mandate any particular approach in the data plane. Implementations should strive to avoid losing information in counters. One common implementation technique is to implement an atomic "read and clear" operation in the data plane that can be invoked by the control plane software. The control plane software invokes this operation frequently enough to

prevent counters from ever wrapping or saturating, and adds the values read to larger counters in driver memory.

```
Counter(bit<32> n_counters, CounterType_t type) {
    this.num_counters = n_counters;
    this.counter_vals = new array of size n_counters, each element with type W;
    this.type = type;
    if (this.type == CounterType_t.packets_and_bytes) {
        // Packet and byte counts share storage in the same counter
        // state. Should we have a separate constructor with an
        // additional argument indicating how many of the bits to use
        // for the byte counter?
        W shift_amount = TBD;
        this.shifted_packet_count = ((W) 1) << shift_amount;
        this.packet_count_mask = (~((W) 0)) << shift_amount;</pre>
        this.byte_count_mask = ~this.packet_count_mask;
    }
}
W next_counter_value(W cur_value, CounterType_t type) {
    if (type == CounterType_t.packets) {
        return (cur_value + 1);
    // Exactly which packet bytes are included in packet_len is
    // implementation-specific.
    PacketLength_t packet_len = <packet length in bytes>;
    if (type == CounterType_t.bytes) {
        return (cur_value + packet_len);
    }
    // type must be CounterType_t.packets_and_bytes
    // In type W, the least significant bits contain the byte
    // count, and most significant bits contain the packet count.
    // This is merely one example storage format. Implementations
    // are free to store packets_and_byte state in other ways, as
    // long as the control plane API returns the correct separate
    // packet and byte count values.
    W next_packet_count = ((cur_value + this.shifted_packet_count) &
                           this.packet_count_mask);
    W next_byte_count = (cur_value + packet_len) & this.byte_count_mask;
    return (next_packet_count | next_byte_count);
}
void count(in S index) {
    if (index < this.num_counters) {</pre>
        this.counter_vals[index] = next_counter_value(this.counter_vals[index],
                                                       this.type);
    } else {
        // No counter_vals updated if index is out of range.
        // See below for optional debug information to record.
}
```

Optional debugging information that may be kept if an index value is out of range includes:

- Number of times this occurs.
- A FIFO of the first N out-of-range index valus that occur, where N is implementation-defined (e.g. it might only be 1). Extra information to identify which count() method call in the P4 program had the out-of-range index value is also recommended.

#### 3.5.3. Direct Counter

```
extern DirectCounter<W> {
  DirectCounter(CounterType_t type);
  void count();
  @ControlPlaneAPI
    W
                       (in TableEntry key);
         read<W>
         sync_read<W> (in TableEntry key);
    void set
                       (in W seed);
    void reset
                       (in TableEntry key);
    void start
                       (in TableEntry key);
    void stop
                       (in TableEntry key);
  }
}
```

A DirectCounter instance must appear in the list of values of the psa\_direct\_counters table attribute for exactly one table. We call this table the DirectCounter instance's "owner". It is an error to call the count method for a DirectCounter instance anywhere except inside an action of its owner table.

The counter value updated by an invocation of count is always the one associated with the table entry that matched.

TBD: How to describe which counter value is updated for tables with action profiles and direct counters? Or should this combination even be allowed?

An action of an owner table need not have count method calls for all of the DirectCounter instances that the table owns. You must use an explicit count() method call on a DirectCounter to update it, otherwise its state will not change.

An example implementation for the DirectCounter extern is essentially the same as the one for Counter. Since there is no index parameter to the count method, there is no need to check for whether it is in range.

The rules here mean that an action that calls count on a DirectCounter instance may only be an action of that instance's one owner table. If you want to have a single action A that can be invoked by multiple tables, you can still do so by having a unique action for each such table with a DirectCounter, where each such action in turn calls action A, in addition to any count invocations they have.

A DirectCounter instance must have a counter value associated with its owner table that is updated when there is a default action assigned to the table, and a search of the table results in a miss. If there is no default action assigned to the table, then there need not be any counter updated when a search of the table results in a miss.

By "a default action is assigned to a table", we mean that either the table has a default\_action table property with an action assigned to it in the P4 program, or the control plane has made an explicit call to assign the table a default action. If neither of these is true, then there is no default action assigned to the table.

TBD: Verify that the method of reading this default action counter state is documented for the control plane API. I believe that Antonin Bas said that it can be accessed using the same API call

used to read a DirectCounter value associated with a table entry, except that the key in the API call should be empty.

TBD: Should a single table be restricted to have at most one DirectCounter associated with it, or should it be allowed to have more than one?

#### 3.5.4. Example program using counters

The following partial P4 program demonstrates the instantiation and updating of Counter and DirectCounter externs.

```
typedef bit<48> ByteCounter_t;
typedef bit<32> PacketCounter_t;
typedef bit<80> PacketByteCounter_t;
const PortId_t NUM_PORTS = 512;
struct headers {
    ethernet_t
                     ethernet;
    ipv4_t
                     ipv4;
}
control ingress(inout headers hdr,
                inout metadata user_meta,
                PacketReplicationEngine pre,
                in psa_ingress_input_metadata_t istd,
                out psa_ingress_output_metadata_t ostd)
{
    Counter<ByteCounter_t, PortId_t>((bit<32>) NUM_PORTS, CounterType_t.bytes)
        port_bytes_in;
    DirectCounter<PacketByteCounter_t>(CounterType_t.packets_and_bytes)
        per_prefix_pkt_byte_count;
    action next_hop(PortId_t oport) {
        per_prefix_pkt_byte_count.count();
        ostd.egress_port = oport;
    action default_route_drop() {
        per_prefix_pkt_byte_count.count();
        pre.drop();
    table ipv4_da_lpm {
        key = { hdr.ipv4.dstAddr: lpm; }
        actions = {
            next_hop;
            default_route_drop;
        default_action = default_route_drop;
        //psa_direct_counters = {
              // table ipv4_da_lpm owns this DirectCounter instance
              per_prefix_pkt_byte_count;
        //
        //}
    }
    apply {
```

3.6. Meters 3. PSA EXTERNS

```
port_bytes_in.count(istd.ingress_port);
        ostd.egress_port = 0;
        if (hdr.ipv4.isValid()) {
            ipv4_da_lpm.apply();
        }
   }
}
control egress(inout headers hdr,
               inout metadata user_meta,
               BufferingQueueingEngine bge,
               in psa_egress_input_metadata_t istd)
{
   Counter<ByteCounter_t, PortId_t>((bit<32>) NUM_PORTS, CounterType_t.bytes)
       port_bytes_out;
   apply {
        // By doing these stats updates on egress, as long as IP
        // multicast replication happens in the packet buffer, this
        // update will occur once for each copy made, which in this
        // example is intentional.
       port_bytes_out.count(istd.egress_port);
   }
}
```

#### 3.6. Meters

Meters (RFC 2698) are a more complex mechanism for keeping statistics about packets, most often used for dropping or "marking" packets that exceed an average packet or bit rate. To mark a packet means to change one or more of its quality of service values in packet headers such as the 802.1Q PCP (priority code point) or DSCP (differentiated service code point) bits within the IPv4 or IPv6 type of service byte. The meters specified in the PSA are 3-color meters.

PSA meters do not require any particular drop or marking actions, nor do they automatically implement those behaviors for you. Meters keep enough state, and update their state during execute() method calls, in such a way that they return a GREEN (also known as conform), YELLOW (exceed), or RED (violate) result. See RFC 2698 for details on the conditions under which one of these three results is returned. The P4 program is responsible for examining that returned result, and making changes to packet forwarding behavior as a result.

RFC 2698 describes "color aware" and "color blind" variations of meters. The Meter and DirectMeter externs implement both. The only difference is in which execute method you use when updating them. See the comments on the extern definitions below.

Similar to counters, there are two flavors of meters: indexed and direct. (Indexed) meters are addressed by index, while direct meters always update a meter state corresponding to the matched table entry or action, and from the control plane API are addressed using P4Runtime table entry as key.

There are many other similarities between counters and meters, including:

- The number of independently updatable meter values.
- Where meter updates are allowed in a P4 program.
- For bytes type meters, the packet length used in the update is determined by the PSA implementation, and can vary from one PSA implementation to another.

Further similarities between direct counters and direct meters include:

• DirectMeter execute method calls must be performed within actions invoked by the table

3.6. Meters 3. PSA EXTERNS

that owns the DirectMeter instance. It is optional for such an action to call the execute method.

• There must be a meter state associated with a DirectMeter instance's owner table, that can be updated when the table result is a miss. As for a DirectCounter, this state only needs to exist if a default action is assigned to the table.

The table attribute to specify that a table owns a DirectMeter instance is psa\_direct\_meters. The value of this table attribute is a list of meter instances.

As for counters, if you call the execute(idx) method on an indexed meter and idx is at least the number of meter states, so idx is out of range, no meter state is updated. The execute call still returns a value of type MeterColor\_t, but the value is undefined – programs that wish to have predictable behavior across implementations must not use the undefined value in a way that affects the output packet or other side effects. The example code below shows one way to achieve predictable behavior. Note that this undefined behavior cannot occur if the value of  $n_meters$  of an indexed meter is  $2^W$ , and the type S used to construct the meter is bit<W>, since the index value could never be out of range.

```
#define METER1_SIZE 100
Meter<bit<7>>(METER1_SIZE, MeterType_t.bytes) meter1;
bit<7> idx;
MeterColor_t color1;

// ... later ...

if (idx < METER1_SIZE) {
    color1 = meter1.execute(idx, MeterColor_t.GREEN);
} else {
    // If idx is out of range, use a default value for color1. One
    // may also choose to store an error flag in some metadata field.
    color1 = MeterColor_t.RED;
}</pre>
```

Any implementation will have a finite range that can be specified for the Peak Burst Size and Committed Burst Size. An implementation should document the maximum burst sizes they support, and if the implementation internally truncates the values that the control plane requests to something more coarse than any number of bytes, that should also be documented. It is recommended that the maximum burst sizes be allowed as large as the number of bytes that can be transmitted across the implementation's maximum speed port in 100 milliseconds.

Implementations will also have finite ranges and precisions that they support for the Peak Information Rate and Committed Information Rate. An implementation should document the maximum rate it supports, as well as the precision it supports for implementing requested rates. It is recommended that the maximum rate supported be at least the rate of the implementation's fastest port, and that the actual implemented rate should always be within plus or minus 0.1% of the requested rate.

```
3.6.1. Meter types
enum MeterType_t {
   packets,
```

bytes

}

3. 7. Registers 3. PSA EXTERNS

# 3.6.2. Meter colors enum MeterColor\_t { RED, GREEN, YELLOW }; 3.6.3. Meter // Indexed meter with n\_meters independent meter states. extern Meter<S> { Meter(bit<32> n\_meters, MeterType\_t type); // Use this method call to perform a color aware meter update (see // RFC 2698). The color of the packet before the method call was // made is specified by the color parameter. MeterColor\_t execute(in S index, in MeterColor\_t color); // Use this method call to perform a color blind meter update (see // RFC 2698). It may be implemented via a call to execute(index, // MeterColor\_t.GREEN), which has the same behavior. MeterColor\_t execute(in S index); /\* @ControlPlaneAPI reset(in MeterColor\_t color); setParams(in S index, in MeterConfig config); getParams(in S index, out MeterConfig config); } \*/ } 3.6.4. Direct Meter extern DirectMeter { DirectMeter(MeterType\_t type); // See the corresponding methods for extern Meter. MeterColor\_t execute(in MeterColor\_t color); MeterColor\_t execute(); /\* @ControlPlaneAPI reset(in TableEntry entry, in MeterColor\_t color); void setConfig(in TableEntry entry, in MeterConfig config); void getConfig(in TableEntry entry, out MeterConfig config); }

# 3.7. Registers

}

Registers are stateful memories whose values can be read and written in actions. Registers are similar to counters, but can be used in a more general way to keep state.

3.8. Random 3. PSA EXTERNS

Although registers cannot be used directly in matching, register read may be used as the RHS of an assignment operation, allowing the current value of the register to be copied into metadata and be available for matching in subsequent tables.

A simple usage example might be to verify that a "first packet" was seen for a particular type of flow. A register cell would be allocated to the flow, initialized to "clear". When the protocol signaled a "first packet", the table would match on this value and update the flow's cell to "marked". Subsequent packets in the flow could would be mapped to the same cell; the current cell value would be stored in metadata for the packet and a subsequent table could check that the flow was marked as active.

```
extern Register<T, S> {
 Register(S size);
       read (in S index);
 void write (in S index, in T value);
  /*
 @ControlPlaneAPI
  {
    Т
                       (in S index);
         read<T>
                       (in S index, in T seed);
    void set
    void reset
                       (in S index);
 }
}
```

#### 3.8. Random

The random extern provides a reliable, target specific number generator in the min .. max range.

The set of distributions supported by the Random extern. \TODO: should this be removed in favor of letting the extern return whatever distribution is supported by the target?

```
enum RandomDistribution {
   PRNG,
   Binomial,
   Poisson
}
extern Random<T> {
   Random(RandomDistribution dist, T min, T max);
   T read();

   /*
   @ControlPlaneAPI
   {
     void reset();
     void setSeed(in T seed);
   }
   */
}
```

# 3.9. Action Profile

Action profiles are used as table implementation attributes.

3.10. Action Selector 3. PSA EXTERNS

Action profiles implement a mechanism to populate table entries with actions and action data. The only data plane operation required is to instantiate this extern. When the control plane adds entries (members) into the extern, they are essentially populating the corresponding table entries.

```
extern ActionProfile {
    /// Construct an action profile of 'size' entries
    ActionProfile(bit<32> size);

    /*
    @ControlPlaneAPI
    {
        entry_handle add_member (action_ref, action_data);
        void delete_member (entry_handle);
        entry_handle modify_member (entry_handle, action_ref, action_data);
    }
    */
}
```

#### 3.10. Action Selector

Action selectors are used as table implementation attributes.

Action selectors implement another mechanism to populate table entries with actions and action data. They are similar to action profiles, with additional support to define groups of entries. Action selectors require a hash algorithm to select members in a group. The only data plane operation required is to instantiate this extern. When the control plane adds entries (members) into the extern, they are essentially populating the corresponding table entries.

```
extern ActionSelector {
 /// Construct an action selector of 'size' entries
 /// @param algo hash algorithm to select a member in a group
 /// Cparam size number of entries in the action selector
 /// @param outputWidth size of the key
 ActionSelector(HashAlgorithm algo, bit<32> size, bit<32> outputWidth);
  /*
 @ControlPlaneAPI
                                    (action_ref, action_data);
    entry_handle add_member
                  delete_member
                                    (entry_handle);
    void
    entry_handle modify_member
                                    (entry_handle, action_ref, action_data);
     group_handle create_group
    void
                  delete_group
                                    (group_handle);
                                    (group_handle, entry_handle);
    void
                  add_to_group
    void
                  delete_from_group (group_handle, entry_handle);
 }
}
```

#### 3.11. Packet Generation

\TODO: is generating a new packet and sending it to the stream or is it adding a header to the current packet and sending it to the stream (copying or redirecting).

```
extern Digest<T> {
   Digest(PortId_t receiver); /// define a digest stream to receiver
```

3.12. Parser Value Sets 3. PSA EXTERNS

```
void emit(in T data);  /// emit data into the stream

/*
@ControlPlaneAPI
{
   // TBD
   // If the type T is a named struct, the name should be used
   // to generate the control-plane API.
}
   */
}
```

#### 3.12. Parser Value Sets

A parser value set is a named set of values that may be used during packet header parsing time to make decisions. You may use control plane API calls to add values to a set, and remove values from a set, at run time, much like P4 tables. Unlike tables, they may not have actions associated with them. They may only be used to determine whether a particular value is in the set, returning a Boolean value. That Boolean value can then be used in a select statement to control parsing (see examples below).

```
extern ValueSet<D> {
   ValueSet(int<32> size);
   bool is_member(in D data);
   /*
   @ControlPlaneAPI
   message ValueSetEntry {
       uint32 value_set_id = 1;
        // FieldMatch allows specification of exact, lpm, ternary, and
        // range matching on fields for tables, and these options are
        // permitted for the ValueSet extern as well.
        repeated FieldMatch match = 2;
   }
   // ValueSetEntry should be added to the 'message Entity'
   // definition, inside its 'oneof Entity' list of possibilities.
   */
}
```

The control plane API excerpt above is intended to be added as part of the P4Runtime API<sup>1</sup>.

The control plane API for a ValueSet is similar to that of a table, except only match fields may be specified, with no actions. This includes API calls that specify ternary or range matching, although for ValueSets these do not require specifying any priority values, since the only result of a ValueSet is\_member call is "in the set" or "not in the set".

If a PSA target can do so, it should implement control plane API calls involving ternary or range matching using ternary or range matching capabilities in the target, consuming the minimal table entries possible.

However, a PSA target is allowed to implement such control plane API calls by "expanding" them into as many exact match entries as needed to have the same behavior. For example, a control plane API call adding all values in the range 5 through 8 may be implemented as adding the four separate exact match values 5, 6, 7, and 8.

<sup>&</sup>lt;sup>1</sup>The P4Runtime API, defined as a Google Protocol Buffer .proto file, can be found at https://github.com/p4lang/PI/blob/master/proto/p4/p4runtime.proto

3.12. Parser Value Sets 3. PSA EXTERNS

The parser definition below shows an example that uses two ValueSet instances called tpid\_types and trill\_types.

```
parser ParserImpl(packet_in buffer,
                  out headers parsed_hdr,
                  inout metadata user_meta,
                  in psa_parser_input_metadata_t istd)
{
   ValueSet<bit<16>>(4) tpid_types;
   ValueSet<bit<16>>(2) trill_types;
   state start {
       buffer.extract(parsed_hdr.ethernet);
        transition select(parsed_hdr.ethernet.etherType) {
            0x0800: parse_ipv4;
            0x86DD: parse_ipv6;
            default: dispatch_tpid_value_set;
        }
   }
   state dispatch_tpid_value_set {
       bool is_tpid = tpid_types.is_member(parsed_hdr.ethernet.etherType);
        transition select(is_tpid) {
            true: parse_vlan_tag;
            default: dispatch_trill_value_set;
        }
   }
   state dispatch_trill_value_set {
        bool is_trill = trill_types.is_member(parsed_hdr.ethernet.etherType);
        transition select(is_trill) {
            true: parse_trill;
            default: accept;
        }
   }
   state parse_vlan_tag {
        // extract VLAN 802.1Q header here
        transition accept;
   state parse_trill {
        // extract TRILL header here
        transition accept;
   }
   state parse_ipv4 {
        transition accept;
   state parse_ipv6 {
        transition accept;
   }
}
```

The second example (below) has the same parsing behavior as the example above, but combines the two parse states dispatch\_tpid\_value\_set and dispatch\_trill\_value\_set into one.

```
state dispatch_tpid_value_set {
   bool is_tpid = tpid_types.is_member(parsed_hdr.ethernet.etherType);
   bool is_trill = trill_types.is_member(parsed_hdr.ethernet.etherType);
```

3.13. Timestamps 3. PSA EXTERNS

```
transition select(is_tpid, is_trill) {
     (true, _): parse_vlan_tag;
     (false, true): parse_trill;
     default: accept;
}
```

The third example (below) demonstrates one way to have a ValueSet that matches on multiple fields, by making the type D a struct containing multiple bit vectors.

```
struct CustomValueSet1_t {
    bit<16> etherType;
    bit<8> partialMacAddress;
}
parser ParserImpl(packet_in buffer,
                  out headers parsed_hdr,
                  inout metadata user_meta,
                  in psa_parser_input_metadata_t istd)
{
    ValueSet<CustomValueSet1_t>(2) trill_types;
    state dispatch_tpid_value_set {
        bool is_trill =
            trill_types.is_member({parsed_hdr.ethernet.etherType,
                                    parsed_hdr.ethernet.dstAddr[7:0]});
        transition select(is_trill) {
            true: parse_vlan_tag;
            default: accept;
        }
    }
    // ... etc.
```

A PSA compliant implementation is not required to support any use of a ValueSet is\_member method call return value, other than directly inside of a select expression. For example, a program fragment like the one shown below may be rejected, and thus P4 programmers striving for maximum portability should avoid writing such code.

```
bool is_tpid = tpid_types.is_member(parsed_hdr.ethernet.etherType);
is_tpid = is_tpid && (parsed_hdr.ethernet.dstAddr[47:40] == 0xfe);
transition select(is_tpid) {
    // ...
```

# 3.13. Timestamps

A PSA implementation provides an ingress\_timestamp value for every packet in the ingress control block, as a field in the struct with type psa\_ingress\_input\_metadata\_t. This timestamp should be close to the time that the first bit of the packet arrived to the device, or alternately, to the time that the device began parsing the packet. This timestamp is *not* automatically included with the packet in the egress control block. A P4 program wishing to use the value of ingress\_timestamp in egress code must copy it to a user-defined metadata field that reaches egress.

A PSA implementation also provides an egress\_timestamp value for every packet in the egress control block, as a field of the struct with type psa\_egress\_input\_metadata\_t.

3.13. Timestamps 3. PSA EXTERNS

One expected use case for timestamps is to store them in tables or Register instances to implement checking for timeout events for protocols, where precision on the order of milliseconds is sufficient for most protocols.

Another expected use case is INT (Inband Network Telemetry<sup>2</sup>), where precision on the order of microseconds or smaller is necessary to measure queueing latencies that differ by those amounts. It takes only 0.74 microseconds to transmit a 9 Kbyte Ethernet jumbo frame on a 100 gigabit per second link.

For these applications, it is recommended that an implementation's timestamp increments at least once every microsecond. Incrementing once per clock cycle in an ASIC or FPGA implementation would be a reasonable choice. The timestamp should increment at a constant rate over time. For example, it should not be a simple count of clock cycles in a device that implements dynamic frequency scaling<sup>3</sup>.

Timestamps are of type timestamp\_t, which is type bit<W> for a value of W defined by the implementation. Timestamps are expected to wrap around during the normal passage of time. It is recommended that an implementation pick a rate of advance and a bit width such that wrapping around occurs at most once every hour. Making the wrap time this long (or longer) makes timestamps more useful for several use cases.

- Checking for timeouts of protocol hello / keep-alive traffic that is on the order of seconds or minutes.
- If timestamps are placed into packets without converting them to other formats, then external data analysis systems using those timestamps will in many cases need to do so, e.g. to compare timestamps stored in packets by different PSA devices. These systems will need different formulas and/or parameters to perform this conversion for each wrap period, or to add extra external time references to the recorded data. The extra data required for accurate conversion is lower, and the likelihood of conversion mistakes is lower, if the timestamp values wrap less often.
- If timestamps are converted to other formats within a P4 program, it will need access to parameters that are likely to change every wrap time, e.g. at least a "base value" to add some calculated value to. A straightforward way to do this requires the control plane to update these values at least once or twice per timestamp wrap time.
- Programs that wish to use (egress\_timestamp ingress\_timestamp) to calculate the queueing latency experienced by a packet need the wrap time to exceed the maximum queueing latency.

Examples of the number of bits required for wrap times of at least one hour:

- A 32-bit timestamp advancing by 1 per microsecond takes 1.19 hours to wrap.
- A 42-bit timestamp advancing by 1 per nanosecond takes 1.22 hours to wrap.

A PSA implementation is not required to implement time synchronization, e.g. via PTP<sup>4</sup> or NTP<sup>5</sup>. TBD: This text has been written assuming that it is more important for timestamps to be increasing at a constant rate, with no sudden "jumps" due to time synchronization events. Is this what people want from timestamps?

TBD: Some time synchronization methods avoid sudden "jumps" by temporarily speeding up or slowing down the rate of increase by a small percentage, until the desired synchronization is achieved. (TBD: which ones? citation?). Would anyone mind if PSA implementations were allowed to do this with their timestamp values?

The control plane API excerpt below is intended to be added as part of the P4Runtime API<sup>1</sup>.

```
^2 \verb|http://p4.org/p4/inband-network-telemetry|
```

<sup>3</sup>https://en.wikipedia.org/wiki/Dynamic\_frequency\_scaling

<sup>4</sup>https://en.wikipedia.org/wiki/Precision\_Time\_Protocol

<sup>5</sup>https://en.wikipedia.org/wiki/Network\_Time\_Protocol

<sup>&</sup>lt;sup>1</sup>The P4Runtime API, defined as a Google Protocol Buffer .proto file, can be found at https://github.com/p4lang/PI/blob/master/proto/p4/p4runtime.proto

3.13. Timestamps 3. PSA EXTERNS

```
// The TimestampInfo and Timestamp messages should be added to the
// "oneof" inside of message "Entity".
// TimestampInfo is only intended to be read. Attempts to update this
// entity have no effect, and should return an error status that the
// entity is read only.
message TimestampInfo {
  // The number of bits in the device's 'timestamp_t' type.
  uint32 size_in_bits = 1;
  // The timestamp value of this device increments
  // 'increments_per_period' times every 'period_in_seconds' seconds.
  uint64 increments_per_period = 2;
  uint64 period_in_seconds = 3;
// The timestamp value can be read or written. Note that if there are
// already timestamp values stored in tables or 'Register' instances,
// they will not be updated as a result of writing this timestamp
// value. Writing the device timestamp is intended only for
// initialization and testing.
message Timestamp {
  bytes value = 1;
}
```

For every packet P that is processed by ingress and then egress, with the minimum possible latency in the packet buffer, it is guaranteed that the egress\_timestamp value for that packet will be the same as, or slightly larger than, the ingress\_timestamp value that the packet was assigned on ingress. By "slightly larger than", we mean that the difference (egress\_timestamp - ingress\_timestamp) should be a reasonably accurate estimate of this minimum possible latency through the packet buffer, perhaps truncated down to 0 if timestamps advance more slowly than this minimum latency.

Consider two packets such that at the same time (e.g. the same clock cycle), one is assigned its value of ingress\_timestamp near the time it begins parsing, and the other is assigned its value of egress\_timestamp near the time that it begins its egress processing. It is allowed that these timestamps differ by a few tens of nanoseconds (or by one "tick" of the timestamp, if one tick is larger than that time), due to practical difficulties in making them always equal.

Recall that the binary operators + and - on the bit W type in P4 are defined to perform wrap-around unsigned arithmetic. Thus even if a timestamp value wraps around from its maximum value back to 0, you can always calculate the number of ticks that have elapsed from timestamp t1 until timestamp t2 using the expression (t2-t1) (if more than  $2^W$  ticks have elapsed, there will be aliasing of the result). For example, if timestamps were W >= 4 bits in size,  $t1 = 2^W - 5$ , and t2 = 3, then (t2-t1) = 8.

It is sometimes useful to minimize storage costs by discarding some bits of a timestamp value in a P4 program for use cases that do not need the full wrap time or precision. For example, an application that only needs to detect protocol timeouts with an accuracy of 1 second can discard the least significant bits of a timestamp that change more often than every 1 second.

Another example is an application that needed full precision of the least significant bits of a timestamp, but the combination of the control plane and P4 program are designed to examine all entries of a Register array where these partial timestamps are stored more often than once every 5 seconds, to prevent wrapping. In that case, the P4 program could discard the most significant bits of the timestamp so that the remaining bits wrap every 8 seconds, and store those partial timestamps in the Register instance.

# 4. Programmable blocks

The following declarations provide a template for the programmable blocks in the PSA. The P4 programmer is responsible for implementing controls that match these interfaces and instantiate them in a package definition.

The current implementation uses the same user-defined metadata structure for all the controls. An alternative design is to split the user-defined metadata into an input parameter and an output parameter for each block. The compiler will have to check that the out parameter of a block matches the in parameter of the subsequent block.

```
parser Parser<H, M>(packet_in buffer, out H parsed_hdr, inout M user_meta,
                    in psa_parser_input_metadata_t istd);
control VerifyChecksum<H, M>(in H hdr, inout M user_meta);
control Ingress<H, M>(inout H hdr, inout M user_meta,
                      PacketReplicationEngine pre,
                      in psa_ingress_input_metadata_t istd,
                      out psa_ingress_output_metadata_t ostd);
control Egress<H, M>(inout H hdr, inout M user_meta,
                     BufferingQueueingEngine bqe,
                     in psa_egress_input_metadata_t istd);
control ComputeChecksum<H, M>(inout H hdr, inout M user_meta);
control Deparser<H>(packet_out buffer, in H hdr);
package PSA_Switch<H, M>(Parser<H, M> p,
                         VerifyChecksum<H, M> vr,
                         Ingress<H, M> ig,
                         Egress<H, M> eg,
                         ComputeChecksum<H, M> ck,
                         Deparser<H> dep);
```