

Imperas Peripheral Model Guide

Model Specific Information for freescale.ovpworld.org / KinetisPMC

Imperas Software Limited

Imperas Buildings, North Weston Thame, Oxfordshire, OX9 2HA, U.K. docs@imperas.com.



Author	Imperas Software Limited
Version	20150901.0
Filename	OVP_Peripheral_Specific_Information_KinetisPMC.pdf
Created	26 August 2015
Status	OVP Standard Release

Copyright Notice

Copyright 2015 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the readers responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED, AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Model Release Status

This model is released as part of OVP releases and is included in OVPworld packages. Please visit OVPworld.org.

G : 1.// >2015 I G G I : '. 1

Table Of Contents

1.0 Model Specific Information	• •	. 4
1.1 Licensing		. 4
1.2 Location		. 4
2.0 Net Ports		. 4
3.0 Bus Slave Ports		. 4
3.1 Bus Slave Port: bport1		. 4
4.0 Peripheral components in the library		. 5
5.0 General Information on Peripheral Models		. 7
5.1 Background		. 7
6.0 Building peripherals easily with Imperas iGen		. 7
7.0 Peripheral model internals		. 7
8.0 Parts of peripheral models		. 8
8.1 Configuring the Peripheral Instance with Parameters		. 8
8.2 Net Ports		. 8
8.3 Bus master ports		. 8
8.4 Bus slave ports		. 8
8.5 Packetnets		. 8
9.0 More information (documentation) on peripheral models and modeling		. 8

1.0 Model Specific Information

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers, other component parts, and configuration options and general information for peripheral modeling with Imperas OVP.

1.1 Licensing

Open Source Apache 2.0

1.2 Location

The KinetisPMC peripheral model is located in an Imperas/OVP installation at the VLNV: freescale.ovpworld.org / peripheral / KinetisPMC / 1.0.

2.0 Net Ports

This model has the following net ports:

Table 1. Net Ports

Name	Туре	Must Be Connected	Description
Reset	input	F (False)	

3.0 Bus Slave Ports

This model has the following bus slave ports:

3.1 Bus Slave Port: bport1

Table 2. Bus Slave Port: bport1

Name	Size (bytes)	Must Be Connected	Description
bport1	0x1000	F (False)	

Table 3. Bus Slave Port: bport1 Registers:

Name	Offset	Width (bits)	Description	R/W	is Volatile
ab_LVDSC1	0x0		Low Voltage Detect Status and Control 1 Register, offset: 0x0		
ab_LVDSC2	0x1	8	Low Voltage Detect Status and Control 2 Register, offset: 0x1		
ab_REGSC	0x2		Regulator Status and Control Register, offset: 0x2		

4.0 Peripheral components in the library

s/OVP peripheral models (158 models)	els)
Peripheral	Peripheral
freescale.ovpworld.org/KinetisRCM	freescale.ovpworld.org/KinetisRFSYS
freescale.ovpworld.org/KinetisRNG	freescale.ovpworld.org/KinetisRTC
freescale.ovpworld.org/KinetisSIM	freescale.ovpworld.org/KinetisSMC
freescale.ovpworld.org/KinetisTSI	freescale.ovpworld.org/KinetisUART
freescale.ovpworld.org/KinetisUSBDCD	freescale.ovpworld.org/KinetisUSBHS
freescale.ovpworld.org/KinetisWDOG	freescale.ovpworld.org/Uart
freescale.ovpworld.org/VybridANADIG	freescale.ovpworld.org/VybridCCM
freescale.ovpworld.org/VybridGPIO	freescale.ovpworld.org/VybridI2C
freescale.ovpworld.org/VybridQUADSPI	freescale.ovpworld.org/VybridSDHC
freescale.ovpworld.org/VybridUART	freescale.ovpworld.org/VybridUSB
intel.ovpworld.org/82371EB	intel.ovpworld.org/8253
intel.ovpworld.org/NorFlash48F4400	intel.ovpworld.org/PciIDE
intel.ovpworld.org/PciUSB	intel.ovpworld.org/Ps2Control
mips.ovpworld.org/16450C	mips.ovpworld.org/MaltaFPGA
motorola.ovpworld.org/MC146818	national.ovpworld.org/16450
ovpworld.org/Alpha2x16Display	ovpworld.org/dummyPort
ovpworld.org/FlashDevice	ovpworld.org/ledRegister
ovpworld.org/SimpleDma	ovpworld.org/VirtioBlkMMIO
renesas.ovpworld.org/adc	renesas.ovpworld.org/bcu
renesas.ovpworld.org/can	renesas.ovpworld.org/can
renesas.ovpworld.org/crc	renesas.ovpworld.org/csib
renesas.ovpworld.org/dma	renesas.ovpworld.org/intc
renesas.ovpworld.org/rng	renesas.ovpworld.org/taa
renesas.ovpworld.org/tmt	renesas.ovpworld.org/uartc
smsc.ovpworld.org/LAN9118	smsc.ovpworld.org/LAN91C111
xilinx.ovpworld.org/mdm	xilinx.ovpworld.org/mpmc
xilinx.ovpworld.org/xps-iic	xilinx.ovpworld.org/xps-intc
xilinx.ovpworld.org/xps-mch-emc	xilinx.ovpworld.org/xps-sysace
xilinx.ovpworld.org/xps-uartlite	altera.ovpworld.org/dw-apb-timer
altera.ovpworld.org/IntervalTimer32Core	altera.ovpworld.org/IntervalTimer64Core
altera.ovpworld.org/PerformanceCounterCore	altera.ovpworld.org/RSTMGR
altera.ovpworld.org/Uart	amd.ovpworld.org/79C970
arm.ovpworld.org/CompactFlashRegs	arm.ovpworld.org/CoreModule9x6
	arm.ovpworld.org/IcpControl
arm.ovpworld.org/IntICP	arm.ovpworld.org/IntICP
arm.ovpworld.org/L2CachePL310	arm.ovpworld.org/LcdPL110
	arm.ovpworld.org/SerBusDviRegs
	arm.ovpworld.org/SMemCtrlPL354
	arm.ovpworld.org/TzpcBP147
	arm.ovpworld.org/WdtSP805
	atmel.ovpworld.org/PowerSaving
	1 0 11 11 10
atmel.ovpworld.org/TimerCounter	atmel.ovpworld.org/UsartInterface
	freescale.ovpworld.org/KinetisRCM freescale.ovpworld.org/KinetisRNG freescale.ovpworld.org/KinetisSIM freescale.ovpworld.org/KinetisUSBDCD freescale.ovpworld.org/KinetisUSBDCD freescale.ovpworld.org/KinetisWDOG freescale.ovpworld.org/VybridANADIG freescale.ovpworld.org/VybridQUADSPI freescale.ovpworld.org/VybridQUADSPI freescale.ovpworld.org/VybridUART intel.ovpworld.org/ReiUSB intel.ovpworld.org/NorFlash48F4400 intel.ovpworld.org/PciUSB mips.ovpworld.org/I6450C motorola.ovpworld.org/MC146818 ovpworld.org/Alpha2x16Display ovpworld.org/FlashDevice ovpworld.org/SimpleDma renesas.ovpworld.org/can renesas.ovpworld.org/can renesas.ovpworld.org/crc renesas.ovpworld.org/fring renesas.ovpworld.org/fring renesas.ovpworld.org/mdm xilinx.ovpworld.org/mdm xilinx.ovpworld.org/xps-mch-emc xilinx.ovpworld.org/xps-mch-emc xilinx.ovpworld.org/xps-mch-emc xilinx.ovpworld.org/performanceCounterCore altera.ovpworld.org/PerformanceCounterCore altera.ovpworld.org/DMemCtrlPL341

freescale.ovpworld.org/KinetisAIPS	freescale.ovpworld.org/KinetisAXBS	freescale.ovpworld.org/KinetisCAN
freescale.ovpworld.org/KinetisCMP	freescale.ovpworld.org/KinetisCMT	freescale.ovpworld.org/KinetisCRC
freescale.ovpworld.org/KinetisDAC	freescale.ovpworld.org/KinetisDDR	freescale.ovpworld.org/KinetisDMA
freescale.ovpworld.org/KinetisDMAC	freescale.ovpworld.org/KinetisDMAMUX	freescale.ovpworld.org/KinetisENET
freescale.ovpworld.org/KinetisEWM	freescale.ovpworld.org/KinetisFB	freescale.ovpworld.org/KinetisFMC
freescale.ovpworld.org/KinetisFTFE	freescale.ovpworld.org/KinetisFTM	freescale.ovpworld.org/KinetisGPIO
freescale.ovpworld.org/KinetisI2C	freescale.ovpworld.org/KinetisI2S	freescale.ovpworld.org/KinetisLLWU
freescale.ovpworld.org/KinetisLPTMR	freescale.ovpworld.org/KinetisMCG	freescale.ovpworld.org/KinetisMPU
freescale.ovpworld.org/KinetisNFC	freescale.ovpworld.org/KinetisOSC	freescale.ovpworld.org/KinetisPDB
freescale.ovpworld.org/KinetisPIT	freescale.ovpworld.org/KinetisPMC	

Copyright (c) 2015 Imperas Software Limited OVP License. Release 20150901.0

5.0 General Information on Peripheral Models

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers etc. and configuration options and general information for peripheral modeling with Imperas OVP.

5.1 Background

Imperas OVP simulation technology enables very high performance simulation, debug and analysis of platforms containing multiple processors and peripheral models. The technology is designed to be extensible: you can create new models of processors, peripherals and other platform components using interfaces and libraries defined by OVP.

The peripheral models created using the OVP APIs run on the Peripheral Simulation Engine (PSE).

The model is typically written in C and compiled into an executable for the PSE processor architecture. The model is compiled for speed of execution and to protect IP. It is dynamically loaded by the simulator at run time.

6.0 Building peripherals easily with Imperas iGen

To aid with model creation, Imperas products include iGen, a model generation tool. iGen takes the laborious and error-prone task of constructing the various hardware model and software element files required for a typical model, and automates this process. iGen creates the needed C files. iGen also creates the C++ SystemC TLM2 interface files needed to run peripheral models in SystemC simulations.

iGen takes as input a simple script specification that includes device internals such as registers and memories, port information, component descriptors, and other elements. iGen then builds the C code model files and user editable templates. These include model frameworks with registers, function calls, memory map, and other items. It ensures that all component parts of the model are well-structured using best practices, and are consistent throughout the files, thus eliminating a common source of errors.

More information on iGen can be found: <u>imperas.com/products</u>.

Please contact Imperas to get access to the Imperas documents: Imperas_Model_Generator_Guide.pdf and Imperas_Peripheral_Generator_Guide.pdf.

7.0 Peripheral model internals

Each instance of a peripheral model runs on its own virtual machine with an address space large enough for the model. This processor (the PSE) and its memory are separate from any processors, memories and buses

Copyright (c) 2015 Imperas Software Limited www.imperas.com

OVP License. Release 20150901.0 Page 7 of 9

in the platform being simulated; they exist only to execute the code of the peripheral model.

Interception of functions defined in the peripheral model allows the use of features of the host system in the implementation of the behavior of a peripheral. As an example, a real platform might contain a video display device. When simulating this system, it is generally more convenient not to simulate the complete video display device but to use a video package available on the host machine, such as SDL, and to use this to render to the host display. Also models of uarts, ethernet devices and USB components can make use of the host PC resources during simulation, to allow, for example, a simulation to browse the real internet, or the simulation to connect to a real USB device.

8.0 Parts of peripheral models

8.1 Configuring the Peripheral Instance with Parameters

A peripheral can include the behaviour of several configurations. These are controlled when the peripheral is instanced in the platform by setting parameters defined on the peripheral.

8.2 Net Ports

Peripherals may be connected to other peripherals or processors with signal wires (nets). These can be used to act as interrupt signals or used to control behavior between peripherals.

The wires are created in the platform as nets and this net is connected into the peripheral using a net port.

8.3 Bus master ports

A bus master port initiates (and controls the address of) a bus cycle. Bus cycles are generated by behavioral code within the peripheral model.

8.4 Bus slave ports

A peripheral can be defined as having several bus slave ports. The bus slave ports can be split into several address blocks. Each address block be either local memory or memory mapped registers. Both of these can have associated callback functions. A memory mapped register can also be defined as specific read/write access, whether it is volatile, and also whether it is associated with a reset pin and mask. A memory mapped register can also have specific bit fields defined.

8.5 Packetnets

A peripheral can be defined as being connected to packetnet ports. A packetnet is used to model packet based communication such as Ethernet, CAN bus or GSM. A packetnet is created in a platform, then connected to packetnet ports on model instances. A packetnet can have many connections, each able to send or receive packets. A packetnet is used as an efficient method of communication within OVP models.

For more information on modeling with packetnets, please see the peripheral modeling documentation: OVP_Peripheral_Modeling_Guide.pdf, OVPsim_and_CpuManager_User_Guide.pdf and the example: \$IMPERAS_HOME/Examples/Models/Peripherals/packetnet.

Copyright (c) 2015 Imperas Software Limited www.imperas.com

OVP License. Release 20150901.0 Page 8 of 9

	Peri	oheral	Model	Documentation	for freescale.	.ovpworld.org	/ KinetisPMC
--	------	--------	-------	---------------	----------------	---------------	--------------

9.0 More information (documentation) on peripheral models and mode	eling
More information on modeling and APIs can be found at: OVPworld.org/technology ar	ois.

Specifics on modeling peripherals can be found: <u>OVP_Peripheral_Modeling_Guide.pdf</u>.

A full list of the currently available OVP documentation is available: OVPworld.org/documentation.
#

Copyright (c) 2015 Imperas Software Limited

OVP License. Release 20150901.0