

OVP Guide to Using Processor Models

Model Specific Information for variant ARM_ARM940T

Imperas Software Limited

Imperas Buildings, North Weston Thame, Oxfordshire, OX9 2HA, UK docs@imperas.com



Author	Imperas Software Limited
Version	0.4
Filename	OVP_Model_Specific_Information_arm_ARM940T.pdf
Created	25 August 2015

Copyright Notice

Copyright © 2015 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Table of Contents

1.0 Overview	4
1.1 Description	4
1.2 Licensing.	4
1.3 Limitations	5
1.4 Verification	5
1.5 Features	5
2.0 Configuration	5
2.1 Location	5
2.2 GDB Path	5
2.3 Semi-Host Library	5
2.4 Processor Endian-ness.	5
2.5 QuantumLeap Support	5
2.6 Processor ELF Code	5
3.0 Other Variants in this Model	5
4.0 Bus Ports	7
5.0 Net Ports	7
6.0 FIFO Ports	8
7.0 Parameters	8
8.0 Execution Modes	9
9.0 Exceptions	9
10.0 Hierarchy of the model	10
10.1 Level 1: CPU	10
11.0 Model Commands	11
11.1 Level 1: CPU	11
12.0 Registers	11
12.1 Level 1: CPU	11
12.1.1 Core	11
12.1.2 Control	11
12.1.3 User	12
12.1.4 FIQ	12
12.1.5 IRQ	12
12.1.6 Supervisor	12
12.1.7 Undefined	13
12.1.8 Abort	13
12.1.9 Coprocessor_32_bit	13
12.1.10 Integration support	14

1.0 Overview

This document provides the details of an OVP Fast Processor Model variant.

OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms. The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance. Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners.

There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

1.1 Description

model.

ARM Processor Model

1.2 Licensing

Usage of binary model under license governing simulator usage.

Note that for models of ARM CPUs the license includes the following terms:

Licensee is granted a non-exclusive, worldwide, non-transferable, revocable licence to:

If no source is being provided to the Licensee: use and copy only (no modifications rights are granted) the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used to emulate an ARM based system to run application software in a production or live environment.

If source code is being provided to the Licensee: use, copy and modify the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used to emulate an ARM based system to run application software in a production or live environment.

In the case of any Licensee who is either or both an academic or educational institution the purposes shall be limited to internal use.

Except to the extent that such activity is permitted by applicable law, Licensee shall not reverse engineer, decompile, or disassemble this model. If this model was provided to Licensee in Europe, Licensee shall not reverse engineer, decompile or disassemble the Model for the purposes of error correction.

The License agreement does not entitle Licensee to manufacture in silicon any product based on this model.

The License agreement does not entitle Licensee to use this model for evaluating the validity of any ARM patent.

Source of model available under separate Imperas Software License Agreement.

1.3 Limitations

Instruction pipelines are not modeled in any way. All instructions are assumed to complete immediately. This means that instruction barrier instructions (e.g. ISB, CP15ISB) are treated as NOPs, with the exception of any undefined instruction behavior, which is modeled. The model does not implement speculative fetch behavior. The branch cache is not modeled.

Caches and write buffers are not modeled in any way. All loads, fetches and stores complete immediately and in order, and are fully synchronous (as if the memory was of Strongly Ordered or Device-nGnRnE type). Data barrier instructions (e.g. DSB, CP15DSB) are treated as NOPs, with the exception of any undefined instruction behavior, which is modeled. Cache manipulation instructions are implemented as NOPs, with the exception of any undefined instruction behavior, which is modeled.

Real-world timing effects are not modeled: all instructions are assumed to complete in a single cycle.

1.4 Verification

Models have been extensively tested by Imperas. ARM9 models have been successfully used by customers to simulate Linux and Nucleus on ArmIntegrator virtual platforms.

1.5 Features

Thumb instructions are supported.

PMSA address translation is implemented.

2.0 Configuration

2.1 Location

The model source and object file is found in the VLNV tree at: arm.ovpworld.org/processor/arm/1.0

2.2 GDB Path

The default GDB for this model is found at: \$IMPERAS_HOME/lib/\$IMPERAS_ARCH/gdb/arm-none-eabi-gdb

2.3 Semi-Host Library

The default semi-host library file is found in the VLNV tree at : arm.ovpworld.org/semihosting/armNewlib/1.0

2.4 Processor Endian-ness

This model can be set to either endian-ness (normally by a pin, or the ELF code).

2.5 QuantumLeap Support

This processor is qualified to run in a QuantumLeap enabled simulator.

2.6 Processor ELF Code

The ELF code supported by this model is: 0x28

3.0 Other Variants in this Model

Table 1.

14010 1.
Variant
ARMv4T
ARMv4xM
ARMv4
ARMv4TxM
ARMv5xM
ARMv5
ARMv5TxM
ARMv5T
ARMv5TExP
ARMv5TE
ARMv5TEJ
ARMv6
ARMv6K
ARMv6T2
ARMv6KZ
ARMv7
ARM7TDMI
ARM7EJ-S
ARM720T
ARM920T
ARM922T
ARM926EJ-S
ARM940T
ARM946E
ARM966E
ARM968E-S
ARM1020E
ARM1022E
ARM1026EJ-S
ARM1136J-S
ARM1156T2-S
ARM1176JZ-S
Cortex-R4
Cortex-R4F
Cortex-A5UP
Cortex-A5MPx1
Cortex-A5MPx2
Cortex-A5MPx3
Cortex-A5MPx4
Cortex-A8

Cortex-A9UP	
Cortex-A9MPx1	
Cortex-A9MPx2	
Cortex-A9MPx3	
Cortex-A9MPx4	
Cortex-A7UP	
Cortex-A7MPx1	
Cortex-A7MPx2	
Cortex-A7MPx3	
Cortex-A7MPx4	
Cortex-A15UP	
Cortex-A15MPx1	
Cortex-A15MPx2	
Cortex-A15MPx3	
Cortex-A15MPx4	
Cortex-A17MPx1	
Cortex-A17MPx2	
Cortex-A17MPx3	
Cortex-A17MPx4	
AArch32	
AArch64	
Cortex-A53MPx1	
Cortex-A53MPx2	
Cortex-A53MPx3	
Cortex-A53MPx4	
Cortex-A57MPx1	
Cortex-A57MPx2	
Cortex-A57MPx3	
Cortex-A57MPx4	

4.0 Bus Ports

Table 2.

Туре	Name	Bits
master (initiator)	INSTRUCTION	32
master (initiator)	DATA	32

5.0 Net Ports

Table 3.

Name	Туре	Description
reset	input	Processor reset, active high

fiq	input	FIQ interrupt, active high (negation of nFIQ)
irq	input	IRQ interrupt, active high (negation of nIRQ)

6.0 FIFO Ports

No FIFO Ports in this model.

7.0 Parameters

Table 4.

Name	Туре	Description
verbose	Boolean	Specify verbosity of output
showHiddenRegs	Boolean	Show hidden registers during register tracing
UAL	Boolean	Disassemble using UAL syntax
compatibility	Enumeration	Specify compatibility mode ISA=0 gdb=1 nopSVC=2
override_debugMask	Uns32	Specifies debug mask, enabling debug output for model components
override_fcsePresent	Boolean	Specifies that FCSE is present (if true)
override_SCTLR_V	Boolean	Override SCTLR.V with the passed value (enables high vectors)
override_SCTLR_CP15BEN_Present	Boolean	Enable ARMv7 SCTLR.CP15BEN bit (CP15 barrier enable)
override_MIDR	Uns32	Override MIDR register
override_CTR	Uns32	Override CTR register
override_MPUIR	Uns32	Override MPUIR register
override_CLIDR	Uns32	Override CLIDR register
override_AIDR	Uns32	Override AIDR register
override_ERG	Uns32	Specifies exclusive reservation granule
override_STRoffsetPC12	Boolean	Specifies that STR/STR of PC should do so with 12:byte offset from the current instruction (if true), otherwise an 8:byte offset is used
override_mpuV5ExtAP	Boolean	Specifies that ARMv5 MPU extended access permissions implemented (cp15/5/2 and cp15/5/2)
override_ignoreBadCp15	Boolean	Specifies whether invalid coprocessor 15 access should be ignored (if true) or cause Invalid Instruction exceptions (if false)
override_SGIDisable	Boolean	Override whether GIC SGIs may be disabled (if true) or are permanently enabled (if false)
override_condUndefined	Boolean	Force undefined instructions to take Undefined Instruction exception even if they are conditional
override_deviceStrongAligned	Boolean	Force accesses to Device and Strongly Ordered regions to be aligned

override_Control_V	Boolean	Override SCTLR.V with the passed value (deprecated, use override_SCTLR_V)
override_MainId	Uns32	Override MIDR register (deprecated, use override_MIDR)
override_CacheType	Uns32	Override CTR register (deprecated, use override_CTR)
override_MPUType	Uns32	Override MPUIR register (deprecated, use override_MPUIR)

8.0 Execution Modes

Table 5.

Name	Code
User	16
FIQ	17
IRQ	18
Supervisor	19
Abort	23
Undefined	27
System	31

9.0 Exceptions

Table 6.

Name	Code
Reset	0
Undefined	1
SupervisorCall	2
PrefetchAbort	5
DataAbort	6
IRQ	8
FIQ	9

10.0 Hierarchy of the model

A CPU core may allow the user to configure it to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy.

Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

10.1 Level 1: CPU

This level in the model hierarchy has 4 commands.

This level in the model hierarchy has 10 register groups:

Table 7.

Group name	Registers
Core	16
Control	3
User	7
FIQ	8
IRQ	3
Supervisor	3
Undefined	3
Abort	3
Coprocessor_32_bit	36
Integration_support	2

This level in the model hierarchy has no children.

11.0 Model Commands

11.1 Level 1: CPU

Table 8.

Name	Arguments
debugflags	
dumpTLB	
isync	specify instruction address range for synchronous execution
itrace	enable or disable instruction tracing

12.0 Registers

12.1 Level 1: CPU

12.1.1 Core

Table 9.

Name	Bits	Initial value (Hex)		Description
r0	32	0	rw	
r1	32	0	rw	
r2	32	0	rw	
r3	32	0	rw	
r4	32	0	rw	
r5	32	0	rw	
r6	32	0	rw	
r7	32	0	rw	
r8	32	0	rw	
r9	32	0	rw	
r10	32	0	rw	
r11	32	0	rw	frame pointer
r12	32	0	rw	
sp	32	0	rw	stack pointer
lr	32	0	rw	
рс	32	0	rw	program counter

12.1.2 Control

Table 10.

Name	Bits	Initial	Description
Haine	ال ال	IIIII	Description
		value (Hex)	
		value (i lex)	

fps	32	0	rw archaic FPSCR view (for gdb)		
cpsr	32	d3	rw		
spsr	32	0	rw		

12.1.3 User

Table 11.

Name	Bits	Initial value (Hex)		Description
r8_usr	32	0	rw	
r9_usr	32	0	rw	
r10_usr	32	0	rw	
r11_usr	32	0	rw	
r12_usr	32	0	rw	
sp_usr	32	0	rw	
Ir_usr	32	0	rw	

12.1.4 FIQ

Table 12.

Name	Bits	Initial value (Hex)		Description
		raido (ilox)		
r8_fiq	32	0	rw	
r9_fiq	32	0	rw	
r10_fiq	32	0	rw	
r11_fiq	32	0	rw	
r12_fiq	32	0	rw	
sp_fiq	32	0	rw	
Ir_fiq	32	0	rw	
spsr_fiq	32	0	rw	

12.1.5 IRQ

Table 13.

Name		Initial value (Hex)		Description
sp_irq	32	0	rw	
Ir_irq	32	0	rw	
spsr_irq	32	0	rw	

12.1.6 Supervisor

Table 14.

Name		Initial value (Hex)		Description
sp_svc	32	0	rw	
Ir_svc	32	0	rw	
spsr_svc	32	0	rw	

12.1.7 Undefined

Table 15.

Name		Initial value (Hex)		Description
sp_undef	32	0	rw	
Ir_undef	32	0	rw	
spsr_undef	32	0	rw	

12.1.8 Abort

Table 16.

Name		Initial value (Hex)		Description
sp_abt	32	0	rw	
Ir_abt	32	0	rw	
spsr_abt	32	0	rw	

12.1.9 Coprocessor_32_bit

Table 17.

Name	Bits	Initial value (Hex)		Description
CTR	32	f0f10f1	r-	Cache Type
CleanDCacheLineSW	32	-	-w	Data Cache Line Clean by Set/Way
CleanInvalDCacheLineSW	32	-	-w	Data Cache Line Clean and Invalidate by Set/ Way
DAPR	32	0	rw	Data Space Access Permissions
DBR	32	0	rw	
DCLR	32	fff0	rw	Data Cache Lockdown
DCR	32	0	rw	Data Control
DMRR0	32	0	rw	Data Memory Region 0
DMRR1	32	0	rw	Data Memory Region 1
DMRR2	32	0	rw	Data Memory Region 2

		1	_	1
DMRR3	32	0	rw	Data Memory Region 3
DMRR4	32	0	rw	Data Memory Region 4
DMRR5	32	0	rw	Data Memory Region 5
DMRR6	32	0	rw	Data Memory Region 6
DMRR7	32	0	rw	Data Memory Region 7
DataSynchBarrier	32	-	-w	Data Synchronization Barrier
IAPR	32	0	rw	Instruction Space Access Permissions
ICLR	32	fff0	rw	Instruction Cache Lockdown
ICR	32	0	rw	Instruction Control
IMRR0	32	0	rw	Instruction Memory Region 0
IMRR1	32	0	rw	Instruction Memory Region 1
IMRR2	32	0	rw	Instruction Memory Region 2
IMRR3	32	0	rw	Instruction Memory Region 3
IMRR4	32	0	rw	Instruction Memory Region 4
IMRR5	32	0	rw	Instruction Memory Region 5
IMRR6	32	0	rw	Instruction Memory Region 6
IMRR7	32	0	rw	Instruction Memory Region 7
InvalDCache	32	-	-w	Invalidate Data Cache
InvalDCacheLineSW	32	-	-w	Invalidate Data Cache Line by Set/Way
InvallCache	32	-	-w	Invalidate Instruction Cache
InvallCacheLineSW	32	-	-w	Invalidate Instruction Cache Line by Set/Way
MIDR	32	41029400	r-	Main ID
PrefetchlCacheLine	32	-	-w	Prefetch Instruction Cache Line
SCTLR	32	78	rw	System Control
WaitForInterrupt	32	-	-w	Wait For Interrupt
WaitForInterrupt2	32	-	-w	Wait For Interrupt

12.1.10 Integration_support

Table 18.

Name		Initial value (Hex)		Description
transactPL	32	1	r-	privilege level of current memory transaction
transactAT	32	0	r-	current memory transaction type: PA=1, VA=0

#