ELEC 309 Signals and Systems

Frequency-Domain Analysis of

Continuous-Time (Chapter 5, Schaum's Outline of Signals and Systems)

and Discrete-Time (Chapter 6, Schaum's Outline of Signals and Systems)

Systems

Dr. Jason S. Skinner

October 28, 2014

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [1 of 71]

System Representation in the Continuous-Time Domain

Previously, we showed that the response y(t) of a continuous-time LTI system is the convolution of the input x(t) with the impulse response h(t), or

$$x(t) \longrightarrow h(t) \longrightarrow y(t)$$

where

$$y(t) = x(t) * h(t).$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [2 of 71]

System Representation in the Frequency Domain

Applying the convolution property to the previous convolution equation, we have

$$X(\omega) \longrightarrow H(\omega) \longrightarrow Y(\omega)$$

where

$$Y(\omega) = X(\omega)H(\omega),$$

and $X(\omega)$, $Y(\omega)$, and $H(\omega)$ are the Fourier transforms of x(t), y(t), and h(t), respectively.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [3 of 71]

The System Frequency Response

Solving for $H(\omega)$, we have

$$\mathcal{F}\left\{h(t)\right\} = \left|H(\omega) = \frac{Y(\omega)}{X(\omega)}\right| = \frac{\mathcal{F}\left\{y(t)\right\}}{\mathcal{F}\left\{x(t)\right\}}.$$

The Fourier transform $H(\omega)$ of h(t) is called the **frequency response** of the system.

The System Frequency Response: Magnitude Response and Phase Response

Recall that the frequency response is, in general, complex and therefore can be written as

$$H(\omega) = |H(\omega)|e^{j\theta_H(\omega)}.$$

The term $|H(\omega)|$ is called the **magnitude response** of the system.

The term $\theta_H(\omega)$ is called the **phase response** of the system.

Frequency Response of Continuous-Time LTI Systems: Frequency Domain

Recall that

ELEC 309: Signals and Systems

$$1 \longrightarrow \mathsf{LTI} \; \mathsf{System} \longrightarrow H(\omega),$$

and

$$X(\omega) \longrightarrow \mathsf{LTI} \; \mathsf{System} \longmapsto Y(\omega) = H(\omega)X(\omega).$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [5 of 71]

Frequency Response of Continuous-Time LTI Systems: Time Domain

Recall that

$$\delta(t) \longrightarrow \operatorname{LTI} \operatorname{System} \longrightarrow h(t),$$

and

$$x(t) \longrightarrow \operatorname{LTI} \operatorname{System} \longrightarrow y(t) = h(t) * x(t).$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [7 of 71]

Frequency Response of Continuous-Time LTI Systems

Consider a continuous-time LTI system with an input $x(t)=e^{j\omega_0t}$, which has Fourier transform

$$X(\omega) = 2\pi\delta(\omega - \omega_0).$$

The Fourier transform of the output of this continuoustime LTI system is given by

$$Y(\omega) = H(\omega)X(\omega)$$

= $H(\omega)2\pi\delta(\omega - \omega_0) = 2\pi H(\omega_0)\delta(\omega - \omega_0).$

Frequency Response of Continuous-Time LTI Systems

Taking the inverse Fourier transform of $Y(\omega)$, we have

$$y(t) = H(\omega_0)e^{j\omega_0 t}.$$

Therefore, for a single-frequency-component input,

$$x(t) = e^{j\omega_0 t} \longrightarrow H(\omega) \longrightarrow y(t) = H(\omega_0)e^{j\omega_0 t}.$$

From our previous analyses of signals using Fourier transformations, we observed that we can represent signals as linear expressions of terms of the form $e^{j\omega_0 t}$.

ELEC 309: Signals and Systems

Response of Continuous-Time LTI Systems: Aperiodic Inputs

If x(t) is aperiodic, then, from the definition of the inverse Fourier transform, we have

$$x(t) = \mathcal{F}^{-1}\{X(\omega)\} = \frac{1}{2\pi} \int_{-\infty}^{\infty} X(\omega) e^{j\omega t} d\omega,$$

and the corresponding output of the continuous-time LTI system can be written as

$$y(t) = \frac{1}{2\pi} \int_{-\infty}^{\infty} H(\omega) X(\omega) e^{j\omega t} d\omega$$
$$= \frac{1}{2\pi} \int_{-\infty}^{\infty} Y(\omega) e^{j\omega t} d\omega = \mathcal{F}^{-1} \{Y(\omega)\}.$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [9 of 71]

Response of Continuous-Time LTI Systems: Periodic Inputs

Since the Fourier transform is linear, then if the input $\boldsymbol{x}(t)$ is periodic with the Fourier series representation

$$x(t) = \sum_{n=-\infty}^{\infty} D_n e^{jn\omega_0 t},$$

then the corresponding output of the continuous-time LTI system is also periodic with the Fourier series representation

$$y(t) = \sum_{n=-\infty}^{\infty} D_n H(n\omega_0) e^{jn\omega_0 t}.$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [11 of 71]

Response of Continuous-Time LTI Systems

The behavior of a continuous-time LTI system in the frequency domain is completely characterized by its frequency response $H(\omega)$.

Let

$$X(\omega) = |X(\omega)|e^{j\theta_X(\omega)}$$

and

$$Y(\omega) = |Y(\omega)|e^{j\theta_Y(\omega)}.$$

Response of Continuous-Time LTI Systems: Magnitude Spectrum

The magnitude spectrum of the output can be written as

$$|Y(\omega)| = |H(\omega)||X(\omega)|,$$

which says that the magnitude spectrum $\big|Y(\omega)\big|$ of the output is the product of the magnitude spectrum $\big|X(\omega)\big|$ of the input and the magnitude response $\big|H(\omega)\big|$ of the system.

The magnitude response $|H(\omega)|$ is sometimes referred to as the **gain** of the system.

Response of Continuous-Time LTI Systems: Distortionless Transmission

For **distortionless transmission** through a continuoustime LTI system, we require that the signal retain its overall shape. In other words, the system may only alter the amplitude (by a multiplicative constant) of the input signal or delay it in time. Therefore, if x(t) is the input signal to a continuous-time LTI system, then the inputoutput equation

$$y(t) = Kx(t - t_d)$$

is required for distortionless transmission, where t_d is the **time delay** and K > 0 is a **gain constant**.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [13 of 71]

Response of Continuous-Time LTI Systems: Phase Spectrum

The phase spectrum of the output can be written as

$$\theta_Y(\omega) = \theta_H(\omega) + \theta_X(\omega),$$

which says that the phase spectrum $\theta_Y(\omega)$ of the output is the sum of the phase spectrum $\theta_X(\omega)$ of the input and the phase response $\theta_H(\omega)$ of the system.

ELEC 309: Signals and Systems

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [15 of 71]

Response of Continuous-Time LTI Systems: Distortionless Transmission

Taking the Fourier transform of both sides, we see that

$$Y(\omega) = Ke^{-j\omega t_d}X(\omega).$$

Therefore, for distortionless transmission, the system must have a frequency response given by

$$H(\omega) = |H(\omega)|e^{j\theta_H(\omega)} = Ke^{-j\omega t_d}.$$

Therefore.

$$|H(\omega)| = K \text{ and} \tag{1}$$

$$\theta_H(\omega) = -\omega t_d. \tag{2}$$

Response of Continuous-Time LTI Systems: Amplitude Distortion

For distortionless transmission, the amplitude of $H(\omega)$ must be **constant** over all frequencies ω .

When the magnitude spectrum $|H(\omega)|$ of the system is not constant with the frequency band of interest, the frequency components of the input signal are transmitted with a different amount of **gain** or **attenuation**.

This effect is referred to as **amplitude distortion**.

Frequency Response for Continuous-Time LTI Systems Described by LCCDEs

Previously, we considered a continuous-time LTI system for which input x(t) and output y(t) satisfy a general $N^{\rm th}$ -order linear constant-coefficient differential equation (LCCDE) given by

$$\sum_{n=0}^{N} a_n \frac{d^n y(t)}{dt^n} = \sum_{m=0}^{M} b_m \frac{d^m x(t)}{dt^m}$$

with $M \leq N$.

ELEC 309: Signals and Systems

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [17 of 71]

Response of Continuous-Time LTI Systems: Phase Distortion

For distortionless transmission, the phase of $H(\omega)$ must be **linear** with respect to frequency ω .

When the phase spectrum $\theta_H(\omega)$ of the system is not linear over the frequency band of interest, the different frequency components of the input signal encounter different delays in passing through the system, which results in a different waveform at the output of the system.

This effect is referred to as **phase distortion**.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [19 of 71]

Frequency Response for Continuous-Time LTI Systems Described by LCCDEs

Taking the Fourier transform of both sides, and applying the linearity and time-differentiation properties of the Fourier transform, we have

$$\sum_{n=0}^{N} a_n (j\omega)^n Y(\omega) = \sum_{m=0}^{M} b_m (j\omega)^m X(\omega).$$

or

$$Y(\omega)\sum_{n=0}^{N}a_n(j\omega)^n=X(\omega)\sum_{m=0}^{M}b_m(j\omega)^m.$$

Frequency Response for Continuous-Time LTI Systems Described by LCCDEs

Therefore, a continuous-time LTI system whose input x(t) and output y(t) satisfy a general $N^{\rm th}$ -order LCCDE has a **frequency response** given by

$$H(\omega) = \frac{Y(\omega)}{X(\omega)} = \frac{\sum_{m=0}^{M} b_m (j\omega)^m}{\sum_{n=0}^{N} a_n (j\omega)^n},$$
 (3)

which is a rational function of ω .

ELEC 309: Signals and Systems

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [23 of 71]

Filtering is one of the most basic operations in any signal processing system.

Filtering

Example (continued):

Filtering is the process by which the relative amplitudes of the frequency components in a signal are changed or even suppressed.

For continuous-time LTI system: $Y(\omega) = X(\omega)H(\omega)$.

Therefore, an LTI system acts as a filter on the input signal, and the term **filter** is used to describe any system that exhibits some type of frequency-selective behavior.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [21 of 71]

Example:

Consider a continuous-time system whose input $\boldsymbol{x}(t)$ and output $\boldsymbol{y}(t)$ are related by

$$\frac{dy(t)}{dt} + 2y(t) = x(t).$$

Find the impulse response h(t) of the system.

Ideal Frequency-Selective Filters

An **ideal frequency-selective filter** exactly passes signal in one set of frequencies and completely suppresses the rest.

The band of frequencies passed by the filter is referred to as the **pass band**.

The band of frequencies rejected by the filter is referred to as the **stop band**.

ELEC 309: Signals and Systems


Frequency-Domain Analysis of Systems [25 of 71]

Ideal Frequency-Selective Filters: Ideal Low-Pass Filter Amplitude Response

An ideal low-pass filter (LPF) amplitude response is given by

$$|H(\omega)| = \begin{cases} 1 & |\omega| \le \omega_c \\ 0 & |\omega| > \omega_c. \end{cases}$$

The frequency ω_c is called the **cutoff frequency**.




ELEC 309: Signals and Systems

Ideal Frequency-Selective Filters: Ideal High-Pass Filter Amplitude Response

An ideal high-pass filter (HPF) amplitude response is given by

$$|H(\omega)| = \begin{cases} 0 & |\omega| < \omega_c \\ 1 & |\omega| \ge \omega_c. \end{cases}$$




ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [27 of 71]

Ideal Frequency-Selective Filters: Ideal Band-Pass Filter Amplitude Response

An ideal band-pass filter (BPF) amplitude response is given by


$$\left| H\left(\omega \right) \right| = egin{cases} 1 & \omega_1 \leq |\omega| \leq \omega_2 \\ 0 & \text{otherwise.} \end{cases}$$



Ideal Frequency-Selective Filters: Ideal Band-Stop Filter Amplitude Response

An ideal band-stop filter (BSF) amplitude response is given by

$$\left| H\left(\omega \right) \right| = egin{cases} 0 & \omega_1 < \left| \omega \right| < \omega_2 \\ 1 & \text{otherwise.} \end{cases}$$



ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [29 of 71]

Ideal Frequency-Selective Filters: Phase Response

To avoid phase distortion in the filtering process, a filter should have a linear phase characteristic over the pass band of the filter, or

$$\theta_H(\omega) = -\omega t_d$$

where t_d is a constant.

All ideal frequency-selective filters are *noncausal* systems.

ELEC 309: Signals and Systems

Example:

Consider the periodic square wave given by

$$x(t) = \begin{cases} 1 & 2\pi k \le t < 2\pi(k+0.5) \\ 0 & 2\pi(k+0.5) \le t < 2\pi(k+1) \end{cases}$$

for all integers k. Suppose this signal passes through an ideal low-pass filter with ideal phase response and amplitude response given by

$$|H(\omega)| = \begin{cases} 1 & |\omega| \le 6 \\ 0 & |\omega| > 6. \end{cases}$$

Determine the output y(t) of this filter.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [31 of 71]

Example (continued):

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [32 of 71]

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [34 of 71]

Nonideal Frequency-Selective Filters

The input-output equation for this circuit is given by

$$RC\frac{dy(t)}{dt} + y(t) = x(t).$$

Taking the Fourier transform of both sides of the input-output equation, the frequency response $H(\omega)$ of the RC filter is given by

$$H(\omega) = \frac{Y(\omega)}{X(\omega)} = \frac{1}{1 + j\omega RC} = \frac{1}{1 + j\frac{\omega}{\omega_0}}$$

where $\omega_0 = \frac{1}{RC}$ is the **cutoff frequency**.

This is a first-order low-pass Butterworth filter.


ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [33 of 71]

Nonideal Frequency-Selective Filters

Example (continued):

Consider the RC filter shown below:




ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [35 of 71]

Nonideal Frequency-Selective Filters

The amplitude response is given by


$$\left|H(\omega)\right| = \frac{1}{\left|1 + j\frac{\omega}{\omega_0}\right|} = \frac{1}{\sqrt{1 + \left(\frac{\omega}{\omega_0}\right)^2}}.$$



Nonideal Frequency-Selective Filters

The phase response is given by

$$\theta_H(\omega) = -\tan^{-1}\left(\frac{\omega}{\omega_0}\right).$$




ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [37 of 71]

Example:

Consider the RC filter shown below.



Nonideal Frequency-Selective Filters

The input-output equation for this circuit is given by

$$RC\frac{dy(t)}{dt} + y(t) = RCx'(t).$$

Taking the Fourier transform of both sides of the inputoutput equation, the frequency response H(f) of the RCfilter is given by

$$H(\omega) = \frac{Y(\omega)}{X(\omega)} = \frac{j\omega RC}{1 + j\omega RC} = \frac{1}{1 - j\frac{\omega_0}{\omega}}$$

where $\omega_0 = \frac{1}{RC}$ is the **cutoff frequency**.

This is a first-order high-pass Butterworth filter.

ELEC 309: Signals and Systems


ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [39 of 71]

Nonideal Frequency-Selective Filters

The amplitude response is given by


$$|H(\omega)| = \frac{1}{\left|1 - j\frac{\omega_0}{\omega}\right|} = \frac{1}{\sqrt{1 + \left(\frac{\omega_0}{\omega}\right)^2}}.$$



Nonideal Frequency-Selective Filters

The phase response is given by

$$\theta_H(\omega) = \tan^{-1}\left(\frac{\omega_0}{\omega}\right).$$



ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [41 of 71]

Filter or System Bandwidth

One important concept in system analysis is the **bandwidth** of a filter or system.


The **bandwidth** of a filter or system is defined as the width of the range of positive frequencies of components that are not filtered out when passing through a filter or system.

There are *many* different definitions of bandwidth.

Absolute Bandwidth of Ideal Filters

The **absolute bandwidth** is defined only for *ideal* low-pass or band-pass filters.

The absolute bandwidth W_B of an ideal low-pass filter is its cutoff frequency. In other words, $W_B=f_c=\frac{\omega_c}{2\pi}$ Hz.



ELEC 309: Signals and Systems


ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [43 of 71]

Absolute Bandwidth of Ideal Filters

The absolute bandwidth W_B of an ideal band-pass filter is given by $W_B=f_2-f_1=\frac{\omega_2-\omega_1}{2\pi}$ Hz.

A band-pass filter is called **narrowband** if $W_B \ll f_m$, where $f_m = \frac{f_1 + f_2}{2} = \frac{\omega_1 + \omega_2}{4\pi}$ is the center frequency of the filter.



Half-Power Bandwidth of Nonideal Filters

For causal or practical filters, a commonly-used definition of filter or system bandwidth is the **half-power (or 3-dB)** bandwidth $W_{3\text{-dB}}$.

The **half-power bandwidth** is defined as the width of the range of positive frequencies for which

$$|H(\omega)| \ge \frac{\max\{|H(\omega)|\}}{\sqrt{2}}.$$


The half-power bandwidth is also known as the **3-dB** bandwidth because a power attenuation by a factor of 2 is equivalent to a attenuation of 3 dB.

ELEC 309: Signals and Systems Frequency-Domain Analysis of Systems [45 of 71]

Half-Power Bandwidth of Nonideal Low-Pass Filters

For a causal or practical low-pass filter, we have $\max{\{H(\omega)\}} = \big|H(0)\big|$ and its cutoff frequency ω_0 must meet the condition


$$|H(\omega_0)| = \frac{|H(0)|}{\sqrt{2}}.$$



Half-Power Bandwidth of Nonideal Low-Pass Filters

For a causal or practical low-pass filter, the **half-power** (or 3-dB) bandwidth is given by

$$W_{ extsf{3-dB}} = f_0 = rac{\omega_0}{2\pi} \; extsf{Hz}.$$



ELEC 309: Signals and Systems


ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [47 of 71]

Half-Power Bandwidth of Nonideal Low-Pass Filters

For the low-pass RC filter discussed previously, the half-power (or 3-dB) bandwidth is given by

$$W_{ extsf{3-dB}}=f_0=rac{\omega_0}{2\pi}=rac{1}{2\pi RC}\; extsf{Hz}.$$




Half-Power Bandwidth of Nonideal Band-Pass Filters

For a causal or practical band-pass filter, its two cutoff frequencies ω_1 and ω_2 must meet the conditions

$$\omega_1 = \min \left\{ \text{positive } \omega : \left| H(\omega) \right| \geq \frac{\left| H(0) \right|}{\sqrt{2}} \right\} \text{ and }$$

$$\omega_2 = \max \left\{ \text{positive } \omega : \left| H(\omega) \right| \geq \frac{\left| H(0) \right|}{\sqrt{2}} \right\}.$$




ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [49 of 71]

Half-Power Bandwidth of Nonideal Band-Pass Filters

For a causal or practical band-pass filter, the **half-power** (or 3-dB) bandwidth is given by

$$W_{ extsf{3-dB}}=f_2-f_1=rac{\omega_2-\omega_1}{2\pi}\; extsf{Hz}.$$



ELEC 309: Signals and Systems

Signal Bandwidth

The **bandwidth** of a signal is defined as the width of the range of "significant" positive frequencies contained in a signal.

The **absolute bandwidth** of a signal is defined as the width of the range of positive frequency components contained in a signal.

The **bandwidth** of a signal can also be defined as the width of the range of positive frequencies in which "most" of the energy or power lies.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [51 of 71]

Half-Power Bandwidth of a Signal

The bandwidth of a signal x(t) can also be defined on a similar basis as a filter bandwidth, such as the half-power (or 3-dB) bandwidth, using the amplitude spectrum $\left|X(\omega)\right|$ of the signal.

If we replace $|H(\omega)|$ by $|X(\omega)|$ in our previous amplitude response plots, we will have frequency-domain plots of **low-pass**, **high-pass**, and **band-pass** signals.

Band-Limited Signal

A signal x(t) is said to be **band-limited** if

$$|X(\omega)| = 0 \text{ if } |\omega| > \omega_M$$

The bandwidth of a band-limited signal is given by ω_M radians per second or $f_M=\frac{\omega_M}{2\pi}$ Hz.

ELEC 309: Signals and Systems

System Representation in the Frequency Domain

Applying the convolution property to the previous convolution equation, we have

$$X(\Omega) \longrightarrow H(\Omega) \longrightarrow Y(\Omega)$$

where

$$Y(\Omega) = X(\Omega)H(\Omega),$$

and $X(\Omega)$, $Y(\Omega)$, and $H(\Omega)$ are the Fourier transforms of x[n], y[n], and h[n], respectively.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [53 of 71]

System Representation in the Discrete-Time Domain

Previously, we showed that the response y[n] of a discrete-time LTI system is the convolution of the input x[n] with the impulse response h[n], or

$$x[n] \longrightarrow h[n] \longrightarrow y[n]$$

where

$$y[n] = x[n] * h[n].$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [55 of 71]

The System Frequency Response

Solving for $H(\Omega)$, we have

$$\mathcal{F}\left\{h[n]\right\} = \boxed{H(\Omega) = \frac{Y(\Omega)}{X(\Omega)}} = \frac{\mathcal{F}\left\{y[n]\right\}}{\mathcal{F}\left\{x[n]\right\}}.$$

The Fourier transform $H(\Omega)$ of h[n] is called the **frequency response** of the system.

The System Frequency Response: Magnitude Response and Phase Response

Recall that the frequency response is, in general, complex and therefore can be written as

$$H(\Omega) = |H(\Omega)|e^{j\theta_H(\Omega)}.$$

The term $|H(\Omega)|$ is called the **magnitude response** of the system.

The term $\theta_H(\Omega)$ is called the **phase response** of the system.

Frequency Response of Discrete-Time LTI Systems: Frequency Domain

Recall that

ELEC 309: Signals and Systems

$$1 \longrightarrow \mathsf{LTI} \; \mathsf{System} \longrightarrow H(\Omega),$$

and

$$X(\Omega) \longrightarrow \mathsf{LTI} \; \mathsf{System} \longmapsto Y(\Omega) = H(\Omega)X(\Omega).$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [57 of 71]

Frequency Response of Discrete-Time LTI Systems: Time Domain

Recall that

$$\delta[n] \longrightarrow \mathsf{LTI} \; \mathsf{System} \longrightarrow h[n],$$

and

$$x[n] \longrightarrow \mathsf{LTI} \; \mathsf{System} \longrightarrow y[n] = h[n] * x[n].$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [59 of 71]

Frequency Response of Discrete-Time LTI Systems

Consider a discrete-time LTI system with an input $x[n]=e^{j\Omega_0n}$, which has Fourier transform

$$X(\Omega) = 2\pi\delta(\Omega - \Omega_0).$$

The Fourier transform of the output of this discrete-time LTI system is given by

$$Y(\Omega) = H(\Omega)X(\Omega)$$

= $H(\Omega)2\pi\delta(\Omega - \Omega_0) = 2\pi H(\Omega_0)\delta(\Omega - \Omega_0).$

Frequency Response of Discrete-Time LTI Systems

Taking the inverse Fourier transform of $Y(\Omega)$, we have

$$y[n] = H(\Omega_0)e^{j\Omega_0 n}.$$

Therefore, for a single-frequency-component input,

$$x[n] = e^{j\Omega_0 n} \longrightarrow H(\Omega) \longrightarrow y[n] = H(\Omega_0)e^{j\Omega_0 n}.$$

From our previous analyses of signals using Fourier transformations, we observed that we can represent signals as linear expressions of terms of the form $e^{j\Omega_0 n}$.

ELEC 309: Signals and Systems

Response of Discrete-Time LTI Systems: Aperiodic Inputs

If x[n] is aperiodic, then, from the definition of the inverse Fourier transform, we have

$$x[n] = \mathcal{F}^{-1} \{X(\Omega)\} = \frac{1}{2\pi} \int_{2\pi} X(\Omega) e^{j\Omega n} d\Omega,$$

and the corresponding output of the discrete-time LTI system can be written as

$$y[n] = \frac{1}{2\pi} \int_{2\pi} H(\Omega) X(\Omega) e^{j\Omega n} d\Omega$$
$$= \frac{1}{2\pi} \int_{2\pi} Y(\Omega) e^{j\Omega n} d\Omega = \mathcal{F}^{-1} \left\{ Y(\Omega) \right\}.$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [61 of 71]

Response of Discrete-Time LTI Systems: Periodic Inputs

Since the Fourier transform is linear, then if the input x[n] is periodic with the Fourier series representation

$$x[n] = \sum_{k=\langle N_0 \rangle} \mathcal{D}_n e^{jk\Omega_0 n},$$

then the corresponding output of the discrete-time LTI system is also periodic with the Fourier series representation

$$y[n] = \sum_{k=\langle N_0 \rangle} \mathcal{D}_n H(k\Omega_0) e^{jk\Omega_0 n}.$$

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [63 of 71]

Response of Discrete-Time LTI Systems

The behavior of a discrete-time LTI system in the frequency domain is completely characterized by its frequency response $H(\Omega)$.

Let

$$X(\Omega) = |X(\Omega)|e^{j\theta_X(\Omega)}$$

and

$$Y(\Omega) = |Y(\Omega)|e^{j\theta_Y(\Omega)}.$$

Response of Discrete-Time LTI Systems: Magnitude Spectrum

The magnitude spectrum of the output can be written as

$$|Y(\Omega)| = |H(\Omega)||X(\Omega)|,$$

which says that the magnitude spectrum $\big|Y(\Omega)\big|$ of the output is the product of the magnitude spectrum $\big|X(\Omega)\big|$ of the input and the magnitude response $\big|H(\Omega)\big|$ of the system.

The magnitude response $\left|H(\Omega)\right|$ is sometimes referred to as the **gain** of the system.

ELEC 309: Signals and Systems

Periodic Nature of the Frequency Response

Note that

$$H(\Omega + 2\pi) = H(\Omega).$$

Unlike the frequency response of continuous-time systems, the frequency response of discrete-time systems is periodic with period 2π .

Therefore, we need to consider the frequency response of a discrete-time system only over the range $0 \le \Omega < 2\pi$ or $-\pi \le \Omega < \pi$.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [65 of 71]

Response of Discrete-Time LTI Systems: Phase Spectrum

The phase spectrum of the output can be written as

$$\theta_Y(\Omega) = \theta_H(\Omega) + \theta_X(\Omega),$$

which says that the phase spectrum $\theta_Y(\Omega)$ of the output is the sum of the phase spectrum $\theta_X(\Omega)$ of the input and the phase response $\theta_H(\Omega)$ of the system.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [67 of 71]

Frequency Response for Discrete-Time LTI Systems Described by LCCDEs

Previously, we considered a discrete-time LTI system for which input x[n] and output y[n] satisfy a general $N^{\rm th}$ -order linear constant-coefficient difference equation (LCCDE) given by

$$\sum_{k=0}^{N} a_k y[n-k] = \sum_{m=0}^{M} b_m x[n-m]$$

with M < N.

Frequency Response for Discrete-Time LTI Systems Described by LCCDEs

Taking the Fourier transform of both sides, and applying the linearity and time-shifting properties of the Fourier transform, we have

$$\sum_{k=0}^{N} a_k e^{-jk\Omega} Y(\Omega) = \sum_{m=0}^{M} b_m e^{-jm\Omega} X(\Omega).$$

or

$$Y(\Omega)\sum_{k=0}^{N} a_k e^{-jk\Omega} = X(\Omega)\sum_{m=0}^{M} b_m e^{-jm\Omega}.$$

Example:

Consider a discrete-time system whose input x[n] and output y[n] are related by

$$y[n] - 0.5y[n-1] = x[n].$$

Find the impulse response h[n] of the system.

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [69 of 71]

Frequency Response for Discrete-Time LTI Systems Described by LCCDEs

Therefore, a discrete-time LTI system whose input x[n] and output y[n] satisfy a general $N^{\rm th}$ -order LCCDE has a **frequency response** given by

$$H(\Omega) = \frac{Y(\Omega)}{X(\Omega)} = \frac{\sum_{m=0}^{M} b_m e^{-jm\Omega}}{\sum_{k=0}^{N} a_k e^{-jk\Omega}}.$$
 (4)

ELEC 309: Signals and Systems

ELEC 309: Signals and Systems

Frequency-Domain Analysis of Systems [71 of 71]

Example (continued):