Dimensional Analysis & Scale-Up

Dimensional Analysis & Scale-Up

Dimensional analysis is a powerful tool in engineering and science for checking equations, converting units, and deriving relationships between physical quantities. Often, real problems are too complex for straightforward analysis. The Buckingham Pi theorem is a key method for reducing complex physical problems to their fundamental dimensionless groups.

Key Concepts

- Fundamental and Derived Units
- Dimensionless Groups
- Buckingham Pi Theorem
- Scale-Up

Definitions

- **Dimensionless number:** A quantity with no units, used to compare different systems or scales.
- A unit's dimension: Basic units of measurement (e.g., mass [M], length [L], time [T], temperature $[\Theta]$).
- Dimensional homogeneity: An equation is dimensionally homogeneous if all terms have the same dimensions.

Fundamental and Derived Units

Fundamental units are the basic building blocks of measurement, representing a single physical dimension. Examples include:

- Mass [M]
- Length [L]

- Time [T]
- Temperature $[\Theta]$

Derived units are combinations of fundamental units and represent more complex physical quantities. Examples include:

- Velocity [L/T]
- Acceleration [L/T²]
- Force $[M \cdot L/T^2]$
- Pressure $[M/(L \cdot T^2)]$

We can go even further and define other units like energy, power, and viscosity.

Dimensionless Groups

Dimensionless groups are quantities that have no units and are used to compare different systems or scales. They are often formed by combining variables in a way that cancels out all units. Dimensionless numbers are usually ratios of different quantities. Common dimensionless groups include:

- Reynolds Number (Re): Ratio of inertial to viscous forces in fluid flow.
- Froude Number (Fr): Ratio of inertial to gravitational forces.
- Péclet Number (Pe): Ratio of advective to diffusive transport rates.
- Prandtl Number (Pr): Ratio of momentum diffusivity to thermal diffusivity.

To find more dimensionless numbers, visit here.

Buckingham Pi Theorem

The Buckingham Pi theorem is a key principle in dimensional analysis that provides a systematic way to reduce the number of variables in a problem by identifying dimensionless groups. The theorem states that if you have a physical problem with n independent variables and k fundamental dimensions, you can form n - k + 1 independent dimensionless groups (π terms).

Example: Drag Force on a Sphere

Suppose you are studying the drag force F_d on a sphere moving through a fluid. The drag force depends on the following variables:

- Diameter of the sphere D [L]
- Velocity of the sphere V [L/T]
- Density of the fluid ρ [M/L³]
- Viscosity of the fluid μ [M/(L·T)]

So this is saying you have

 $F_d \propto D^a V^b \rho^c \mu^d$ (where a, b, c, d are exponents to be determined).

Step 1: List dimensions of each variable

$$F_d: [M \cdot L/T^2], \quad D: [L], \quad V: [L/T], \quad \rho: [M/L^3], \quad \mu: [M/(L \cdot T)]$$

Step 2: Set up the dimensional equation

$$[M \cdot L/T^2] = [L]^a [L/T]^b [M/L^3]^c [M/(L \cdot T)]^d$$

Step 3: Expand and collect exponents for each dimension

$$M: c+d, L: a+b-3c-d, T: -b-d$$

Step 4: Set up system of equations to match dimensions

$$M: 1 = c + d$$
, $L: 1 = a + b - 3c - d$, $T: -2 = -b - d$

Step 5: Solve for a, b, c

$$a = 1 - d$$
, $b = 2 - d$, $c = 1 - d$

Step 6: Substitute and simplify to get the dimensionless groups

$$F_d = D^{1-d} V^{2-d} \rho^{1-d} \mu^d$$

Step 7: Move integers to one side and group letters (d) on one side

$$\frac{F_d}{\rho VD} = \left(\frac{\rho VD}{\mu}\right)^d$$

3

Dimensionless Groups Obtained

One possible set of dimensionless groups is:

- Drag Coefficient: $C_d = \frac{F_d}{\frac{1}{2}\rho V^2 A}$, where A is the cross-sectional area of the sphere.

By expressing the drag force in terms of these dimensionless groups, we can analyze the problem more easily and apply the results to different scales and conditions.

Scale-Up

When scaling systems, maintaining similarity in dimensionless numbers ensures that the scaled system behaves like the original. This is crucial in engineering applications such as chemical reactors, fluid flow systems, and heat exchangers. By keeping key dimensionless groups constant, we can predict performance and behavior across different scales.

Recap

Dimensional analysis and the Buckingham Pi theorem are essential tools for simplifying complex physical problems. By identifying dimensionless groups, we can reduce the number of variables and analyze systems more effectively. This approach is particularly useful in scaling up processes, ensuring that the behavior of the system remains consistent across different sizes and conditions.