

# **Supported configurations**

Cloud Volumes ONTAP 9.11.0 release notes

NetApp May 16, 2022

This PDF was generated from https://docs.netapp.com/us-en/cloud-volumes-ontap-relnotes/reference-configs-aws.html on May 16, 2022. Always check docs.netapp.com for the latest.

# **Table of Contents**

| Supported configurations                 | <br> | . 1 |
|--|------|------|------|------|------|------|------|------|------|-----|
| Supported configurations in AWS          | <br> | . 1 |
| Supported configurations in Azure        | <br> | . 4 |
| Supported configurations in Google Cloud | <br> | . 7 |

## Supported configurations

## Supported configurations in AWS

Several Cloud Volumes ONTAP configurations are supported in AWS.

### Supported number of nodes

Cloud Volumes ONTAP is available in AWS as a single node system and as a high-availability (HA) pair of nodes for fault tolerance and nondisruptive operations.

Upgrading a single node system to an HA pair is not supported. If you want to switch between a single node system and an HA pair, then you need to deploy a new system and replicate data from the existing system to the new system.

### Supported storage

Cloud Volumes ONTAP supports several types of EBS disks, and S3 object storage for data tiering. The maximum storage capacity is determined by the license that you choose.

#### Storage support by license

Each license supports a different maximum system capacity. The maximum system capacity includes disk-based storage plus object storage used for data tiering. NetApp doesn't support exceeding this limit.

	Freemium	PAYGO Explore	PAYGO Standard	PAYGO Premium	Node-based license	Capacity- based license		
Maximum system capacity (disks + object storage) <sup>1</sup>	500 GiB	2 TiB	10 TiB	368 TiB <sup>2</sup>	368 TiB per license <sup>2</sup>	2 PiB <sup>2</sup>		
Supported disk types	<ul> <li>General Purpose SSD (gp3 and gp2) <sup>3</sup></li> <li>Provisioned IOPS SSD (io1) <sup>3</sup></li> <li>Throughput Optimized HDD (st1) <sup>4</sup></li> </ul>							
Cold data tiering to S3	Supported	Not supported	Supported					

- 1. For an HA pair, the capacity limit is for the entire HA pair. It's not per node. For example, if you use the Premium license, you can have up to 368 TiB of capacity between both nodes.
- For some configurations, disk limits prevent you from reaching the capacity limit by using disks alone. In those cases, you can reach the capacity limit by tiering inactive data to object storage. For information about disk limits, refer to storage limits.
- Enhanced write performance is enabled when using SSDs with all Cloud Volumes ONTAP configurations, except for PAYGO Explore.

4. Tiering data to object storage is not recommended when using Throughput Optimized HDDs (st1).

#### Supported disk sizes

In AWS, an aggregate can contain up to 6 disks that are all the same type and size.

General Purpose SSDs (gp3 and gp2)	Provisioned IOPS SSDs (io1)	Throughput Optimized HDDs (st1)
• 100 GiB	• 100 GiB	• 500 GiB
• 500 GiB	• 500 GiB	• 1 TiB
• 1 TiB	• 1 TiB	• 2 TiB
• 2 TiB	• 2 TiB	• 4 TiB
• 4 TiB	• 4 TiB	• 6 TiB
• 6 TiB	• 6 TiB	• 8 TiB
• 8 TiB	• 8 TiB	• 16 TiB
• 16 TiB	• 16 TiB	

## **Supported EC2 compute**

Each Cloud Volumes ONTAP license supports different EC2 instance types. For your convenience, the table below shows the vCPU, RAM, and bandwidth for each supported instance type. You should refer to AWS for the latest and complete details about EC2 instance types.

The bandwidths shown in the table below match the documented AWS limits for each instance type. These limits don't completely align with what Cloud Volumes ONTAP can provide. For the expected performance, refer to NetApp Technical Report 4383: Performance Characterization of Cloud Volumes ONTAP in Amazon Web Services with Application Workloads.

License	Supported instance	vCPU	RAM	Flash Cache <sup>1</sup>	Network bandwidth (Gbps)	EBS bandwidth (Mbps)	High write speed <sup>2</sup>
Explore or any other license	m5.xlarge	4	16	Not supported	Up to 10	Up to 4,750	Supported (single node only)
Standard or any other license	r5.xlarge	4	32	Not supported	Up to 10	Up to 4,750	Supported (single node only)
	m5a.2xlarge	8	32	Not supported	Up to 10	Up to 2,880	Supported
	m5.2xlarge	8	32	Not supported	Up to 10	Up to 4,750	Supported

License	Supported instance	vCPU	RAM	Flash Cache <sup>1</sup>	Network bandwidth (Gbps)	EBS bandwidth (Mbps)	High write speed <sup>2</sup>
Premium or any other license	m5n.2xlarge	8	32	Not supported	Up to 25	Up to 4,750	Supported
	r5.2xlarge	8	64	Not supported	Up to 10	Up to 4,750	Supported
	r5d.2xlarge	8	64	Supported	Up to 10	Up to 4,750	Supported
	c5d.4xlarge	16	32	Supported	Up to 10	4,570	Supported
	m5.4xlarge	16	64	Not supported	Up to 10	4,750	Supported
	m5d.8xlarge	32	128	Supported	10	6,800	Supported
	r5.8xlarge	32	256	Not supported	10	6,800	Supported
	c5.9xlarge	36	72	Not supported	10	9,500	Supported
	c5d.9xlarge	36	72	Supported	10	9,500	Supported
	c5n.9xlarge	36	96	Not supported	50	9,500	Supported
	c5a.12xlarg e	48 4	96	Not supported	12	4,750	Supported
	c5.18xlarge	48 4	144	Not supported	25	19,000	Supported
	c5d.18xlarg e	48 4	144	Supported	25	19,000	Supported
	m5d.12xlarg e	48	192	Supported	12	9,500	Supported
	c5n.18xlarg e	48 4	192	Not supported	100	19,000	Supported
	m5a.16xlarg e	48 4	256	Not supported	12	9,500	Supported
	m5.16xlarge	48 4	256	Not supported	20	13,600	Supported
	r5.12xlarge <sup>3</sup>	48	384	Not supported	10	9,500	Supported
	m5dn.24xlar ge	48 4	384	Supported	100	19,000	Supported

Some instance types include local NVMe storage, which Cloud Volumes ONTAP uses as Flash Cache.
Flash Cache speeds access to data through real-time intelligent caching of recently read user data and
NetApp metadata. It's effective for random read-intensive workloads, including databases, email, and file
services. Compression must be disabled on all volumes to take advantage of the Flash Cache
performance improvements. Learn more about Flash Cache.

- 2. Cloud Volumes ONTAP supports high write speed with most instance types when using an HA pair. High write speed is supported with all instance types when using a single node system. Learn more about choosing a write speed.
- 3. The r5.12xlarge instance type has a known limitation with supportability. If a node unexpectedly reboots due to a panic, the system might not collect core files used to troubleshoot and root cause the problem. The customer accepts the risks and limited support terms and bears all support responsibility if this condition occurs. This limitation affects newly deployed HA pairs and HA pairs upgraded from 9.8. The limitation does not affect newly deployed single node systems.
- 4. While these EC2 instance types support more than 48 vCPUs, Cloud Volumes ONTAP supports up to 48 vCPUs.
- 5. When you choose an EC2 instance type, you can specify whether it is a shared instance or a dedicated instance.
- 6. Cloud Volumes ONTAP can run on either a Reserved or On-demand EC2 instance. Solutions that use other instance types aren't supported.

### **Supported regions**

For AWS region support, see Cloud Volumes Global Regions.

## Supported configurations in Azure

Several Cloud Volumes ONTAP configurations are supported in Azure.

### Supported configurations by license

Cloud Volumes ONTAP is available in Azure as a single node system and as a high-availability (HA) pair of nodes for fault tolerance and nondisruptive operations.

Upgrading a single node system to an HA pair is not supported. If you want to switch between a single node system and an HA pair, then you need to deploy a new system and replicate data from the existing system to the new system.

#### Single node systems

You can choose from the following configurations when deploying Cloud Volumes ONTAP as a single-node system in Azure:

	Freemium	PAYGO Explore	PAYGO Standard	PAYGO Premium	Node-based license	Capacity- based license
Maximum system capacity (disks + object storage)	500 GiB	2 TiB <sup>1</sup>	10 TiB	368 TiB	368 TiB per license	2 PiB

	Freemium	PAYGO Explore	PAYGO Standard	PAYGO Premium	Node-based license	Capacity- based license
Supported	• DS4_v2	• E4s_v3	• DS4_v2	• DS5_v2	• DS4_v2	• DS4_v2
virtual machine	• DS5_v2	• E4ds_v4 <sup>3</sup>	• DS13_v2	• DS14_v2	• DS5_v2	• DS5_v2
types	• DS13_v2		• E8s_v3	• DS15_v2	• DS13_v2	• DS13_v2
	• DS14_v2		• E8ds_v4 <sup>3</sup>	• E32s_v3 <sup>3</sup>	• DS14_v2	• DS14_v2
	• DS15_v2			• E48s_v3 <sup>3</sup>	• DS15_v2	• DS15_v2
	• L8s_v2 <sup>2</sup>			• E64is_v3 <sup>3</sup>	• L8s_v2 <sup>2</sup>	• L8s_v2 <sup>2</sup>
	• E4s_v3			•	• E4s_v3	• E4s_v3
	• E8s_v3			• <u>E</u> 48ds_v4	• E8s_v3	• E8s_v3
	• E32s_v3 <sup>3</sup>			3 1000_	• E32s_v3 <sup>3</sup>	• E32s_v3 <sup>3</sup>
	• E48s_v3 <sup>3</sup>			• E80ids_v4	• E48s_v3 <sup>3</sup>	• E48s_v3 <sup>3</sup>
	• E64is_v3 <sup>3</sup>				• E64is_v3 <sup>3</sup>	• E64is_v3 <sup>3</sup>
	• E4ds_v4 <sup>3</sup>				• E4ds_v4 <sup>3</sup>	• E4ds_v4 <sup>3</sup>
	• E8ds_v4 <sup>3</sup>				• E8ds_v4 <sup>3</sup>	• E8ds_v4 <sup>3</sup>
	• £32ds_v4				• <u>F</u> 32ds_v4	• <u>F</u> 32ds_v4
	• <u>E</u> 48ds_v4				• <u>E</u> 48ds_v4	• <u>E</u> 48ds_v4
	• E80ids_v4				• E80ids_v4	• E80ids_v4
Supported disk types <sup>4</sup>	Standard HDD Disks	Managed Disks	, Standard SSD	Managed Disks	s, and Premium	SSD Managed

#### Notes:

- 1. Data tiering to Azure Blob storage isn't supported with PAYGO Explore.
- 2. This VM type includes local NVMe storage, which Cloud Volumes ONTAP uses as Flash Cache. Flash Cache speeds access to data through real-time intelligent caching of recently read user data and NetApp metadata. It is effective for random read-intensive workloads, including databases, email, and file services. Compression must be disabled on all volumes to take advantage of the Flash Cache performance improvements. Learn more.
- 3. These VM types use an Ultra SSD for VNVRAM, which provides better write performance.

If you choose any of these VM types when you deploy a new Cloud Volumes ONTAP system, you can't change to another VM type that *doesn't* use an Ultra SSD for VNVRAM. For example, you can't change from E8ds\_v4 to E8s\_v3, but you can change from E8ds\_v4 to E32ds\_v4 because both of those VM types use Ultra SSDs.

Conversely, if you deployed Cloud Volumes ONTAP using any other VM type, you won't be able to change to a VM type that uses an Ultra SSD for VNVRAM. For example, you can't change from E8s\_v3 to E8ds v4.

4. Enhanced write performance is enabled when using SSDs.

- 5. For Azure region support, see Cloud Volumes Global Regions.
- 6. Cloud Volumes ONTAP can run on either a Reserved or On-demand VM instance from your cloud provider. Solutions that use other VM instance types aren't supported.

#### **HA** pairs

You can choose from the following configurations when deploying Cloud Volumes ONTAP as an HA pair in Azure.

	Freemium	PAYGO Standard	PAYGO Premium	Node-based license	Capacity-based license
Maximum system capacity (disks + object storage)	500 GiB	10 TiB	368 TiB	368 TiB per license	2 PiB
Supported virtual machine	• DS4_v2	• DS4_v2	• DS5_v2 <sup>1</sup>	• DS4_v2	• DS4_v2
types	• DS5_v2 1	• DS13_v2	• DS14_v2 <sup>1</sup>	• DS5_v2 1	• DS5_v2 <sup>1</sup>
	• DS13_v2	• E8ds_v4 <sup>1</sup>	• DS15_v2 1	• DS13_v2	• DS13_v2
	• DS14_v2 <sup>1</sup>		• E8s_v3	• DS14_v2 <sup>1</sup>	• DS14_v2 1
	• DS15_v2 <sup>1</sup>		• E48s_v3 <sup>1</sup>	• DS15_v2 <sup>1</sup>	• DS15_v2 1
	• E8s_v3		• E32ds_v4 <sup>1</sup>	• E8s_v3	• E8s_v3
	• E48s_v3 <sup>1</sup>		• E48ds_v4 <sup>1</sup>	• E48s_v3 <sup>1</sup>	• E48s_v3 <sup>1</sup>
	• E8ds_v4 <sup>1</sup>		• E80ids_v4 <sup>2</sup>	• E8ds_v4 <sup>1</sup>	• E8ds_v4 <sup>1</sup>
	• E32ds_v4 <sup>1</sup>			• E32ds_v4 <sup>1</sup>	• E32ds_v4 <sup>1</sup>
	• E48ds_v4 <sup>1</sup>			• E48ds_v4 <sup>1</sup>	• E48ds_v4 <sup>1</sup>
	• E80ids_v4 <sup>2</sup>			• E80ids_v4 <sup>2</sup>	• E80ids_v4 <sup>2</sup>
Supported disk types	Premium page blo	obs			

#### Notes:

- Cloud Volumes ONTAP supports high write speed with these VM types when using an HA pair. High write speed is supported with all instance types when using a single node system. Learn more about choosing a write speed.
- 2. This VM is recommended only when Azure maintenance control is needed. It's not recommended for any other use case due to the higher pricing.
- 3. PAYGO Explore isn't supported with HA pairs in Azure.
- 4. For Azure region support, see Cloud Volumes Global Regions.
- 5. Cloud Volumes ONTAP can run on either a Reserved or On-demand VM instance from your cloud provider. Solutions that use other VM instance types aren't supported.

### Supported disk sizes

In Azure, an aggregate can contain up to 12 disks that are all the same type and size.

#### Single node systems

Single node systems use Azure Managed Disks. The following disk sizes are supported:

Premium SSD	Standard SSD	Standard HDD
• 500 GiB	• 100 GiB	• 100 GiB
• 1 TiB	• 500 GiB	• 500 GiB
• 2 TiB	• 1 TiB	• 1 TiB
• 4 TiB	• 2 TiB	• 2 TiB
• 8 TiB	• 4 TiB	• 4 TiB
• 16 TiB	• 8 TiB	• 8 TiB
• 32 TiB	• 16 TiB	• 16 TiB
	• 32 TiB	• 32 TiB

#### **HA** pairs

HA pairs use Premium page blobs. The following disk sizes are supported:

- 500 GiB
- 1 TiB
- 2 TiB
- 4 TiB
- 8 TiB

## Supported configurations in Google Cloud

Several Cloud Volumes ONTAP configurations are supported in Google Cloud.

## Supported configurations by license

Cloud Volumes ONTAP is available in Google Cloud Platform as a single node system and as a high-availability (HA) pair of nodes for fault tolerance and nondisruptive operations.

Upgrading a single node system to an HA pair isn't supported. If you want to switch between a single node system and an HA pair, then you need to deploy a new system and replicate data from the existing system to the new system.

	Freemium	PAYGO Explore	PAYGO Standard	PAYGO Premium	Node-based license	Capacity- based license
Maximum system capacity (disks + object storage) <sup>1</sup>	500 GB	2 TB <sup>2</sup>	10 TB	368 TB	368 TB per license	2 PiB
Supported machine types <sup>3</sup>	• n1- standard- 8	• n2- standard- 4	• n1- standard- 8	• n1- standard- 32	• n1- standard- 8	• n1- standard- 8
	• n1- standard- 32		• n2- standard- 8	• n2- standard- 16	• n1- standard- 32	• n1- standard- 32
	• n2- standard- 4			• n2- standard- 32	• n2- standard- 4	• n2- standard- 4
	• n2- standard- 8				• n2- standard- 8	• n2- standard- 8
	• n2- standard- 16				• n2- standard- 16	• n2- standard- 16
	• n2- standard- 32				• n2- standard- 32	• n2- standard- 32
Supported disk types 4	Zonal persister	nt disks (SSD, ba	alanced, and sta	andard)		

#### Notes:

1. Disk limits can prevent you from reaching the maximum system capacity limit by using disks alone. You can reach the capacity limit by tiering inactive data to object storage.

Learn more about disk limits in Google Cloud.

- 2. Data tiering to Google Cloud Storage isn't supported with PAYGO Explore.
- 3. The custom-4-16384 machine type is no longer supported with new Cloud Volumes ONTAP systems.

If you have an existing system running on this machine type, you can keep using it, but we recommend switching to the n2-standard-4 machine type.

- 4. Enhanced write performance is enabled when using SSDs.
- 5. The Cloud Manager interface shows an additional supported machine type for Standard and BYOL: n1-highmem-4. However, this machine type isn't meant for production environments. We've made it available for a specific lab environment only.
- 6. For Google Cloud Platform region support, see Cloud Volumes Global Regions.

7. Cloud Volumes ONTAP can run on either a Reserved or On-demand VM instance from your cloud provider. Solutions that use other VM instance types aren't supported.

## Supported disk sizes

In Google Cloud, an aggregate can contain up to 6 disks that are all the same type and size. The following disk sizes are supported:

- 100 GB
- 500 GB
- 1 TB
- 2 TB
- 4 TB
- 8 TB
- 16 TB
- 64 TB

#### **Copyright Information**

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

#### **Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.