# Recap of last class


- Characteristics of embedded systems
  - Real-time, low power, performance constraints
- Why use a microprocessor
  - Alternatives: ASIC, microprocessor, FPGA
  - Microprocessor: reprogramability, performance/power ratio
- Design methodology
  - Top-down vs. bottom-up
  - Requirement, specification, architecture, component design, system integration

### ECE 1175 Embedded Systems Design

# **Embedded System Architecture**

Wei Gao

## **Embedding A Computer**



### Microprocessor Architecture


- von Neumann vs. Harvard
- CISC vs. RISC
  - Complex vs. Reduced Instruction Set Computer
- Two opposite examples
  - Super Harvard Architecture Single-Chip Computer (SHARC)
  - ARM7

### Von Neumann Architecture

- Feature: memory holds data and instructions
  - Memory can be either read or written
- Central processing unit (CPU) fetches instructions from memory.
  - Separate CPU and memory distinguishes programmable computer.
- CPU registers help out:
  - Program counter (PC),
  - Instruction register (IR),
  - General-purpose registers, etc.

```
data segment
dw 8 dup (0)
data ends
code segment
start:mov AX, data
mov SS, AX
mov SP, 16
```

# **CPU + Memory in von Neumann**



#### Von Neumann vs. Harvard


#### von Neumann

- Same memory holds both data and instructions.
- A single set of address/data buses between CPU and memory

#### Harvard

- Separate memories for data and instructions.
- Two sets of address/data buses between CPU and memory

### **Harvard Architecture**



#### Von Neumann vs. Harvard


- Harvard makes it harder to write
  - Self-modifying code (data values used as instructions)
  - Less reprogrammable
- Harvard allows two simultaneous memory fetches.
- Harvard architectures are widely used because
  - Most DSPs use Harvard for streaming data
    - The separation of program and data memories → greater memory bandwidth → higher performance for digital signal processing
    - Speed is gained at the expense of more complex electrical circuitry.
  - Other examples: On chip cache of CPUs is divided into an instruction cache and a data cache

#### RISC vs. CISC

- Complex Instruction Set Computer (CISC)
  - Used in early computer architectures
  - Many addressing modes and instructions
  - High code density
  - Often require manual optimization of assembly code for embedded systems
- Reduced Instruction Set Computer (RISC)
  - Compact, uniform instructions 

     facilitate pipelining
  - More lines of code → poor memory footprint
  - Allow effective compiler optimization


# **ARM Pipeline Execution**



## Multiple implementations

- Successful architectures have several implementations:
  - Varying CPU clock speeds
  - different bus widths
  - different cache sizes
  - etc.
- The key performance bottleneck
  - Speed difference between CPU and memory
  - Solutions
    - Higher bus bandwidth
    - Use CPU cache: multiple levels

# Microprocessors



#### **Digital Signal Processor = Harvard + CISC**

- Streaming data
  - → need high data throughput
  - → Harvard architecture

- Memory footprint
  - > require high code density
  - → Need CISC instead of RISC

### **DSP Optimizations**

- Signal processing
  - Support floating point operation
  - Support loops (matrix, vector operations)
  - Finite Impulse Response (FIR) filters → multiplyaccumulate in one cycle!
- Real-time requirements
  - Execution time must be predictable → opportunistic optimization in general purpose processor may not work (e.g., caching, branch prediction)

#### **SHARC Architecture**

- Modified Harvard architecture.
  - Separate data/code memories.
  - Program memory can be used to store data.
    - Two pieces of data can be loaded in parallel
- Support for signal processing
  - Powerful floating point operations
  - Efficient loop
  - Parallel instructions

#### **SHARC**

- CISC + Harvard architecture
- Computation
  - Floating point operations
  - Hardware multiplier
  - Parallel operations
- Memory Access
  - Parallel load/store
  - Circular buffer
- Zero-overhead and nested loop

#### ARM7

- von Neumann + RISC
  - Used as chip in Nokia 6110
- Compact, uniform instruction set
  - 32 bit or 12 bit
  - Usually one instruction/cycle
  - Poor code density
  - No parallel operations
- Memory access
  - No parallel access
  - No direct addressing

# **Sample Prices**

- ARM7: \$14.54

SHARC: \$51.46 - \$612.74


#### MIPS/FLOPS: Poor Metrics for DSPs

- MIPS: Million Instructions Per Second
- FLOPS: FLoating point Operations Per Second
- They do not indicate how much work is accomplished by each instruction, which depends on the architecture and instruction set.

# **Evaluating DSP Speed**

- Implement and compare complete application on each DSP
  - Time consuming: implement and (manually) optimize a complete application on multiple DSPs
- Benchmarks: a set of small pieces (kernel) of representative code
  - Ex. FIR filter
  - Inherent to most embedded systems
  - Small enough to allow manual optimization on multiple DSPs
- Application profile + benchmark testing
  - Assign relative importance of each kernel

#### Benchmarks



The figure is from a paper in the reading list:

J. Eyre and J. Bier, <u>DSP</u>
<u>Processors Hit the</u>
<u>Mainstream</u>, IEEE Micro.

# **Other Important Metrics**

- Power consumption
- Cost
- Code density
- •••

### Summary

- Von Neumann vs. Harvard
  - Harvard has separate memories for data and instructions
  - Higher performance for digital signal processing
- RISC vs. CISC
  - CISC: high code density, suitable for DSP
  - RISC: compact instructions, pipelining but poor memory footprint
- Two opposite examples
  - SHARC
    - DSP, CISC + modified Harvard
  - ARM7
    - RISC + von Neumann

# Reading

- Optional: J. Eyre and J. Bier, <u>DSP Processors Hit the</u>
   <u>Mainstream</u>, IEEE Micro, August 1998.
- Optional: More about SHARC http://www.analog.com/processors/processors/sharc/