<u>CPE403 – Advanced Embedded</u> Systems

Design Assignment 2

Name: Jenifer Christina

Email: chrisj14@unlv.nevada.edu

Github Repository link: https://github.com/chrisj14/CCS-Assignment

Youtube Playlist link: https://youtu.be/cwDEEj2b8To

Follow the submission guideline to be awarded points for this Assignment.

 Code for Tasks. for each task submit the modified or included code (from the base code) with highlights and justifications of the modifications. Also include the comments. If no base code is provided, submit the base code for the first task only. Use separate page for each task.

Task 01: Interface the TMP006 IR Temperature Sensor (MKII Educational Boosterpack). Determine the object temperature. Perform all computations using IQ Math Structures and Functions. Display the results in the terminal.

```
#include <stdint.h>
#include <stdbool.h>
#include <string.h>
#include "inc/hw ints.h"
#include "inc/tm4c123gh6pm.h" //def. for the interrupt and register
assignments on the <u>Tiva</u> C Series device on the launchPad board
#include "inc/hw_memmap.h"
#include "inc/hw types.h"
#include "inc/hw uart.h"
#include "driverlib/fpu.h"
#include "driverlib/gpio.h"
#include "driverlib/interrupt.h"
#include "driverlib/pin map.h"
#include "driverlib/rom.h"
#include "driverlib/sysctl.h"
#include "driverlib/udma.h"
#include "driverlib/timer.h"
                                  //Defines and macros for Timer API of
driverLib.
#include "driverlib/adc.h"
#include "driverlib/debug.h"
#include "driverlib/uart.h"
```

```
#include "utils/uartstdio.h"
// For Temperature value
uint32 t ui32Period;
char buffer [4];
uint32 t ui32ADC0Value[4];
volatile uint32_t ui32TempAvg;
volatile uint32_t ui32TempValueC;
volatile uint32 t ui32TempValueF;
// Define source and destination buffers
#define MEM BUFFER SIZE
static uint32 t g ui32SrcBuf[MEM BUFFER SIZE];
static uint32_t g_ui32DstBuf[MEM_BUFFER SIZE];
// Define errors counters
static uint32 t g ui32DMAErrCount = 0;
static uint32 t g ui32BadISR = 0;
// Define transfer counter
static uint32 t g ui32MemXferCount = 0;
// The control table used by the uDMA controller. This table must be aligned
to a 1024 byte boundary.
#pragma DATA ALIGN(pui8ControlTable, 1024)
uint8 t pui8ControlTable[1024];
// Library error routine
#ifdef DEBUG
void
 error__(char *pcFilename, uint32_t ui32Line)
#endif
// uDMA transfer error handler
void
uDMAErrorHandler(void)
    uint32 t ui32Status;
    // Check for uDMA error bit
    ui32Status = uDMAErrorStatusGet();
    // If there is a uDMA error, then clear the error and increment the error
counter.
    if(ui32Status)
    {
        uDMAErrorStatusClear();
        g ui32DMAErrCount++;
    }
}
// uDMA interrupt handler. Run when transfer is complete.
void
```


```
uDMAIntHandler(void)
    uint32 t ui32Mode;
    // Check for the primary control structure to indicate complete.
    ui32Mode = uDMAChannelModeGet(UDMA CHANNEL SW);
    if(ui32Mode == UDMA MODE STOP)
        // Increment the count of completed transfers.
        g ui32MemXferCount++;
        // Configure it for another transfer.
        uDMAChannelTransferSet(UDMA CHANNEL SW, UDMA MODE AUTO,
                                   g ui32SrcBuf, g ui32DstBuf,
MEM BUFFER SIZE);
        // Initiate another transfer.
        uDMAChannelEnable(UDMA CHANNEL SW);
        uDMAChannelRequest(UDMA CHANNEL SW);
        uint32 t ui32Status;
            ui32Status = UARTIntStatus(UARTO BASE, true); //get interrupt
status
            UARTIntClear(UARTO BASE, ui32Status); //clear the asserted
interrupts
            while(UARTCharsAvail(UARTO BASE)) //loop while there are chars
            {
                char cChar=UARTCharGet(UART0 BASE);
                UARTCharPutNonBlocking(UARTO_BASE, cChar); //echo character
                if (cChar=='R') {
                                        //Turn on RED LED
                    GPIOPinWrite(GPI0_PORTF_BASE, GPI0_PIN_1, GPI0_PIN_1);
                else if (cChar=='r') { //Turn off RED LED
                    GPIOPinWrite(GPIO PORTF BASE, GPIO PIN 1, 0);
                else if (cChar=='G') { //Turn on Green LED
                    GPIOPinWrite(GPI0_PORTF_BASE, GPI0_PIN_3, GPI0_PIN_3);
                else if (cChar=='g') { //Turn off Green LED
                    GPIOPinWrite(GPI0_PORTF_BASE, GPI0_PIN_3, 0);
                else if (cChar=='B') { //Turn on Blue LED
                    GPIOPinWrite(GPIO PORTF BASE, GPIO PIN 2, GPIO PIN 2);
                else if (cChar=='b') { //Turn off Blue LED
                    GPIOPinWrite(GPIO PORTF BASE, GPIO PIN 2, 0);
                else if (cChar=='T') { //Show Temperature in Centigrade
                    ADCIntClear(ADC0 BASE,2);
                    ADCProcessorTrigger(ADC0 BASE, 2);
                    ADCSequenceDataGet(ADC0 BASE, 2, ui32ADC0Value);
```


```
ui32TempAvg = (ui32ADC0Value[0] + ui32ADC0Value[1] +
ui32ADC0Value[2] + ui32ADC0Value[3] + 2)/4;
                    ui32TempValueC = (1475 - ((2475 * ui32TempAvg)) /
4096)/10;
                    ui32TempValueF = ((ui32TempValueC * 9) + 160) / 5;
                    UARTprintf("\n C %3d\t \n",ui32TempValueC );
                else if (cChar=='t') { //Show Temperature in Farenheit
                    ADCIntClear(ADC0 BASE,2);
                    ADCProcessorTrigger(ADC0_BASE, 2);
                    ADCSequenceDataGet(ADC0 BASE, 2, ui32ADC0Value);
                    ui32TempAvg = (ui32ADC0Value[0] + ui32ADC0Value[1] +
ui32ADC0Value[2] + ui32ADC0Value[3] + 2)/4;
                    ui32TempValueC = (1475 - ((2475 * ui32TempAvg)) /
4096)/10;
                    ui32TempValueF = ((ui32TempValueC * 9) + 160) / 5;
                    UARTprintf("\n F %3d\t \n",ui32TempValueF );
              else if (cChar=='S') { //Show LED Status
                    UARTprintf("\n");
                    if (GPIOPinRead(GPIO PORTF BASE, GPIO PIN 1))
                        UARTprintf("Red LED is on \n");
                    if (GPIOPinRead(GPIO_PORTF_BASE, GPIO_PIN_2))
                        UARTprintf("Blue LED is on \n");
                    if (GPIOPinRead(GPIO_PORTF_BASE, GPIO_PIN_3))
                        UARTprintf("Green LED is on \n");
                }
            }
    }
    // If the channel is not stopped, then something is wrong.
    else
    {
        q ui32BadISR++;
    }
}
// Initialize the uDMA software channel to perform a memory to memory uDMA
transfer.
void
InitSWTransfer(void)
    uint32 t ui32Idx;
    // Fill the source memory buffer with a simple incrementing pattern.
    for(ui32Idx = 0; ui32Idx < MEM BUFFER SIZE; ui32Idx++)</pre>
    {
        g_ui32SrcBuf[ui32Idx] = ui32Idx;
    }
    // Enable interrupts from the uDMA software channel.
    IntEnable(INT UDMA);
```

```
// Place the uDMA channel attributes in a known state. These should
already be disabled by default.
    uDMAChannelAttributeDisable(UDMA CHANNEL SW,
                                    UDMA ATTR USEBURST | UDMA ATTR ALTSELECT
I
                                    (UDMA ATTR HIGH PRIORITY |
                                    UDMA ATTR REQMASK));
    // Configure the control parameters for the SW channel. The SW channel
    // will be used to transfer between two memory buffers, 32 bits at a
time.
    // and the address increment is 32 bits for both source and destination.
    // The arbitration size will be set to 8, which causes the uDMA
controller
    // to rearbitrate after 8 items are transferred. This keeps this channel
from
    // hogging the uDMA controller once the transfer is started, and allows
other
    // channels to get serviced if they are higher priority.
    uDMAChannelControlSet(UDMA CHANNEL SW | UDMA PRI SELECT,
                              UDMA SIZE 32 | UDMA SRC INC 32 |
UDMA DST INC 32 |
                              UDMA ARB 8);
    // Set up the transfer parameters for the software channel. This will
    // configure the transfer buffers and the transfer size. Auto mode must
be
    // used for software transfers.
    uDMAChannelTransferSet(UDMA CHANNEL SW | UDMA PRI SELECT,
                               UDMA MODE AUTO, g ui32SrcBuf, g ui32DstBuf,
                               MEM BUFFER SIZE);
    // Now the software channel is primed to start a transfer. The channel
    // must be enabled. For software based transfers, a request must be
    // issued. After this, the uDMA memory transfer begins.
    uDMAChannelEnable(UDMA CHANNEL SW);
    uDMAChannelRequest(UDMA CHANNEL SW);
}
int
main(void)
    //Configure peripherals
    SysCtlPeripheralEnable(SYSCTL PERIPH GPIOA);
    SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
    SysCtlPeripheralEnable(SYSCTL PERIPH ADC0);
    //Setup for ADC
    ADCHardwareOversampleConfigure(ADCO BASE, 32);
    ADCSequenceConfigure(ADC0_BASE, 2, ADC_TRIGGER_PROCESSOR, 0);
    ADCSequenceStepConfigure(ADC0 BASE, 2, 0, ADC CTL TS);
    ADCSequenceStepConfigure(ADC0 BASE, 2, 1, ADC CTL TS);
    ADCSequenceStepConfigure(ADC0 BASE, 2, 2, ADC CTL TS);
```


```
ADCSequenceStepConfigure(ADC0 BASE, 2, 3, ADC CTL TS|ADC CTL IE|
ADC CTL_END);
    ADCSequenceEnable(ADC0 BASE, 2);
    GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, GPIO_PIN_1|GPIO_PIN_2|GPIO_PIN_3);
//enable pin for LED PF2
    IntMasterEnable(); //enable processor interrupts
    FPULazyStackingEnable();
    SysCtlClockSet(SYSCTL_SYSDIV_4 | SYSCTL_USE_PLL | SYSCTL_OSC_MAIN |
                       SYSCTL XTAL 16MHZ);
    SysCtlPeripheralClockGating(true);
    SysCtlPeripheralEnable(SYSCTL_PERIPH_UDMA);
    SysCtlPeripheralSleepEnable(SYSCTL PERIPH UDMA);
    IntEnable(INT UDMAERR);
    uDMAEnable();
    uDMAControlBaseSet(pui8ControlTable);
    InitSWTransfer();
    UARTprintf("Enter the cmd: \n"
                    "R: Red LED, \n"
                    "G: Green LED, \n"
                    "B: Blue LED, \n"
                    "T: Temperature, \n"
                    "S: status of the LEDs. \n");
    while(1)
    }
}
```

2. Block diagram and/or Schematics showing the components, pins used, and interface.






Boosterpack is placed on top of Launchpad.



3. Screenshots of the IDE, physical setup, debugging process - Provide screenshot of successful compilation, screenshots of registers, variables, graphs, etc.



```
☐ /dev/ttyACM0 ☎

Temperature: C 22
                          71
Temperature: C 22
                       F 71
Temperature: C 23
                       F 73
                       F 73
Temperature: C 23
Temperature: C 23
                       F 73
                      F 73
Temperature: C 23
Temperature: C 23
                       F 73
Temperature: C 23
                       F 73
Temperature: C 23
                      F 73
Temperature: C 23 F 73
Temperature: C 23
                      F 73
Temperature: C 23 F 73
Temperature: C 23 F 73
Temperature: C 23 F 73
Temperature: C 23 F 73
```

4. Declaration I understand the Student Academic Misconduct Policy http://studentconduct.unlv.edu/misconduct/policy.html

> "This assignment submission is my own, original work". Jenifer Christina