the life-changing magic of ida python


embedded device edition

maddie stone
madeline.stone@jhuapl.edu
@maddiestone



who am i? – maddie stone

- reverse engineer and embedded developer at Johns Hopkins Applied Physics Lab
 - mostly embedded devices
 - merge of hardware and firmware reverse engineering
 - lead of reverse engineering working group at JHU/APL



reduce time required to analyze firmware of embedded devices using ida python

ida python embedded toolkit

https://github.com/maddiestone/IDAPythonEmbeddedToolkit

ida python

- "IDAPython is an IDA Pro plugin that integrates the Python programming language, allowing scripts to run in IDA Pro"
 - https://github.com/idapython/src/
 - Docs: https://www.hex-rays.com/products/ida/support/idapython_docs/
 - idc contains 98% of the functions we use

why do you care?


- current resources for ida python
 - mostly x86 or ARM based (PC applications or malware)
 - Palo Alto Networks:


 http://researchcenter.paloaltonetworks.com/2015/12/using-idapython-to-make-your-life-easier-part-1/
 - "The Beginner's Guide to IDAPython" by Alexander Hanel
- more embedded devices (hello, Internet of Things!)
 - microcontroller/microprocessor architectures
 - different goals of analysis than malware/application RE

important differences for embedded firmware images

- purpose of analysis
- entire firmware image vs. application
- memory structure
- many different architectures


scripting the reverse engineering process





how ida python helps -- triage


- define_data_as_types.py
 - mass assign bytes as instructions, data, offsets
- define_code_functions.py
 - auto-assign "unexplored" bytes as code and attempt to define functions
- make_strings.py
 - searches an address range for series of ASCII characters to define as strings




```
# Enter a regular expression for how this architecture usually
# begins and ends functions. If the architecture does not
# dictate how to start or end a function use r".*" to allow
# for any instruction.
# 8051 Architecture Prologue and Epilogue
smart_prolog = re.compile(r".*")
smart_epilog = re.compile(r"reti{0,1}")
# PIC18 Architecture Prologue and Epilogue
#smart_prolog = re.compile(r".*")
#smart_epilog = re.compile(r"return 0")
# Mitsubishi M32R Architecutre Prologue and Epilogue
#smart_prolog = re.compile(r"push +lr")
#smart_epilog = re.compile(r"jmp +lr.*")
# Texas Instruments TMS320C28x
#smart_prolog = re.compile(r".*")
#smart_epilog = re.compile(r"lretr")
# AVR
#smart_prolog = re.compile(r"push +r")
#smart_epilog = re.compile(r"reti{0,1}")
```

how ida python helps -- analysis

- find_mem_accesses.py
 - identifies all memory accesses for architectures such as 8051 which use a variable to access memory (DPTR)
- data_offset_calc.py
 - find the memory address accesses and
 - 1) create a data cross-reference to the memory address
 - 2) write the value at the memory address as a comment at the instructions
 - 3) create a file with all of the accesses memory address and the instructions accessing them





```
data_offset_calc.py
                                     index of operand to get
 operand = GetOpnd(curr_addr,
                                                          change how the operand
 if (offset):
                                                              is displayed
      if '-' in operand :
        new_opnd = offset_var_value - int(offset[0],
      else:
        new_opnd = offset_var_value + int(offset[0], 16)
      OpAlt(curr_addr, 1, new_opnd_display % new_opnd) 
      result = add_dref(curr_addr, new_opnd, dr_T)
 MakeComm(curr_addr, '0x%08x' % new_opnd)
                                                           create a data cross-
                                               dr_T: text
                                                              reference
  curr_addr = NextHead(curr_addr)
                                               dr_R: read
                                              dr_W: write
                                              dr_O: offset
ld
     R1, @(0x4114, fp)
     R10, fp, 0x4147
                                      add3
                                            R10, fp, 0x4147
                                                             ; @[0x80C147]
add3
```

how ida python helps -- annotate

- lable_funcs_with_no_xrefs.py
 - check for functions with no cross-references to them and annotate their function name with a "noXrefs" prefix
- identify_port_use_locations.py
 - searches all code for pin/port operations based on the defined regex for the architecture and lists all references in a text file and optionally labels each function

ida python functions used

AskAddr MakeByte OpAlt

AskFile MakeCode add_dref*

AskLong MakeComm NextFunction

AskYN MakeDword NextHead

GetDisasm MakeFunction PrevHead

MakeName FindUnexplored

GetFunctionAttr MakeStr XrefsTo*

GetFunctionName MakeUnkn isCode(GetFlags())

GetOperandValue MakeWord Byte

GetOpnd Warning Word

all can be found in the idc module except (*)

what's next?

- ida python embedded toolkit: https://github.com/maddiestone/IDAPythonEmbeddedToolkit
- other script ideas
 - architecture independent CAN or serial identifiers
 - integrate and automate more of the triage processes
 - segment creation
 - automate architecture selection for scripts
 - other manners to display information
 - more robust examples and docs

thank you

maddie stone
madeline.stone@jhuapl edu
@maddiestone